

MacDon™

M Series Self-Propelled Windrower

**UNLOADING AND ASSEMBLY
INSTRUCTIONS
for
CONTAINER SHIPMENTS**

Published: October, 2011

Form 169242

Revision E



MACDON M SERIES SELF-PROPELLED WINDROWER

INTRODUCTION

This instructional manual describes the unloading, set-up and pre-delivery requirements for the MacDon M Series Self-Propelled Windrowers that have been shipped in containers.

Use the Table of Contents to guide you to specific areas. Retain this instruction for future reference.

CAREFULLY READ ALL THE MATERIAL PROVIDED BEFORE ATTEMPTING TO UNLOAD, ASSEMBLE, OR USE THE MACHINE.

TABLE OF CONTENTS

INTRODUCTION	1
GENERAL SAFETY	3
RECOMMENDED TORQUES	5
A. GENERAL	5
B. SAE BOLTS	5
C. METRIC BOLTS.....	5
D. FLARE TYPE HYDRAULIC FITTINGS.....	6
E. O-RING BOSS (ORB) HYDRAULIC FITTINGS.....	6
F. O-RING FACE SEAL (ORFS) HYDRAULIC FITTINGS.....	7
CONVERSION CHART	8
DEFINITIONS	8
STEP 1. UNLOAD CONTAINER	9
STEP 2. MOVE TO ASSEMBLY AREA	10
STEP 2. MOVE TO ASSEMBLY AREA	10
A. CRANE METHOD	10
B. FORKLIFT METHOD	11
STEP 3. REMOVE WHEEL AND STEP ASSEMBLY	12
STEP 4. REMOVE DRIVE WHEELS	14
STEP 5. REMOVE PLATFORMS	15
STEP 6. REMOVE HAND RAILS AND EXHAUST STACK	16
STEP 7. REMOVE LEG ASSEMBLIES	17
STEP 8. REMOVE WHEEL AND PLATFORM SUPPORT	18
STEP 9. ASSEMBLE WINDROWER SUPPORT STAND	18
STEP 10. LIFT WINDROWER ONTO STAND	19
A. CRANE METHOD	19
B. FORKLIFT METHOD	20
STEP 11. INSTALL LEGS	21
STEP 12. INSTALL FRONT WHEELS	23
STEP 13. INSTALL CASTER WHEELS	25
STEP 14. INSTALL HYDRAULICS	27
A. M205.....	27

B.	M155.....	30
C.	M105.....	34
STEP 15.	INSTALL PLATFORMS.....	37
STEP 16.	INSTALL STEPS	39
STEP 17.	INSTALL EXHAUST STACK	40
STEP 18.	POSITION LIGHT AND MIRROR ASSEMBLIES	41
STEP 19.	INSTALL BATTERIES.....	42
A.	M205, M155.....	42
B.	M105.....	43
STEP 20.	PRIME HYDRAULIC SYSTEM.....	44
A.	M205.....	44
B.	M155.....	45
C.	M105.....	47
STEP 21.	START ENGINE.....	49
STEP 22.	CHECK TRACTION DRIVE.....	50
STEP 23.	REMOVE WINDROWER FROM STAND	51
A.	FACTORY STAND.....	51
B.	FIELD-CONSTRUCTED STAND.....	51
STEP 24.	INSTALL AM/FM RADIO.....	52
STEP 25.	INSTALL BEACONS	54
STEP 26.	INSTALL SLOW MOVING VEHICLE (SMV) SIGN.....	54
STEP 27.	ATTACH HEADER	55
A.	HEADER ATTACHMENT: D SERIES.....	55
B.	HEADER ATTACHMENT: A SERIES.....	61
C.	HEADER ATTACHMENT: R SERIES (M205, M155 ONLY).....	67
STEP 28.	LUBRICATE MACHINE.....	72
STEP 29.	PROGRAM CAB DISPLAY MODULE (CDM).....	74
A.	M205, M155 DETAILED PROGRAMMING INSTRUCTIONS	75
B.	M105 DETAILED PROGRAMMING INSTRUCTIONS	81
STEP 30.	PERFORM HYDRAULIC PURGE	86
STEP 31.	PERFORM PRE-DELIVERY CHECKS	88
A.	FINAL DRIVE LUBRICANT LEVEL	88
B.	TIRE PRESSURES AND BALLAST REQUIREMENTS	88
C.	ENGINE AIR INTAKE.....	90
D.	HYDRAULIC OIL LEVEL.....	91
E.	FUEL SEPARATOR.....	91
F.	ENGINE COOLANT	91
G.	GEAR BOX LUBRICANT LEVEL.....	92
H.	A/C COMPRESSOR BELT	92
I.	PERFORM SAFETY SYSTEM CHECKS	93
J.	OPERATIONAL CHECKS.....	94
K.	MANUALS.....	102
L.	CAB INTERIOR.....	102


GENERAL SAFETY




CAUTION

The following are general farm safety precautions that should be part of your operating procedure for all types of machinery.

- Protect yourself.
- When assembling, operating and servicing machinery, wear all the protective clothing and personal safety devices that **COULD** be necessary for the job at hand. Don't take chances.
- You may need:




- a hard hat.
- protective shoes with slip resistant soles.
- protective glasses or goggles.
- heavy gloves.
- wet weather gear.
- respirator or filter mask.



- hearing protection. Be aware that prolonged exposure to loud noise can cause impairment or loss of hearing. Wearing a suitable hearing protective device such as ear muffs (A) or ear plugs (B) protects against objectionable or loud noises.



- Provide a first-aid kit for use in case of emergencies.
- Keep a fire extinguisher on the machine. Be sure the extinguisher is properly maintained and be familiar with its proper use.
- Keep young children away from machinery at all times.
- Be aware that accidents often happen when the Operator is tired or in a hurry to get finished. Take the time to consider the safest way. Never ignore warning signs of fatigue.
- Wear close-fitting clothing and cover long hair. Never wear dangling items such as scarves or bracelets.
- Keep hands, feet, clothing and hair away from moving parts.



- Never attempt to clear obstructions or objects from a machine while the engine is running.
- Keep all shields in place. Never alter or remove safety equipment. Make sure driveline guards can rotate independently of the shaft and can telescope freely.
- Use only service and repair parts made or approved by the equipment manufacturer. Substituted parts may not meet strength, design, or safety requirements.

(continued next page)

- Do not modify the machine. Unauthorized modifications may impair the function and/or safety and affect machine life.
- Stop engine, and remove key from ignition before leaving Operator's seat for any reason. A child or even a pet could engage an idling machine.



- Keep the area used for servicing machinery clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment. Be sure all electrical outlets and tools are properly grounded.
- Use adequate light for the job at hand.
- Keep machinery clean. Do not allow oil or grease to accumulate on service platforms, ladders or controls. Clean machines before storage.
- Never use gasoline, naphtha or any volatile material for cleaning purposes. These materials may be toxic and/or flammable.
- When storing machinery, cover sharp or extending components to prevent injury from accidental contact.

RECOMMENDED TORQUES

A. GENERAL


The tables shown below give correct torque values for various bolts and capscrews.

- Tighten all bolts to the torques specified in chart (unless otherwise noted throughout this manual).
- Check tightness of bolts periodically, using bolt torque chart as a guide.
- Replace hardware with the same strength bolt.
- Torque figures are valid for non-greased or non-oiled threads and heads unless otherwise specified. Do not grease or oil bolts or capscrews unless specified in this manual.
- When using locking elements, increase torque values by 5%.

B. SAE BOLTS

BOLT DIA. "A"	NC BOLT TORQUE*			
	SAE-5		SAE-8	
	ft·lbf	N·m	ft·lbf	N·m
1/4	9	12	11	15
5/16	18	24	25	34
3/8	32	43	41	56
7/16	50	68	70	95
1/2	75	102	105	142
9/16	110	149	149	202
5/8	150	203	200	271
3/4	265	359	365	495
7/8	420	569	600	813
1	640	867	890	1205


* Torque categories for bolts and capscrews are identified by their head markings.




C. METRIC BOLTS

BOLT DIA. "A"	STD COARSE BOLT TORQUE*			
	8.8		10.9	
	ft·lbf	N·m	ft·lbf	N·m
M3	0.4	0.5	1.3	1.8
M4	2.2	3	3.3	4.5
M5	4	6	7	9
M6	7	10	11	15
M8	18	25	26	35
M10	37	50	52	70
M12	66	90	92	125
M14	103	140	148	200
M16	166	225	229	310
M20	321	435	450	610
M24	553	750	774	1050
M30	1103	1495	1550	2100
M36	1917	2600	2710	3675

* Torque categories for bolts and capscrews are identified by their head markings.



D. FLARE TYPE HYDRAULIC FITTINGS




- Check flare and flare seat for defects that might cause leakage.
- Align tube with fitting before tightening.
- Lubricate connection, and hand-tighten swivel nut until snug.
- To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body, and with the second, tighten the swivel nut to the torque shown.


SAE NO.	TUBE SIZE O.D. (in.)	THD SIZE (in.)	NUT SIZE ACROSS FLATS (in.)	TORQUE VALUE*		RECOMMENDED TURNS TO TIGHTEN (AFTER FINGER TIGHTENING)	
				ft·lbf	N·m	Flats	Turns
3	3/16	3/8	7/16	6	8	1	1/6
4	1/4	7/16	9/16	9	12	1	1/6
5	5/16	1/2	5/8	12	16	1	1/6
6	3/8	9/16	11/16	18	24	1	1/6
8	1/2	3/4	7/8	34	46	1	1/6
10	5/8	7/8	1	46	62	1	1/6
12	3/4	1-1/16	1-1/4	75	102	3/4	1/8
14	7/8	1-3/8	1-3/8	90	122	3/4	1/8
16	1	1-5/16	1-1/2	105	142	3/4	1/8

* Torque values shown are based on lubricated connections as in re-assembly.

E. O-RING BOSS (ORB) HYDRAULIC FITTINGS



- Inspect O-ring and seat for dirt or obvious defects.





- On angle fittings, back off the lock nut until washer (A) bottoms out at top of groove (B) in fitting.
- Hand-tighten fitting until back up washer (A) or washer face (if straight fitting) bottoms on part face (C) and O-ring is seated.
- Position angle fittings by unscrewing **no more than one turn**.
- Tighten straight fittings to torque shown.
- Tighten angle fittings to torque shown in the following table, while holding body of fitting with a wrench.

SAE NO.	THD SIZE (in.)	NUT SIZE ACROSS FLATS (in.)	TORQUE VALUE*		RECOMMENDED TURNS TO TIGHTEN (AFTER FINGER TIGHTENING)	
			ft·lbf	N·m	Flats	Turns
3	3/8	1/2	6	8	2	1/3
4	7/16	9/16	9	12	2	1/3
5	1/2	5/8	12	16	2	1/3
6	9/16	11/16	18	24	2	1/3
8	3/4	7/8	34	46	2	1/3
10	7/8	1	46	62	1-1/2	1/4
12	1-1/16	1-1/4	75	102	1	1/6
14	1-3/16	1-3/8	90	122	1	1/6
16	1-5/16	1-1/2	105	142	3/4	1/8
20	1-5/8	1-7/8	140	190	3/4	1/8
24	1-7/8	2-1/8	160	217	1/2	1/12

* Torque values shown are based on lubricated connections as in re-assembly.

F. O-RING FACE SEAL (ORFS) HYDRAULIC FITTINGS



- Check components to ensure that the sealing surfaces and fitting threads are free of burrs, nicks, and scratches, or any foreign material.
- Apply lubricant (typically Petroleum Jelly) to O-ring and threads. If O-ring is not already installed, install O-ring.
- Align the tube or hose assembly. Ensure that flat face of the mating flange comes in full contact with O-ring.
- Thread tube or hose nut until hand-tight. The nut should turn freely until it is bottomed out. Torque fitting further to the specified number of F.F.F.T ("Flats From Finger Tight"), or to a given torque value in the table shown in the opposite column.

NOTE

If available, always hold the hex on the fitting body to prevent unwanted rotation of fitting body and hose when tightening the fitting nut.

- When assembling unions or two hoses together, three wrenches will be required.

SAE NO.	THD SIZE (in.)	TUBE O.D. (in.)	TORQUE VALUE*		RECOMMENDED TURNS TO TIGHTEN (AFTER FINGER TIGHTENING)**	
			ft-lbf	N·m	Tube Nuts	Swivel & Hose
3	***	3/16	---	---	---	---
4	9/16	1/4	11 - 12	14 - 16	1/4 - 1/2	1/2 - 3/4
5	***	5/16	---	---	---	---
6	11/16	3/8	18 - 20	24 - 27	1/4 - 1/2	1/2 - 3/4
8	13/16	1/2	32 - 35	43 - 47		
10	1	5/8	45 - 51	60 - 68		
12	1-3/16	3/4	67 - 71	90 - 95	1/4 - 1/2	1/3 - 1/2
14	1-3/16	7/8	67 - 71	90 - 95		
16	1-7/16	1	93 - 100	125 - 135		
20	1-11/16	1-1/4	126 - 141	170 - 190		
24	2	1-1/2	148 - 167	200 - 225	---	---
32	2-1/2	2	---	---	---	---

* Torque values and angles shown are based on lubricated connection, as in re-assembly.

** Always default to the torque value for evaluation of adequate torque

*** O-ring face seal type end not defined for this tube size.

CONVERSION CHART

QUANTITY	INCH-POUND UNITS		FACTOR	SI UNITS (METRIC)	
	UNIT NAME	ABBR.		UNIT NAME	ABBR.
Area	acres	acres	x 0.4047 =	hectares	ha
Flow	US gallons per minute	(gpm)	x 3.7854 =	liters per minute	L/min
Force	pounds force	lbf	x 4.4482 =	Newtons	N
Length	inch	in.	x 25.4 =	millimeters	mm
	foot	ft	x 0.305 =	meters	m
Power	horsepower	hp	x 0.7457 =	kilowatts	kW
Pressure	pounds per square inch	psi	x 6.8948 =	kilopascals	kPa
			x .00689 =	megapascals	MPa
Torque	pound feet or foot pounds	lbf-ft or ft-lbf	x 1.3558 =	newton meters	N·m
	pound inches or inch pounds	lbf-in. or in-lbf	x 0.1129 =	newton meters	N·m
Temperature	degrees Fahrenheit	°F	(°F - 32) x 0.56 =	Celsius	°C
Velocity	feet per minute	ft/min	x 0.3048 =	meters per minute	m/min
	feet per second	ft/s	x 0.3048 =	meters per second	m/s
	miles per hour	mph	x 1.6063 =	kilometers per hour	km/h
Volume	US gallons	US gal.	x 3.7854 =	liters	L
	ounces	oz.	x 29.5735 =	milliliters	ml
	cubic inches	in. ³	x 16.3871 =	cubic centimeters	cm ³ or cc
Weight	pounds	lb	x 0.4536 =	kilograms	kg

DEFINITIONS

TERM	DEFINITION
API	American Petroleum Institute
ASTM	American Society of Testing And Materials
Cab-Forward	Windrower operation with the Operator and the cab facing in the direction of travel.
CDM	Cab Display Module
DWA	Double Windrow Attachment
Engine-Forward	Windrower operation with the Operator and the engine facing in the direction of travel.
ISC	Integrated Speed Control
N-DETENT	The slot opposite the NEUTRAL position on Operator's console.
rpm	revolutions per minute
SAE	Society Of Automotive Engineers
WCM	Windrower Control Module
Windrower	Windrower with header attached.
Windrower Tractor	Power unit only. (Windrower without the header attached)

UNLOADING AND ASSEMBLY

STEP 1. UNLOAD CONTAINER



CAUTION

To avoid injury to bystanders from being struck by machinery, do not allow persons to stand in unloading area.

- a. Move trailer into position, and block trailer wheels.
- b. Lower trailer storage stands.
- c. Open container doors, and remove all blocking.
- d. Check container floor for nails or other obstructions, and remove if necessary.
- e. Position platform or ramp at container opening.



- f. Attach chain/pull strap to slots in support channels (as shown).
- g. Slowly pull windrower from container onto platform.

UNLOADING AND ASSEMBLY

STEP 2. MOVE TO ASSEMBLY AREA

A. CRANE METHOD



CAUTION



To avoid injury to bystanders from being struck by machinery, do not allow persons to stand in unloading area.



CAUTION

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.

LIFTING VEHICLE	
Minimum Lifting Capacity	20,000 lb. (9072 kg)
CHAIN	
Type	Overhead 1/2 in. Lifting Quality
Minimum Working Load	7100 lb. (3221 kg)



- a. Attach chains or cable to the four lift points on the lifting frame (MacDon Part # 163871) and connect loop ends to crane hook. Use cable or chain with a minimum lifting capacity of 7100 lb (3221 kg).



- b. Attach lifting frame assembly (MacDon Part #163871) to the four designated lift points on windrower shipping frame.
- c. Lift windrower off platform, and move to setup area.



- d. Lower assembly onto 5-6 inch (127-152 mm) blocks as shown.
- e. Remove chains from shipping frame.
- f. Check for shipping damage and missing parts.

UNLOADING AND ASSEMBLY

B. FORKLIFT METHOD



CAUTION

To avoid injury to bystanders from being struck by machinery, do not allow persons to stand in unloading area.



CAUTION

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.



- c. Lower assembly onto 5 - 6 inch (127 - 152 mm) blocks (as shown above).
- d. Check for shipping damage and missing parts.

LIFTING VEHICLE	
Minimum Lifting Capacity *	20,000 lb (9072 kg)

* At 48 inches (1220 mm) from “back end” of forks.

IMPORTANT

Forklifts are normally rated for a load located 24 inches (610 mm) ahead of “back end” of the forks.

To obtain the forklift capacity at 48 inches (1220 mm), check with your forklift distributor.



WARNING

Be sure forks are secure before moving away from load. Stand clear when lifting.




- a. Approach windrower from the hood end, and slide forks underneath lifting framework.
- b. Raise windrower off platform, and move to assembly area.

UNLOADING AND ASSEMBLY

STEP 3. REMOVE WHEEL AND STEP ASSEMBLY



- a. Remove shipping wire and bolt securing hose support to shipping frame, and remove hose support.
- b. Lay hose support off to the side.





- c. Remove the 3/4 in. x 16.5 long bolts (one per side) at front frame beam. Retain for re-installation.



- d. Remove the 1 inch (25.4 mm) pin at the center-link.



- e. Remove the four (two per side) carriage bolts at the rear of the wheel/step assembly.




- f. Remove plastic cable tie and shipping wire securing hose bundles to frame.

(continued next page)


UNLOADING AND ASSEMBLY



- g. Attach a chain to wheel/step assembly, and pull away from shipping assembly with lifting device.



- h. Lift center-link so that it clears wheel/step assembly frame.




- i. Re-install leg bolts, washers, and nuts to secure the lifting plate onto the mainframe.

UNLOADING AND ASSEMBLY


STEP 4. REMOVE DRIVE WHEELS

IMPORTANT

Remove the drive wheels as a pair from above the hood.



- a. Remove the two bolts at front cross member over the hood.



- b. Remove one bolt at rear of hood directly under center of drive wheel.



- c. Attach a lifting device to lift hooks located in the center of each drive wheel.



- d. Carefully lift wheels off frame.

IMPORTANT


Ensure that tire is guided away from cab roof when lifting wheels to prevent damage to the cab. Chain on forward wheel should be snug and loose on the aft wheel.

- e. Set wheels aside for later installation.


UNLOADING AND ASSEMBLY

STEP 5. REMOVE PLATFORMS

- a. Remove the two support tubes on either side of hood.



- b. To prevent paint damage, attach two slings and a chain to platform at locations shown, and to a lifting device with a minimum lifting capacity of 5000 lb (2268 kg), and a lift height of 13 feet (4 m).




- c. Remove two 5/8 in. x 5.0 bolts at top of vertical supports, and two 5/8 in. x 1.25 bolts attaching angle braces to platforms.


NOTE

The M105 windrower is equipped with only one platform.

- d. Carefully lift platform/light assembly off frame.



- e. Back away from windrower, and set assembly on a level surface.
f. Unhook one sling and chain.
g. Lift end of assembly so that it can be inverted and laid down again, base on the floor. Use a piece of cardboard under platform to protect the paint.




- h. Unhook remaining sling.



UNLOADING AND ASSEMBLY

STEP 6. REMOVE HAND RAILS AND EXHAUST STACK

- f. Repeat for other hand rail on opposite side. Retain hardware.
- g. Set parts aside for later installation.



- a. Cut plastic cable ties, and move hose bundle clear of platform.





- b. Remove shipping wire and foam from exhaust stack.
- c. Remove nuts from clamp, and remove exhaust stack and clamp from shipping frame.
- d. Re-install nuts onto clamp, and set stack aside for later installation.
- e. Remove the two bolts securing hand rail to shipping frame, and remove hand rail.

UNLOADING AND ASSEMBLY

STEP 7. REMOVE LEG ASSEMBLIES

- a. Ensure that lift bar is attached to leg assembly as shown, and that clevis pin is installed with head on near side.




- b. Attach chain to lifting bar on leg assembly, and hook up to lifting device with a minimum lifting capacity of 5000 lb (2268 kg).



- d. Remove two bolts near top of leg, and remove bars from leg.

NOTE

Insert cardboard or foam between leg assembly and hood to prevent damage to hood.



- c. Remove two bolts at lower support channel.



- e. Lift off leg assembly, and set securely on level ground.
f. Repeat above steps for second leg assembly.

UNLOADING AND ASSEMBLY

STEP 8. REMOVE WHEEL AND PLATFORM SUPPORT



- a. Remove cross brace, and the two upright supports from frame.



- b. Remove the cross member over the hood, and the two uprights on either side.


STEP 9. ASSEMBLE WINDROWER SUPPORT STAND

Special stands for assembling the windrower are available from the factory. If this stand is not available, an equivalent support system can be used.

The stand must be capable of holding a 20,000 lb (9072 kg) load.

Assemble factory stand as follows:

- a. Remove all shipping materials from stand.



- b. Arrange forward and rear stands on level ground, so that attachment lugs on each stand face each other.
- c. Attach four support tubes to stands as shown with hardware provided, and tighten.
- d. Set up air control valve tripod. Remove plug on valve, and install a 100 psi (689 kPa) air line.
- e. The stand is now operational. Instructions for use are given in the appropriate sections.



WARNING

- Use stand only as instructed in this manual. Do not use stand for any other purpose.
- Do not pressurize air bags beyond 120 psi (827 kPa).

UNLOADING AND ASSEMBLY

STEP 10. LIFT WINDROWER ONTO STAND



CAUTION

To avoid injury to bystanders from being struck by machinery, do not allow persons to stand in unloading area.




CAUTION

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.

A. CRANE METHOD

CRANE LIFTING VEHICLE	
Minimum Lifting Capacity	20,000 lb.(9072 kg)
CHAIN	
Type	Overhead 1/2 in. Lifting Quality
Minimum Working Load	7100 lb (3221 kg)



- a. Attach four chains or cables to the four lift points on the lifting frame (MacDon Part # 163871), and connect loop ends to crane hook. Use cable or chain with a minimum lifting capacity of 7100 lb (3221 kg).




- b. Attach the lifting frame to the four designated lift points on windrower shipping frame as shown.



CAUTION

Stand clear when lifting, as machine may swing.



- c. Lift windrower onto stand.
d. Remove chains from shipping frame, and set lifting frame assembly clear of work area.

UNLOADING AND ASSEMBLY


B. FORKLIFT METHOD

LIFTING VEHICLE	
Minimum Lifting Capacity *	20,000 lb (9072 kg)

* At 48 inches (1220 mm) from “back end” of forks.




- a. Approach windrower from aft end, and slide forks fully into shipping support channels.




- b. Raise windrower, and place onto stand.
- c. Back away forklift.

UNLOADING AND ASSEMBLY



STEP 11. INSTALL LEGS




- a. Remove front leg bolts and pins, and set aside for re-installation. Remove carriage bolt, and remove lifting plate.



- b. Attach front leg to lifting device with lifting bar.
c. Position leg at frame.




- d. Feed hydraulic hose bundle into frame, and through hole at center of frame.



- e. Insert leg into frame, and line-up holes in frame and leg at the "first position" (widest tread with one exposed hole).
f. Insert pins, and secure with 3/4 in. x 16.5 long bolts, washers, and nuts. Torque to 100 ft-lbf (136 N·m).
g. Repeat above steps for other leg.

(continued next page)

UNLOADING AND ASSEMBLY




- h. Slightly lift the header lift arms with lifting device, and remove lifting bars from legs. Re-locate spring locking pins to front of lift arms.

UNLOADING AND ASSEMBLY

STEP 12. INSTALL FRONT WHEELS

- a. If factory stand is being used, proceed as follows. Otherwise, proceed to step b:




1. Ensure that the three (one at rear, two at front) lift locks are activated on lift mechanism.

NOTE

Lock is activated when keeper is vertical, and latch is free to move back and forth.

2. Pressurize air bag system (100 psi (689 kPa) air pressure required), and raise windrower to maximum height (approximately 7 inches (178 mm) above the stand).




3. Verify that all three locks are engaged, before to proceeding to next step.

NOTE

Lock is engaged when witness hole above pin is exposed.

4. Release pressure so that locks support weight of windrower.




- b. Remove shipping supports on drive wheel hubs, and remove wheel lug nuts.



- c. Position wheel against hub so that that air valves are on the outside, and tire tread points forward. For "Turf" tires (diamond tread), be sure arrow on sidewall points in forward rotation.
- d. Lift wheel on hub with lifting device. Lower lifting device.
- e. Rotate wheel to align holes with studs, and push wheel onto studs.

(continued next page)

UNLOADING AND ASSEMBLY



- f. Install wheel nuts, and tighten to 220 ft·lbf (300 N·m) using the tightening sequence as shown above.


NOTE

To avoid damage to wheel disks, do not over-tighten wheel nuts.



- g. Repeat sequence three times.

UNLOADING AND ASSEMBLY

STEP 13. INSTALL CASTER WHEELS



- a. Remove the two guide plates from ends of walking beam.



- b. Support shipping frame channel, and remove bolts attaching shipping frame to walking beam and mainframe side rail. Remove shipping frame.


NOTE

Shipping frame does not need to be removed if air bag lifting stand is used. Ensure bolts are removed prior to moving windrower off stand.

- c. Repeat above for opposite shipping frame channel.



- d. Remove tie bar between the two caster wheels.




- e. Remove the two braces from caster wheels and frame. Retain bolts for attaching caster to walking beam.



- f. Attach a chain to RH caster, and support caster with lifting device.

(continued next page)

UNLOADING AND ASSEMBLY




- g. Remove five remaining bolts securing caster to shipping frame. Retain bolts for attaching caster to walking beam.




CAUTION

Stand clear when lifting, as caster may swing.



- h. Lift caster assembly off shipping frame, and position at end of walking beam.
i. Insert RH caster extension into walking beam, and position for desired tread.



- j. Install six 3/4 in. bolts and hardened washers into walking beam and caster beam. Use longer bolts through anti-shimmy bracket.

- k. Tighten bolts as follows:

1. Snug up the two bolts underneath beam.
2. Tighten the four back bolts to 330 ft·lbf (447 N·m).
3. Tighten bolts underneath beam to 330 ft·lbf (447 N·m).


- l. Repeat above steps g. to k. for LH caster.

- m. Re-torque bolts at 5, and 10 hours of operation.


UNLOADING AND ASSEMBLY

STEP 14. INSTALL HYDRAULICS

A. M205



- a. Retrieve all capped off hoses from inside frame.




- b. Locate the three hoses with capped off tees from valve block.
c. Remove caps on fittings with similar colored plastic ties, and connect hoses to tees. Do not connect the large case drain hoses from the wheel motors at this time.

NOTE


Remove caps on tee last to minimize oil loss.

- d. Position hoses into frame.
e. Locate two hoses with capped off ends and matching colored ties. A union is connected to one of the hoses.

- f. Remove caps and connect these two hoses together. Position hoses in frame.
g. Retrieve the four remaining capped-off hoses coming out of frame.




- h. Loosen bolts (A), and move valve block to improve access through hole in frame for wrenches when tightening fittings.
i. Remove caps on hoses, and matching valve block fittings.
j. Make connections, using colored plastic cable ties as a guide. Tighten fittings.
k. Re-position valve block, and re-tighten bolts.




- l. Position the two smaller hoses (111323) (B) and the two larger hoses (111328, 111557) (C) against support as shown, and secure with plastic ties.

(continued next page)


UNLOADING AND ASSEMBLY



- m. Remove clamp from round plastic hose block. Case drain hose is pre-installed in block.




VIEW LOOKING FORWARD




- n. Insert four traction drive hoses into slots in block as shown, and re-install clamp.


- o. Connect drive hoses to pump as follows:



1. Remove caps, and attach hoses with short elbows to respective side of pump (either yellow or no tie). Tighten fittings.



2. Remove caps, and attach hoses with long elbows to respective side of pump (either red or no tie). Tighten fittings.




- p. Retrieve the two motor case drain hoses (111312) at front frame, and the 7/8 in. tee fitting on the hose, from the pump.
- q. Remove caps from the hoses only.

(continued next page)

UNLOADING AND ASSEMBLY

- r. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
- s. Remove second cap from tee, and quickly connect other hose.
- t. Tighten fittings.
- u. Push hoses into frame.




- v. Secure hoses with plastic ties as required.


UNLOADING AND ASSEMBLY

B. M155

- a. The hydraulic hoses under the cab may require proper placement under the existing clip. If necessary, proceed as follows:




1. Locate hose clip under the cab, and remove clip.



VIEW LOOKING FORWARD

2. Position hose 111323 (orange tie) and hose 111324 with tee (white tie), as shown under the center of the clip, and loosely install two bolts and nuts. Part numbers are located on hoses. (If M200, place another hose 1132A with tee under clip)
3. Position remaining hoses under clip as shown, and tighten bolts.

- b. Connect hoses as follows, using colored plastic cable ties as a guide.




1. Locate two hoses 111327 (green ties) in frame opening, and existing tee fitting (green tie).
2. Remove caps on green lines and tee, and make connections. Tighten fittings.

NOTE

Remove caps on tee last to minimize oil loss.


3. Position hoses into frame.




4. Locate two hoses (white ties) inside frame, and hose 111324 with tee (white tie).
5. Remove caps, make connections, and tighten fittings.
6. Push hoses into frame.

(continued next page)


UNLOADING AND ASSEMBLY




7. Locate two hoses (red ties) inside frame.
8. Route RH hose behind bundle.
9. Remove caps, make connection, and tighten fitting.
10. Push hose into frame.




11. Retrieve long hose 119328 (white tie), and route through hole in LH frame.




12. Remove caps on hose, and valve block fitting (white tie), and make connection. Tighten fitting.



13. Remove the caps from three fittings (blue, orange, and yellow ties) on the valve block from inboard side of frame.



14. Loosen bolts, and move valve block to improve access through hole in frame for wrenches when tightening fittings.





15. Retrieve matching hoses and make connections on valve block. Tighten fittings.
16. Re-position valve block, and re-tighten bolts.

(continued next page)


UNLOADING AND ASSEMBLY

c. Remove clamp from round plastic hose block.




d. Insert four traction drive hoses and one case drain hose into slots in block as shown, and re-install clamp.


e. Connect drive hoses to pump as follows:



1. Remove caps, and attach hoses with short elbows to respective side of pump (either yellow or no tie). Tighten fittings.



2. Remove caps, and attach hoses with long elbows to respective side of pump (either red or no tie). Tighten fittings.




f. Retrieve the two motor case drain hoses (111312) at front frame, and the 7/8 in. tee fitting on the hose, from the pump.



(continued next page)

UNLOADING AND ASSEMBLY

- g. Remove caps from the hoses only.




- h. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
i. Remove second cap from tee, and quickly connect other hose.
j. Tighten fittings.



- k. Locate hose bundle from valve blocks on LH side of frame. Route hose ends with electrical harness through hose support.



- l. Disengage hook, and rotate to "up" position. Position hose bundle over hose support, and locate under hook. Rotate hook, and re-engage in bracket.




- m. Attach reel hose support tube to the RH reel leg with two 3/8 in. x 1.0 carriage bolts and nuts.

UNLOADING AND ASSEMBLY

C. M105

- a. Connect hoses as follows, using colored plastic cable ties as a guide.




1. Locate two hoses 111324 (green ties) in frame opening, and existing tee fitting (green tie) on the hose from the valve block.
2. Remove caps on green lines and tee, and make connections. Tighten fittings.


NOTE

Remove caps on tee last to minimize oil loss.

3. Position hoses into frame.




4. Locate two hoses (white ties) inside frame, and hose 111324 with tee (white tie).
5. Remove caps, make connections, and tighten fittings.
6. Push hoses into frame.



7. Locate two hoses (red ties) inside frame.
8. Route RH hose behind bundle.
9. Remove caps, make connection, and tighten fitting.
10. Push hose into frame.




11. Retrieve long hose 119328 (white tie), and route through hole in LH frame.




12. Remove caps on hose, and valve block fitting (white tie), and make connection. Tighten fitting.

(continued next page)

UNLOADING AND ASSEMBLY



13. Remove the cap from fitting with yellow tie on the valve block from inboard side of frame.




14. Loosen bolts, and move valve block to improve access through hole in frame for wrenches when tightening fittings.


15. Retrieve matching hose, and make connection on valve block. Tighten fitting.

16. Re-position valve block, and re-tighten bolts.


- b. Connect drive hoses to pump as follows:




1. Remove caps, and attach hoses (green and yellow ties) to matching fittings on top of pump. Tighten fittings.



2. Remove caps, and attach hoses (red and white ties) to matching fittings on bottom of pump. Tighten fittings.




- c. Retrieve the two motor case drain hoses (111312) at front frame, and the 7/8 in. tee fitting on the hose from the pump.





- d. Remove caps from the hoses only.
- e. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
- f. Remove second cap from tee, and quickly connect other hose.
- g. Tighten fittings.

(continued next page)

UNLOADING AND ASSEMBLY




- h. Bundle traction drive hoses, and secure with two plastic cable ties at 7-3/4 inch (200 mm) intervals from frame opening.
- i. Bundle smaller hoses, and secure with two plastic cable ties at 6 inch (150 mm) intervals from frame opening.
- j. Attach hose supports to windrower frame as follows:



- 1. Locate hose bundle from valve blocks on LH side of frame. Route hose ends with electrical harness through hose support.



- 2. Disengage hook, and rotate to "up" position. Position hose bundle over hose support, and locate under hook. Rotate hook, and re-engage in bracket.




- 3. Attach reel hose support tube to the RH leg with two 3/8 in. x 1.0 carriage bolts and nuts.

UNLOADING AND ASSEMBLY


STEP 15. INSTALL PLATFORMS

NOTE

The following procedure is applicable to M155 and M205 machines with LH and RH platforms. The M105 has a LH platform only. LH installation is shown. RH installation is opposite.



- Remove the two 1/2 inch x 0.75 bolts securing rails to shipping beam, and remove rails. Retain hardware.
- Remove shipping brackets from platform assembly. Retain hardware.




- Attach a sling to platform, and other end to lifting device.




CAUTION


Stand clear when lifting, as platform may swing.



- Position platform against windrower frame.




- Attach main beam of platform to side frame with three 1/2 in. x 1.25 long carriage bolts. Bolt heads face inboard. Tighten just enough for adjustment.




- Attach steering arm to frame with two 3/8 in. x 0.75 long carriage bolts and nuts. Bolt heads face inboard. Tighten bolts.

(continued next page)


UNLOADING AND ASSEMBLY




- g. Attach railings to platform with 1/2 inch x 0.75 locking bolts provided. Tighten bolts to 75 ft·lbf. (102 N·m).





- i. Check that rubber bumper is contacting the frame, and that front of platform is contacting the guide.



- h. Slowly close platform, and check that vertical rail tubes are parallel with cab posts when viewing from the rear. Laterally adjust king pin mounting as required.



- j. Adjust platform horizontally with the 1/2 in. x 2.25 bolt as required.




- k. If major adjustment is required, re-locate steering arm into either of the other holes on the bracket.
l. Tighten the three main beam attachment bolts to 80 ft·lbf (108 N·m).


UNLOADING AND ASSEMBLY

STEP 16. INSTALL STEPS

The following procedure is applicable to M155 and M205 machines with LH and RH platforms. The M105 has a LH platform only. RH installation is shown. LH installation is opposite.



- a. Remove the two existing upper bolts.
- b. Check that two lower bolts are not threaded in fully.





- c. Hang step assembly on bolts. If required, back off bolts.
- d. Install two bolts in upper holes in step, and tighten.
- e. Tighten lower bolts.
- f. Repeat for other step assembly (except M105).


UNLOADING AND ASSEMBLY

STEP 17. INSTALL EXHAUST STACK

- a. Open engine compartment hood.
- b. Retrieve exhaust stack that was previously removed.




- c. Loosen clamp (A) on exhaust stack (B), and clamp (C) on muffler (D).




- d. Position stack (B) in slot in exhaust shroud (E), and connect stack (B) and clamp (A) to muffler (D).

NOTE

If shroud (E) interferes with the stack, loosen the wing-nut (F) on the shroud, and move the shroud so that stack can be installed.




- e. Tighten both clamps (A) and (C), but only just enough so stack can be moved.




- f. Slowly close hood so that stack (B) enters hole (G) in hood. Adjust the position of the stack as required to clear the hole in the hood.
- g. Raise the hood.
- h. Tighten clamps (A) and (C).
- i. Re-position shroud (E), and tighten wing-nut (F).

UNLOADING AND ASSEMBLY

STEP 18. POSITION LIGHT AND MIRROR ASSEMBLIES



- a. Remove nut and bolt (A) from shipping position.
- b. Swing mirror/light assembly (B) forward up to stop.



- c. Re-install bolt (A) and nut in other hole.
- d. Repeat for opposite mirror assembly.

UNLOADING AND ASSEMBLY

STEP 19. INSTALL BATTERIES

A. M205, M155


Batteries should meet the following specification:

RATING	GROUP	CCA	VOLT	MAXIMUM DIMENSION
Heavy Duty, Off-Road, Vibration Resistant	BCI 31A	750 (min)	12	13 x 6.81 x 9.44 in. (330 x 173 x 240 mm)


IMPORTANT

BATTERY IS NEGATIVE GROUNDED. Always connect starter cable to the positive (+) terminal of battery and battery ground cable to negative (-) terminal of battery. Reversed polarity in battery or alternator may result in permanent damage to electrical system.

- a. Open right hand (cab-forward) maintenance platform.



- b. A battery main disconnect switch is located on the RH frame rail behind the maintenance platform, and can be accessed by moving the platform. Ensure battery switch is switched to POWER OFF position.
- c. Remove cable ties securing battery clamps and cables to frame.



- d. Position new batteries on holder (A).
- e. Install clamp (B) with bolts (C) provided, and tighten securely.

- f. Attach positive (red) cable terminals (D) to positive post on batteries, and tighten. Re-position plastic covers onto clamps.
- g. Attach negative (black) cable terminals (E) to negative post on batteries, and tighten clamps.
- h. Switch battery switch to POWER ON position.
- i. Move platform back to "closed position".

(continued next page)


UNLOADING AND ASSEMBLY

B. M105

Batteries should meet the following specification:

RATING	GROUP	CCA	VOLT	MAXIMUM DIMENSION
Heavy Duty, Off-Road, Vibration Resistant	BCI 31A OR 29H	650 (min)	12	13 x 7.4 x 9.13 in. (334 x 188 x 232 mm)

- a. Open engine compartment hood to highest position.



- b. A battery main disconnect switch is located on the battery tray. Ensure battery switch is switched to POWER OFF position.
- c. Remove cable ties securing battery clamps and cables to frame.

- d. Position new batteries on holder (A).
- e. Install strap (B) with bolts (C).

IMPORTANT

BATTERY IS NEGATIVE GROUNDED. Always connect starter cable to the positive (+) terminal of battery, and battery ground cable to negative (-) terminal of battery. Reversed polarity in battery or alternator may result in permanent damage to electrical system.



- f. Attach negative (black) cable clamps (D) to negative post on batteries, and tighten clamps.
- g. Attach positive (red) cable clamps (E) to positive post on batteries, and tighten. Re-position plastic covers onto clamps.
- h. Switch battery switch to POWER ON position.
- i. Close engine compartment hood.

UNLOADING AND ASSEMBLY


STEP 20. PRIME HYDRAULIC SYSTEM

A. M205

- a. Open maintenance platform on LH side.



- b. Disconnect brake engage solenoid (plug P44) at valve block on LH side of windrower.



- c. Remove Allen screw (A) with a 4 mm Allen wrench, and remove ECM connector (B) from engine. This prevents engine from starting during cranking.




CAUTION

Check to be sure all bystanders have cleared the area.


- d. Crank engine with starter for 15 seconds to prime the system.
- e. Re-install ECM connector (B) with screw (A).
- f. Re-connect brake engage solenoid plug.

UNLOADING AND ASSEMBLY


B. M155




- a. Remove hydraulic oil reservoir filler cap/dipstick.
- b. Open engine compartment hood fully.



- c. Locate plug on SIDE of HEADER drive pump housing from underneath machine, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.



- d. Locate plug on TOP of HEADER drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.




- e. Locate plug on TOP of TRACTION drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.
- f. Replace hydraulic oil reservoir filler cap.


(continued next page)

UNLOADING AND ASSEMBLY

- g. Open maintenance platform on LH side.





- h. Disconnect brake engage solenoid connector (P-V3) at valve block on LH side of windrower.



- i. Disconnect electrical connection at fuel pump on right side of engine.

- j. Open maintenance platform on RH side (M205, M155).




- k. Open circuit breaker/fuse box, and remove ECM ignition fuse (5A).



CAUTION

Check to be sure all bystanders have cleared the area.


- l. To prime the system, crank engine with starter for 15 seconds.
- m. Re-connect electrical connection at fuel pump and at brake engage solenoid.
- n. Re-install ECM ignition fuse, and close fuse box.
- o. Close engine compartment hood.




- p. Check hydraulic oil level in reservoir. Add SAE15W-40 oil if necessary.

UNLOADING AND ASSEMBLY


C. M105




- a. Remove hydraulic oil reservoir filler cap/dipstick.
- b. Open engine compartment hood fully.



- c. Locate plug on TOP of HEADER drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.



- d. Locate plug on TOP of TRACTION drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.
- e. Replace hydraulic oil reservoir filler cap.
- f. Open maintenance platform on LH side.




- g. Disconnect brake engage solenoid connector (P-V3) at valve block on LH side of windrower.


(continued next page)

UNLOADING AND ASSEMBLY


- m. Close engine compartment hood.



- n. Check hydraulic oil level in reservoir. If necessary, add SAE15W-40 oil.



- h. Disconnect electrical connection at fuel pump on right side of engine.



- i. Open circuit breaker/fuse box, and remove ECM ignition fuse (5A).



CAUTION

Check to be sure all bystanders have cleared the area.

- j. To prime the system, crank engine with starter for 15 seconds.
- k. Re-connect electrical connection at fuel pump and at brake engage solenoid.
- l. Re-install ECM ignition fuse, and close fuse box.


UNLOADING AND ASSEMBLY

STEP 21. START ENGINE

- a. Check fuel level, and if required add sufficient fuel for a 15 minute run.



- b. Lock (A) should be engaged at cab-forward or engine-forward position (M155 and M205 only).
- c. Move GSL (B) into N-DETENT.
- d. Turn steering wheel until it locks.



- e. Push HEADER DRIVE switch (C) to OFF.
- f. **Normal Start (All Engines):** engine temperature above 60°F (16°C).
 1. Set throttle to START position (D) - fully back.



CAUTION

Check to be sure all bystanders have cleared the area.



2. Sound horn (E) three times.
3. Turn ignition key (F) to RUN position.

4. Single loud tone sounds, and engine warning lights illuminate, and CDM displays "HEADER DISENGAGED" and "IN PARK".



WARNING

If starter engages with steering wheel unlocked, ground speed lever out of NEUTRAL, or header clutch engaged, **DO NOT START ENGINE.** See your Dealer.

5. Turn ignition key (F) to START position until engine starts, and then release key. Tone ceases, and warning lights go out.

IMPORTANT

Do not operate starter for longer than 15 seconds at a time.

If engine does not start, wait at least two minutes before trying again.

After the third 15 second crank attempt, allow starter motor to cool for 10 minutes before further cranking attempts.

If engine still does not start, refer to the following table:

PROBLEM	SOLUTION
Controls Not In NEUTRAL.	Move GSL to NEUTRAL. Move steering wheel to locked position. Disengage header clutch.
Operator's Station Not Locked. (M155 and M205 only).	Adjust position of Operator's station. Ensure lock is engaged.
Neutral Interlock Misadjusted.	Contact MacDon Dealer.
No Fuel To Engine.	Fill empty fuel tank. Replace clogged filter.
Old Fuel In Tank.	Drain tank. Refill with fresh fuel.
Water, Dirt Or Air In Fuel System.	Drain, flush, fill and prime system.
Improper Type Of Fuel.	Use proper fuel for operating conditions.
Crankcase Oil Too Heavy.	Use recommended oil.
Low Battery Output.	Have battery tested. Check battery electrolyte level.
Poor Battery Connection.	Clean and tighten loose connections.
Faulty Starter.	Contact MacDon Dealer.
Wiring Shorted, Circuit Breaker Open.	Check continuity of wiring and breaker (manual reset).
Faulty Injectors.	Contact MacDon Dealer.

(continued next page)

UNLOADING AND ASSEMBLY

- g. **Cold Start:** engine temperature below 40°F (5°C).

NOTE

Engines are not equipped with cold start assist system.

1. Follow **step e. Normal Start** procedure on last page.
2. Engine will cycle through a period where it appears to labor until engine warms up.

NOTE

Throttle is non-responsive during this time as engine is in "WARM UP" mode. This mode will last from 30 seconds to 3 minutes depending on temperature. After engine has stabilized and idling normally, throttle becomes active.

IMPORTANT

Do not operate engine above 1500 rpm, until engine temperature gauge is above 100°F (40°C).

STEP 22. CHECK TRACTION DRIVE



CAUTION

Check to be sure all bystanders have cleared the area.




M155, M205 SHOWN - M105 SIMILAR

- a. With engine running, move GSL out of N-DETENT, and slowly move GSL forward.
- b. Drive wheels should be rotating in the forward direction, and at the same speed.
- c. Turn steering wheel, and observe motion of drive wheels. They should rotate at different speeds, with the slower rotating wheel on the same side of the machine that the steering wheel was turned toward.
- d. Repeat above for opposite direction.
- e. Move GSL back into reverse. Drive wheels should be rotating in the reverse direction, and at the same speed.
- f. Move GSL back into N-DETENT, and shut down engine.


UNLOADING AND ASSEMBLY

STEP 23. REMOVE WINDROWER FROM STAND

A. FACTORY STAND



- a. Open valve on air supply control to raise windrower slightly, and take load off lift locks.



- b. Release lift lock mechanism (3 places), and turn keeper to keep lock in "released position".
- c. Lower machine to ground by slowly releasing pressure to air bag system.



CAUTION

Ensure all three lifts have fully retracted and are clear of windrower frame before driving windrower ahead.


- d. Start engine, and drive machine straight ahead, leaving shipping support channels supported on rear support stand.

B. FIELD-CONSTRUCTED STAND

- a. Position a jack under the jack point of each drive wheel leg, and another under the rear hitch.
- b. Raise jacks to take weight off stands, and remove stands.
- c. Slowly lower windrower to ground, and remove jacks.

UNLOADING AND ASSEMBLY

STEP 24. INSTALL AM/FM RADIO




Provision has been made for installation of AM/FM radio. The mounting is designed to fit a DIN E style radio with a depth 'X' = 161 mm, and having a 5 mm threaded stud centered on the rear for support.

Provision has been made for adjustments, should the radio fall outside these parameters.


NOTE

M105 configuration is slightly different, but the installation procedure is the same.


- a. Ensure the ignition is turned to the OFF position.




- b. Remove radio panel by removing four screws (A).




- c. Remove screw and nuts (B) and (C) to remove support (D) from panel. Retain metric nut (C) and lockwasher.




- d. Remove the cut-out by cutting the tabs (E) in the panel. Remove sharp edges on panel.



- e. Locate receptacle (F) (supplied with radio) in opening, and secure by bending tabs (G) on receptacle against panel.



- f. Insert radio into receptacle and attach radio bezel. Ensure radio locks into position, and faceplate (H) is against the panel.
- g. A six-pin connector for the radio is included in the wiring harness. In order to mate properly with this connector, the radio must have a six-pin connector (Packard #2977042), and have a terminal arrangement as follows:



(continued next page)

UNLOADING AND ASSEMBLY


- h. Attach two additional wires in the wiring harness to the radio:
 - 1. **Circuit 503:** Red with 1/4 in. female blade terminal. This is a live wire provided for powering a radio clock/memory, if these exist on your radio.
 - 2. **Circuit 315:** Black ground wire attaches to radio body.
- i. Plug cable from antenna into radio.

NOTE

An approved radio package is available from Radio Engineering Industries (REI) of Omaha, Nebraska.


- j. Attach stud (supplied with radio) to center rear of radio.

- k. Attach support (D) to stud on back of radio chassis, with lock washer and metric nut (C) that was supplied with the support.



Support can be attached to chassis in multiple locations to allow for proper mounting of radio.

- l. Re-install radio panel with original screws.



- m. Adjust bracket (J) if necessary by loosening nuts (K) to allow radio to slide into opening, and securely capture support (D).
- n. Turn ignition key to ACC, switch radio ON, and check operation in accordance with instructions supplied with the radio.

UNLOADING AND ASSEMBLY

STEP 25. INSTALL BEACONS


- a. Retrieve the two beacons from shipment.



- b. Remove hardware and rubber base from one of the beacons as shown.




- c. Feed connectors from harness through center hole in rubber base, and place base on beacon bracket - making sure mounting holes in rubber base line-up with holes in bracket.



- d. Connect orange wire from harness to the red wire in beacon. Black harness wire connects to ground terminal in beacon.




- e. Fit beacon onto base making sure beacon is oriented as shown, with the point on lens facing forward (Cab-Forward).



- f. Mount beacon to base with lockwashers and nuts supplied with beacon.
g. Similarly install other beacon on opposite side of cab roof.

STEP 26. INSTALL SLOW MOVING VEHICLE (SMV) SIGN



Install SMV sign in accordance with the instructions supplied with the kit.



UNLOADING AND ASSEMBLY

STEP 27. ATTACH HEADER


A. HEADER ATTACHMENT: D SERIES

I. CONFIGURE HYDRAULICS

M205 and M155 windrowers must be fitted with a draper drive basic kit and a completion kit to operate the D-Series draper headers.





DRAPER HEADER HYDRAULICS FOR M205



DRAPER HEADER HYDRAULICS FOR M155

The M105 needs to be equipped with reel drive, reel lift, and reel fore/aft hydraulics.



DRAPER HEADER REEL HYDRAULICS


Windrowers equipped with D-Series hydraulics have four header drive hoses on the LH side, and up to five reel drive hoses on the RH side.

If necessary, obtain the following kits from your MacDon Dealer, and install them in accordance with instructions supplied with the kits.

KIT DESCRIPTION	KIT NUMBER		
	M205	M155	M105
Base Kit	B5491	B5577	B5577
Completion	B5496	---	---
Reverser	B5492	B4656	---

UNLOADING AND ASSEMBLY


II. ATTACH HEADER BOOTS




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (A), and not installed at hole location (B).

If not installed, attach draper header boots (supplied with header) to windrower lift linkage as follows:




- a. Remove pin (C) from boot (D).



- b. Locate boot (D) on lift linkage (E), and re-install pin (C). Pin may be installed from either side of boot.
- c. Secure pin (C) with hairpin.
- d. Repeat for opposite side.

UNLOADING AND ASSEMBLY

III. ATTACH HEADER




- Remove hairpin on pins (F), and remove pins from header legs.



CAUTION


Check to be sure all bystanders have cleared the area.




- Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.




- If necessary, adjust position of the hydraulic center-link (G) so that the hook (H) is above the attachment pin on the header by one of the following methods:



- If the optional center-link self-alignment kit is installed, activate the REEL UP switch on the GSL to raise the center-link (G).



- Without the self-alignment kit, re-locate the pin (J) at the frame linkage as required to raise the center-link (G).






- Slowly drive windrower forward so that boots (D) enter header legs (K). Continue to drive slowly forward until lift linkages contact support plates in the header legs, and header nudges forward.
- Ensure that lift linkages are properly engaged in header legs, contacting support plates.

(continued next page)

UNLOADING AND ASSEMBLY

f. Connect center-link:

HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT (M205, M155)




1. Adjust position of the center-link cylinder (G) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.

IMPORTANT

Hook release (L) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.

2. Lower center-link (G) onto the header with REEL DOWN switch until it locks into position (hook release (L) is "down").



3. Check that center-link (G) is locked onto header by pressing the REEL UP switch on the GSL.
4. Proceed to step g. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M205 STANDARD, M155, M105 OPTIONAL)

1. Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (G) so that the hook lines-up with the header attachment pin.
2. Stop engine, and remove key from ignition.
3. Push down on rod end of link cylinder (G) until hook engages pin on header, and is locked.

IMPORTANT

Hook release (L) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.

4. Check that center-link is locked onto header by pulling upward on rod end of cylinder.
5. Proceed to step g. on next page.

(continued next page)


UNLOADING AND ASSEMBLY

MECHANICAL LINK (M155, M105 OPTIONAL)



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.




1. Stop engine, and remove key from ignition.
2. Loosen nut (M), and rotate barrel (N) to adjust length so that the link lines-up with header bracket.
3. Install pin (O), and secure with cotter pin.
4. Adjust link to required length for proper header angle by rotating barrel (N). Tighten nut (M) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



- g. If engine is not running, start engine, and press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require re-phasing. If re-phasing is needed, proceed as follows:

1. Press and hold the HEADER UP switch until both cylinders stop moving.
2. Continue to hold the switch for 3 - 4 seconds.
3. Cylinders are phased.




DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.

- h. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:


1. Stop engine, and remove key from ignition.




2. Pull lever (P), and rotate toward header to release and lower cylinder stop (Q) onto cylinder.
3. Repeat for opposite lift cylinder.

(continued next page)


UNLOADING AND ASSEMBLY



- i. Install pin (F) through header leg, (engaging U-bracket in lift linkage) on both sides, and secure with hairpin.
- j. Raise header stand (R) to “storage position” by pulling pin (S), and lifting stand into “uppermost” position. Release pin (S).



- k. Remove pin from “storage position” (T) in linkage, and insert in hole (U) to engage float springs. Secure with hairpin.



- l. Disengage lift cylinder stop by turning lever (P) downward to release and lower stop until lever locks into “vertical” position.
- m. Repeat for opposite lift cylinder stop.



CAUTION


Check to be sure all bystanders have cleared the area.

- n. Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.




WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.



- o. Connect header drive hoses (V) and electrical harness (W) to header. Refer to the Draper Header Operator’s Manual.



- p. Connect reel hydraulics (X) at RH side of windrower. Refer to the Draper Header Operator’s Manual.




CAUTION

Check to be sure all bystanders have cleared the area.



- q. Start engine, and raise and lower header and reel a few times to allow trapped air to pass back to the reservoir.

UNLOADING AND ASSEMBLY

B. HEADER ATTACHMENT: A SERIES



I. CONFIGURE HYDRAULICS



AUGER HEADER HYDRAULICS FOR M205

The M205 windrower must be fitted with an auger drive completion kit to operate the A-Series draper header.


Windrowers equipped with A-Series hydraulics have four header drive hoses on the LH side.

If necessary, obtain the following kit from your MacDon Dealer, and install it in accordance with instructions supplied with the kits.


KIT DESCRIPTION	KIT NUMBER
Basic Drive	B5491
Completion / Reverser	B5492

The M155 and M105 are factory-equipped to run the A-Series auger headers.

II. ATTACH HEADER



- a. Remove hairpin from pin (A), and remove pin from left and right header boots (B) on header.



IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and not installed at hole location (D).


(continued next page)

UNLOADING AND ASSEMBLY



CAUTION


Check to be sure all bystanders have cleared the area.




- b. Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.




- c. If necessary, adjust position of the hydraulic center-link (E) so that the hook (F) is above the attachment pin on the header by one of 2 the following methods (shown in next column):



1. If the optional center-link self-alignment kit is installed, activate the REEL UP switch on the GSL to raise the center-link (E).



2. Without the self-alignment kit, re-locate the pin (G) at the frame linkage as required to raise the center-link (E).






- d. Slowly drive windrower forward so that feet (H) on windrower enter boots (B) on the header. Continue to drive slowly forward until feet engage the boots, and header nudges forward.

(continued next page)

UNLOADING AND ASSEMBLY

e. Connect center-link:


HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT



1. Adjust position of the center-link cylinder (E) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.

IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.



2. Lower the center-link onto the header with REEL DOWN switch until it locks into position (hook release (J) is "down").
3. Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.
4. Proceed to step f. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M205 STANDARD, M155, M105 OPTIONAL)

1. Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (E) so that the hook lines-up with the header attachment pin.
2. Stop engine, and remove key from ignition.
3. Push down on rod end of link cylinder (E) until hook engages pin on header, and is locked.

IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.


4. Check that the center-link is locked onto header by pulling upward on rod end of cylinder.
5. Proceed to step f. on next page.

(continued next page)

UNLOADING AND ASSEMBLY

MECHANICAL LINK (M155, M105 OPTIONAL)

1. Stop engine, and remove key from ignition.




2. Loosen nut (H), and rotate barrel (J), to adjust length so that other end lines-up with header bracket.
3. Install pin (K), and secure with cotter pins.
4. Adjust link to required length for proper header angle by rotating barrel (J). Tighten nut (H) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



- f. If engine is not running, start engine. Press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require re-phasing. If re-phasing is needed, proceed as follows:

1. Press and hold HEADER UP switch until both cylinders stop moving.
2. Continue to hold the switch for 3 - 4 seconds.
3. Cylinders are phased.



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.





DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.

- g. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:


1. Stop engine, and remove key from ignition.



2. Pull lever (L), and rotate toward header to release and lower cylinder stop (M) onto cylinder.
3. Repeat for opposite lift cylinder.

(continued next page)


UNLOADING AND ASSEMBLY




- h. Install pin (N) through each boot and foot, and secure with hairpin.

IMPORTANT


Ensure pin (N) is fully inserted, and hairpin is installed behind bracket.



- Remove lynch pin from pin (O) in stand (P).
- Hold stand (P), and remove pin (O).
- Re-position stand to "storage position" by inverting stand, and re-locating on bracket as shown
- Re-insert pin (O), and secure with lynch pin.



- m. Remove pin (Q) from "storage position" in linkage, and insert in hole (R) to engage float springs. Secure with lynch pin.




- Disengage lift cylinder stop by turning lever (L) downward to raise stop until lever locks into "vertical" position.
- Repeat for opposite cylinder stop.



CAUTION

Check to be sure all bystanders have cleared the area.



- p. Start engine, and activate HEADER DOWN switch on GSL to lower header fully.

(continued next page)


UNLOADING AND ASSEMBLY



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

- q. Stop engine, and remove key.



- r. Connect header drive hydraulics (S) and electrical harness (T) to header. Refer to Auger Header Operator's Manual.

UNLOADING AND ASSEMBLY

C. HEADER ATTACHMENT: R SERIES (M205, M155 ONLY)




I. CONFIGURE HYDRAULICS

M205

The M205 is factory-equipped with hydraulics and connections to run the R-Series Rotary Disc headers.


R85 16 and 19 FT headers are factory-equipped with hydraulic connections for attachment to the M205 windrower.



KIT B5456

13 FT R80 and R85 headers need to be equipped with Kit B5456 (motor and hoses).

M155




KIT B5510


The M155 windrower operates only the R85 and R80 13 FT headers, and these headers need to be equipped with Kit B5510 (motor and hoses).

To operate these headers, the M155 windrower requires the installation of hydraulic valve Kit B4657. See your MacDon Dealer.

II. ATTACH HEADER



- a. Remove hairpin from pin (A), and remove pin from on left and right header boots (B) on header.



IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and not installed at hole location (D).


(continued next page)

UNLOADING AND ASSEMBLY



CAUTION


Check to be sure all bystanders have cleared the area.




- b. Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.




- c. If necessary, adjust position of the hydraulic center-link (E) so that the hook (F) is above the attachment pin on the header by one of the following 2 methods (shown in next column):



1. If the optional center-link self-alignment kit is installed, activate the REEL UP switch on the GSL to raise the center-link (E).



2. Without the self-alignment kit, re-locate the pin (G) at the frame linkage as required to raise the center-link (E).




- d. Slowly drive windrower forward so that feet (H) on windrower enter boots (B) on the header.
- e. Continue to drive slowly forward until feet engage the boots, and header nudges forward.

(continued next page)


UNLOADING AND ASSEMBLY

f. Connect center-link:

HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT



1. Adjust position of the center-link cylinder (E) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.




IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.

2. Push the REEL DOWN switch on the GSL to lower the center-link onto the header until it locks into position (release (J) is "down").
3. Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.
4. Proceed to step g. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M205 STANDARD, M155 OPTIONAL)



1. Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (E) so that the hook lines-up with the header attachment pin.
2. Stop engine, and remove key from ignition.
3. Push down on rod end of link cylinder (E) until hook engages pin on header, and is locked.

IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open ("up"), manually push it down after hook engages header pin.

4. Check that center-link is locked onto header by pulling upward on rod end of cylinder.
5. Proceed to step g. on next page.

(continued next page)

UNLOADING AND ASSEMBLY


MECHANICAL LINK (M155 OPTIONAL)




WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

1. Stop engine, and remove key from ignition.



2. Loosen nut (J), and rotate barrel (K), to adjust length so that other end lines-up with header bracket.




3. Install clevis pin (L), and secure with cotter pin.
4. Adjust link to required length for proper header angle by rotating barrel (K). Tighten nut (J) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



- g. Start engine (if not running), and press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require re-phasing. If re-phasing is needed, proceed as follows:

1. Press and hold HEADER UP switch until both cylinders stop moving.
2. Continue to hold the switch for 3 - 4 seconds.
3. Cylinders are phased.

(continued next page)

UNLOADING AND ASSEMBLY



DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.



- h. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:




WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

1. Stop engine, and remove key from ignition.




2. Pull lever (M), and rotate toward header to release and lower cylinder stop (N) onto cylinder.
3. Repeat for opposite lift cylinder.




- i. Install pin (O) through each boot and foot, and secure with hairpin.

IMPORTANT

Ensure pin (O) is fully inserted, and hairpin is installed behind bracket.



- j. Remove pin (P) from “storage position” in linkage, and insert in hole (Q) to engage float springs. Secure with hairpin.



- k. Disengage lift cylinder stops by turning lever (M) downward to release and lower stop until lever locks into “vertical” position. Repeat for opposite lift cylinder stop.


(continued next page)

UNLOADING AND ASSEMBLY



CAUTION

Check to be sure all bystanders have cleared the area.



- i. Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

- m. Connect header drive hydraulics and electrical harness to header. Refer to your Rotary Disc Header Operator's Manual.

STEP 28. LUBRICATE MACHINE

Recommended Lubricant

SPEC	DESCRIPTION	USE
SAE Multi-Purpose	High Temperature Extreme Pressure (EP2) Performance With 1% Max Molybdenum Disulphide (NLGI Grade 2) Lithium Base	As Required Unless Otherwise Specified


- a. Wipe grease fitting with a clean cloth before greasing, to avoid injecting dirt and grit.
- b. Inject grease through fitting with grease gun until grease overflows fitting, except where noted.
- c. Leave excess grease on fitting to keep out dirt.
- d. Replace any loose or broken fittings immediately.
- e. If fitting will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.
- f. Refer to the following illustrations to identify the various locations requiring lubrication.

(continued next page)


UNLOADING AND ASSEMBLY

Lubrication Points (Cont'd)

High Temperature Extreme Pressure (EP2) Performance With 1% Max Molybdenum Disulphide (NLGI Grade 2). Lithium Base.




WALKING BEAM PIVOT)



TOP LINK - TWO FITTINGS (BOTH SIDES)



FORMED CASTER WHEEL BEARING 1 PLACE (BOTH WHEELS)



FORKED CASTER SPINDLE BEARINGS TWO PLACES (BOTH WHEELS)



CASTER PIVOT (BOTH SIDES)

UNLOADING AND ASSEMBLY

STEP 29. PROGRAM CAB DISPLAY MODULE (CDM)

The monitoring system requires programming for each header, and the header must be attached to the windrower.

Programming the system may be accomplished with, or without the engine running. If the engine is running, the transmission must be in NEUTRAL. If the engine is not running, the ignition must be ON.

Exit programming mode at any time by pressing the PROGRAM switch, or by turning OFF ignition.

The system only needs to be programmed once for each header. The Operator may make changes later on to a particular setting to suit windrowing conditions or modifications to the machine. Most functions have been pre-programmed at the factory, but can be changed by the Operator if required.

The following functions can be programmed by the Dealer, provided the applicable information from the Operator has been provided, and the header is installed:

- **DWA INSTALLED (M155, M205 ONLY)**
- **HDR CUT WIDTH**
- **HAY CONDITIONER INSTALLED**
- **CALIBRATE SENSORS**

Proceed to program the CDM as follows:


IMPORTANT

Header must be attached to the windrower so that the CDM can detect the type of header (Header ID), and adjust the programming mode accordingly.

- a. Turn ignition key to RUN, or start the engine. Refer to STEP 21. START ENGINE.
- b. Press PROGRAM and SELECT switches together on CDM to enter programming mode. Header ID code is displayed.
- c. Press SELECT. TRACTOR SETUP? is displayed.
- d. Press \rightarrow . SET KNIFE SPEED? is displayed.
- e. Press SELECT until DWA INSTALLED? is displayed.
- f. Press \leftarrow or \rightarrow .
- g. Press SELECT to advance to the next L1 item.
- h. Press PROGRAM to exit programming mode.
- i. Refer to the following pages depending on your machine. The functions requiring programming are highlighted with \square in the Programming Instructions:

A. M205, M155 Detailed Programming Instructions, or

B. M105 Detailed Programming Instructions.



UNLOADING AND ASSEMBLY

A. M205, M155 DETAILED PROGRAMMING INSTRUCTIONS

(Ignition ON / Engine Running or Not / Header Disengaged).

(Press **PROGRAM** and **SELECT** on CDM to enter programming mode).

(If necessary, refer to the M Series Windrower Operator's Manual for programming to specific crop types and conditions).

Programming Menu Flow Chart

	L1 C x x x TRACTOR SETUP?	If "NO" then jump to:
	L2 M x x x ← NO / YES →	C A B D I S P L A Y S E T U P ?
<div style="border: 1px solid black; padding: 5px; width: 20px; height: 20px; margin: 0 auto; transform: rotate(45deg);"></div>	L1 C x x x SET KNIFE SPEED?	When the programming mode is entered the header ID will be displayed on the top line of the CDM using the last 4 display positions. Pressing "SELECT" will go to the next line 1 (L1) menu selection. The turn signal "arrow" keys are used to change the values. Pressing "PROGRAM" at any time will cancel the programming mode / menus and return back to the main operating displays.
	L2 M x x x ← 1 2 0 0 S P M →	
L1 C x x x KNIFE OVERLOAD SPD?		
L2 M x x x ← 1 0 0 0 S P M →		
L1 C x x x DISC OVERLOAD SPD?		
L2 M x x x ← 2 0 0 0 R P M →		
L1 C x x x OVERLOAD PRESSURE?		
L2 M x x x ← 4 0 0 0 P S I →		
L1 C x x x HEADER INDEX MODE?		
L2 M x x x ← REEL & CONVEYOR →		
L2 M x x x ← REEL ONLY →		
L1 C x x x RETURN TO CUT MODE?	The auto raise setting can be changed from 4.0 (min.) to 10.0 (max.) in 0.5 increments OFF disables the auto raise function.	
L2 M x x x ← HEIGHT & TILT →		
L2 M x x x ← HEIGHT ONLY →		
L1 C x x x AUTO RAISE HEIGHT?	If "NO" then jump to: H E A D E R C U T W I D T H ?	
L2 M x x x ← - 4 . 0 + →		
L2 M x x x ← - OFF + →		
L1 C x x x DWA INSTALLED?	Swaps the GSL reel fore / aft with the DWA console controls. If NO jump to DWA AUTO UP & DOWN?	
L2 M x x x ← NO / YES →		
L1 C x x x SWAP DWA CONTROLS?	Enables the express up and down feature with the header RTC. If NO jump to HEADER CUT WIDTH?	
L2 M x x x ← NO / YES →		
L1 C x x x DWA AUTO UP / DOWN?	Appears for M150/155 ONLY - If "NO" then jump to H E A D E R C U T W I D T H ?	
L2 M x x x ← NO / YES →		
L1 C x x x TILT CYL INSTALLED?	If "NO" then jump to: H E A D E R C U T W I D T H ?	
L2 M x x x ← NO / YES →		
L1 C x x x DISC BLK INSTALLED?	Use the "arrow" keys to set the header cut width. The header ID appears at the RHS.	
L2 M x x x ← NO / YES →		
L1 C x x x HDR CUT WIDTH? 0 1 0 1	DRAPER HEADER ONLY. Default will be flashing. Use "arrow" keys to select.	
L2 M x x x ← 2 0 . 5 F E E T →		
L1 C x x x HAY CONDITIONER?	AUGER HEADER ONLY For IMPERIAL display. For METRIC display.	
L2 M x x x ← NO / YES →		
L1 C x x x AUGER HDR REEL SPD	Pressing "SELECT" will go to the next line 1 (L1) menu selection. The turn signal "arrow" keys are used to change the values.	
L2 M x x x ← RPM / MPH →		
L2 M x x x ← RPM / KPH →		
L1 C x x x SET TIRE SIZE?		
L2 M x x x ← 1 8 . 4 X 2 6 T U R F →		
L2 M x x x ← 1 8 . 4 X 2 6 B A R →		
L2 M x x x ← 2 3 . 1 X 2 6 T U R F →	If "NO" then jump to: S E T C O N T R O L L O C K S ?	
L2 M x x x ← 6 0 0 - 6 5 R 2 8 →		
L2 M x x x ← 5 8 0 / 7 0 R 2 6 T U R F →		
L1 C x x x SET ENGINE ISC RPM?		
L2 M x x x ← NO / YES →		

(continued next page)

UNLOADING AND ASSEMBLY

```

L1  C x x x || P R E S S   H A Z A R D   T O   S E T
L2  M x x x || I S C   R P M   O F F   ← →

L1  C x x x || P R E S S   H A Z A R D   T O   S E T
L2  M x x x || I S C   R P M   2 2 0 0   ← →

L1  C x x x || P R E S S   H A Z A R D   T O   S E T
L2  M x x x || I S C   R P M   2 0 0 0   ← →

L1  C x x x || P R E S S   H A Z A R D   T O   S E T
L2  M x x x || I S C   R P M   1 8 0 0   ← →

L1  C x x x || E X I T   E N G I N E   I S C ?
L2  M x x x || ←   N O / Y E S   →
    
```

This is used to set the Intermediate Speed Control function for the engine. The default or last selected rpm will be displayed first and will be flashing.

The "arrow" keys are used to cycle between the selections. When "SELECT" is pressed the program goes to the EXIT ENGINE ISC? menu selection.

If "NO" then jump to:
P R E S S H A Z A R D T O S E T

```

L1  C x x x || S E T   C O N T R O L   L O C K S ?
L2  M x x x || ←   N O / Y E S   →
    
```

If "NO" then jump to:
V I E W C O N T R O L L O C K S ?

```

L1  C x x x || H E A D E R   T I L T
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || H E A D E R   F L O A T
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || R E E L   F O R E / A F T
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || D R A P E R   S P E E D
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || A U G E R   S P E E D
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || K N I F E   S P E E D
L2  M x x x || ← E N A B L E D / L O C K E D →
or
L1  C x x x || D I S K   S P E E D
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || R E E L   S P E E D
L2  M x x x || ← E N A B L E D / L O C K E D →

L1  C x x x || E X I T   C O N T R O L   L O C K S ?
L2  M x x x || ←   N O / Y E S   →
    
```

This menu allows the operator to selectably "lock out" the control functions for the various header functions. The default or selected "status" for each item will flash.

The "arrow" keys are used to ENABLE or LOCK OUT each function. Pressing "SELECT" will go to the next L1 menu item.

If "NO" then jump to:
H E A D E R T I L T

```

L1  C x x x || V I E W   C O N T R O L   L O C K S ?
L2  M x x x || ←   N O / Y E S   →
    
```

If "NO" then jump to:
E X I T T R A C T O R S E T U P ?

```

L1  C x x x || H E A D E R   T I L T   ← →
L2  M x x x ||   5 7 5 . 1   H R S   E N A B L E D
L2  M x x x ||   6 4 8 . 6   H R S   L O C K E D

L1  C x x x || H E A D E R   F L O A T   ← →
L2  M x x x ||   5 7 5 . 1   H R S   E N A B L E D
L2  M x x x ||   6 4 8 . 6   H R S   L O C K E D

L1  C x x x || R E E L   F O R E / A F T   ← →
L2  M x x x ||   5 7 5 . 1   H R S   E N A B L E D
L2  M x x x ||   6 4 8 . 6   H R S   L O C K E D

L1  C x x x || D R A P E R   S P E E D   ← →
L2  M x x x ||   5 7 5 . 1   H R S   E N A B L E D
L2  M x x x ||   6 4 8 . 6   H R S   L O C K E D

L1  C x x x || A U G E R   S P E E D   ← →
L2  M x x x ||   5 7 5 . 1   H R S   E N A B L E D
L2  M x x x ||   6 4 8 . 6   H R S   L O C K E D
    
```

When the control lock outs are viewed the lower display line (L2) will show the engine hours and either ENABLED or LOCKED to indicate the present status along with the engine hours at which time the function was either ENABLED or LOCKED.

Using the "arrow" keys allows the operator to select the various functions. Pressing "SELECT" will go to the EXIT VIEW LOCKOUTS? menu selection.

(continued next page)

UNLOADING AND ASSEMBLY

IMPORTANT: ENGINE MUST BE RUNNING TO CALIBRATE SENSORS

L1	C x x x KNIFE SPEED	← →	
L2	M x x x 5 7 5 . 1 HRS ENABLED		
L2	M x x x 6 4 8 . 6 HRS LOCKED		
L1	C x x x DISK SPEED	← →	
L2	M x x x 5 7 5 . 1 HRS ENABLED		
L2	M x x x 6 4 8 . 6 HRS LOCKED		
L1	C x x x REEL SPEED	← →	
L2	M x x x 5 7 5 . 1 HRS ENABLED		
L2	M x x x 6 4 8 . 6 HRS LOCKED		
L1	C x x x EXIT VIEW LOCKOUTS?		
L2	M x x x ← NO / YES →		
L1	C x x x EXIT TRACTOR SETUP?		if "NO" then jump to:
L2	M x x x ← NO / YES →		SET KNIFE SPEED?

L1	C x x x CAB DISPLAY SETUP?		if "NO" then jump to:
L2	M x x x ← NO / YES →		CALIBRATE SENSORS?

L1	C x x x DISPLAY LANGUAGE?		Use the "arrow" keys to change the default language. Pressing "SELECT" goes to the next L1 menu selection.
L2	M x x x ← ENGLISH →		
L2	M x x x ← ESPANOL →		
L1	C x x x DISPLAY UNITS?		The "arrow" keys are used to select between IMPERIAL or METRIC. The default value will be displayed first.
L2	M x x x ← IMPERIAL →		
L2	M x x x ← METRIC →		
L1	C x x x CDM BUZZER VOLUME		The "arrow" keys are used to change the CDM buzzer volume, CDM backlighting or the CDM contrast, with the bar graph indicating the relative level for each item. When "SELECT" is pressed the program goes to the EXIT DISPLAY SETUP? menu selection.
L2	M x x x ← [Bar Graph] →		
L1	C x x x CDM BACKLIGHTING		
L2	M x x x ← [Bar Graph] →		
L1	C x x x CDM CONTRAST		if "NO" then jump to:
L2	M x x x ← [Bar Graph] →		
L2	M x x x ← NO / YES →		

L1	C x x x CALIBRATE SENSORS?		if "NO" then jump to:
L2	M x x x ← NO / YES →		DIAGNOSTIC MODE?

L1	C x x x TO CALIBRATE SELECT		The operator can select any of the three items requiring calibration (or exit the CAL menu) by using the turn signal switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor.
L2	M x x x ← HEADER HEIGHT →		
L2	M x x x ← HEADER TILT →		
L2	M x x x ← HEADER FLOAT →		
L2	M x x x EXIT CAL? ← NO / YES →		
L1	C x x x HEIGHT SENSOR CAL		
L2	M x x x RAISE HDR TO START		
L1	C x x x CALIBRATING HEIGHT		When the header raise is done, the CDM will prompt the user to lower the header. COMPLETE (with buzzer) will flash on the screen for 2 seconds when the calibration is finished.
L2	M x x x RAISE HEADER HOLD		
L2	M x x x HEADER RAISE DONE		
L1	C x x x CALIBRATING HEIGHT		The operator can select any of the three items requiring calibration (or exit the CAL menu) by using the turn signal switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor.
L2	M x x x LOWER HEADER HOLD		
L2	M x x x HT SENSOR COMPLETE		
L1	C x x x TO CALIBRATE SELECT		
L2	M x x x ← HEADER HEIGHT →		
L2	M x x x ← HEADER TILT →		
L2	M x x x ← HEADER FLOAT →		
L2	M x x x EXIT CAL? ← NO / YES →		

(continued next page)

UNLOADING AND ASSEMBLY

```

L1 | C x x x | HDR TILT SENSOR CAL |
L2 | M x x x | EXTEND TLT TO START |

L1 | C x x x | CALIBRATING TILT |
L2 | M x x x | EXTEND TILT HOLD |
L2 | M x x x | EXTEND TILT DONE |

L1 | C x x x | CALIBRATING TILT |
L2 | M x x x | RETRACT TILT HOLD |
L2 | M x x x | HDR TILT COMPLETE |

L1 | C x x x | TO CALIBRATE SELECT |
L2 | M x x x | ← HEADER HEIGHT → |
L2 | M x x x | ← HEADER TILT → |
L2 | M x x x | ← HEADER FLOAT → |
L2 | M x x x | EXIT CAL? ← NO / YES → |

L1 | C x x x | CALIBRATING FLOAT |
L2 | M x x x | PRESS FLT+ TO START |

L1 | C x x x | CALIBRATING FLOAT |
L2 | M x x x | FLOAT (+) HOLD |
L2 | M x x x | FLOAT (+) DONE |

L1 | C x x x | CALIBRATING FLOAT |
L2 | M x x x | FLOAT (-) HOLD |
L2 | M x x x | HDR FLOAT COMPLETE |

L2 | C x x x | TO CALIBRATE SELECT |
L2 | M x x x | ← HEADER HEIGHT → |
L2 | M x x x | ← HEADER TILT → |
L1 | M x x x | ← HEADER FLOAT → |
L2 | M x x x | EXIT CAL? ← NO / YES →
    
```

The display will indicate the sensor being calibrated. The operator will be prompted to extend the header tilt and HOLD will flash until the system has completed reading in the signal with the header tilt fully extended. HOLD will change to DONE (with buzzer).

When the header tilt extend is done, the CDM will prompt the user to press the header tilt retract. COMPLETE (with buzzer) will flash on the screen for 2 seconds when the calibration is finished.

The operator can select any of the three items requiring calibration (or exit the CAL menu) by using the turn signal switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor.

The display will indicate the sensor being calibrated. The operator will be prompted to press the float (+) and HOLD will flash until the system has completed reading in the signal with the header float fully extended. HOLD will change to DONE (with buzzer).

When the header float (+) is done, the CDM will prompt the user to press the header float (-). COMPLETE (with buzzer) will flash on the screen for 2 seconds when the calibration is finished.

Select any of the sensors by using the turn signal switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor. NO is the default for EXIT CAL?. If "NO" then jump to:

TO CALIBRATE SELECT

```

L1 | C x x x | DIAGNOSTIC MODE? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to:
TRACTOR SETUP?

```

L1 | C x x x | VIEW ERROR CODES? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to:
ENTER SENSOR SETUP?

```

L1 | C x x x | VIEW TRACTOR CODES? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to:
VIEW ENGINE CODES?

```

L1 | 1 | 1234.5 HRS 123 |
L2 | E 47 | SENSOR VOLTS LOW |
    
```

The last 10 distinct error codes are stored along with the code #, Exxx, engine hours and number of occurrences. The "arrow" keys are used to cycle between codes.

```

L1 | 2 | 1230.5 HRS 123 |
L2 | E 71 | LOW HYDRAULIC OIL |
    
```

If "NO" then jump to the first error code logged.

```

L1 | C x x x | EXIT TRACTOR CODES? |
L2 | M x x x | ← NO / YES →
    
```

```

L1 | C x x x | VIEW ENGINE CODES? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to:
ENTER SENSOR SETUP?

```

L1 | 1 | 1234.5 HRS 123 |
L2 | 449 | FUEL PRESSURE HIGH |
    
```

The last 10 distinct error codes are stored.

```

L1 | C x x x | EXIT ENGINE CODES? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to the first engine error code logged.

```

L1 | C x x x | EXIT ERROR CODES? |
L2 | M x x x | ← NO / YES →
    
```

If "NO" then jump to:
VIEW TRACTOR CODES?

(continued next page)

UNLOADING AND ASSEMBLY

L1 | C x x x | ENTER SENSOR SETUP? | If "NO" then jump to:
 L2 | M x x x | ← NO / YES → | READ SENSOR INPUTS?

↳ L1 | C x x x | KNIFE SPEED SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | REEL SPEED SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | HEADER HT SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | HEADER TILT SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | HEADER FLOAT SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | OVERLOAD PRESSURE |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | HYD OIL TEMP SENSOR |
 L2 | M x x x | ← ENABLE / DISABLE →

L1 | C x x x | EXIT SENSOR SETUP? |
 L2 | M x x x | ← NO / YES →

The operator can select each sensor and selectively enable or disable the sensor. This can be used to disable a failed sensor to eliminate false or erratic display readings.

When "SELECT" is pressed the program goes to the EXIT SENSOR SETUP? menu selection.

NOTE: Oil temp. readouts apply to models with the Sensata oil temp. sensor.

If "NO" then jump to:
KNIFE SPEED SENSOR

L1 | C x x x | READ SENSOR INPUTS? | If "NO" then jump to:
 L2 | M x x x | ← NO / YES → | ACTIVATE FUNCTIONS?

↳ L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HDR HEIGHT | 3 . 5 9 V

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HDR ANGLE | 1 . 8 4 V

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | 2 . 4 5 V FLOAT | 2 . 8 4 V

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | KNIFE SPEED | 1 2 3 HZ

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | REEL SPEED | 1 2 3 HZ

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | WHEEL SPEED | 1 2 3 HZ

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HYD OIL TEMP | 1 . 0 0 V

L1 | C x x x | EXIT READ SENSORS? |
 L2 | M x x x | ← NO / YES →

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HDR HEIGHT | SENSOR

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HDR ANGLE | SENSOR

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | 2 . 4 5 V FLOAT | SENSOR

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | KNIFE SPEED | SENSOR

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | REEL SPEED | SENSOR

L1 | C x x x | SENSOR INPUT | ← → |
 L2 | M x x x | HYD OIL TEMP | SENSOR

For diagnostic purposes each sensors input signal can be read. This helps in determining how each sensor is operating and if the proper output voltages are being received by the control system.

NOTE: Oil temp. readouts apply to models with the Sensata oil temp. sensor.

When "SELECT" is pressed the program goes to the EXIT READ SENSORS? menu

If "NO" then jump to:
SENSOR INPUT | ← → |
 HDR HEIGHT | 3 . 5 9 V

If a sensor has been disabled "SENSOR" will be flashing in the area where the input reading would have been.

NOTE: Oil temp. readouts apply to models with the Sensata oil temp. sensor.

UNLOADING AND ASSEMBLY

L1	C x x x	ACTIVATE FUNCTIONS?	if "NO" then jump to:
L2	M x x x	← NO / YES →	FORCE HEADER TYPE?

L1	C x x x	ACTIVATE FUNCTIONS?	For diagnostic purposes each header function can be activated by using the "arrow" keys on the CDM. When "SELECT" is pressed the program will go to the next function that can be activated. If a disk header is detected then the nomenclature should read: DISC DRIVE instead of KNIFE DRIVE. PWM OPERATION: If the HAZARD switch is pressed instead of the TURN SIGNAL switch the GSL will operate the PWM valve (HAZARD sw must be held) and the PWM value will reset to zero when released. The DWA menu selection should only be available if the DWA INSTALLED? is set to YES.
L2	M x x x	← HEADER DOWN / UP →	

L1	C x x x	ACTIVATE FUNCTIONS?	ACTIVATE HYD PURGE - This is to allow the operator to purge the air from a new or changed pump system. Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← REEL DOWN / UP →	

L1	C x x x	ACTIVATE FUNCTIONS?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← HDR TILT IN / OUT →	

L1	C x x x	ACTIVATE FUNCTIONS?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← KNIFE DRIVE ON →	

L1	C x x x	ACTIVATE FUNCTIONS?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← DRAPER / AUGER ON →	

L1	C x x x	ACTIVATE FUNCTIONS?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← REEL ← FORE / AFT →	

L1	C x x x	ACTIVATE FUNCTIONS?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← DWA DRIVE ON →	

L1	C x x x	ACTIVATE HYD PURGE?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← NO / YES →	

L1	C x x x	TO ACTIVATE PURGE	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← PRESS AND HOLD →	

L1	C x x x	PURGE CYCLE STARTED	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← PRESS AND HOLD →	

L1	C x x x	PURGE CYCLE ENDED	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← NO EXIT YES →	

L1	C x x x	PURGE CYCLE ENDED	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← NO EXIT YES →	

L1	C x x x	EXIT FUNCTION MENU?	Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.
L2	M x x x	← NO / YES →	

L1	C x x x	FORCE HEADER TYPE?	if "NO" then jump to:
L2	M x x x	← NO / YES →	EXIT DIAGNOSTICS?

L1	C x x x	SELECT HEADER TYPE	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← DISC HEADER →	

L2	M x x x	← SK AUGER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← DK AUGER →	

L2	M x x x	← GRASS SEED →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 20 FT SK DRAPER →	

L2	M x x x	← 25 FT SK DRAPER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 30 FT SK DRAPER →	

L2	M x x x	← 35 FT SK DRAPER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 15 FT DK DRAPER →	

L2	M x x x	← 20 FT DK DRAPER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 25 FT DK DRAPER →	

L2	M x x x	← 30 FT DK DRAPER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 35 FT DK DRAPER →	

L2	M x x x	← 40 FT DK DRAPER →	This allows the operator to select or "force" a header ID configuration if a "NO HEADER" ID is being read by the control system. The header type will revert back to "NO HEADER" every time the ignition is cycled. When "SELECT" is pressed the program goes to the EXIT HEADER TYPE? menu selection.
L2	M x x x	← 40 FT DK DRAPER →	

L1	C x x x	EXIT HEADER TYPE?	if "NO" then jump to:
L2	M x x x	← NO / YES →	FORCE HEADER TYPE?

L1	C x x x	EXIT DIAGNOSTICS?	if "NO" then jump to:
L2	M x x x	← NO / YES →	DIAGNOSTIC MODE?

UNLOADING AND ASSEMBLY


B. M105 DETAILED PROGRAMMING INSTRUCTIONS

(Ignition ON / Engine Running or Not / Header Disengaged).

(Press **PROGRAM** and **SELECT** on CDM to enter programming mode).

(If necessary, refer to the M Series Windrower Operator's Manual for programming to specific crop types and conditions).

Programming Menu Flow Chart



(continued next page)

UNLOADING AND ASSEMBLY

L1 L2	C x x x DRAPER SPEED M x x x ← ENABLED / LOCKED →	This menu allows the operator to selectably "lock out" the control functions for the various header functions. The default or selected "status" for each item will flash.
L1 L2	C x x x AUGER SPEED M x x x ← ENABLED / LOCKED →	
L1 L2	C x x x REEL SPEED M x x x ← ENABLED / LOCKED →	If the expansion module is not installed the corresponding menu items should be suppressed.
L1 L2	C x x x REEL FORE / AFT M x x x ← ENABLED / LOCKED →	The "arrow" keys are used to ENABLE or LOCK OUT each function. Pressing "SELECT" will go to the next L1 menu item.
L1 L2	C x x x HEADER TILT M x x x ← ENABLED / LOCKED →	Tilt to be suppressed if not "installed" in the tractor setup menu.
L1 L2	C x x x EXIT CONTROL LOCKS? M x x x ← NO / YES →	If "NO" then jump to: DRAPER SPEED ← ENABLED / LOCKED →

L1 L2	C x x x VIEW CONTROL LOCKS? M x x x ← NO / YES →	If "NO" then jump to: EXIT TRACTOR SETUP?
----------	---	--

L1 L2 L2	C x x x DRAPER SPEED M x x x 575.1 HRS ENABLED M x x x 648.6 HRS LOCKED	When the control lock outs are viewed, the lower display line (L2) will show the engine hours and either ENABLED or LOCKED to indicate the present status along with the engine hours at which time the function was either ENABLED or LOCKED.
L1 L2 L2	C x x x AUGER SPEED M x x x 575.1 HRS ENABLED M x x x 648.6 HRS LOCKED	
L1 L2 L2	C x x x REEL SPEED M x x x 575.1 HRS ENABLED M x x x 648.6 HRS LOCKED	Using the "arrow" keys allows the operator to select the various functions. Pressing "SELECT" will go to the EXIT VIEW LOCKOUTS? menu selection.
L1 L2 L2	C x x x REEL FORE / AFT M x x x 575.1 HRS ENABLED M x x x 648.6 HRS LOCKED	If any of the HDR ANGLE / KNIFE SPEED or REEL SPEED sensors are not "installed" (no expansion module or A30 Auger header selected, they should be suppressed.
L1 L2 L2	C x x x HEADER TILT M x x x 575.1 HRS ENABLED M x x x 648.6 HRS LOCKED	
L1 L2	C x x x EXIT VIEW LOCKOUTS? M x x x ← NO / YES →	If "NO" then jump to: DRAPER SPEED ← →

L1 L2	C x x x EXIT TRACTOR SETUP? M x x x ← NO / YES →	If "NO" then jump to: TILT CYL INSTALLED?
----------	---	--

L1 L2	C x x x CAB DISPLAY SETUP? M x x x ← NO / YES →	If "NO" then jump to: CALIBRATE SENSORS?
L1 L2 L2	C x x x DISPLAY LANGUAGE? M x x x ← ENGLISH → M x x x ← ESPANOL → M x x x ← RUSSIAN →	Use the "arrow" keys to change the default language. Pressing "SELECT" goes to the next L1 menu selection.
L1 L2 L2	C x x x DISPLAY UNITS? M x x x ← IMPERIAL → M x x x ← METRIC →	The "arrow" keys are used to select between IMPERIAL or METRIC. The default value will be displayed first.

(continued next page)

UNLOADING AND ASSEMBLY

IMPORTANT: ENGINE MUST BE RUNNING TO CALIBRATE SENSORS

L1	C x x x CDM BUZZER VOLUME	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x CDM BACKLIGHTING	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x CDM CONTRAST	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x EXIT DISPLAY SETUP?	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	

The "arrow" keys are used to change the CDM buzzer volume, CDM backlighting or the CDM contrast, with the bar graph indicating the relative level for each item. When "SELECT" is pressed the program goes to the EXIT DISPLAY SETUP? menu selection.

If "NO" then jump to:
DISPLAY LANGUAGE?

L1	C x x x CALIBRATE SENSORS?	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	

If "NO" then jump to:
DIAGNOSTIC MODE?

L1	C x x x TO CALIBRATE SELECT	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x HEIGHT SENSOR CAL	
L2	M x x x RAISE HDR TO START	
L1	C x x x CALIBRATING HEIGHT	
L2	M x x x RAISE HEADER HOLD	
L2	M x x x RAISE HEADER DONE	
L1	C x x x HEIGHT SENSOR CAL	
L2	M x x x PRESS LOWER HEADER	
L1	M x x x CALIBRATING HEIGHT	
L2	M x x x LOWER HEADER HOLD	
L2	M x x x HT SENSOR COMPLETE	
L1	C x x x TO CALIBRATE SELECT	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x TO CALIBRATE SELECT	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	M x x x HDR TILT SENSOR CAL	
L2	M x x x EXTEND TLT TO START	
L1	C x x x CALIBRATING TILT	
L2	M x x x EXTEND TILT HOLD	
L2	M x x x EXTEND TILT DONE	
L1	M x x x HDR TILT SENSOR CAL	
L2	M x x x PRESS RETRACT TILT	
L1	C x x x CALIBRATING TILT	
L2	M x x x RETRACT TILT HOLD	
L2	M x x x HDR TILT COMPLETE	
L1	C x x x TO CALIBRATE SELECT	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	
L1	C x x x EXIT CALIBRATION?	
L2	M x x x ← [] [] [] [] [] [] [] [] [] [] →	

The operator can select any of the two items requiring calibration or to STOP & EXIT the menu.

When a function is activated, the display will indicate the function being calibrated. HOLD will flash until the system has completed reading in the signal with the header fully raised.

DONE will flash and prompt the operator to COMPLETE the sensor calibration by lowering the header.

The menu will display the last item selected when the calibration routine is completed.

If the HEADER TILT option in the TRACTOR SETUP is set to NO then only HEIGHT should be available as a menu selection for calibration.

If "NO" then jump to:
TO CALIBRATE SELECT

(continued next page)

UNLOADING AND ASSEMBLY

L1	C x x x DIAGNOSTIC MODE ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		TRACTOR SETUP ?
<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; margin-bottom: 5px;"></div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px;"></div> </div> <div style="margin-right: 10px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; margin-bottom: 5px;"></div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px;"></div> </div> </div>			
L1	C x x x VIEW ERROR CODES ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		ENTER SENSOR SETUP ?
<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; margin-bottom: 5px;"></div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px;"></div> </div> </div>			
L1	C x x x VIEW TRACTOR CODES ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		ENTER SENSOR SETUP ?
L1	1 1 2 3 4 . 5 HRS 1 2 3	← →	The last 10 distinct error codes are stored along with the code #, Exxx, engine hours and number of occurrences. The "arrow" keys are used to cycle between codes.
L2	E 4 7 SENSOR VOLTS LOW		
L1	2 1 2 3 4 . 5 HRS 1 2 3	← →	The last 10 distinct error codes are stored along with the code #, Exxx, engine hours and number of occurrences. The "arrow" keys are used to cycle between codes.
L2	E 7 1 LOW HYDRAULIC OIL		
L1	C x x x EXIT TRACTOR CODES ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		VIEW TRACTOR CODES ?
L1	C x x x ENTER SENSOR SETUP ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		READ SENSOR INPUTS ?
<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; margin-bottom: 5px;"></div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px;"></div> </div> </div>			
L1	C x x x HEADER HT SENSOR		The operator can select each sensor and selectively enable or disable the sensor in the event of a sensor malfunction.
L2	M x x x ← ENABLE / DISABLE →		
L1	C x x x HEADER TILT SENSOR		If no expansion module or an A30 auger header is selected, the corresponding menu items should be suppressed.
L2	M x x x ← ENABLE / DISABLE →		
L1	C x x x KNIFE SPEED SENSOR		When "SELECT" is pressed the program goes to the EXIT SENSOR SETUP? selection.
L2	M x x x ← ENABLE / DISABLE →		
L1	C x x x REEL SPEED SENSOR		When "SELECT" is pressed the program goes to the EXIT SENSOR SETUP? selection.
L2	M x x x ← ENABLE / DISABLE →		
L1	C x x x EXIT SENSOR SETUP ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		KNIFE SPEED SENSOR
Or to the first sensor "installed"			
L1	C x x x READ SENSOR INPUTS ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		ACTIVATE FUNCTIONS ?
<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; margin-bottom: 5px;"></div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px;"></div> </div> </div>			
L1	C x x x SENSOR INPUT	← →	For diagnostic purposes each sensors input signal can be read.
L2	M x x x HDR HEIGHT 3 . 5 9 V		
L1	C x x x SENSOR INPUT	← →	If no expansion module or an A30 auger header is selected, the corresponding menu items should be suppressed.
L2	M x x x HEADER ANGLE 1 . 8 4 V		
L1	C x x x SENSOR INPUT	← →	When "SELECT" is pressed the program goes to the EXIT READ SENSORS? menu selection.
L2	M x x x KNIFE SPEED 1 2 3 H Z		
L1	C x x x SENSOR INPUT	← →	Adds a selection to be able to read in the wheel speed frequency.
L2	M x x x WHEEL SPEED 1 2 3 H Z		
L1	C x x x EXIT READ SENSORS ?		If "NO" then jump to:
L2	M x x x ← NO / YES →		SENSOR INPUT
HDR HEIGHT 3 . 5 9 V			

(continued next page)

UNLOADING AND ASSEMBLY

L1	C x x x S E N S O R I N P U T	↔
L2	M x x x H D R H E I G H T	S E N S O R
L1	C x x x S E N S O R I N P U T	↔
L2	M x x x H E A D E R A N G L E	S E N S O R
L1	C x x x S E N S O R I N P U T	↔
L2	M x x x K N I F E S P E E D	S E N S O R
L1	C x x x S E N S O R I N P U T	↔
L2	M x x x R E E L S P E E D	S E N S O R

If a sensor has been disabled "SENSOR" will be flashing in the area where the input reading would have been.

If no expansion module or an A30 auger header is selected, the corresponding menu items should be suppressed.

L1	C x x x A C T I V A T E F U N C T I O N S ?	↔	If "NO" then jump to:
L2	M x x x	↔	N O / Y E S
			E X I T D I A G N O S T I C S ?

L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x H E A D E R	D O W N / U P
L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x R E E L	D O W N / U P
L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x H D R T I L T	I N / O U T
L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x K N I F E D R I V E	O N
L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x D R A P E R / A U G E R	O N
L1	C x x x A C T I V A T E F U N C T I O N S ?	↔
L2	M x x x R E E L	F O R E / A F T
L1	C x x x A C T I V A T E H Y D P U R G E ?	↔
L2	M x x x	N O / Y E S
L1	C x x x T O A C T I V A T E P U R G E	↔
L2	M x x x P R E S S A N D H O L D	↔
L1	C x x x P U R G E C Y C L E S T A R T E D	↔
L2	M x x x P R E S S A N D H O L D	↔
L1	C x x x P U R G E C Y C L E E N D E D	↔
L2	M x x x	↔
L1	C x x x P U R G E C Y C L E E N D E D	↔
L2	M x x x	N O E X I T Y E S
L1	C x x x E X I T F U N C T I O N M E N U ?	↔
L2	M x x x	N O / Y E S
L1	C x x x E X I T D I A G N O S T I C S ?	↔
L2	M x x x	N O / Y E S

For diagnostic purposes each header function can be activated by using the "arrow" keys on the CDM. When "SELECT" is pressed the program will go to the next function that can be activated.

If the HEADER TILT cylinder or the REEL FORE / AFT valve is not installed under the TRACTOR SETUP menu then the ACTIVATE FUNCTIONS menu selection for these items should be suppressed.

ACTIVATE HYD PURGE - This is to allow the operator to purge the air from a new or changed pump system.

Pressing and holding the right hand "arrow" button activates a predetermined timed purge cycle. Releasing pressure on the switch or a completed cycle (timed out) will jump to the PURGE CYCLE ENDED menu selection.

If "NO" then jump to:			
H E A D E R	↔	D O W N / U P	↔
If "NO" then jump to:			
D I A G N O S T I C M O D E ?	↔	↔	↔

UNLOADING AND ASSEMBLY

STEP 30. PERFORM HYDRAULIC PURGE

The purge cycle allows for low flow and pressure staging of the pumps when running up a new windrower with all the lines and filters empty. This has been performed at the factory, but is recommended that it be repeated when the windrower has been disassembled for shipping and then reassembled. The header must be attached to the windrower.



CAUTION

Check to be sure all bystanders have cleared the area.

- Start the engine. Refer to STEP 21.
- Ensure the M105 and M155 Windrower CDM is programmed for either the A Series auger header, or the D Series draper header. Program the M205 Windrower CDM for the R Series rotary header.

IMPORTANT

Do not engage the header drive.



- Simultaneously press the PROGRAM and SELECT buttons to bring up the TRACTOR SETUP screen.



- Push the SELECT button several times until the DIAGNOSTIC MODE screen is displayed.



- Highlight YES with the ARROW buttons, and then press the SELECT button.



- Press SELECT until the ACTIVATE FUNCTIONS screen appears.
- Highlight YES with the ARROW buttons, and press SELECT.
- Press SELECT until ACTIVATE HYD PURGE is displayed.
- Highlight YES with the ARROW buttons, and press SELECT. The TO ACTIVATE PURGE PRESS AND HOLD message appears.



- Press and hold the RIGHT ARROW button to activate and run the purge cycle until the purge is complete (approximately 1 minute). Release the ARROW button at any time to stop the cycle.

(continued next page)

UNLOADING AND ASSEMBLY

- k. Message PURGE CYCLE ENDED appears when cycle is complete. Release the ARROW button.



- l. Press PROGRAM button to return to operating screens.

PRE-DELIVERY CHECKS

STEP 31. PERFORM PRE-DELIVERY CHECKS




WARNING

Stop windrower engine and remove key before making adjustments to machine. A child or even a pet could engage the drive.

- a. Perform the final checks and adjustments as listed on the "Pre-Delivery Checklist" (yellow sheet attached to back of instruction), to ensure the machine is field-ready. Refer to the following pages for detailed instructions as indicated on the Checklist.
- b. The completed Checklist should be retained either by the Operator or the Dealer.

A. FINAL DRIVE LUBRICANT LEVEL



- a. Rotate wheel so that one of the plugs is horizontally aligned with the center of the hub.
- b. Remove the plug. The oil should be visible through the hole, or slightly running out.

B. TIRE PRESSURES AND BALLAST REQUIREMENTS

I. TIRE PRESSURES

Measure tire pressure with a gauge:

- Bar: 32 psi (221 kPa)
- Turf: 20 psi (138 kPa)
- Caster: 10 psi (69 kPa)

II. BALLAST REQUIREMENTS

Fluid ballasting of rear caster tires is recommended to provide adequate machine stability when using large headers on the windrower.

Also, the stability of machine varies with different attachments, windrower options, terrain and Operator's driving technique.

Ballast capability per tire is at a maximum fill of 75%, or when fluid is level with valve stem when the stem is positioned at the "12 o'clock" position.

Fluid can be added to any level up to maximum fill, and always add an equal amount of fluid on both sides.

TIRE SIZE	FLUID PER TIRE AT 75% FILL U.S. Gal. (Liters)	TOTAL WEIGHT OF BOTH TIRES lb (kg) *
7.5 X 16	10 (38)	200 (91)
10 X 16	18 (69)	380 (170)
16.5 X 16.1	41 (158)	830 (377)

* Weights are given for typical calcium chloride and water mixtures. Weight is reduced by 20% if only water is used (for areas that do not require anti-freeze protection).

(continued next page)





PRE-DELIVERY CHECKS

APPLICABLE WINDROWER	HEADER DESCRIPTION		RECOMMENDED TIRE SIZE	RECOMMENDED BALLAST					
	TYPE	SIZE		LEVEL GROUND		HILLS			
				PER TIRE	BOTH TIRES	PER TIRE	BOTH TIRES		
				U.S. Gal. (Liters)	lb (kg) *	U.S. Gal. (Liters)	lb (kg) *		
M105	A Series All Options	All	7.5 X 16 10 X 16 16.5 X16.1	0					
	D Series	25 FT and Down		Level Ground: 10 X 16 16.5 X16.1 Hills: 16.5 X 16.1	0		10 (38)	200 (91)	
		30 FT SR or DR W/O Conditioner	18 (69)		380 (170)		30 (115) 630 (288)		
		35 FT SR							
30 FT DR Steel Fingers and Conditioner	35 FT DR (5 or 6-Bat)								
M155	A Series All Options	All	7.5 X 16 10 X 16 16.5 X16.1	0					
	D Series	25 FT and Down		Level Ground: 10 X 16 16.5 X16.1 Hills: 16.5 X 16.1	18 (69)	380 (170)	30 (115)	630 (288)	
		30 FT SR or DR W/O Conditioner	30 (115)		630 (288)		41 (158) 830 (377)		
		35 FT SR							
		30 FT DR Steel Fingers and Conditioner	35 FT DR (5 or 6-Bat)						
	40 FT	16.5 X 16.1	30 (115)	630 (288)	41 (158)	830 (377)			
R Series All Options	13 FT	7.5 X 16 10 X 16 16.5 X16.1	0						
M205	A Series All Options	All	7.5 X 16 10 X 16 16.5 X16.1	0					
	D Series	25 FT and Down		Level Ground: 10 X 16 16.5 X16.1 Hills: 16.5 X 16.1	18 (69)	380 (170)	30 (115)	630 (288)	
		30 FT SR or DR W/O Conditioner	30 (115)		630 (288)		41 (158) 830 (377)		
		35 FT SR							
		30 FT DR Steel Fingers and Conditioner	35 FT DR (5 or 6-Bat)						
	40 FT	16.5 X 16.1	30 (115)	630 (288)	41 (158)	830 (377)			
R Series All Options	All	7.5 X 16 10 X 16 16.5 X16.1	0						


* If only water is used, increase volume of water by 20% (up to maximum allowable fill per tire) to compensate.

PRE-DELIVERY CHECKS



C. ENGINE AIR INTAKE



- Check that air cleaner cap is firmly attached, and that latches and clamps are secure.
- Check constant torque spring clamp (A) at back of air cleaner (M155, M105).



- Constant torque spring type clamps (A) and (C) should be tightened to achieve gap as shown.




- Check constant torque clamps (B) on charge air cooling duct connection at turbocharger inlet (M205). Constant torque type clamps (B) should be tightened to achieve gap as shown.

- Check constant torque clamps (C) on charge air cooling duct connections at turbocharger outlet and engine air intake. Clamps (C) should be tightened to achieve gap as shown opposite.


PRE-DELIVERY CHECKS

D. HYDRAULIC OIL LEVEL



M105

- a. Turn filler cap counter clockwise to loosen bung, and remove dipstick (M105).



M205, M155


- b. Turn filler cap counter-clockwise to unlock cap, and remove dipstick (M155, M205).
- c. Check that level is between LOW and FULL marks.
- d. Re-install dipstick, and turn clockwise to tighten/lock.

E. FUEL SEPARATOR



- a. Place a container under the filter drain.
- b. Turn drain valve by hand 1-1/2 to 2 turns counter clockwise, until draining occurs.
- c. Drain the filter sump of water and sediment, until clear fuel is visible. Clean as necessary.
- d. Turn the valve clockwise to close the drain.
- e. Safely dispose of fluid in container.



F. ENGINE COOLANT



- a. Check the coolant level in the coolant recovery tank. Tank should be at least one-half full.
- b. Check coolant concentration in the radiator. Coolant shall be rated for temperatures of -30°F (-34°C).


PRE-DELIVERY CHECKS

G. GEAR BOX LUBRICANT LEVEL



- a. Remove plug (A). The lubricant should be visible through the hole, or slightly running out.
- b. Replace plug, and tighten.

H. A/C COMPRESSOR BELT



- a. Tension on A/C compressor belt should be such that a force of 8 to 12 lbf (35 - 55 N) deflects the belt 3/16 inch (5 mm) at mid-span.

PRE-DELIVERY CHECKS

I. PERFORM SAFETY SYSTEM CHECKS

Ensure battery main disconnect switch is switched to POWER ON position. Refer to *Section J. OPERATIONAL CHECKS*.

A properly functioning system should operate as follows:

- The starter should engage ONLY when the GSL is in N-DETENT, the steering wheel is locked in the CENTER position, and the HEADER DRIVE switch is in the OFF position.
- Under the above conditions, the brake should engage, and the machine should not move after engine start-up.
- The steering wheel should not lock with the engine running, and the GSL is out of the N-DETENT.
- The machine should not move with the engine running, and with the steering wheel still centered, when the GSL is pulled straight out of N-DETENT (not in forward or reverse).

If the system does not function as described above, refer to the Technical Service Manual.




CAUTION

Check to be sure all bystanders have cleared the area.

- a. With the engine shut down and the HEADER DRIVE switch engaged, try to start the engine. The CDM will display “HEADER ENGAGED” on the upper line, and “DISENGAGE HEADER’ on the lower line.

If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.

- b. With the engine shut down, do the following:
1. Open engine compartment hood.



2. Pry the steering interlock away from pintle arms by inserting a wedge or pry bar between one of the interlock channels and pintle arm.
 3. Insert a wood block approximately 3/4 inch (19 mm) thick, between the other channel and pintle arm, so that the interlock channel is clear of the pintle arm.
 4. Turn the steering wheel “off center”, and move the GSL in N-DETENT.
 5. Try to start the engine. The CDM will flash “CENTER STEERING”, accompanied by a short beep with each flash, and the engine should not turn over.
- If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.
6. Remove key.
 7. Remove wood block inserted at Step 3. above, and close hood.
- c. With the engine shut down, steering wheel centered, and the GSL in NEUTRAL but not in N-DETENT:

1. Try to start the engine. The CDM will flash “CENTER STEERING” on the upper line, and “PLACE GSL INTO N” on the lower line accompanied by a short beep with each flash, and the engine should not turn over.


If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.

- d. **M155 and M205 ONLY:** With the engine shut down, steering wheel centered, GSL in N-DETENT, and Operator’s station not locked:
1. Try to start the engine. Engine will crank but will not start. The CDM will display “SEAT BASE NOT LOCKED”.

If engine starts, the system requires adjustment. Refer to the Technical Service Manual.


PRE-DELIVERY CHECKS

J. OPERATIONAL CHECKS



M205, M155

M205, M155: A battery main disconnect switch is located on the RH (cab-forward) frame rail, behind the maintenance platform, and can be accessed by moving the platform.



M105

M105: A battery main disconnect switch is located on the LH frame rail on the battery tray, and can be accessed by raising the engine compartment hood.

Ensure switch is switched to POWER ON position.

I. ENGINE WARNING LIGHTS

- Turn ignition key to RUN position.
- Single loud tone sounds, and engine warning lights illuminate.

II. START ENGINE

Refer to STEP 21. START ENGINE, and then proceed as follows:

- The brakes should engage, and the machine should not move after engine start-up.



M155, M205 SHOWN - M105 SIMILAR

- Ensure the steering wheel is centered. Move GSL (A) straight out of N-DETENT (neither forward nor reverse). The machine should not move.
- With the GSL out of N-DETENT, check that the steering wheel is free to move.
- If the machine does not function as described above, the system requires adjustment. Refer to the Technical Service Manual.

III. ENGINE SPEED

- Check engine rpm on CDM.


	IDLE	MAX RPM (No Load)
M105	1100	2270 - 2330
M155		2320 - 2350
M205		2250 - 2340

PRE-DELIVERY CHECKS

IV. GAUGES AND CDM DISPLAY



- a. Check engine temperature gauge and fuel gauge are working (M205, M155 ONLY).



- b. Check CDM display is working by pushing SELECT on CDM, or SELECT button on GSL.

V. ELECTRICAL

Push the SELECT button on GSL, or SELECT switch on CDM to display VOLTS. The display indicates the condition of the battery and alternator. Refer to following table.


IGNITION	ENGINE	READING	INDICATED CONDITION
ON	Running	13.8 - 15.0	Normal.
		> 16.0 See Note.	Regulator Out of Adjustment.
	< 12.5 See Note.	Alternator Not Working, OR Regulator Out of Adjustment.	
	Shutdown	12.0	Battery Normal.

NOTE

Display flashes voltage reading with single loud tone. Repeats every 30 minutes until condition fixed.

PRE-DELIVERY CHECKS

VI. OPERATOR'S PRESENCE SYSTEM CHECKS



M155, M205 SHOWN - M105 SIMILAR

- a. With the windrower engine running, place the GSL (A) in NEUTRAL, and turn the steering wheel until it locks.
4. If the engine does not shut down, the seat position switches require adjustment. Refer to Technical Service Manual.
- d. With the windrower moving at **less than 5 mph** (8 km/h):
 1. Stand up out of the seat.
 2. The CDM will flash "NO OPERATOR" on the upper line, and "ENGINE SHUTDOWN 5...4...3...2...1...0" on the lower line accompanied by a steady tone. At "0", the engine shuts down.
 3. If the engine does not shut down, the Operator Presence System requires adjustment. Refer to Technical Service Manual.
- e. With the windrower moving at **more than 5 mph** (8 km/h):
 1. Stand up out of the seat.
 2. The CDM beeps once, and displays "NO OPERATOR" on the lower line.
 3. If not, the Operator Presence System requires adjustment. Refer to Technical Service Manual.



CAUTION

Check to be sure all bystanders have cleared the area.

- b. With everyone clear of the machine, engage HEADER DRIVE switch (B).
 1. After header drives are running, stand up out of the seat. In approximately 5 seconds the header should shut off.

If not, the Operator Presence System requires adjustment. Refer to Technical Service Manual.

NOTE

To re-start the header, move the HEADER DRIVE switch (B) to the OFF position and back to the ON position again.



- c. **M155, M205 ONLY:** With the engine running, position the GSL (A) in NEUTRAL, and in N-DETENT:
 1. Swivel the Operator's station, but do not lock into position.
 2. Move GSL out of N-DETENT. The engine should shutdown, and the lower display will flash "LOCK SEAT BASE ---> CENTER STEERING WHEEL ---> NOT IN NEUTRAL".
 3. Swivel and lock the Operator's station, and the display should return to normal.

PRE-DELIVERY CHECKS



VII. EXTERIOR LIGHTS

M155, M205

- Ensure Operator's seat is in **cab-forward mode**.
- Switch **FIELD** lights ON, and check that all lights are functioning as shown below:



- Switch **ROAD** lights ON, and check that all lights are functioning as shown below:




- Activate **HIGH/LOW** switch.
- Activate turn signals and hazard warning lights with switches on CDM.
- Turn lights **OFF**.


(continued next page)

PRE-DELIVERY CHECKS


- g. Rotate Operator's seat to **engine-forward mode**.
- h. Switch ROAD lights ON, and check that all lights are functioning as shown below:



FRONT: ENGINE-FORWARD



REAR: ENGINE-FORWARD





- k. Switch beacons ON, and check that they are working properly.

- i. Activate HIGH/LOW switch, and check lights.
- j. Activate turn signals and hazard warning lights with switches on CDM, and check lights.


PRE-DELIVERY CHECKS

M105

- a. Switch FIELD lights ON, and check that all lights shown are functioning as shown below:




FRONT




REAR

- b. Activate HIGH/LOW switch.

- c. Switch ROAD lights ON, and check that all lights shown are functioning as shown below:



FRONT




REAR

- d. Activate HIGH/LOW switch.
e. Activate turn signals and hazard warning lights with switches on CDM.

(continued next page)

PRE-DELIVERY CHECKS



- f. Switch beacons ON, and check that they are working properly.

VIII. INTERIOR LIGHTS



M155, M205 SHOWN - M105 SIMILAR

- a. Switch lights ON and OFF with switches on each light. Overhead ambient light only works with ROAD/FIELD light switch ON.




- b. Check gauge lights (M155, M205).

PRE-DELIVERY CHECKS


IX. A/C AND HEATER

IMPORTANT

To distribute the oil throughout the A/C system, perform the following steps whenever the machine is first started after storage for more than one week:



M155, M205




M105

- With the engine running, turn BLOWER switch to the "first" position, turn TEMPERATURE CONTROL switch to "maximum heating", and A/C control to OFF.
- Click A/C switch from the OFF to the ON position for one second, then back to OFF for 5 to 10 seconds. Repeat this step ten times.


PRE-DELIVERY CHECKS

K. MANUALS



L. CAB INTERIOR

- a. Remove plastic coverings from Cab Display Module and seats, after pre-delivery check is complete.



M105

M155, M205

The following manuals should be stored in the manual storage case behind the Operator's seat:

MODEL	OPERATOR'S MANUAL	PARTS CATALOG	QUICK CARD	ENGINE MANUAL
M105	Engl. 169552 Rus. 169553	169549	169570	166240
M155	Engl. 169563 Rus. 169546	169564	169565	
M205	Engl. 169469 Rus. 169482	169472	169475	

NOTES

M Series Self-Propelled Windrower Pre-Delivery Checklist - Export

Perform these checks and adjustments prior to delivery to your Customer. The completed Checklist should be retained either by the Operator or the Dealer.



CAUTION: Carefully follow the instructions given. Be alert for safety related messages which bring your attention to hazards and unsafe practices.

Windrower Tractor Serial Number: _____ Engine Serial Number: _____

✓	ITEM	PAGE
	Check for shipping damage or missing parts. Be sure all shipping dunnage is removed.	---
	Check for loose hardware. Tighten to required torque.	5
	Check tire air pressures and adjust as required.	88
	Check final drive hub lubricant level.	88
	Check air cleaner and clamps.	90
	Check engine coolant level and strength at reserve tank.	91
	Check hydraulic oil level and check for leaks along lines.	91
	Check fuel separator for water and foreign material. Drain and clean as necessary. Add fuel.	91
	Check gear box lubricant level (M155, M205).	92
	Check tension of A/C compressor belt.	92
	Check machine completely lubricated.	72
	Check neutral interlock system.	93
	Check engine warning lights at Cab Display Module (CDM).	94
	START ENGINE AND RUN TO OPERATING TEMPERATURE	49
	Check Cab Display Module (CDM) for operation.	95
	Check Operator's Presence System.	96
	Check alternator charge rate on Cab Display Module (CDM).	95
	Check fuel gauge/indicator for operation.	95
	Check air conditioning functioning properly.	101
	Check heater functioning properly.	101
	Check instrument console gauge lights (M155, M205).	100
	Check maximum (no load) engine speed at Cab Display Module (CDM).	94
	Check exterior lights for operation.	97 - 100
	Check interior lights for operation.	100
	Complete the Header Pre-Delivery Checklist.	---
	Check that manuals are with the windrower.	102
	Check plastic coverings from cab interior removed.	102

Date Checked: _____

Checked by: _____

MacDon™

MacDon Industries Ltd.

680 Moray Street
Winnipeg, Manitoba
Canada R3J 3S3
t. (204) 885-5590
f. (204) 832-7749

MacDon Inc.

10708 N. Pomona Avenue
Kansas City, Missouri
United States, 64153-1924
t. (816) 891-7313
f. (816) 891-7323

MacDon Australia Pty. Ltd.

A.C.N. 079 393 721
P.O. Box 243
Suite 3, 143 Main Street
Greensborough, Victoria
Australia 3088
t. 03 9432 9982
f. 03 9432 9972

LLC MacDon Russia Ltd.

123317 Moscow, Russia
10 Presnenskaya nab. Block C,
Floor 5, Office No. 534
Regus Business Centre
t. +7 495 775 6971 direct line
f. +7 495 967 7600

CUSTOMERS

www.macdon.com

DEALERS

www.macdondealers.com

Trademarks of products are the marks of their
respective manufacturers and/or distributors.

Printed in Canada