MacDon^{*}

M Series Self-Propelled Windrower

UNLOADING AND ASSEMBLY INSTRUCTIONS FOR CONTAINER SHIPMENTS

Published: May 2013 Original Instructions



MACDON M SERIES SELF-PROPELLED WINDROWER



EC Declaration of Conformity

MacDon Industries Ltd 680 Moray Street Winnipeg, Manitoba, Canada R3J 3S3

The person named below declares that:

Machine type: Windrower Lift Sling

Model: Part 163871
Serial Number(s): Not Applicable

fulfills all relevant provisions and essential requirements of the following directives:

Directive	Number	Certification Method
Machinery Directive	2006/42/EC	Self-Certification

Name and address of the person in the European Community authorized to compile the technical construction file:

> Johannes Molitor Schwarzwald Strasse 87 68482 Zweibrucken / Germany HRB 31002, Amtgericht Zweibrucken

Place of Declaration: Winnipeg, Manitoba, Canada Name: Ibrahim Saleh

Date of Declaration: 21 May 2013 Title: Director, Product Integrity

CE

EC Declaration of Conformity

MacDon Industries Ltd 680 Moray Street Winnipeg, Manitoba, Canada R3J 3S3

The person named below declares that:

Machine type: Windrower Assembly Supports

Model: Part 163655
Serial Number(s): Not Applicable

fulfills all relevant provisions and essential requirements of the following directives:

Directive	Number	Certification Method
Machinery Directive	2006/42/EC	Self-Certification

Name and address of the person in the European Community authorized to compile the technical construction file:

> Johannes Molitor Schwarzwald Strasse 67 68482 Zweibrucken / Germany HRB 31002, Amtgericht Zweibrucken

Place of Declaration:	Winnipeg, Manitoba, Canada	Name:	Ibrahim Saleh
Date of Declaration:	21 May 2013	Title:	Director, Product Integrity

INTRODUCTION

This instructional manual describes the unloading, set-up and pre-delivery requirements for the MacDon M Series Self-Propelled Windrowers that have been shipped in containers.

Use the Table of Contents to guide you to specific areas. Retain this instruction for future reference.

CAREFULLY READ ALL THE MATERIAL PROVIDED BEFORE ATTEMPTING TO UNLOAD, ASSEMBLE, OR USE THE MACHINE.

TABLE OF CONTENTS

INTRODU	CTION	5
GENERA	L SAFETY	8
RECOMM	ENDED TORQUES	10
A.	GENERAL	
B.	SAE BOLTS	10
C.	METRIC BOLTS	
D.	FLARE TYPE HYDRAULIC FITTINGS	
E.	O-RING BOSS (ORB) HYDRAULIC FITTINGS	
	II. NON-ADJUSTABLE	
F.	O-RING FACE SEAL (ORFS) HYDRAULIC FITTINGS	
CONVER	SION CHART	16
DEFINITION	ONS	16
STEP 1.	UNLOAD CONTAINER	17
STEP 2.	MOVE TO ASSEMBLY AREA	18
А.	CRANE METHOD	18
B.	FORKLIFT METHOD	20
STEP 3.	REMOVE WHEEL AND STEP ASSEMBLY	21
STEP 4.	REMOVE DRIVE WHEELS	23
STEP 5.	REMOVE PLATFORMS	24
STEP 6.	REMOVE HAND RAILS AND EXHAUST STACK	25
STEP 7.	REMOVE LEG ASSEMBLIES	26
STEP 8.	REMOVE WHEEL AND PLATFORM SUPPORT	27
STEP 9.	ASSEMBLE SUPPORT STAND	27
STEP 10.	LIFT WINDROWER ONTO STAND	28
А.	CRANE METHOD	28
B.	FORKLIFT METHOD	29
STEP 11.	INSTALL LEGS	30
STEP 12.	INSTALL FRONT WHEELS	32
STEP 13.	INSTALL CASTER WHEELS	34
STEP 14.	INSTALL HYDRAULICS	36
A.	M205	36
B.	M155	
C.	M105	
	REMOVE BATTERY SHIPPING SHIELD	
STEP 16.	UNPACK IGNITION KEYS	49
STEP 17.	INSTALL PLATFORMS	50
	INSTALL STEPS	
STEP 19.	INSTALL EXHAUST STACK	53
STEP 20.	POSITION LIGHT AND MIRROR ASSEMBLIES	54
STEP 21.	CONNECT BATTERIES	55
A.	M205, M155	55
B.	M105	56

TABLE OF CONTENTS

STEP 22.	PRIME HYDRAULIC SYSTEM	57
Α.	M205	57
B.	M155	58
C.	M105	60
STEP 23.	START ENGINE	62
STEP 24.	CHECK TRACTION DRIVE	63
STEP 25.	REMOVE WINDROWER FROM STAND	64
Α.	FACTORY STAND	
А. В.	FIELD-CONSTRUCTED STAND	
	INSTALL AM/FM RADIO	
	INSTALL BEACONS	
	INSTALL SLOW MOVING VEHICLE (SMV) SIGN	
STEP 29.	ATTACH HEADER	
Α.	<i>M</i> 205	
	I. HEADER ATTACHMENT - D SERIES	
	II. HEADER ATTACHMENT - A SERIES	
_	III. HEADER ATTACHMENT - R SERIES	
B.	M155, M105	
	I. HEADER ATTACHMENT: A SERIES	84
	II. HEADER ATTACHMENT: R SERIES (M155 ONLY)	
	LUBRICATE MACHINE	
STEP 31.	PROGRAM CAB DISPLAY MODULE (CDM)	97
Α.	M205, DETAILED PROGRAMMING INSTRUCTIONS	98
B.	M155, DETAILED PROGRAMMING INSTRUCTIONS	102
C.	M105 DETAILED PROGRAMMING INSTRUCTIONS	107
STEP 32.	PERFORM HYDRAULIC PURGE	112
STEP 33.	PERFORM PRE-DELIVERY CHECKS	114
Α.	FINAL DRIVE LUBRICANT LEVEL	
д. В.	TIRE PRESSURES AND BALLAST REQUIREMENTS	
ъ.	I. Tire Pressures	
	II. Ballast Requirements	
C.	ENGINE AIR INTAKE	
D.	HYDRAULIC OIL LEVEL	
E.	FUEL SEPARATOR	
F.	ENGINE COOLANT	117
G.	GEAR BOX LUBRICANT LEVEL	118
Н.	A/C COMPRESSOR BELT	
I.	PERFORM SAFETY SYSTEM CHECKS	119
J.	OPERATIONAL CHECKS	120
	I. Engine Warning Lights	
	II. Start Engine	
	III. Engine Speed	
	IV. Gauges and CDM Display	
	V. Electrical VI. Operator's Presence System Checks	
	VII. Exterior Lights	
	VIII. Interior Lights	
	IX. A/C and Heater	
K.	MANUALS	
L.	CAB INTERIOR	128

GENERAL SAFETY




CAUTION

The following are general farm safety precautions that should be part of your operating procedure for all types of machinery.

- Protect yourself.
- When assembling, operating and servicing machinery, wear all the protective clothing and personal safety devices that COULD be necessary for the job at hand. Don't take chances.



- You may need:
 - a hard hat.
 - protective shoes with slip resistant soles.
 - o protective glasses or goggles.
 - heavy gloves.
 - o wet weather gear.
 - respirator or filter mask.




hearing protection. Be aware that prolonged exposure to loud noise can cause impairment or loss of hearing. Wearing a suitable hearing protective device such as ear muffs (A) or ear plugs (B) protects against objectionable or loud noises.



- Provide a first-aid kit for use in case of emergencies.
- Keep a fire extinguisher on the machine.
 Be sure the extinguisher is properly maintained and be familiar with its proper use.
- Keep young children away from machinery at all times.
- Be aware that accidents often happen when the Operator is tired or in a hurry to get finished. Take the time to consider the safest way. Never ignore warning signs of fatigue.
- Wear close-fitting clothing and cover long hair. Never wear dangling items such as scarves or bracelets.



- Keep hands, feet, clothing and hair away from moving parts.
- Never attempt to clear obstructions or objects from a machine while the engine is running.



 Keep all shields in place. Never alter or remove safety equipment. Make sure driveline guards can rotate independently of the shaft and can telescope freely.

(continued next page)

- Use only service and repair parts made or approved by the equipment manufacturer. Substituted parts may not meet strength, design, or safety requirements.
- Do NOT modify the machine. Unauthorized modifications may impair the function and/or safety and affect machine life.
- Stop engine, and remove key from ignition before leaving Operator's seat for any reason. A child or even a pet could engage an idling machine.



- Keep the area used for servicing machinery clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment. Be sure all electrical outlets and tools are properly grounded.
- Use adequate light for the job at hand.
- Keep machinery clean. Do NOT allow oil or grease to accumulate on service platforms, ladders or controls. Clean machines before storage.
- Never use gasoline, naphtha or any volatile material for cleaning purposes.
 These materials may be toxic and/or flammable.
- When storing machinery, cover sharp or extending components to prevent injury from accidental contact.

RECOMMENDED TORQUES


A. GENERAL

The tables shown below give correct torque values for various bolts and capscrews.

- Tighten all bolts to the torques specified in chart (unless otherwise noted throughout this manual).
- Check tightness of bolts periodically, using bolt torque chart as a guide.
- Replace hardware with the same strength bolt.
- Torque figures are valid for non-greased or non-oiled threads and heads unless otherwise specified. Do NOT grease or oil bolts or capscrews unless specified in this manual.
- Torque categories for bolts and capscrews are identified by their head markings.

B. SAE BOLTS

SAE Grade 5 Bolt and Grade 5 Free Spinning Nut




Nominal Size		e (ft-lbf) n-lbf)		rque (N·m)	
Size	Min.	Max.	Min.	Max.	
1/4-20	*106	*117	11.9	13.2	
5/16-18	*218	*241	24.6	27.1	
3/8-16	32	36	44	48	
7/16-14	52	57	70	77	
1/2-13	79	87	106	118	
9/16-12	114	126	153	170	
5/8-11	157	173	212	234	
3/4-10	281	311	380	420	
7/8-9	449	496	606	669	
1-8	611	676	825	912	

SAE Grade 5 Bolt and Grade 5 Distorted Thread Nut


Nominal	Torque (*in	e (ft-lbf) -lbf)	Torque (N·m)	
Size	Min.	Max.	Min.	Max.
1/4-20	*72	*80	8.1	9.0
5/16-18	*149	*164	16.7	18.5
3/8-16	22	24	30	33
7/16-14	35	39	48	53
1/2-13	54	59	73	80
9/16-12	77	86	105	116
5/8-11	107	118	144	160
3/4-10	192	212	259	286
7/8-9	306	338	413	456
1-8	459	507	619	684

SAE Grade 8 Bolt and Grade 8 Free Spinning Nut



Nominal Size		e (ft-lbf) -lbf)	Torque (N·m)	
Size	Min.	Max.	Min.	Max.
1/4-20	*150	*165	16.8	18.6
5/16-18	26	28	35	38
3/8-16	46	50	61	68
7/16-14	73	81	98	109
1/2-13	111	123	150	166
9/16-12	160	177	217	239
5/8-11	221	345	299	330
3/4-10	393	435	531	587
7/8-9	633	700	855	945
1-8	863	954	1165	1288


SAE Grade 8 Bolt and Grade 8 Distorted Thread Nut



Nominal Size		e (ft-lbf) -lbf)	Torque (N⋅m)	
Size	Min.	Max.	Min.	Max.
1/4-20	*150	*165	16.8	18.6
5/16-18	18	19	24	26
3/8-16	31	34	42	46
7/16-14	50	55	67	74
1/2-13	76	84	102	113
9/16-12	109	121	148	163
5/8-11	151	167	204	225
3/4-10	268	296	362	400
7/8-9	432	477	583	644
1-8	647	716	874	966

C. METRIC BOLTS

Metric Class 8.8 Bolts and Class 9 Free Spinning Nut




Nominal Size	Torque (ft-lbf) (*in-lbf)		Torque	e (N⋅m)
	Min.	Max.	Min.	Max.
3-0.5	*13	*14	1.4	1.6
3.5-0.6	*20	*22	2.2	2.5
4-0.7	*29	*32	3.3	3.7
5-0.8	*59	*66	6.7	7.4
6-1.0	*101	*112	11.4	12.6
8-1.25	20	23	28	30
10-1.5	40	45	55	60
12-1.75	70	78	95	105
14-2.0	113	124	152	168
16-2.0	175	193	236	261
20-2.5	341	377	460	509
24-3.0	589	651	796	879

Metric Class 8.8 Bolts and Class 9 Distorted Thread Nut

Nominal		Torque (ft·lbf) (*in·lbf)		e (N-m)
Size	Min.	Max.	Min.	Max.
3-0.5	*9	*10	1.0	1.1
3.5-0.6	*14	*15	1.5	1.7
4-0.7	*20	*22	2.3	2.5
5-0.8	*40	*45	4.5	5.0
6-1.0	*69	*76	7.7	8.6
8-1.25	*167	*185	18.8	20.8
10-1.5	28	30	37	41
12-1.75	48	53	65	72
14-2.0	77	85	104	115
16-2.0	119	132	161	178
20-2.5	233	257	314	347
24-3.0	402	444	543	600

Metric Class 10.9 Bolts and Class 10 Free Spinning Nut




Nominal Size		Torque (ft-lbf) (*in-lbf)		e (N·m)
Size	Min.	Max.	Min.	Max.
3-0.5	*18	*19	1.8	2.0
3.5-0.6	*27	*30	2.8	3.1
4-0.7	*41	*45	4.2	4.6
5-0.8	*82	*91	8.4	9.3
6-1.0	*140	*154	14.3	15.8
8-1.25	28	31	38	42
10-1.5	56	62	75	83
12-1.75	97	108	132	145
14-2.0	156	172	210	232
16-2.0	242	267	326	360
20-2.5	472	521	637	704
24-3.0	815	901	1101	1217

Metric Class 10.9 Bolts and Class 10 Distorted Thread Nut

Nominal	Torque (ft-lbf) (*in-lbf)		Torque (N⋅m)	
Size	Min.	Max.	Min.	Max.
3-0.5	*12	*13	1.3	1.5
3.5-0.6	*19	*21	2.1	2.3
4-0.7	*28	*31	3.1	3.4
5-0.8	*56	*62	6.3	7.0
6-1.0	*95	*105	10.7	11.8
8-1.25	19	21	26	29
10-1.5	38	42	51	57
12-1.75	66	73	90	99
14-2.0	106	117	143	158
16-2.0	165	182	222	246
20-2.5	322	356	434	480
24-3.0	556	614	750	829

D. FLARE TYPE HYDRAULIC FITTINGS




- a. Check flare and flare seat for defects that might cause leakage.
- b. Assemble fittings without lubrication until the flared surfaces contact each other (some fittings may require a wrench).
- c. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body, and with the second, tighten the swivel nut to the specified number of FFFT or to the torque shown.
- d. Check the final condition of the fitting.

SAE	THD	TORQUE VALUE*		FLATS FROM FINGER TIGHT (FFFT)	
DASH SIZE	SIZE (in.)	ft·lbf (*in·lbf)	N∙m	TUBE CONN.	SWIVEL NUT OR HOSE CONN.
-3	3/8-24	*60-72	7-8		
-4	7/16-20	*156-168	18-19	2-1/2	2
-5	1/2-20	14-15	19-21	2	2
-6	9/16-18	22-24	30-33	2	1-1/2
-8	3/4-16	42-46	57-63	2	1-1/2
-10	7/8-14	60-66	81-89	1-1/2	1-1/2
-12	1-1/16-12	83-91	113-124	1-1/2	1-1/4
-14	1-3/8-12	100-110	136-149	1-1/2	1-1/4
-16	1-5/16-12	118-130	160-176	1-1/2	1
-20	1-5/8-12	168-184	228-250	1	1
-24	1-7/8-12	195-215	264-291	1	1


^{*} Torque values shown are based on lubricated connections as in re-assembly.

E. O-RING BOSS (ORB) HYDRAULIC FITTINGS

I. ADJUSTABLE



- Inspect O-ring and seat for dirt or obvious defects.
- b. Back off the lock nut as far as possible. Ensure that washer is not loose and is pushed toward the lock nut as far as possible.
- c. Check that O-ring is not on the threads, adjust if necessary.
- d. Apply hydraulic system oil to the O-ring.




- e. Install fitting into port until back up washer (A) and O-ring contacts on part face (C).
- f. Position angle fittings by unscrewing no more than one turn.

- g. Turn lock-nut down to washer and tighten to torque shown. Use two wrenches, one on the fitting and the other on the lock-nut.
- h. Check the final condition of the fitting.

SAE	THD SIZE	TORQUE VALUE*		
DASH SIZE	(in.)	ft-lbf (*in-lbf)	N-m	
-3	3/8-24	*106-115	12-13	
-4	7/16-20	14-15	19-21	
-5	1/2-20	15-24	21-33	
-6	9/16-18	19-21	26-29	
-8	3/4-16	34-37	46-50	
-10	7/8-14	55-60	75-82	
-12	1-1/16-12	88-97	120-132	
-14	1-3/8-12	113-124	153-168	
-16	1-5/16-12	130-142	176-193	
-20	1-5/8-12	163-179	221-243	
-24	1-7/8-12	199-220	270-298	


^{*} Torque values shown are based on lubricated connections as in re-assembly.


II. NON-ADJUSTABLE



- Inspect O-ring (A) and seat for dirt or obvious defects.
- b. Check that O-ring is not on the threads, adjust if necessary.
- c. Apply hydraulic system oil to the O-ring.
- d. Install fitting into port until fitting is hand tightened.
- e. Torque the fitting to the proper value as shown above.
- Check the final condition of the fitting.

F. O-RING FACE SEAL (ORFS) HYDRAULIC FITTINGS





- a. Check components to ensure that the sealing surfaces and fitting threads are free of burrs, nicks, and scratches, or any foreign material.
- b. Apply hydraulic system oil to the O-ring.
- c. Align the tube or hose assembly. Ensure that flat face of the mating flange comes in full contact with O-ring.
- d. Thread tube or hose nut until hand-tight. The nut should turn freely until it is bottomed out.
- e. Torque fitting further to a given torque value in the table shown in the opposite column.

NOTE

If applicable, always hold the hex on the fitting body to prevent unwanted rotation of fitting body and hose when tightening the fitting nut.

- f. When assembling unions or two hoses together, three wrenches will be required.
- g. Check the final condition of the fitting.

SAE	THD SIZE	TORQUE VALUE*	
DASH SIZE	(in.)	ft-lbf (*in-lbf)	N∙m
-3	***		
-4	9/16-18	18-21	25-28
-5	***		
-6	11/16-16	29-32	40-44
-8	13/16-16	41-45	55-61
-10	1-14	59-65	80-88
-12	1-3/16-12	85-94	115-127
-14	***		
-16	1-7/16-12	111-122	150-165
-20	1-11/16-12	151-167	205-226
-24	2-12	232-256	315-347
-32	2-1/2-12	376-414	510-561

- Torque values and angles shown ar based on lubricated connection, as in re-assembly.
- ** Always default to the torque value for evaluation of adequate torque
- *** O-ring face seal type end not defined for this tube size.

CONVERSION CHART

QUANTITY INCH-POUND UNITS		FACTOR	SI UNITS (METRIC)		
QUANTITY	UNIT NAME	ABBR.	FACTOR	UNIT NAME	ABBR.
Area	acres	acres	x 0.4047 =	hectares	ha
Flow	US gallons per minute	(gpm)	x 3.7854 =	liters per minute	L/min
Force	pounds force	lbf	x 4.4482 =	Newtons	N
Longth	inch	in.	x 25.4 =	millimeters	mm
Length	foot	ft	x 0.305 =	meters	m
Power	horsepower	hp	x 0.7457 =	kilowatts	kW
Dressure	pounds per square inch	psi	x 6.8948 =	kilopascals	kPa
Pressure			x .00689 =	megapascals	MPa
Targue	pound feet or foot pounds	lbf-ft or ft-lbf	x 1.3558 =	newton meters	N∙m
Torque	pound inches or inch pounds	lbf·in. or in·lbf	x 0.1129 =	newton meters	N∙m
Temperature	degrees Fahrenheit	°F	(°F - 32) x 0.56 =	Celsius	°C
	feet per minute	ft/min	x 0.3048 =	meters per minute	m/min
Velocity	feet per second	ft/s	x 0.3048 =	meters per second	m/s
	miles per hour	mph	x 1.6063 =	kilometers per hour	km/h
	US gallons	US gal.	x 3.7854 =	liters	L
Volume	ounces	oz.	x 29.5735 =	milliliters	ml
	cubic inches	in. ³	x 16.3871 =	cubic centimeters	cm ³ or cc
Weight	pounds	lb	x 0.4536 =	kilograms	kg

DEFINITIONS

TERM	DEFINITION
API	American Petroleum Institute
ASTM	American Society of Testing And Materials
Cab-Forward	Windrower operation with the Operator and the cab facing in the direction of travel.
CDM	Cab Display Module
DWA	Double Windrow Attachment
Engine-Forward	Windrower operation with the Operator and the engine facing in the direction of travel.
ISC	Integrated Speed Control
N-DETENT	The slot opposite the NEUTRAL position on Operator's console.
rpm	revolutions per minute
SAE	Society Of Automotive Engineers
WCM	Windrower Control Module
Windrower	Windrower with header attached.
Windrower Tractor	Power unit only. (Windrower without the header attached)

STEP 1. UNLOAD CONTAINER



CAUTION

To avoid injury to bystanders from being struck by machinery, do NOT allow persons to stand in unloading area.

- Move trailer into position, and block trailer wheels.
- b. Lower trailer storage stands.
- c. Open container doors, and remove all blocking.
- d. Check container floor for nails or other obstructions, and remove if necessary.
- e. Position platform or ramp at container opening.



- f. Attach chain/pull strap to slots in support channels (as shown).
- g. Slowly pull windrower from container onto platform.

STEP 2. MOVE TO ASSEMBLY AREA

A. CRANE METHOD



CAUTION

To avoid injury to bystanders from being struck by machinery, do NOT allow persons to stand in unloading area.




CAUTION


Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.

LIFTING VEHICLE		
Minimum Lifting	20,000 lb	
Capacity (9072 kg)		

CHAIN		
Туре	Overhead 1/2 in. Lifting Quality	
Minimum Working Load	7100 lb (3221 kg)	

LIFTING FRAME (See Below)		
Type MacDon Part #163871		
Maximum Working Load	28,404 lb (12884 kg)	





a. Attach chains or cable to the four lift points on the lifting frame (MacDon Part # 163871) and connect loop ends to crane hook. Use cable or chain with a minimum lifting capacity of 7100 lb (3221 kg).



b. Attach lifting frame assembly (MacDon Part #163871) to the four designated lift points on windrower shipping frame.



DANGER

To avoid injury or death from fall or swinging of raised load, keep all bystanders clear when lifting.

c. Lift windrower off platform, and move to setup area.



- d. Lower assembly onto 5–6 inch (127–152 mm) blocks as shown.
- e. Remove chains from shipping frame.
- f. Check for shipping damage and missing parts.

B. FORKLIFT METHOD



DANGER

To avoid injury or death from fall or swinging of raised load, keep all bystanders clear when lifting.



WARNING

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.

LIFTING VEHICLE		
Minimum Lifting Capacity *	20,000 lb (9072 kg)	

* At 48 inches (1220 mm) from back end of forks.

IMPORTANT

Forklifts are normally rated for a load located 24 inches (610 mm) ahead of back end of the forks.

To obtain the forklift capacity at 48 inches (1220 mm), check with your forklift distributor.



WARNING

Be sure forks are secure before moving away from load. Stand clear when lifting.



- a. Approach windrower from the hood end, and slide forks underneath lifting framework.
- b. Raise windrower off platform, and move to assembly area.



- c. Lower assembly onto 5–6 inch (127–152 mm) blocks (as shown above).
- d. Check for shipping damage and missing parts.


STEP 3. REMOVE WHEEL AND STEP ASSEMBLY



- Remove shipping wire and bolt securing hose support to shipping frame, and remove hose support.
- b. Lay hose support off to the side.



c. Remove the two 3/4 in. x 16.5 long bolts (one per side) at front frame beam. Retain for re-installation.



d. Remove the 1 inch (25.4 mm) pin at the center-link.



e. Remove the four (two per side) carriage bolts at the rear of the wheel/step assembly.






f. Remove plastic cable tie and shipping wire securing hose bundles to frame.

(continued next page)



g. Attach a chain to wheel/step assembly, and pull away from shipping assembly with lifting device.



h. Lift center-link so that it clears wheel/step assembly frame.




i. Re-install leg bolts, washers, and nuts to secure the lifting plate onto the mainframe.

STEP 4. REMOVE DRIVE WHEELS

IMPORTANT

Remove the drive wheels as a pair from above the hood.



 Remove the two bolts at front cross member over the hood.



b. Remove one bolt at rear of hood directly under center of drive wheel.



 Attach a lifting device to lift hooks located in the center of each drive wheel.



d. Carefully lift wheels off frame.


IMPORTANT

Ensure that tire is guided away from cab roof when lifting wheels to prevent damage to the cab. Chain on forward wheel should be snug and loose on the aft wheel.


e. Set wheels aside for later installation.

STEP 5. REMOVE PLATFORMS

 Remove the two support tubes on either side of hood.



b. To prevent paint damage, attach two slings and a chain to platform at locations shown, and to a lifting device with a minimum lifting capacity of 5,000 lb (2268 kg), and a lift height of 13 feet (4 m).




c. Remove two 5/8 in. x 5.0 bolts at top of vertical supports, and two 5/8 in. x 1.25 bolts attaching angle braces to platforms.


NOTE

The M105 windrower is equipped with only one platform.

d. Carefully lift platform off frame.



- e. Back away from windrower, and set assembly on a level surface.
- f. Unhook one sling and chain.
- g. Lift end of assembly so that it can be inverted and laid down again, base on the floor. Use a piece of cardboard under platform to protect the paint.





h. Unhook remaining sling.

STEP 6. REMOVE HAND RAILS AND EXHAUST STACK



a. Cut plastic cable ties, and move hose bundle clear of platform.





- b. Remove shipping wire and foam from exhaust stack.
- c. Remove nuts from clamp, and remove exhaust stack and clamp from shipping frame.
- d. Re-install nuts onto clamp, and set stack aside for later installation.
- e. Remove the two bolts securing hand rail to shipping frame, and remove hand rail.

- f. Repeat for other hand rail on opposite side. Retain hardware.
- g. Set parts aside for later installation.

STEP 7. REMOVE LEG ASSEMBLIES


a. Ensure that lift bar is attached to leg assembly as shown, and that clevis pin is installed with head on near side.



b. Attach chain to lifting bar on leg assembly, and hook up to lifting device with a minimum lifting capacity of 5,000 lb (2,268 kg).



c. Remove two bolts at lower support channel.



d. Remove two bolts near top of leg, and remove bars from leg.

NOTE

Insert cardboard or foam between leg assembly and hood to prevent damage to hood.





- e. Lift off leg assembly, and set securely on level ground.
- f. Repeat above steps for second leg assembly.

STEP 8. REMOVE WHEEL AND PLATFORM SUPPORT



a. Remove cross brace, and the two upright supports from frame.





b. Remove the cross member over the hood, and the two uprights on either side.


STEP 9. ASSEMBLE SUPPORT STAND

Special stands for assembling the windrower are available from the factory. If this stand is not available, an equivalent support system can be used.

The stand must be capable of holding a 15,000 lb (6800 kg) load.

Assemble factory stand as follows:

a. Remove all shipping materials from stand.



- b. Arrange forward and rear stands on level ground, so that attachment lugs on each stand face each other.
- c. Attach four support tubes to stands as shown with hardware provided, and tighten.
- d. Set up air control valve tripod. Remove plug on valve, and install a 100 psi (690 kPa) air line.
- e. The stand is now operational. Instructions for use are given in the appropriate sections.



WARNING

Use stand only as instructed in this manual. Do NOT use stand for any other purpose.

Do NOT pressurize air bags beyond 100 psi (690 kPa).

STEP 10. LIFT WINDROWER ONTO STAND



DANGER

To avoid injury or death from fall or swinging of raised load, keep all bystanders clear when lifting.



WARNING

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.


A. CRANE METHOD

CRANE LIFTING VEHICLE		
Minimum Lifting	20,000 lb	
Capacity	(9072 kg)	

CHAIN		
Туре	Overhead 1/2 in. Lifting Quality	
Minimum Working Load	7,100 lb (3221 kg)	

LIFTING FRAME (See Below)	
Туре	MacDon Part #163871
Maximum Working Load	28404 lb (12884 kg)





- a. Attach four chains or cables to the four lift points on the lifting frame (MacDon Part # 163871), and connect loop ends to crane hook. Use cable or chain with a minimum lifting capacity of 7,100 lb (3221 kg).
- b. Attach the lifting frame to the four designated lift points on windrower shipping frame as shown.



WARNING

Stand clear when lifting, as machine may swing.



- c. Lift windrower onto stand.
- d. Remove chains from shipping frame, and set lifting frame assembly clear of work area.

B. FORKLIFT METHOD



DANGER

To avoid injury or death from fall or swinging of raised load, keep all bystanders clear when lifting.



WARNING


Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping or machine damage.

LIFTING VEHICLE		
Minimum Lifting Capacity *	20,000 lb (9072 kg)	

* At 48 inches (1220 mm) from back end of forks.




a. Approach windrower from aft end, and slide forks fully into shipping support channels.



- b. Raise windrower, and place onto stand.
- c. Back away forklift.


STEP 11. INSTALL LEGS



a. Remove front leg bolts and pins, and set aside for re-installation. Remove carriage bolt, and remove lifting plate.




- b. Attach front leg to lifting device with lifting bar.
- c. Position leg at frame.






d. Feed hydraulic hose bundle into frame, and through hole at center of frame.



- e. Insert leg into frame, and line-up holes in frame and leg at the first position (widest tread with one exposed hole).
- f. Insert pins, and secure with 3/4 in. x 16.5 long bolts, washers, and nuts. Torque to 100 ft·lbf (136 N·m).
- g. Repeat above steps for other leg.


(continued next page)



h. Slightly lift the header lift arms with lifting device, and remove lifting bars from legs. Relocate spring locking pins to front of lift arms.

STEP 12. INSTALL FRONT WHEELS

a. If factory stand is being used, proceed as follows. Otherwise, proceed to step b:




 Ensure that the three (one at rear, two at front) lift locks are activated on lift mechanism.

NOTE

Lock is activated when keeper is vertical, and latch is free to move back and forth.

Pressurize air bag system (100 psi (689 kPa) air pressure required), and raise windrower to maximum height (approximately 7 inches [178 mm]) above the stand.




3. Verify that all three locks are engaged, before to proceeding to next step.

NOTE

Lock is engaged when witness hole above pin is exposed.

4. Release pressure so that locks support weight of windrower.



b. Remove shipping supports on drive wheel hubs, and remove wheel lug nuts.




 Position wheel against hub so that that air valves are on the outside, and tire tread points forward.

For Turf tires (diamond tread), be sure arrow on sidewall points in forward rotation.

(continued next page)

- d. Lift wheel on hub with lifting device. Lower lifting device.
- e. Rotate wheel to align holes with studs, and push wheel onto studs.



f. Install wheel nuts, and tighten to 220 ft-lbf (300 N·m) using the tightening sequence as shown above.

NOTE


To avoid damage to wheel disks, do NOT over-tighten wheel nuts.

g. Repeat sequence three times.

IMPORTANT

After 1 hour of operation, re-torque wheel nuts as per steps f. and g. above. Repeat torquing procedure at one hour intervals of operation until two consecutive checks produce no movement of the nuts.

STEP 13. INSTALL CASTER WHEELS



a. Remove the two guide plates from ends of walking beam.



 Support shipping frame channel, and remove bolts attaching shipping frame to walking beam and mainframe side rail. Remove shipping frame.


NOTE

Shipping frame does not need to be removed if air bag lifting stand is used. Ensure bolts are removed prior to moving windrower off stand.


c. Repeat above for opposite shipping frame channel.



d. Remove tie bar between the two caster wheels.




e. Remove the two braces from caster wheels and frame. Retain bolts for attaching caster to walking beam.



f. Attach a chain to RH caster, and support caster with lifting device.

(continued next page)



g. Remove five remaining bolts securing caster to shipping frame. Retain bolts for attaching caster to walking beam.




CAUTION

Stand clear when lifting, as caster may swing.



- h. Lift caster assembly off shipping frame, and position at end of walking beam.
- Insert RH caster extension into walking beam, and position for desired tread.



j. Install six 3/4 in. bolts and hardened washers into walking beam and caster beam. Use longer bolts through anti-shimmy bracket.


- k. Tighten bolts as follows:
 - 1. Snug up the two bolts underneath beam.
 - 2. Tighten the four back bolts to 330 ft-lbf (447 N·m).
 - 3. Tighten bolts underneath beam to 330 ft·lbf (447 N·m).
- I. Repeat above steps g. to k. for LH caster.
- m. Re-torque bolts at 5, and 10 hours of operation.

STEP 14. INSTALL HYDRAULICS

A. M205

Retrieve all capped off hoses from inside frame.






- Locate the three hoses with capped off tees from valve block.
- c. Remove caps on fittings with similar colored cable ties and connect hoses to tees. Do NOT connect the large case drain hoses from the wheel motors at this time.

NOTE


Remove caps on tee last to minimize oil loss.

- d. Position hoses into frame.
- Locate two hoses with capped off ends and matching coloured ties. A union is connected to one of the hoses.

- f. Remove caps and connect these two hoses together. Position hoses in frame.
- g. Retrieve the four remaining capped off hoses coming out of frame.




- h. Loosen bolts (A), and move valve block to improve access through hole in frame for wrenches when tightening fittings.
- i. Remove caps on hoses, and matching valve block fittings.
- j. Make connections, using coloured plastic cable ties as a guide. Tighten fittings.
- k. Reposition valve block, and re-tighten bolts.




Position the two smaller hoses (MD #111323)
 (B) and the two larger hoses (MD #111328, MD #111557)
 (C) against support as shown, and secure with plastic ties.


(continued next page)



m. Remove clamp from round plastic hose block. Case drain hose is pre-installed in block.



VIEW LOOKING FORWARD




n. Insert four traction drive hoses into slots in block as shown, and reinstall clamp.


o. Connect drive hoses to pump as follows:



1. Remove caps, and attach hoses with short elbows to respective side of pump (either yellow or no tie). Tighten fittings.




2. Remove caps, and attach hoses with long elbows to respective side of pump (either red or no tie). Tighten fittings.



- p. Retrieve the two motor case drain hoses (MD #111312) at front frame, and the 7/8 in. tee fitting on the hose, from the pump.
- q. Remove caps from the hoses only.


- r. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
- s. Remove second cap from tee, and quickly connect other hose.
- t. Tighten fittings.
- u. Push hoses into frame.




v. Secure hoses with cable ties as required.

B. M155

a. The hydraulic hoses under the cab may require proper placement under the existing clip. If necessary, proceed as follows:



 Locate hose clip under the cab, and remove clip.



VIEW LOOKING FORWARD

- Position hose MD #111323 (orange tie) and hose MD #111324 with tee (white tie), as shown under the center of the clip, and loosely install two bolts and nuts. Part numbers are located on hoses. (If M200, place another hose MD #1132A with tee under clip)
- 3. Position remaining hoses under clip as shown, and tighten bolts.

b. Connect hoses as follows, using colored plastic cable ties as a guide.




- 1. Locate two hoses MD #111327 (green ties) in frame opening, and existing tee fitting (green tie).
- 2. Remove caps on green lines and tee, and make connections. Tighten fittings.

NOTE

Remove caps on tee last to minimize oil loss.

3. Position hoses into frame.




- 4. Locate two hoses (white ties) inside frame, and hose MD #111324 with tee (white tie).
- 5. Remove caps, make connections, and tighten fittings.
- 6. Push hoses into frame.




- 7. Locate two hoses (red ties) inside frame.
- 8. Route RH hose behind bundle.
- 9. Remove caps, make connection, and tighten fitting.
- 10. Push hose into frame.




11. Retrieve long hose 119328 (white tie), and route through hole in LH frame.




12. Remove caps on hose, and valve block fitting (white tie), and make connection. Tighten fitting.



13. Remove the caps from three fittings (blue, orange, and yellow ties) on the valve block from inboard side of frame.





14. Loosen bolts, and move valve block to improve access through hole in frame for wrenches when tightening fittings.



- 15. Retrieve matching hoses and make connections on valve block. Tighten fittings.
- 16. Re-position valve block, and re-tighten bolts. *(continued next page)*

c. Remove clamp from round plastic hose block.






d. Insert four traction drive hoses and one case drain hose into slots in block as shown, and re-install clamp.


e. Connect drive hoses to pump as follows:



 Remove caps, and attach hoses with short elbows to respective side of pump (either yellow or no tie). Tighten fittings.




2. Remove caps, and attach hoses with long elbows to respective side of pump (either red or no tie). Tighten fittings.



f. Retrieve the two motor case drain hoses (MD #111312) at front frame, and the 7/8 in. tee fitting on the hose, from the pump.

g. Remove caps from the hoses only.



- h. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
- i. Remove second cap from tee, and quickly connect other hose.
- j. Tighten fittings.



- k. Locate hose bundle from valve blocks on LH side of frame onto tire.
- I. Note routing of electrical harness.

IMPORTANT


The electrical harness must be routed on the topside of the hose bundle and on the outside of the hose support to prevent chafing to the electrical wires when the windrower is operating with a header.




m. Undo strap (A), cut plastic cable ties (B), and move harness (C) away from hose bundle.




- n. Route hose bundle through hose support and lay on tire.
- o. Route harness (C) along outside of hose support and along hose bundle to hose ends.



p. Attach harness (C) to hose support with hose clip (D).




q. Secure harness (C) to hose bundle with strap
 (A) and new plastic cable ties (B). Ensure harness is clear of pinch and friction points.



r. Disengage hook, and rotate to up position. Position hose bundle over hose support, and locate under hook.



s. Rotate hook, and re-engage in bracket.



t. Attach reel hose support tube to the RH reel leg with two 3/8 in. x 1.0 carriage bolts and nuts.

C. M105

a. Connect hoses as follows, using colored plastic cable ties as a guide.



- Locate two hoses MD #111324 (green ties) in frame opening, and existing tee fitting (green tie) on the hose from the valve block.
- 2. Remove caps on green lines and tee, and make connections. Tighten fittings.

NOTE

Remove caps on tee last to minimize oil loss.

3. Position hoses into frame.




- 4. Locate two hoses (white ties) inside frame, and hose MD #111324 with tee (white tie).
- 5. Remove caps, make connections, and tighten fittings.
- 6. Push hoses into frame.



- 7. Locate two hoses (red ties) inside frame.
- 8. Route RH hose behind bundle.
- 9. Remove caps, make connection, and tighten fitting.
- 10. Push hose into frame.




11. Retrieve long hose MD #119328 (white tie), and route through hole in LH frame.



12. Remove caps on hose, and valve block fitting (white tie), and make connection. Tighten fitting.




 Remove the cap from fitting with yellow tie on the valve block from inboard side of frame.




- 14. Loosen bolts, and move valve block to improve access through hole in frame for wrenches when tightening fittings.
- 15. Retrieve matching hose, and make connection on valve block. Tighten fitting.
- 16. Re-position valve block, and re-tighten bolts.
- b. Connect drive hoses to pump as follows:




1. Remove caps, and attach hoses (green and yellow ties) to matching fittings on top of pump. Tighten fittings.



Remove caps, and attach hoses (red and white ties) to matching fittings on bottom of pump. Tighten fittings.



c. Retrieve the two motor case drain hoses (MD #111312) at front frame, and the 7/8 in. tee fitting on the hose from the pump.




d. Remove caps from the hoses only.

(continued next page)

- e. Remove one cap on tee fitting, and quickly attach hose to minimize oil spillage.
- Remove second cap from tee, and quickly connect other hose.
- g. Tighten fittings.




- h. Bundle traction drive hoses, and secure with two plastic cable ties at 7-3/4 inch (200 mm) intervals from frame opening.
- Bundle smaller hoses, and secure with two plastic cable ties at 6 inch (150 mm) intervals from frame opening.




- Locate hose bundle from valve blocks on LH side of frame onto tire.
- k. Note routing of electrical harness.

IMPORTANT


The electrical harness must be routed on the topside of the hose bundle and on the outside of the hose support to prevent chafing to the electrical wires when the windrower is operating with a header.




I. Undo strap (A), cut plastic cable ties (B), and move harness (C) away from hose bundle.




- m. Route hose bundle through hose support and lay on tire.
- n. Route harness (C) along outside of hose support and along hose bundle to hose ends.



o. Attach harness (C) to hose support with hose clip (D).




p. Secure harness (C) to hose bundle with strap (A) and new plastic cable ties (B). Ensure harness is clear of pinch and friction points.



q. Disengage hook, and rotate to up position. Position hose bundle over hose support, and locate under hook.



r. Rotate hook, and re-engage in bracket.




s. Attach reel hose support tube to the RH reel leg with two 3/8 in. x 1.0 carriage bolts and nuts.


STEP 15. REMOVE BATTERY SHIPPING SHIELD

NOTE


Not applicable to M105.



- a. Loosen the nut (A) on battery clamp.
- b. Slide shield (B) out from under battery and discard. Tighten nut (A) in battery clamp.




c. Remove one of the two bolts (D) and nuts, and loosen the other.




 Rotate angle (C) 180 degrees, align holes, and reinstall the bolt (D) and nut. Leave bolts loose.

STEP 16. UNPACK IGNITION KEYS



a. Remove wing nut (E) from fuse box cover (F) and remove cover.




- b. Remove tape and keys (G) from inside cover. Discard tape.
- c. Unlock cab doors and place key on console.
- d. Close cab doors.
- e. Re-install cover (F) with wing nut (E).


STEP 17. INSTALL PLATFORMS

NOTE

The following procedure is applicable to M155 and M205 machines with LH and RH platforms. The M105 has a LH platform only. LH installation is shown. RH installation is opposite.



- a. Remove the two 1/2 inch x 0.75 bolts securing rails to shipping beam, and remove rails. Retain hardware.
- b. Remove shipping brackets from platform assembly. Retain hardware.




c. Attach a sling to platform, and other end to lifting device.




CAUTION


Stand clear when lifting, as platform may swing.




d. Position platform against windrower frame.




e. Attach main beam of platform to side frame with three 1/2 in. x 1.25 long carriage bolts. Bolt heads face inboard. Tighten just enough for adjustment.




- f. Attach steering arm to frame with two 3/8 in. x 0.75 long carriage bolts and nuts. Bolt heads face inboard. Tighten bolts.
- g. Remove sling.




h. Attach railings to platform with 1/2 inch x 0.75 locking bolts provided. Tighten bolts to 75 ft·lbf. (102 N·m).




 Slowly close platform, and check that vertical rail tubes are parallel with cab posts when viewing from the rear. Laterally adjust king pin mounting as required.






j. Check that rubber bumper is contacting the frame, and that front of platform is contacting the guide.



k. Adjust platform horizontally with the 1/2 in. x 2.25 bolt as required.




- If major adjustment is required, relocate steering arm into either of the other holes on the bracket.
- m. Tighten the three main beam attachment bolts to 80 ft-lbf (108 N·m).
- Repeat above steps c. to I. to install the RH platform.

STEP 18. INSTALL STEPS


The following procedure is applicable to M155 and M205 machines with LH and RH platforms.

The M105 has a LH platform only.

LH installation is shown. RH installation is opposite.




- a. Remove the two existing upper bolts.
- b. Check that two lower bolts are not threaded in fully.




- c. Hang step assembly on bolts. If required, back off bolts.
- d. Install two bolts in upper holes in step, and tighten.
- e. Tighten lower bolts.
- f. Repeat for other step assembly (except M105).


STEP 19. INSTALL EXHAUST STACK

- a. Open engine compartment hood.
- b. Retrieve exhaust stack and clamp (unpacked in STEP 6).






- c. Loosen clamp (A) on exhaust stack (B).
- d. Remove covering from muffler (D) and loosen clamp (C) on muffler.




e. Position stack (B) in slot in exhaust shroud (E), and connect stack (B) to muffler (D).

NOTE

If shroud (E) interferes with the stack, loosen the wing-nut (F) on the shroud and move the shroud so that stack can be installed.




f. Tighten both clamps (A) and (C) but just enough so stack can be moved.




- g. Slowly close hood so that stack (B) enters hole(G) in hood. Adjust the position of the stack as required to clear the hole in the hood.
- h. Raise the hood.
- i. Tighten clamps (A) and (C).
- j. Reposition shroud, and tighten wing-nut (F).

STEP 20. POSITION LIGHT AND MIRROR ASSEMBLIES



- a. Remove nut and bolt (A) from shipping position.
- b. Swing mirror/light assembly (B) forward up to stop.




- c. Re-install bolt (A) and nut in other hole.
- d. Repeat for opposite mirror assembly.

STEP 21. CONNECT BATTERIES

A. M205, M155


a. Open right hand (cab-forward) maintenance platform.



- b. The battery main disconnect switch (A) is located on the RH frame rail beside the batteries. Ensure battery switch (A) is switched to POWER OFF position.
- c. Remove cable ties securing battery cables to battery clamp.

IMPORTANT

BATTERY IS NEGATIVE GROUNDED. Always connect red starter cable to the positive (+) terminal of battery and black ground cable to negative (-) terminal of battery. Reversed polarity in battery or alternator may result in permanent damage to electrical system.



d. Remove plastic caps from battery posts.

NOTE


Ensure that batteries are positioned so that the positive posts (B) face aft.


e. Attach positive (red) cable terminals to positive post (B) on batteries, and tighten. Re-position plastic covers onto clamps.

- f. Attach negative (black) cable terminals to negative post (C) on batteries, and tighten clamps.
- g. Turn battery switch (A) to POWER ON position.
- h. Move platform back to closed position.

B. M105

a. Open engine compartment hood to highest position.





- b. A battery main disconnect switch is located on the battery tray. Ensure battery switch is switched to POWER OFF position.
- c. Remove cable ties securing battery clamps and cables to frame.

IMPORTANT

BATTERY IS NEGATIVE GROUNDED. Always connect red starter cable to the positive (+) terminal of battery, and black ground cable to negative (-) terminal of battery. Reversed polarity in battery or alternator may result in permanent damage to electrical system.

NOTE

Ensure that batteries are positioned so that the positive posts (B) face forward.

- d. Remove plastic caps from battery posts.
- e. Attach negative (black) cable clamps (A) to negative post on batteries, and tighten clamps.
- f. Attach positive (red) cable clamps (B) to positive post on batteries, and tighten.
- g. Re-position plastic covers onto clamps.
- h. Switch battery switch to POWER ON position.
- i. Close engine compartment hood.


STEP 22. PRIME HYDRAULIC SYSTEM

A. M205

a. Open maintenance platform on LH side.



b. Disconnect brake engage solenoid (plug P44) at valve block on LH side of windrower.



c. Remove socket head screw (A) with a 4 mm Allen wrench, and remove ECM connector (B) from engine. This prevents engine from starting during cranking.




CAUTION


Check to be sure all bystanders have cleared the area.

- d. Crank engine with starter for 15 seconds to prime the system.
- e. Re-install ECM connector (B) with screw (A).
- f. Re-connect brake engage solenoid plug.
- g. Check hydraulic oil level in reservoir. Add SAE15W-40 oil if necessary.


B. M155



Remove hydraulic oil reservoir filler cap/dipstick.



- b. Open engine compartment hood fully.
- c. Locate plug on SIDE of HEADER drive pump housing from underneath machine, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.



d. Locate plug on TOP of HEADER drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.




- e. Locate plug on TOP of TRACTION drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.
- f. Replace hydraulic oil reservoir filler cap.

g. Open maintenance platform on LH side.



h. Disconnect brake engage solenoid connector (P-V3) at valve block on LH side of windrower.



i. Disconnect electrical connection at fuel pump on right side of engine.

j. Open maintenance platform on RH side (M205, M155).



k. Open circuit breaker/fuse box, and remove ECM ignition fuse (5A).



CAUTION

Check to be sure all bystanders have cleared the area.

- I. To prime the system, crank engine with starter for 15 seconds.
- m. Re-connect electrical connection at fuel pump and at brake engage solenoid.
- n. Re-install ECM ignition fuse, and close fuse box.
- o. Close engine compartment hood.



 Check hydraulic oil level in reservoir. Add SAE15W-40 oil if necessary.

C. M105




- a. Remove hydraulic oil reservoir filler cap/dipstick.
- b. Open engine compartment hood fully.



c. Locate plug on TOP of HEADER drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.



- d. Locate plug on TOP of TRACTION drive pump housing from above, and loosen plug to bleed pump housing. Re-tighten plug once oil starts to run out.
- e. Replace hydraulic oil reservoir filler cap.
- f. Open maintenance platform on LH side.



g. Disconnect brake engage solenoid connector (P-V3) at valve block on LH side of windrower.



h. Disconnect electrical connection at fuel pump on right side of engine.



i. Open circuit breaker/fuse box, and remove ECM ignition fuse (5A).



CAUTION

Check to be sure all bystanders have cleared the area.

- j. To prime the system, crank engine with starter for 15 seconds.
- k. Re-connect electrical connection at fuel pump and at brake engage solenoid.
- I. Re-install ECM ignition fuse, and close fuse box.

m. Close engine compartment hood.





n. Check hydraulic oil level in reservoir. necessary, add SAE15W-40 oil.

lf

STEP 23. START ENGINE

a. Check fuel level, and if required add sufficient fuel for a 15 minute run.



- Lock (A) should be engaged at cab-forward or engine-forward position (M155 and M205 only).
- c. Move GSL (B) into N-DETENT.
- d. Turn steering wheel until it locks.



- e. Push HEADER DRIVE switch (C) to OFF.
- f. **Normal Start (All Engines):** engine temperature above 60°F (16°C).
 - 1. Set throttle to START position (D)-fully back.



CAUTION

Check to be sure all bystanders have cleared the area.



- Sound horn (E) three times.
- 3. Turn ignition key (F) to RUN position.

4. Single loud tone sounds, and engine warning lights illuminate, and CDM displays "HEADER DISENGAGED" and "IN PARK".



WARNING

If starter engages with steering wheel unlocked, ground speed lever out of NEUTRAL, or header clutch engaged, DO NOT START ENGINE. See your Dealer.

Turn ignition key (F) to START position until engine starts, and then release key. Tone ceases, and warning lights go out.

IMPORTANT

Do **NOT** operate starter for longer than 15 seconds at a time.

If engine does **NOT** start, wait at least two minutes before trying again.

After the third 15 second crank attempt, allow starter motor to cool for 10 minutes before further cranking attempts.

If engine still does **NOT** start, refer to the following table:

PROBLEM	SOLUTION
Controls Not In NEUTRAL.	Move GSL to NEUTRAL. Move steering wheel to locked position. Disengage header clutch.
Operator's Station Not Locked.	Adjust position of Operator's station.
(M155 and M205 only).	Ensure lock is engaged.
Neutral Interlock Misadjusted.	Contact MacDon Dealer.
No Fuel To Engine.	Fill empty fuel tank. Replace clogged filter.
Old Fuel In Tank.	Drain tank. Refill with fresh fuel.
Water, Dirt Or Air In Fuel System.	Drain, flush, fill and prime system.
Improper Type Of Fuel.	Use proper fuel for operating conditions.
Crankcase Oil Too Heavy.	Use recommended oil.
Low Battery Output.	Have battery tested. Check battery electrolyte level.
Poor Battery Connection.	Clean and tighten loose connections.
Faulty Starter.	Contact MacDon Dealer.
Wiring Shorted, Circuit Breaker Open.	Check continuity of wiring and breaker (manual reset).
Faulty Injectors.	Contact MacDon Dealer.

g. **Cold Start:** engine temperature below 40°F (5°C).

NOTE

Engines are not equipped with cold start assist system.

- 1. Follow **step e**. **Normal Start** procedure on last page.
- 2. Engine will cycle through a period where it appears to labour until engine warms up.

NOTE

Throttle is non-responsive during this time as engine is in WARM UP mode. This mode will last from 30 seconds to 3 minutes depending on temperature. After engine has stabilized and idling normally, throttle becomes active.

IMPORTANT

Do **NOT** operate engine above 1500 rpm, until engine temperature gauge is above 100°F (40°C).

STEP 24. CHECK TRACTION DRIVE



CAUTION

Check to be sure all bystanders have cleared the area.




M155, M205 SHOWN - M105 SIMILAR

- a. With engine running, move GSL out of N-DETENT, and slowly move GSL forward.
- b. Drive wheels should be rotating in the forward direction, and at the same speed.
- c. Turn steering wheel, and observe motion of drive wheels. They should rotate at different speeds, with the slower rotating wheel on the same side of the machine that the steering wheel was turned toward.
- d. Repeat above for opposite direction.
- e. Move GSL back into reverse. Drive wheels should be rotating in the reverse direction, and at the same speed.
- f. Move GSL back into N-DETENT, and shut down engine.

STEP 25. REMOVE WINDROWER FROM STAND

A. FACTORY STAND



a. Move valve handle up to raise windrower slightly, and take load off lift locks.



- b. Release lift lock mechanism (3 places), and turn keeper to keep lock in released position.
- Move valve handle down to slowly release pressure to air bag system and lower tractor to ground.



CAUTION


Ensure all three lifts have fully retracted and are clear of windrower frame before driving windrower ahead.

d. Start engine, and drive machine straight ahead, leaving shipping support channels supported on rear support stand.

B. FIELD-CONSTRUCTED STAND

- a. Position a jack under the jack point of each drive wheel leg, and another under the rear hitch.
- b. Raise jacks to take weight off stands, and remove stands.
- c. Slowly lower windrower to ground, and remove jacks.

STEP 26. INSTALL AM/FM RADIO




Provision has been made for installation of AM/FM radio. The mounting is designed to fit a DIN E style radio with a depth 'X' = 161 mm, and having a 5 mm threaded stud centered on the rear for support.

Provision has been made for adjustments, should the radio fall outside these parameters.


NOTE

M105 configuration is slightly different, but the installation procedure is the same.


a. Ensure the ignition is turned to the OFF position.




Remove radio panel by removing four screws (A).




 Remove screw and nuts (B) and (C) to remove support (D) from panel. Retain metric nut (C) and lock washer.




d. Remove the cut-out by cutting the tabs (E) in the panel. Remove sharp edges on panel.



e. Locate receptacle (F) (supplied with radio) in opening, and secure by bending tabs (G) on receptacle against panel.



- f. Insert radio into receptacle and attach radio bezel. Ensure radio locks into position, and faceplate (H) is against the panel.
- g. A six-pin connector for the radio is included in the wiring harness. In order to mate properly with this connector, the radio must have a sixpin connector (Packard #2977042), and have a terminal arrangement as follows:



(continued next page)


- h. Attach two additional wires in the wiring harness to the radio:
 - 1. Circuit 503: Red with 1/4 in. female blade terminal. This is a live wire provided for powering a radio clock/memory, if these exist on your radio.
 - 2. Circuit 315: Black ground wire attaches to radio body.
- i. Plug cable from antenna into radio.

NOTE

An approved radio package is available from Radio Engineering Industries (REI) of Omaha, Nebraska.


- Attach stud (supplied with radio) to center rear of radio.
- k. Attach support (D) to stud on back of radio chassis, with lock washer and metric nut (C) that was supplied with the support.

Support can be attached to chassis multiple in locations to allow




for proper mounting of radio.

Re-install radio panel with original screws.



- m. Adjust bracket (J) if necessary by loosening nuts (K) to allow radio to slide into opening, and securely capture support (D).
- Retrieve antenna from inside cab and remove protective cover from base end.



o. Remove protective cover (L) from antenna mount on cab roof and thread antenna onto base until hand tight.

NOTE

Store protective cover in cab to protect antenna mount if antenna needs to be removed.

p. Turn ignition key to ACC, switch radio ON, and check operation in accordance with instructions supplied with the radio.

STEP 27. INSTALL BEACONS

a. Retrieve the two beacons from shipment.



b. Remove hardware and rubber base from one of the beacons as shown.



 Feed connectors from harness through center hole in rubber base, and place base on beacon bracket - making sure mounting holes in rubber base line-up with holes in bracket.



d. Connect orange wire from harness to the red wire in beacon. Black harness wire connects to ground terminal in beacon.



e. Fit beacon onto base making sure beacon is oriented as shown, with the point on lens facing forward (Cab-Forward).



- f. Mount beacon to base with lock washers and nuts supplied with beacon.
- g. Similarly install other beacon on opposite side of cab roof.

STEP 28. INSTALL SLOW MOVING VEHICLE (SMV) SIGN



ENGINE - FORWARD

 a. Install SMV sign (shipped in cab) on Windrower in accordance with instructions supplied with the sign.



CAB - FORWARD



ALTERNATE LOCATION (CAB-FORWARD)

b. The SMV signs must be visible when travelling on the road.


STEP 29. ATTACH HEADER

A. M205



I.HEADER ATTACHMENT - D SERIES

The M205 must be equipped with a draper drive basic kit and a completion kit as shown.




DRAPER HEADER HYDRAULICS



DRAPER HEADER REEL HYDRAULICS

If necessary, obtain the following kits from your MacDon Dealer, and install them in accordance with the instructions supplied with the kits.


Kit Description	Kit Number
Base Kit	B5491
Completion	B5496
Coupler	B5497




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (A), and **NOT** installed at hole location (B).


 a. If not installed, attach draper header boots (supplied with header) to windrower lift linkage as follows:



1. Remove pin (C) from boot (D). *(continued next page)*



- Locate boot (D) on lift linkage (E), and re-install pin (C). Pin may be installed from either side of boot.
- 3. Secure pin (A) with hairpin.
- 4. Repeat for opposite side.




b. Remove hairpin on pins (F), and remove pins from header legs.




CAUTION


Check to be sure all bystanders have cleared the area.



 Start the engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.



- d. Slowly drive windrower forward so that boots (D) enter header legs (G). Continue to drive slowly forward until lift linkages contact support plates in the header legs, and header nudges forward.
- e. Check that linkages are properly engaged in header legs, contacting support plates.



f. Adjust the position of the center-link cylinder with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.




- g. Lower the center-link onto the header with REEL DOWN switch until it locks into position (handle is down).
- h. Raise the header fully with the HEADER UP switch on the GSL. Stop engine and remove key.



DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header.

i. Engage lift cylinder stops on both lift cylinders.



- J. Install pin (F) through header leg, (engaging U-bracket in lift linkage) on both sides, and secure with hairpin.
- k. Raise header stand (H) to storage position by pulling pin (J), and lifting stand into uppermost position. Release pin (J).




CAUTION

Check to be sure all bystanders have cleared the area.



- I. Remove pin from storage position (K) in linkage, and insert in hole (L) to engage float springs. Secure with hairpin.
- m. Disengage lift cylinder stops.
- n. Start engine, and push HEADER DOWN switch on GSL to lower header fully.



- o. Stop engine, and remove key.
- p. Connect header drive hoses (M) and electrical harness (N) to header. Refer to the Draper Header Unloading and Assembly Instruction.




- q. Connect reel hydraulics (O) at RH side of windrower. Refer to the Draper Header Unloading and Assembly Instruction.
- r. Start engine, and raise and lower header and reel a few times, to allow trapped air to pass back to the reservoir.

II. HEADER ATTACHMENT - A SERIES




The M205 must be equipped with an auger drive basic kit and a completion kit as shown.




AUGER HEADER HYDRAULICS

If necessary, obtain the following kits from your MacDon Dealer, and install them in accordance with the instructions supplied with the kits.

Kit Description	Kit Number
Base Kit	B5491
Completion	B5492
Coupler	B5497



a. Remove hairpin from pin (A), and remove pin from left and right header boots (B) on header.




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and **NOT** installed at hole location (D).




CAUTION


Check to be sure all bystanders have cleared the area.




 Start the engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.



c. Slowly drive windrower forward so that feet (E) on windrower enter boots (B) on the header. Continue to drive slowly forward until feet engage the boots, and header nudges forward.



d. Adjust the position of the center-link cylinder with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.




- e. Lower the center-link onto the header with REEL DOWN switch until it locks into position (handle is down).
- f. Raise the header fully with the HEADER UP switch on the GSL. Stop engine and remove key.



DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header.


g. Engage lift cylinder stops on both lift cylinders. *(continued next page)*




h. Install pin (A) through each boot and foot, and secure with hairpin.

IMPORTANT

Ensure pin (A) is fully inserted, and hairpin is installed behind bracket.




- i. Remove lynch pin from pin (F) in stand (G).
- j. Hold stand, and remove pin (J).
- k. Reposition stand to storage position by inverting stand, and re-locating on bracket as shown. Re-insert pin (F), and secure with lynch pin.



 Remove pin (H) from storage position in linkage, and insert in hole (J) to engage float springs. Secure with lynch pin.

- m. Disengage lift cylinder stops.
- Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.



 Connect header drive hydraulics (K) and electrical harness (L) to header. Refer to your Auger Header Unloading and Assembly Instructions.


III. HEADER ATTACHMENT - R SERIES




The M205 is factory-equipped with hydraulics and connections to run the R-Series Rotary Disc headers.

R85 16 FT headers are factory-equipped with hydraulic connections for attachment to the windrower.


R85 13 FT header and R80 13 and 16 FT headers are shipped without the motor and hoses installed, and the installation of a separate motor and hose bundle is necessary.



a. If required, obtain kit number B5456 from your MacDon Dealer, and install it in accordance with the instructions supplied with the kit.



b. Remove hairpin from pin (A), and remove pin from on left and right header boots (B) on header.




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and **NOT** installed at hole location (D).




CAUTION


Check to be sure all bystanders have cleared the area.




 Start the engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.



d. Slowly drive windrower forward so that feet (E) on windrower enter boots (B) on the header.
 Continue to drive slowly forward until feet engage the boots, and header nudges forward



e. Adjust the position of the center-link cylinder with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.



- f. Lower the center-link onto the header with REEL DOWN switch until it locks into position (handle is down).
- g. Raise the header fully with the HEADER UP switch on the GSL. Stop engine, and remove key.



DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header.


h. Engage lift cylinder stops on both lift cylinders.



i. Install pin (A) through each boot and foot, and secure with hairpin.


IMPORTANT

Ensure pin (A) is fully inserted, and hairpin is installed behind bracket.



- Remove pin (F) from storage position in linkage, and insert in hole (G) to engage float springs. Secure with hairpin.
- k. Disengage lift cylinder stops.
- I. Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.
- m. Connect header drive hydraulics and electrical harness to header. Refer to your Rotary Disc Header Unloading and Assembly Instructions.


B. M155, M105



DRAPER HEADER HYDRAULICS FOR M155

M155 windrowers must be fitted with a draper drive basic kit and a completion kit to operate the D-Series draper headers.

The M105 needs to be equipped with reel drive, reel lift, and reel fore-aft hydraulics.




DRAPER HEADER REEL HYDRAULICS

Windrowers equipped with D-Series hydraulics have four header drive hoses on the LH side, and up to five reel drive hoses on the RH side.

If necessary, obtain the following kits from your MacDon Dealer, and install them in accordance with instructions supplied with the kits.

KIT DESCRIPTION	KIT NUMBER		
	M155	M105	
Base Kit	B5577	B5577	
Completion			
Reverser *	B4656		


^{*} For HC10 Conditioner Operation




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (A), and **NOT** installed at hole location (B).


If not installed, attach draper header boots (supplied with header) to windrower lift linkage as follows:



a. Remove pin (C) from boot (D).



- b. Locate boot (D) on lift linkage (E), and re-install pin (C). Pin may be installed from either side of boot.
- c. Secure pin (C) with hairpin.
- d. Repeat for opposite side.




e. Remove hairpin on pins (F), and remove pins from header legs.



CAUTION


Check to be sure all bystanders have cleared the area.




f. Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.




g. If necessary, adjust position of the hydraulic center-link (G) so that the hook (H) is above the attachment pin on the header by one of the following methods:



1. If the optional center-link self-alignment kit is installed, activate the REEL UP switch on the GSL to raise the center-link (G).




2. Without the self-alignment kit, re-locate the pin (J) at the frame linkage as required to raise the center-link (G).





- h. Slowly drive windrower forward so that boots (D) enter header legs (K). Continue to drive slowly forward until lift linkages contact support plates in the header legs, and header nudges forward.
- i. Ensure that lift linkages are properly engaged in header legs, contacting support plates.

Connect center-link:

HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT (M155)








 Adjust position of the center-link cylinder (G) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.

IMPORTANT

Hook release (L) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

2. Lower center-link (G) onto the header with REEL DOWN switch until it locks into position (hook release (L) is down).



- Check that center-link (G) is locked onto header by pressing the REEL UP switch on the GSL.
- 4. Proceed to step g. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M155, M105 OPTIONAL)

- Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (G) so that the hook lines-up with the header attachment pin.
- 2. Stop engine, and remove key from ignition.
- Push down on rod end of link cylinder (G) until hook engages pin on header, and is locked.

IMPORTANT

Hook release (L) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.


- 4. Check that center-link is locked onto header by pulling upward on rod end of cylinder.
- 5. Proceed to step g. on next page.

MECHANICAL LINK (M155, M105 OPTIONAL)



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.




- 1. Stop engine, and remove key from ignition.
- 2. Loosen nut (M), and rotate barrel (N) to adjust length so that the link lines-up with header bracket.
- 3. Install pin (O), and secure with cotter pin.
- Adjust link to required length for proper header angle by rotating barrel (N). Tighten nut (M) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



k. If engine is not running, start engine, and press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require rephasing. If re-phasing is needed, proceed as follows:


- 1. Press and hold the HEADER UP switch until both cylinders stop moving.
- 2. Continue to hold the switch for 3-4 seconds.
- 3. Cylinders are phased.



DANGER


To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.

- I. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:
 - 1. Stop engine, and remove key from ignition.







- 2. Pull lever (P), and rotate toward header to release and lower cylinder stop (Q) onto cylinder.
- 3. Repeat for opposite lift cylinder.



- m. Install pin (F) through header leg, (engaging Ubracket in lift linkage) on both sides, and secure with hairpin.
- n. Raise header stand (R) to storage position by pulling pin (S), and lifting stand into uppermost position. Release pin (S).



 Remove pin from storage position (T) in linkage, and insert in hole (U) to engage float springs. Secure with hairpin.



- p. Disengage lift cylinder stop by turning lever (P) downward to release and lower stop until lever locks into vertical position.
- q. Repeat for opposite lift cylinder stop.



CAUTION

Check to be sure all bystanders have cleared the area.

r. Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.




WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.



s. Connect header drive hoses (V) and electrical harness (W) to header. Refer to the Draper Header Operator's Manual.



 Connect reel hydraulics (X) at RH side of windrower. Refer to the Draper Header Operator's Manual.



CAUTION

Check to be sure all bystanders have cleared the area.

 Start engine, and raise and lower header and reel a few times to allow trapped air to pass back to the reservoir.

I. HEADER ATTACHMENT: A SERIES




Windrowers equipped with A-Series hydraulics have four header drive hoses on the LH side.


The M155 and M105 are factory-equipped to run the A-Series auger headers.

If necessary, obtain the following kit from your MacDon Dealer, and install it in accordance with instructions supplied with the kits.

KIT DESCRIPTION	KIT NUMBER	
Basic Drive	B5491	
Completion / Reverser	B5492	



a. Remove hairpin from pin (A), and remove pin from left and right header boots (B) on header.




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and **NOT** installed at hole location (D).



CAUTION


Check to be sure all bystanders have cleared the area.




 Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.




c. If necessary, adjust position of the hydraulic center-link (E) so that the hook (F) is above the attachment pin on the header by one of the two following methods (shown in next column):



1. If the optional center-link self-alignment kit is installed, activate the REEL UP switch on the GSL to raise the center-link (E).




2. Without the self-alignment kit, re-locate the pin (G) at the frame linkage as required to raise the center-link (E).




d. Slowly drive windrower forward so that feet (H) on windrower enter boots (B) on the header. Continue to drive slowly forward until feet engage the boots, and header nudges forward.

e. Connect center-link:

HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT






 Adjust position of the center-link cylinder (E) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.

IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.



- 2. Lower the center-link onto the header with REEL DOWN switch until it locks into position (hook release (J) is down).
- Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.
- 4. Proceed to step f. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M155, M105 OPTIONAL)

- Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (E) so that the hook lines-up with the header attachment pin.
- 2. Stop engine, and remove key from ignition.
- Push down on rod end of link cylinder (E) until hook engages pin on header, and is locked.


IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

- Check that the center-link is locked onto header by pulling upward on rod end of cylinder.
- 5. Proceed to step f. on next page.

MECHANICAL LINK (M155, M105 OPTIONAL)

1. Stop engine, and remove key from ignition.




- Loosen nut (H), and rotate barrel (J), to adjust length so that other end lines-up with header bracket.
- 3. Install pin (K), and secure with cotter pins.
- Adjust link to required length for proper header angle by rotating barrel (J). Tighten nut (H) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



f. If engine is not running, start engine. Press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require rephasing. If re-phasing is needed, proceed as follows:

- 1. Press and hold HEADER UP switch until both cylinders stop moving.
- 2. Continue to hold the switch for 3-4 seconds.
- 3. Cylinders are phased.



WARNING


Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.



DANGER


To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.

- g. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:
 - 1. Stop engine, and remove key from ignition.






- 2. Pull lever (L), and rotate toward header to release and lower cylinder stop (M) onto cylinder.
- 3. Repeat for opposite lift cylinder.




h. Install pin (N) through each boot and foot, and secure with hairpin.

IMPORTANT


Ensure pin (N) is fully inserted, and hairpin is installed behind bracket.



- i. Remove lynch pin from pin (O) in stand (P).
- j. Hold stand (P), and remove pin (O).
- Re-position stand to storage position by inverting stand, and re-locating on bracket as shown
- I. Re-insert pin (O), and secure with lynch pin.



m. Remove pin (Q) from storage position in linkage, and insert in hole (R) to engage float springs. Secure with lynch pin.




- Disengage lift cylinder stop by turning lever (L) downward to raise stop until lever locks into vertical position.
- o. Repeat for opposite cylinder stop.



CAUTION

Check to be sure all bystanders have cleared the area.




p. Start engine, and activate HEADER DOWN switch on GSL to lower header fully.



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

q. Stop engine, and remove key.



r. Connect header drive hydraulics (S) and electrical harness (T) to header. Refer to Auger Header Operator's Manual.


II. HEADER ATTACHMENT: R SERIES (M155 ONLY)

The M155 windrower operates <u>only</u> the R85 and R80 13 FT headers, and these headers need to be equipped with Kit B5510 (motor and hoses).




KIT B5510

To operate these headers, the M155 windrower requires the installation of hydraulic valve Kit B4657. See your MacDon Dealer.



a. Remove hairpin from pin (A), and remove pin from on left and right header boots (B) on header.




IMPORTANT

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to windrower, ensure that float engagement pin is installed in storage location (C), and **NOT** installed at hole location (D).



CAUTION


Check to be sure all bystanders have cleared the area.




 Start engine, and activate HEADER DOWN button on the GSL to fully retract header lift cylinders.

IMPORTANT


If the center-link is too low, it may contact the header as the windrower approaches the header for hook-up.



c. If necessary, adjust position of the hydraulic center-link (E) so that the hook (F) is above the attachment pin on the header by one of the following 2 methods (shown in next column):




 If the optional center-link self-alignment kit is installed, activate the REEL UP switch on



the GSL to raise the center-link (E).

2. Without the self-alignment kit, re-locate the pin (G) at the frame linkage as required to




raise the center-link (E).


- d. Slowly drive windrower forward so that feet (H) on windrower enter boots (B) on the header.
- e. Continue to drive slowly forward until feet engage the boots, and header nudges forward.

f. Connect center-link:

HYDRAULIC LINK WITH OPTIONAL SELF-ALIGNMENT KIT



 Adjust position of the center-link cylinder (E) with the REEL UP and REEL DOWN switches, and HEADER TILT switches on the GSL to position the hook above the header attachment pin.




IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

- 2. Push the REEL DOWN switch on the GSL to lower the center-link onto the header until it locks into position (release (J) is down).
- Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.
- 4. Proceed to step g. on next page.

HYDRAULIC LINK WITHOUT SELF-ALIGNMENT KIT (M155 OPTIONAL)



- Activate HEADER TILT cylinder switches on GSL to extend or retract center-link cylinder (E) so that the hook lines-up with the header attachment pin.
- 2. Stop engine, and remove key from ignition.
- Push down on rod end of link cylinder (E) until hook engages pin on header, and is locked.

IMPORTANT

Hook release (J) must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

- 4. Check that center-link is locked onto header by pulling upward on rod end of cylinder.
- 5. Proceed to step g. on next page.


MECHANICAL LINK (M155 OPTIONAL)




WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

1. Stop engine, and remove key from ignition.



Loosen nut (J), and rotate barrel (K), to adjust length so that other end lines-up with header bracket.




- 3. Install clevis pin (L), and secure with cotter pin.
- 4. Adjust link to required length for proper header angle by rotating barrel (K). Tighten nut (J) against barrel. A slight tap with a hammer is sufficient.



CAUTION

Check to be sure all bystanders have cleared the area.



g. Start engine (if not running), and press HEADER UP switch to raise header to maximum height.

NOTE

If one end of the header does not raise fully, the lift cylinders require rephasing. If re-phasing is needed, proceed as follows:

- 1. Press and hold HEADER UP switch until both cylinders stop moving.
- 2. Continue to hold the switch for 3–4 seconds.
- 3. Cylinders are phased.



DANGER

To avoid bodily injury from fall of raised header, always engage header lift cylinder stops when working on or around raised header, and before going under header for any reason.


h. Cylinder stops are located on both header lift cylinders on the windrower. Engage lift cylinder stops on both lift cylinders as follows:



WARNING


Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

1. Stop engine, and remove key from ignition.






- 2. Pull lever (M), and rotate toward header to release and lower cylinder stop (N) onto cylinder.
- 3. Repeat for opposite lift cylinder.




i. Install pin (O) through each boot and foot, and secure with hairpin.

IMPORTANT

Ensure pin (O) is fully inserted, and hairpin is installed behind bracket.



j. Remove pin (P) from storage position in linkage, and insert in hole (Q) to engage float springs. Secure with hairpin.




k. Disengage lift cylinder stops by turning lever (M) downward to release and lower stop until lever locks into vertical position. Repeat for opposite lift cylinder stop.



CAUTION

Check to be sure all bystanders have cleared the area.



 Start engine, and activate HEADER DOWN switch on GSL to lower header fully. Stop engine, and remove key.



WARNING

Stop windrower engine, and remove key before making adjustments to machine. A child or even a pet could engage the drive.

m. Connect header drive hydraulics and electrical harness to header. Refer to your Rotary Disc Header Operator's Manual.

STEP 30. LUBRICATE MACHINE

Recommended Lubricant

SPEC	DESCRIPTION	USE
SAE Multi- Purpose	High Temperature Extreme Pressure (EP2) Performance With 1% Max Molybdenum Disulphide (NLGI Grade 2) Lithium Base	As Required Unless Otherwise Specified

- a. Wipe grease fitting with a clean cloth before greasing, to avoid injecting dirt and grit.
- b. Inject grease through fitting with grease gun until grease overflows fitting, except where noted.
- c. Leave excess grease on fitting to keep out dirt.
- d. Replace any loose or broken fittings immediately.
- e. If fitting will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.
- f. Refer to the following illustrations to identify the various locations requiring lubrication.

Lubrication Points (Cont'd)

High Temperature Extreme Pressure (EP2) Performance With 1% Max Molybdenum Disulphide (NLGI Grade 2). Lithium Base.






TOP LINK - TWO FITTINGS (BOTH SIDES)






FORMED CASTER WHEEL BEARING 1 PLACE (BOTH WHEELS)





FORKED CASTER SPINDLE BEARINGS TWO PLACES (BOTH WHEELS)



CASTER PIVOT (BOTH SIDES)

STEP 31. PROGRAM CAB DISPLAY MODULE (CDM)

The monitoring system requires programming for each header, and the <u>header must be</u> attached to the windrower.

Programming the system may be accomplished with, or without the engine running. If the engine is running, the transmission must be in NEUTRAL. If the engine is not running, the ignition must be ON.

Exit programming mode at any time by pressing the PROGRAM switch, or by turning OFF ignition.

The system only needs to be programmed once for each header. The Operator may make changes later on to a particular setting to suit windrowing conditions or modifications to the machine. Most functions have been preprogrammed at the factory, but can be changed by the Operator if required.

The following functions can be programmed by the Dealer, provided the applicable information from the Operator has been provided, and the header is installed:


DWA INSTALLED (M155, M205 ONLY) HDR CUT WIDTH HAY CONDITIONER INSTALLED CALIBRATE SENSORS Proceed to program the CDM as follows:

IMPORTANT

Header must be attached to the windrower so that the CDM can detect the type of header (Header ID), and adjust the programming mode accordingly.

- a. Turn ignition key to RUN, <u>or</u> start the engine. Refer to STEP 23. START ENGINE.
- Press PROGRAM and SELECT switches together on CDM to enter programming mode. Header ID code is displayed.
- c. Press SELECT. TRACTOR SETUP? is displayed.
- e. Press SELECT until DWA INSTALLED? is displayed.
- f. Press or _____.
- g. Press SELECT to advance to the next L1 item.
- h. Press PROGRAM to exit programming mode.
- i. Refer to the following pages depending on your machine. The functions requiring programming are highlighted with ______ in the Programming Instructions:

A. M205, M155 Detailed Programming Instructions. or




B. M105 Detailed Programming Instructions.


A. M205, DETAILED PROGRAMMING INSTRUCTIONS

(Ignition ON / Engine Running or Not / Header Disengaged).


(Press PROGRAM and SELECT on CDM to enter programming mode).

(If necessary, refer to the M Series Windrower Operator's Manual for programming to specific crop types and conditions).





l lo l'aven		Landahari ada marah marah marah marah ada ada ada ada ada ada ada ada ada a	
L2 X x	XXX □ HEADER TILT □ XXX □ HEADER FLOAT □ XXX □ STOP & EXIT □	switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor.	
L1 Cx	X X II C A L I B R A T I N G F L O A T X X II P R E S S F L T + T O S T A R T	The display will indicate the sensor being calibrated. The operator will be prompted to press the float (+) and HOLD will flash until the system has completed reading in the signal with	
L2 X x	X X X	the header float fully extended. HOLD will change to DONE (with buzze	
L2 X x	X X II F L O A T SENSOR CAL X X II P R E S S F L O A T (-)	When the header float (+) is done, the CDM will prompt the user to press the header float (-). COMPLETE (with buzzer) will flash	
L2 X x	X X II CALIBRATING FLOAT X X II FLOAT (-) HOLD X X II HDR FLOAT COMPLETE	on the screen for 2 seconds when the calibration is finished.	
L2 X x	XXX TO CALIBRATE SELECT XXX ← HEADER HEIGHT ← XXX ← HEADER TILT ←	Select any of the sensors by using the turn signal switches to cycle through the choices. Pressing SELECT will take the operator to the calibration menu for that particular sensor. NO is	
Li XX	XXII CAL? CAL? COOLYES	the default for EXIT CAL?. If "NO" then jump to: T.O. C.A.L.I.B.R.A.T.E. S.E.L.E.C.T.	
L1 C x x x D A	GNOSTIC MODE?	If "NO" then jump to: SETUP?	
	X X II V I EW ERROR CODES?	ENTER SENSOR SETUP?	
L.	>L1 Cxxx VIEW WINDRWR CO	DES? If "NO" then jump to: VIEW ENGINE CODES?	
	L1	with the code #, Exxx, engine hours and number	
	L1 2 1 2 3 0 . 5 HRS 1 2 3 L2 E 7 1 LOW HYDRAULIC O		
	L1 CXXXII EXIT WINDRWR CO	If "NO" then jump to the first error code logged.	
	L1 Cxxx VIEW ENGINE COD L2 Xxxx C NO/YES	EXIT ERROR CODES?	
	L2	O D E S The last 10 distinct error codes are stored.	
	L1 C x x x E X T E N G N E C O D L2 X x x x (logged.	
	L1 C x x x E X T E R R O R C O D E L2 X x x x (= N O / Y E S	S? If "NO" then jump to: VIEW WINDRWR CODES?	
	X X II ENTER SENSOR SETUP?	READ SENSOR INPUTS?	
<u></u>	L1 Cxxx KNIFE SPEED SEN Xxxx C ENABLE / DISAB		
	L1 C X X X HEADER HT SENSO L2 X X X X (ENABLE / DISAB	R be used to disable a failed sensor to eliminate L E ⇔ false or erratic display readings.	
	L1 Cxxx HEADER TILT SEN L2 Xxxx (ENABLE / DISAB	Without "SELECT" is pressed the program oper to	
	L1 Cxxx HEADER FLOAT SE L2 Xxxx ENABLE / DISAB	N S O R the EXIT SENSOR SETUP? menu selection.	
	L1 C x x x O V E R L O A D PRESSUL2 X x x x (E N A B L E / D I S A B	LEC	
	L1 C x x x H Y D O I L T E M P S E L2 X x x x	the Sensata oil temp. sensor.	
14 1 7	L1	KNIFE SPEED SENSOR	
	(x x ←	If "NO" then jump to: A C T I V A T E F U N C T I O N S ?	
	L1	5 9 V For diagnostic purposes each sensors input	
	L2 X X X X II H D R A N G L E 1. L1 C X X X II S E N S O R I N P U T	8 4 V how each sensor is operating and if the proper output voltages are being received by the control	
	L2	8 4 V	
	L2 X X X X II K N I F E S P E E D 1 2 L1 C X X X II S E N S O R I N P U T	3 H Z	
	L2 X X X II WHEEL SPEED 12 L1 C X X X II SENSOR INPUT	3 H Z	
	L2 X X X X II H Y D O I L T E M P 1 .	0 0 V the EXIT READ SENSORS? menu selection.	
	L2 X x x x II (NO / YES		
	L1 Cxxx SENSOR INPUT L2 Xxxx HDR HEIGHT SE	N S O R If a sensor has been disabled "SENSOR" will be flashing in the area where the input reading	
	L1 Cxxx SENSOR INPUT L2 Xxxx HDR ANGLE SE	would have been.	
	L1 C x x x II S E N S O R I N P U T	← □ If a sensor has been disabled "SENSOR" will be	





B. M155, DETAILED PROGRAMMING INSTRUCTIONS

(Ignition ON / Engine Running or Not / Header Disengaged).


(Press PROGRAM and SELECT on CDM to enter programming mode).


(If necessary, refer to the M Series Windrower Operator's Manual for programming to specific crop types and conditions).











Form 169242 **106** Revision H


C. M105 DETAILED PROGRAMMING INSTRUCTIONS


(Ignition ON / Engine Running or Not / Header Disengaged).


(Press **PROGRAM** and **SELECT** on CDM to enter programming mode).


(If necessary, refer to the M Series Windrower Operator's Manual for programming to specific crop types and conditions).











Form 169242 111 Revision H

001735

STEP 32. PERFORM HYDRAULIC PURGE

The purge cycle allows for low flow and pressure staging of the pumps when running up a new windrower with all the lines and filters empty. This has been performed at the factory, but is recommended that it be repeated when the windrower has been disassembled for shipping and then reassembled. The header <u>must</u> be attached to the windrower.



CAUTION

Check to be sure all bystanders have cleared the area.

- a. Start the engine. Refer to STEP 23.
- b. Ensure the M105 and M155 Windrower CDM is programmed for either the A Series auger header, or the D Series draper header. Program the M205 Windrower CDM for the R Series rotary header.

IMPORTANT

Do **NOT** engage the header drive.



 Simultaneously press the PROGRAM and SELECT buttons to bring up the TRACTOR SETUP screen.



d. Push the SELECT button several times until the DIAGNOSTIC MODE screen is displayed.



- e. Highlight YES with the ARROW buttons, and then press the SELECT button.
- f. Press SELECT until the ACTIVATE FUNCTIONS screen appears.
- g. Highlight YES with the ARROW buttons, and press SELECT.



- h. Press SELECT until ACTIVATE HYD PURGE is displayed.
- Highlight YES with the ARROW buttons, and press SELECT. The TO ACTIVATE PURGE PRESS AND HOLD message appears.



j. Press and hold the RIGHT ARROW button to activate and run the purge cycle until the purge is complete (approximately 1 minute). Release the ARROW button at any time to stop the cycle.



- k. Message PURGE CYCLE ENDED appears when cycle is complete. Release the ARROW button.
- I. Press PROGRAM button to return to operating screens.

STEP 33. PERFORM PRE-DELIVERY CHECKS




WARNING

Stop windrower engine and remove key before making adjustments to machine. A child or even a pet could engage the drive.

- a. Perform the final checks and adjustments as listed on the Pre-Delivery Checklist (yellow sheet attached to back of instruction), to ensure the machine is field-ready. Refer to the following pages for detailed instructions as indicated on the Checklist.
- b. The completed Checklist should be retained either by the Operator or the Dealer.

A. FINAL DRIVE LUBRICANT LEVEL



- a. Rotate wheel so that one of the plugs is horizontally aligned with the center of the hub.
- b. Remove the plug. The oil should be visible through the hole, or slightly running out.

B. TIRE PRESSURES AND BALLAST REQUIREMENTS

I.TIRE PRESSURES

Measure tire pressure with a gauge:

Bar: 32 psi (221 kPa)
Turf: 20 psi (138 kPa)
Caster: 10 psi (69 kPa)

II. BALLAST REQUIREMENTS

Fluid ballasting of rear caster tires is recommended to provide adequate machine stability when using large headers on the windrower.

Also, the stability of machine varies with different attachments, windrower options, terrain and Operator's driving technique.

Ballast capability per tire is at a maximum fill of 75%, or when fluid is level with valve stem when the stem is positioned at the "12 o'clock" position.

Fluid can be added to any level up to maximum fill, and always add an equal amount of fluid on both sides.


TIRE SIZE	FLUID <u>PER</u> TIRE AT 75% FILL U.S. Gal. (Liters)	TOTAL WEIGHT OF <u>BOTH</u> TIRES lb (kg) *
7.5 X 16	10 (38)	200 (91)
10 X 16	18 (69)	380 (170)
16.5 X 16.1	41 (158)	830 (377)

^{*} Weights are given for typical calcium chloride and water mixtures. Weight is reduced by 20% if only water is used (for areas that do not require anti-freeze protection).


	HEADER DESCRIPTION		RECOMMENDED BALLAST					
APPLICABLE	HEADER DESCRIPTION		RECOMMENDED	LEVEL GROUND HILLS				
WINDROWER			TIRE SIZE	PER TIRE	BOTH TIRES	PER TIRE	BOTH TIRES	
	TYPE	SIZE		U.S. Gal. (Liters)	lb (kg) *	U.S. Gal. (Liters)	lb (kg) *	
	A Series All Options	All)		
		25 FT and Down	7.5 X 16					
		30 FT SR or DR W/O Conditioner	10 X 16 16.5 X16.1		0	10 (38)	200 (91)	
M105	D. Carrier	35 FT SR						
	D Series	30 FT DR Steel Fingers and Conditioner	Level Ground: 10 X 16 16.5 X16.1	18 (69)	380 (170)	30 (115)	630 (288)	
		35 FT DR (5 or 6-Bat)	Hills: 16.5 X 16.1					
	A Series All Options	All)		
		25 FT and Down	7.5 X 16 10 X 16 16.5 X16.1		`	,		
	W/O Condi 35 FT S D Series 30 FT D Steel Fing and Condit 35 FT D (5 or 6-B	30 FT SR or DR W/O Conditioner		18 (69)	380 (170)	30 (115)	630 (288)	
		35 FT SR						
M155		30 FT DR Steel Fingers and Conditioner	Level Ground: 10 X 16 16.5 X16.1	20 (445)	(200 (200)	44 (450)	020 (277)	
		35 FT DR (5 or 6-Bat)	Hills: 16.5 X 16.1	30 (115)	630 (288)	41 (158)	830 (377)	
		40 FT	16.5 X 16.1					
	R Series All Options	13 FT	7.5 X 16 10 X 16 16.5 X16.1	0)		
	A Series All Options	All			()		
	D Series	25 FT and Down	7.5 X 16 10 X 16 16.5 X16.1					
M205		30 FT SR or DR W/O Conditioner		18 (69)	380 (170)	30 (115)	630 (288)	
		35 FT SR						
		30 FT DR Steel Fingers and Conditioner	Level Ground: 10 X 16 16.5 X16.1	30 (115)	630 (288)	41 (158)	830 (377)	
		35 FT DR (5 or 6-Bat	Hills: 16.5 X 16.1					
		40 FT	16.5 X 16.1					
	R Series All Options	All	7.5 X 16 10 X 16 16.5 X16.1		()		

 $^{^{\}star}$ If only water is used, increase volume of water by 20% (up to maximum allowable fill per tire) to compensate.

C. ENGINE AIR INTAKE




M205




M155, M105

- a. Check that air cleaner cap is firmly attached, and that latches and clamps are secure.
- b. Check constant torque spring clamp (A) at back of air cleaner (M155, M105).




c. Constant torque spring type clamps (A) and (C) should be tightened to achieve gap as shown.




M205

d. Check constant torque clamps (B) on charge air cooling duct connection at turbocharger inlet (M205). Constant torque type clamps (B) should be tightened to achieve gap as shown.




e. Check constant torque clamps (C) on charge air cooling duct connections at turbocharger outlet and engine air intake. Clamps (C) should be tightened to achieve gap as shown opposite.

D. HYDRAULIC OIL LEVEL



M105

a. For M105: Turn filler cap counterclockwise to loosen bung, and remove dipstick.



M205, M155

b. For M205, M155: Turn filler cap counterclockwise to unlock cap, and remove dipstick.




- c. Check that level is between LOW and FULL marks.
- d. Re-install dipstick, and turn clockwise to tighten/lock.

E. FUEL SEPARATOR




- a. Place a container under the filter drain.
- b. Turn drain valve by hand 1-1/2 to 2 turns counterclockwise, until draining occurs.
- c. Drain the filter sump of water and sediment, until clear fuel is visible. Clean as necessary.
- d. Turn the valve clockwise to close the drain.
- e. Safely dispose of fluid in container.

F. ENGINE COOLANT




- a. Check the coolant level in the coolant recovery tank. Tank should be at least one-half full.
- b. Check coolant concentration in the radiator.
 Coolant shall be rated for temperatures of -30°F (-34°C).

G. GEAR BOX LUBRICANT LEVEL



- a. Remove plug (A). The lubricant should be visible through the hole, or slightly running out.
- b. Replace plug, and tighten.

H. A/C COMPRESSOR BELT



a. Tension on A/C compressor belt should be such that a force of 8–12 lbf (35–55 N) deflects the belt 3/16 inch (5 mm) at mid-span.

I.PERFORM SAFETY SYSTEM CHECKS

Ensure battery main disconnect switch is switched to POWER ON position. Refer to Section J. OPERATIONAL CHECKS.

A properly functioning system should operate as follows:

- The starter should engage <u>ONLY</u> when the GSL is in N-DETENT, the steering wheel is locked in the CENTER position, and the HEADER DRIVE switch is in the OFF position.
- Under the above conditions, the brake should engage, and the machine should not move after engine start-up.
- The steering wheel should not lock with the engine running, and the GSL is out of the N-DETENT.
- The machine should not move with the engine running, and with the steering wheel still centered, when the GSL is pulled straight out of N-DETENT (NOT in forward or reverse).

If the system does not function as described above, refer to the Technical Service Manual.




CAUTION

Check to be sure all bystanders have cleared the area.

a. With the engine shut down and the HEADER DRIVE switch engaged, try to start the engine. The CDM will display "HEADER ENGAGED" on the upper line, and "DISENGAGE HEADER' on the lower line.

If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.

- b. With the engine shut down, do the following:
 - 1. Open engine compartment hood.



- Pry the steering interlock away from pintle arms by inserting a wedge or pry bar between one of the interlock channels and pintle arm.
- 3. Insert a wood block approximately 3/4 inch (19 mm) thick, between the other channel and pintle arm, so that the interlock channel is clear of the pintle arm.
- 4. Turn the steering wheel off center, and move the GSL in N-DETENT.
- 5. Try to start the engine. The CDM will flash "CENTER STEERING", accompanied by a short beep with each flash, and the engine should not turn over.

If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.


- 6. Remove key.
- 7. Remove wood block inserted at Step 3. above, and close hood.
- c. With the engine shut down, steering wheel centered, and the GSL in NEUTRAL but not in N-DETENT:
 - Try to start the engine. The CDM will flash "CENTER STEERING" on the upper line, and "PLACE GSL INTO N" on the lower line accompanied by a short beep with each flash, and the engine should not turn over.

If the engine turns over, the system requires adjustment. Refer to the Technical Service Manual.

- d. **M155 and M205 ONLY**: With the engine shut down, steering wheel centered, GSL in N-DETENT, and Operator's station not locked:
 - Try to start the engine. Engine will crank but will not start. The CDM will display "SEAT BASE NOT LOCKED".


If engine starts, the system requires adjustment. Refer to the Technical Manual.

J. OPERATIONAL CHECKS



M205, M155

M205, M155: A battery main disconnect switch is located on the RH (cab-forward) frame rail, behind the maintenance platform, and can be accessed by moving the platform.



M105: A battery main disconnect switch is located on the LH frame rail on the battery tray, and can be accessed by raising the engine compartment hood.

Ensure switch is switched to POWER ON position.

I. ENGINE WARNING LIGHTS

- a. Turn ignition key to RUN position.
- b. Single loud tone sounds, and engine warning lights illuminate.

II. START ENGINE

Refer to STEP 23. START ENGINE, and then proceed as follows:

a. The brakes should engage, and the machine should not move after engine start-up.



M155, M205 SHOWN - M105 SIMILAR

- Ensure the steering wheel is centered. Move GSL (A) straight out of N-DETENT (neither forward nor reverse). The machine should not move.
- c. With the GSL out of N-DETENT, check that the steering wheel is free to move.
- d. If the machine does not function as described above, the system requires adjustment. Refer to the Technical Service Manual.

III. ENGINE SPEED


a. Check engine rpm on CDM.

	IDLE	MAX RPM (No Load)
M105		2270–2330
M155	1100	2320–2350
M205		2250–2340

IV.GAUGES AND CDM DISPLAY



a. Check engine temperature gauge and fuel gauge are working (M205, M155 ONLY).



b. Check CDM display is working by pushing SELECT on CDM, or SELECT button on GSL.

V. ELECTRICAL

Push the SELECT button on GSL, or SELECT switch on CDM to display VOLTS. The display indicates the condition of the battery and alternator. Refer to following table.

IGNITION	ENGINE	READING	INDICATED CONDITION
		13.8–15.0	Normal.
ON Running		> 16.0 See Note.	Regulator Out of Adjustment.
	< 12.5 See Note.	Alternator Not Working, OR Regulator Out of Adjustment.	
	Shutdown	12.0	Battery Normal.

NOTE

Display flashes voltage reading with single loud tone. Repeats every 30 minutes until condition fixed.

VI.OPERATOR'S PRESENCE SYSTEM CHECKS



M155, M205 SHOWN - M105 SIMILAR

 With the windrower engine running, place the GSL (A) in NEUTRAL, and turn the steering wheel until it locks.



CAUTION

Check to be sure all bystanders have cleared the area.

- b. With everyone clear of the machine, engage HEADER DRIVE switch (B).
 - 1. After header drives are running, stand up out of the seat. In approximately 5 seconds the header should shut off.

If not, the Operator Presence System requires adjustment. Refer to Technical Manual.

NOTE

To re-start the header, move the HEADER DRIVE switch (B) to the OFF position and back to the ON position again.


- c. **M155, M205 ONLY**: With the engine running, position the GSL (A) in NEUTRAL, and in N-DETENT:
 - 1. Swivel the Operator's station, but do **NOT** lock into position.
 - Move GSL out of N-DETENT. The engine should shutdown, and the lower display will flash "LOCK SEAT BASE ---> CENTER STEERING WHEEL ---> NOT IN NEUTRAL".


- 3. Swivel and lock the Operator's station, and the display should return to normal.
- 4. If the engine does not shut down, the seat position switches require adjustment. Refer to Technical Manual.
- d. With the windrower moving at less than 5 mph (8 km/h):
 - 1. Stand up out of the seat.
 - 2. The CDM will flash "NO OPERATOR" on the upper line, and "ENGINE SHUTDOWN 5...4...3...2...1...0" on the lower line accompanied by a steady tone. At "0", the engine shuts down.
 - 3. If the engine does not shut down, the Operator Presence System requires adjustment. Refer to Technical Manual.
- e. With the windrower moving at **more than** 5 mph (8 km/h):
 - 1. Stand up out of the seat.
 - 2. The CDM beeps once, and displays "NO OPERATOR" on the lower line.
 - 3. If not, the Operator Presence System requires adjustment. Refer to Technical Manual.


VII. EXTERIOR LIGHTS

M155, M205

- a. Ensure Operator's seat is in cab-forward mode.
- b. Switch FIELD lights ON, and check that all lights are functioning as shown below:









c. Switch ROAD lights ON, and check that all lights are functioning as shown below:






FRONT: CAB-FORWARD




- d. Activate HIGH/LOW switch.
- e. Activate turn signals and hazard warning lights with switches on CDM.
- f. Turn lights OFF.

- g. Rotate Operator's seat to **engine-forward mode**.
- h. Switch ROAD lights ON, and check that all lights are functioning as shown below:






FRONT: ENGINE-FORWARD



REAR: ENGINE-FORWARD

- i. Activate HIGH/LOW switch, and check lights.
- Activate turn signals and hazard warning lights with switches on CDM, and check lights.







k. Switch beacons ON, and check that they are working properly.

M105

a. Switch FIELD lights ON, and check that all lights shown are functioning as shown below:









b. Activate HIGH/LOW switch.

c. Switch ROAD lights ON, and check that all lights shown are functioning as shown below:








- d. Activate HIGH/LOW switch.
- e. Activate turn signals and hazard warning lights with switches on CDM.





f. Switch beacons ON, and check that they are working properly.

VIII. INTERIOR LIGHTS



M155, M205 SHOWN - M105 SIMILAR

a. Switch lights ON and OFF with switches on each light. Overhead ambient light only works with ROAD/FIELD light switch ON.




b. Check gauge lights (M155, M205).

IX.A/C AND HEATER


IMPORTANT

To distribute the oil throughout the A/C system, perform the following steps whenever the machine is first started after storage for more than one week:



M155, M205


- With the engine running, turn BLOWER switch to the first position, turn TEMPERATURE CONTROL switch to maximum heating, and A/C control to OFF.
- Click A/C switch from the OFF to the ON position for one second, then back to OFF for 5 to 10 seconds. Repeat this step ten times.



M105

K. MANUALS





M105


M155, M205

The following manuals can be stored in the manual storage case behind the Operator's seat:

MODEL	OPERATOR'S MANUAL	PARTS CATALOG	QUICK CARD	ENGINE MANUAL
M105	Engl. 169552 Rus. 169553	169549	169570	
M155	Engl. 169563 Rus. 169546	169564	169565	166240
M205	Engl. 169469 Rus. 169482	169472	169475	

L. CAB INTERIOR

 Remove plastic coverings from Cab Display Module and seats, after pre-delivery check is complete.





b. Remove decal (166497) from windshield **ONLY** after machine is delivered to end user.



MacDon Industries Ltd.

680 Moray Street Winnipeg, Manitoba Canada R3J 3S3 t. (204) 885-5590 f. (204) 832-7749

MacDon Inc.

10708 N. Pomona Avenue Kansas City, Missouri United States, 64153-1924 t. (816) 891-7313 f. (816) 891-7323

MacDon Australia Pty. Ltd.

A.C.N. 079 393 721 P.O. Box 243 Suite 3, 143 Main Street Greensborough, Victoria Australia 3088 t. 03 9432 9982 f. 03 9432 9972

LLC MacDon Russia Ltd.

123317 Moscow, Russia 10 Presnenskaya nab. Block C, Floor 5, Office No. 534 Regus Business Centre t. +7 495 775 6971 direct line f. +7 495 967 7600

CUSTOMERS www.macdon.com

DEALERS www.macdonDealers.com

Trademarks of products are the marks of their respective manufacturers and/or distributors.

Printed in Canada

M Series Self-Propelled Windrower Pre-Delivery Checklist - Export

Perform these checks and adjustments prior to delivery to your Customer. The completed Checklist should be retained either by the Operator or the Dealer.



CAUTION: Carefully follow the instructions given. Be alert for safety related messages which bring your attention to hazards and unsafe practices.

Windrower Tractor Serial Number:	Ei	ngine Serial Number:	

✓	ITEM	PAGE
	Check for shipping damage or missing parts. Be sure all shipping dunnage is removed.	
	Check for loose hardware. Tighten to required torque.	10
	Check tire air pressures, and adjust as required.	114
	Check final drive hub lubricant level.	114
	Check air cleaner and clamps.	116
	Check engine coolant level and strength at reserve tank.	117
	Check hydraulic oil level, and check for leaks along lines.	117
	Check fuel separator for water and foreign material. Drain and clean as necessary. Add fuel.	117
	Check gear box lubricant level (M155, M205).	118
	Check tension of A/C compressor belt.	118
	Check machine completely lubricated.	95
	Check Neutral Interlock system.	119
	Check engine warning lights at Cab Display Module (CDM).	120
STA	ART ENGINE AND RUN TO OPERATING TEMPERATURE	62
	Check Cab Display Module (CDM) for operation.	121
	Check Operator's Presence System.	122
	Check alternator charge rate on Cab Display Module (CDM).	121
	Check fuel gauge/indicator for operation.	121
	Check air conditioning functioning properly.	127
	Check heater functioning properly.	127
	Check instrument console gauge lights (M155, M205).	126
	Check maximum (no load) engine speed at Cab Display Module (CDM).	120
	Check exterior lights for operation.	123–126
	Check interior lights for operation.	126
	Complete the Header Pre-Delivery Checklist.	
	Check that manuals are with the windrower.	128
	Check plastic coverings from cab interior removed.	128

Date Checked: Checked:	ecked by:
------------------------	-----------

Form 169242 Revision H