

# **M155E4**


## **Self-Propelled Windrower**

Unloading and Assembly Instructions  
(Container Shipments)

214739 Revision A

Original Instruction

Featuring the Dual Direction® and Ultra Glide® suspension on the M155E4.



1011662

Published in June, 2018

## Introduction

This instruction manual describes the unloading, setup, and predelivery requirements for the MacDon M155E4 Self-Propelled Windrowers shipped in containers.

**Carefully read all the material provided before attempting to unload, assemble, or use the machine.**

Retain this instruction for future reference.

### Conventions

The following conventions are used in this document: Right and left are determined from the operator's position. The front of the windrower is the side that faces the crop.



### NOTE:

Keep your MacDon publications up-to-date. The most current version can be downloaded from our Dealer-only site (<https://portal.macdon.com>) (login required).

# EC Declaration of Conformity—Windrower Lift Sling

Figure 1: EC Declaration of Conformity – Windrower Lift Sling (Page 1 of 2)

2147/72 Revision A

 <h2 style="text-align: center;">EC Declaration of Conformity</h2>	
<p>[1] <b>MacDon</b></p> <p><b>MacDon Industries Ltd.</b> 680 Moray Street, Winnipeg, Manitoba, Canada R3J 3S3</p>	<p>[4] Not Applicable</p> <p>[5] May 17, 2018</p> <p>[6] </p> <p style="text-align: right;">Christoph Martens Product Integrity</p>
<p>[2] Windrower Lift Sling</p> <p>[3] Part 163871</p>	

EN	BG	CZ	DA
<p>We, [1]</p> <p>Declare, that the product:</p> <p>Machine Type: [2]</p> <p>Name &amp; Model: [3]</p> <p>Serial Number(s): [4]</p> <p>fulfills all the relevant provisions of the Directive 2006/42/EC.</p> <p>Harmonized standards used, as referred to in Article 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Place and date of declaration: [5]</p> <p>Identity and signature of the person empowered to draw up the declaration: [6]</p> <p>Name and address of the person authorized to compile the technical file:</p> <p>Benedikt von Riedesel General Manager, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Germany) bvonriedesel@macdon.com</p>	<p>Ние, [1]</p> <p>декларираме, че следният продукт:</p> <p>Тип машина: [2]</p> <p>Наименование и модел: [3]</p> <p>Сериен номер(а) [4]</p> <p>отговаря на всички приложими разпоредби на директива 2006/42/ЕО.</p> <p>Използвани са следните хармонизирани стандарти според чл. 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Място и дата на декларацията: [5]</p> <p>Име и подпис на лицето, упълномощено да изготви декларацията: [6]</p> <p>Име и адрес на лицето, упълномощено да състави техническия файл:</p> <p>Бенедикт фон Рийдезел Управител, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Германия) bvonriedesel@macdon.com</p>	<p>My, [1]</p> <p>Prohláším, že produkt:</p> <p>Typ zařízení: [2]</p> <p>Název a model: [3]</p> <p>Sériové(á) číslo(a): [4]</p> <p>splňuje všechna relevantní ustanovení směrnice 2006/42/EC.</p> <p>Byly použity harmonizované standardy, jak je uvedeno v článku 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Místo a datum prohlášení: [5]</p> <p>Identita a podpis osoby oprávněné k vydání prohlášení: [6]</p> <p>Jméno a adresa osoby oprávněné k vyplnění technického souboru:</p> <p>Benedikt von Riedesel generální ředitel, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Německo) bvonriedesel@macdon.com</p>	<p>Vi, [1]</p> <p>erklærer, at produktet:</p> <p>Maskintype [2]</p> <p>Navn og model: [3]</p> <p>Serienummer (-numre): [4]</p> <p>Opfylder alle bestemmelser i direktiv 2006/42/EF.</p> <p>Anvendte harmoniserede standarder, som henviser til i paragraf 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Sted og dato for erklæringen: [5]</p> <p>Identitet på og underskrift fra den person, som er bemyndiget til at udarbejde erklæringen: [6]</p> <p>Navn og adresse på den person, som er bemyndiget til at udarbejde den tekniske fil:</p> <p>Benedikt von Riedesel Direktør, MacDon Europe GmbH Hagenauer Straße 59 D-65203 Wiesbaden (Tyskland) bvonriedesel@macdon.com</p>

DE	ES	ET	FR
<p>Wir, [1]</p> <p>Erklären hiermit, dass das Produkt:</p> <p>Maschinentyp: [2]</p> <p>Name &amp; Modell: [3]</p> <p>Seriennummer (n): [4]</p> <p>alle relevanten Vorschriften der Richtlinie 2006/42/EG erfüllt.</p> <p>Harmonisierte Standards wurden, wie in folgenden Artikeln angegeben, verwendet 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Ort und Datum der Erklärung: [5]</p> <p>Name und Unterschrift der Person, die dazu befugt ist, die Erklärung auszustellen: [6]</p> <p>Name und Anschrift der Person, die dazu berechtigt ist, die technischen Unterlagen zu erstellen:</p> <p>Benedikt von Riedesel General Manager, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden bvonriedesel@macdon.com</p>	<p>Nosotros [1]</p> <p>declaramos que el producto:</p> <p>Tipo de máquina: [2]</p> <p>Nombre y modelo: [3]</p> <p>Números de serie: [4]</p> <p>cumple con todas las disposiciones pertinentes de la directriz 2006/42/EC.</p> <p>Se utilizaron normas armonizadas, según lo dispuesto en el artículo 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Lugar y fecha de la declaración: [5]</p> <p>Identidad y firma de la persona facultada para draw redactar la declaración: [6]</p> <p>Nombre y dirección de la persona autorizada para elaborar el expediente técnico:</p> <p>Benedikt von Riedesel Gerente general - MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Alemania) bvonriedesel@macdon.com</p>	<p>Meie, [1]</p> <p>deklareerime, et toode</p> <p>Seadme tüüp: [2]</p> <p>Nimi ja mudel: [3]</p> <p>Seerianumbrid: [4]</p> <p>vastab kõigile direktiivi 2006/42/EÜ asjakohastele sätetele.</p> <p>Kasutatud on järgnevald harmoniseeritud standardeid, millele on viidatud ka punktis 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Deklaratsiooni koht ja kuupäev: [5]</p> <p>Deklaratsiooni koostamiseks volitatud isiku nimi ja allkiri: [6]</p> <p>Tehnilise dokumendi koostamiseks volitatud isiku nimi ja aadress:</p> <p>Benedikt von Riedesel Peadirektor, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Saksamaal) bvonriedesel@macdon.com</p>	<p>Nous soussignés, [1]</p> <p>Déclarons que le produit :</p> <p>Type de machine : [2]</p> <p>Nom et modèle : [3]</p> <p>Numéro(s) de série : [4]</p> <p>Est conforme à toutes les dispositions pertinentes de la directive 2006/42/EC.</p> <p>Utilisation des normes harmonisées, comme indiqué dans l'Article 7(2):</p> <p style="text-align: center;">EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Lieu et date de la déclaration : [5]</p> <p>Identité et signature de la personne ayant reçu le pouvoir de rédiger cette déclaration : [6]</p> <p>Nom et adresse de la personne autorisée à constituer le dossier technique :</p> <p>Benedikt von Riedesel Directeur général, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Allemagne) bvonriedesel@macdon.com</p>

The Harvesting Specialists.

MacDon

1026190



Figure 2: EC Declaration of Conformity – Windrower Lift Sling (Page 2 of 2)

EC Declaration of Conformity			
IT	HU	LT	LV
<p>Noi, [1] Dichiariamo che il prodotto: Tipo di macchina: [2] Nome e modello: [3] Numero(i) di serie: [4] soddisfa tutte le disposizioni rilevanti della direttiva 2006/42/CE.</p> <p>Utilizzo degli standard armonizzati, come indicato nell'Articolo 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Luogo e data della dichiarazione: [5] Nome e firma della persona autorizzata a redigere la dichiarazione: [6] Nome e persona autorizzata a compilare il file tecnico: Benedikt von Riedesel General Manager, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Germania) bvonriedesel@macdon.com</p>	<p>Mi, [1] Ezennel kijelentjük, hogy a következő termék: Gép típusa: [2] Név és modell: [3] Szériaszám(ok): [4] teljesíti a következő irányelv összes vonatkozó előírásait: 2006/42/EK.</p> <p>Az alábbi harmonizált szabványok kerütek alkalmazásra a 7(2) cikkely szerint:  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>A nyilatkozattétel ideje és helye: [5] Azon személy kiléte és aláírása, aki jogosult a nyilatkozat elkészítésére: [6] Azon személy neve és aláírása, aki felhatalmazott a műszaki dokumentáció összeállítására: Benedikt von Riedesel Vezérigazgató, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Németország) bvonriedesel@macdon.com</p>	<p>Mes, [1] Pareiškiamo, kad šis produktas: Mašinos tipas: [2] Pavadinimas ir modelis: [3] Serijos numeris (-iai): [4] atitinka taikomus reikalavimus pagal Direktyvą 2006/42/EB.</p> <p>Naudojami harmonizuoti standartai, kai nurodoma straipsnyje 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Deklaracijos vieta ir data: [5] Asmens tapatybės duomenys ir parašas asmens, įgijolito sudaryti šią deklaraciją: [6] Vardas ir pavardė asmens, kuris įgaliotas sudaryti šį techninį failą: Benedikt von Riedesel Generalinis direktorius, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Vokietija) bvonriedesel@macdon.com</p>	<p>Mēs, [1] Deklarējam, ka produkts: Mašīnas tips: [2] Nosaukums un modelis: [3] Sērijas numurs(-i): [4] Atbilst visām būtiskajām Direktīvas 2006/42/EK prasībām.</p> <p>Piemēroti šādi saskaņotie standarti, kā minēts 7. panta 2. punktā:  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Deklarācijas parakstīšanas vieta un datums: [5] Tās personas vārds, uzvārds un paraksts, kas ir pilnvarota sagatavot šo deklarāciju: [6] Tās personas vārds, uzvārds un adrese, kas ir pilnvarota sastādīt tehnisko dokumentāciju: Benedikts fon Rīdizels Generāldirektors, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Vācija) bvonriedesel@macdon.com</p>
<p>Wij, [1] Verklaren dat het product: Machinetype: [2] Naam en model: [3] Serienummer(s): [4] voldoet aan alle relevante bepalingen van de Richtlijn 2006/42/EC.</p> <p>Geharmoniseerde normen toegepast, zoals vermeld in Artikel 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Plaats en datum van verklaring: [5] Naam en handtekening van de bevoegde persoon om de verklaring op te stellen: [6] Naam en adres van de geautoriseerde persoon om het technisch dossier samen te stellen: Benedikt von Riedesel Algemeen directeur, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Duitsland) bvonriedesel@macdon.com</p>	<p>My nizej podpisani, [1] Oświadczamy, że produkt: Typ urządzenia: [2] Nazwa i model: [3] Numer seryjny/numery seryjne: [4] spełnia wszystkie odpowiednie przepisy dyrektywy 2006/42/WE.</p> <p>Zastosowaliśmy następujące (zharmonizowane) normy zgodnie z artykułem 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Data i miejsce oświadczenia: [5] Imię i nazwisko oraz podpis osoby upoważnionej do przygotowania deklaracji: [6] Imię i nazwisko oraz adres osoby upoważnionej do przygotowania dokumentacji technicznej: Benedikt von Riedesel Dyrektor generalny, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Niemcy) bvonriedesel@macdon.com</p>	<p>Nós, [1] Declaramos, que o produto: Tipo de máquina: [2] Nome e Modelo: [3] Número(s) de Série: [4] cumpre todas as disposições relevantes da Directiva 2006/42/CE.</p> <p>Normas harmonizadas aplicadas, conforme referido no Artigo 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Local e data da declaração: [5] Identidade e assinatura da pessoa autorizada a elaborar a declaração: [6] Nome e endereço da pessoa autorizada a compilar o ficheiro técnico: Benedikt von Riedesel Gerente Geral, MacDon Europa Ltda. Hagenauer Straße 59 65203 Wiesbaden (Alemanha) bvonriedesel@macdon.com</p>	<p>Noi, [1] Declarăm, că următorul produs: Tipul mașinii: [2] Denumirea și modelul: [3] Număr (numere) serie: [4] corespunde tuturor dispozițiilor esențiale ale directivei 2006/42/EC.</p> <p>Au fost aplicate următoarele standarde armonizate conform articolului 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Data și locul declarației: [5] Identitatea și semnătura persoanei împuternicite pentru întocmirea declarației: [6] Numele și semnătura persoanei autorizate pentru întocmirea cărții tehnice: Benedikt von Riedesel Manager General, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Germania) bvonriedesel@macdon.com</p>
<p>Mi, [1] Izjavljujemo da proizvod Tip mašine: [2] Naziv i model: [3] Serijski broj(ovi): [4] Ispunjava sve relevantne odredbe direktive 2006/42/EC.</p> <p>Korišćeni su usklađeni standardi kao što je navedeno u članu 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Datum i mesto izdavanja deklaracije: [5] Identitet i potpis lica ovlašćenog za sastavljanje deklaracije: [6] Ime i adresa osobe ovlašćene za sastavljanje tehničke datoteke: Benedikt von Riedesel Generalni direktor, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemačka) bvonriedesel@macdon.com</p>	<p>Vi, [1] Intygat att produkten: Maskintyp: [2] Namn och modell: [3] Serienummer: [4] uppfyller alla relevanta villkor i direktivet 2006/42/EG.</p> <p>Harmonierade standarder används, såsom anges i artikel 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Plats och datum för intyget: [5] Identitet och signatur för person med befogenhet att upprätta intyget: [6] Namn och adress för person behörig att upprätta den tekniska dokumentationen: Benedikt von Riedesel Administrativ chef, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Tyskland) bvonriedesel@macdon.com</p>	<p>Mi, [1] izjavljamo, da izdelek: Vrsta stroja: [2] Ime in model: [3] Serijska/-e številka/-e: [4] ustreza vsem zadevnim določbam Direktive 2006/42/ES.</p> <p>Uporabljeni usklajeni standardi, kot je navedeno v členu 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Kraj in datum izjave: [5] Istovetnost in podpis osebe, pooblaščenega za pripravo izjave: [6] Ime in naslov osebe, pooblaščenega za pripravo tehnične datoteke: Benedikt von Riedesel Generalni direktor, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemčija) bvonriedesel@macdon.com</p>	<p>My, [1] týmto prehlasujeme, že tento výrobok: Typ zariadenia: [2] Názov a model: [3] Výrobné číslo: [4] spĺňa príslušné ustanovenia a základné požiadavky smernice č. 2006/42/ES.</p> <p>Použitá harmonizované normy, ktoré sa uvádzajú v článku č. 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009</p> <p>Miesto a dátum prehlásenia: [5] Meno a podpis osoby oprávnenej vypracovať toto prehlásenie: [6] Meno a adresa osoby oprávnenej zostaviť technický súbor: Benedikt von Riedesel Generálny riaditeľ MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemecko) bvonriedesel@macdon.com</p>

# EC Declaration of Conformity—Windrower Assembly Supports

Figure 3: EC Declaration of Conformity – Windrower Assembly Supports (Page 1 of 2)

2147/1 Revision A

 <h2 style="text-align: center;">EC Declaration of Conformity</h2>	
<p>[1] <b>MacDon</b>                  MacDon Industries Ltd.                  680 Moray Street,                  Winnipeg, Manitoba, Canada                  R3J 3S3</p>	<p>[4] Not Applicable</p> <p>[5] May 17, 2018</p> <p>[6]                   Christoph Martens                  Product Integrity</p>
<p>[2] Windrower Assembly Supports</p> <p>[3] Part 163655</p>	

EN	BG	CZ	DA
<p>We, [1]                      Declare, that the product:                      Machine Type: [2]                      Name &amp; Model: [3]                      Serial Number(s): [4]                      fulfils all the relevant provisions of the Directive 2006/42/EC.                      Harmonized standards used, as referred to in Article 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Place and date of declaration: [5]                      Identity and signature of the person empowered to draw up the declaration: [6]                      Name and address of the person authorized to compile the technical file:                      Benedikt von Riedesel                      General Manager, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Germany)                      bvonriedesel@macdon.com</p>	<p>Ние, [1]                      декларираме, че следният продукт:                      Тип машина: [2]                      Наименование и модел: [3]                      Серийен номер(а) [4]                      отговаря на всички приложими разпоредби на директива 2006/42/ЕО.                      Използвани са следните хармонизирани стандарти според чл. 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Место и дата на декларацията: [5]                      Име и подпис на лицето, изпълнено да изготви декларацията: [6]                      Име и адрес на лицето, изпълнено да състави техническия файл:                      Бенедикт фон Райдезел                      Управител, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Германия)                      bvonriedesel@macdon.com</p>	<p>My, [1]                      Prohlašujeme, že produkt:                      Typ zařízení: [2]                      Název a model: [3]                      Sériové(á) číslo(a): [4]                      splňuje všechna relevantní ustanovení směrnice 2006/42/EC.                      Byly použity harmonizované standardy, jak je uvedeno v článku 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Místo a datum prohlášení: [5]                      Identita a podpis osoby oprávněné k vydání prohlášení: [6]                      Jméno a adresa osoby oprávněné k vyplnění technického souboru:                      Benedikt von Riedesel                      generální ředitel, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Německo)                      bvonriedesel@macdon.com</p>	<p>Vi, [1]                      erklærer, at produktet:                      Maskintype [2]                      Navn og model: [3]                      Serienummer (-numre): [4]                      Opfylder alle bestemmelser i direktiv 2006/42/EF.                      Anvendte harmoniserede standarder, som henviser til i paragraf 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Sted og dato for erklæringen: [5]                      Identitet på og underskrift fra den person, som er bemyndiget til at udarbejde erklæringen: [6]                      Navn og adresse på den person, som er bemyndiget til at udarbejde den tekniske fil:                      Benedikt von Riedesel                      Direktør, MacDon Europe GmbH                      Hagenauer Straße 59                      D-65203 Wiesbaden (Tyskland)                      bvonriedesel@macdon.com</p>

DE	ES	ET	FR
<p>Wir, [1]                      Erklären hiermit, dass das Produkt:                      Maschinentyp: [2]                      Name &amp; Modell: [3]                      Seriennummer (n): [4]                      alle relevanten Vorschriften der Richtlinie 2006/42/EG erfüllt.                      Harmonisierte Standards wurden, wie in folgenden Artikeln angegeben, verwendet 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Ort und Datum der Erklärung: [5]                      Name und Unterschrift der Person, die dazu befugt ist, die Erklärung auszustellen: [6]                      Name und Anschrift der Person, die dazu berechtigt ist, die technischen Unterlagen zu erstellen:                      Benedikt von Riedesel                      General Manager, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden                      bvonriedesel@macdon.com</p>	<p>Nosotros [1]                      declaramos que el producto:                      Tipo de máquina: [2]                      Nombre y modelo: [3]                      Números de serie: [4]                      cumple con todas las disposiciones pertinentes de la directriz 2006/42/EC.                      Se utilizaron normas armonizadas, según lo dispuesto en el artículo 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Lugar y fecha de la declaración: [5]                      Identidad y firma de la persona facultada para draw redactar la declaración: [6]                      Nombre y dirección de la persona autorizada para elaborar el expediente técnico:                      Benedikt von Riedesel                      Gerente general - MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Alemania)                      bvonriedesel@macdon.com</p>	<p>Meie, [1]                      deklareerime, et toode                      Seadme tüüp: [2]                      Nimi ja mudel: [3]                      Seerianumbrid: [4]                      vastab kõigile direktiivi 2006/42/EÜ asjakohastele sätetele.                      Kasutatud on järgnevald harmoniseeritud standardeid, millele on viidatud ka punktis 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Deklaratsiooni koht ja kuupäev: [5]                      Deklaratsiooni koostamiseks volitatud isiku nimi ja allkiri: [6]                      Tehnilise dokumendi koostamiseks volitatud isiku nimi ja aadress:                      Benedikt von Riedesel                      Peadirektor, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Saksamaa)                      bvonriedesel@macdon.com</p>	<p>Nous soussignés, [1]                      Déclarons que le produit :                      Type de machine : [2]                      Nom et modèle : [3]                      Numéro(s) de série : [4]                      Est conforme à toutes les dispositions pertinentes de la directive 2006/42/EC.                      Utilisation des normes harmonisées, comme indiqué dans l'Article 7(2):                      EN ISO 4254-1:2013                      EN ISO 4254-7:2009                      Lieu et date de la déclaration : [5]                      Identité et signature de la personne ayant reçu le pouvoir de rédiger cette déclaration : [6]                      Nom et adresse de la personne autorisée à constituer le dossier technique :                      Benedikt von Riedesel                      Directeur général, MacDon Europe GmbH                      Hagenauer Straße 59                      65203 Wiesbaden (Allemagne)                      bvonriedesel@macdon.com</p>

The Harvesting Specialists.

MacDon

1026192

Figure 4: EC Declaration of Conformity – Windrower Assembly Supports (Page 2 of 2)

EC Declaration of Conformity			
IT	HU	LT	LV
<p>Noi, [1] Dichiariamo che il prodotto: Tipo di macchina: [2] Nome e modello: [3] Numero(i) di serie: [4] soddisfa tutte le disposizioni rilevanti della direttiva 2006/42/CE.  Utilizzo degli standard armonizzati, come indicato nell'Articolo 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Luogo e data della dichiarazione: [5] Nome e firma della persona autorizzata a redigere la dichiarazione: [6] Nome e persona autorizzata a compilare il file tecnico: Benedikt von Riedesel General Manager, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Germania) bvonriedesel@macdon.com</p>	<p>Mi, [1] Ezennel kijelentjük, hogy a következő termék: Gép típusa: [2] Név és modell: [3] Szériaszám(ok): [4] teljesíti a következők iránylevél összes vonatkozó előírásait: 2006/42/EK.  Az alábbi harmonizált szabványok kerütek alkalmazásra a 7(2) cikkely szerint:  EN ISO 4254-1:2013 EN ISO 4254-7:2009  A nyilatkozattétel ideje és helye: [5] Azon személy kiléte és aláírása, aki jogosult a nyilatkozat elkészítésére: [6] Azon személy neve és aláírása, aki felhatalmazott a műszaki dokumentáció összeállítására: Benedikt von Riedesel Vezérigazgató, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Németország) bvonriedesel@macdon.com</p>	<p>Mes, [1] Pareiškiamė, kad šis produktas: Mašinos tipas: [2] Pavadinimas ir modelis: [3] Serijos numeris (-iai): [4] atitinka taikomus reikalavimus pagal Direktyvą 2006/42/EB.  Naudojami harmonizuoti standartai, kai nurodoma straipsnyje 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Deklaracijos vieta ir data: [5] Asmens tapatybės duomenys ir parašas asmens, įgijolito sudaryti šią deklaraciją: [6] Vardas ir pavardė asmens, kuris įgaliotas sudaryti šį techninį failą: Benedikt von Riedesel Generalinis direktorius, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Vokietija) bvonriedesel@macdon.com</p>	<p>Mēs, [1] Deklarējam, ka produkts: Mašīnas tips: [2] Nosaukums un modelis: [3] Sērijas numurs(-i): [4] Atbilst visām būtiskajām Direktīvas 2006/42/EK prasībām.  Piemēroti šādi saskaņotie standarti, kā minēts 7. panta 2. punktā:  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Deklarācijas parakstīšanas vieta un datums: [5] Tās personas vārds, uzvārds un paraksts, kas ir pilnvarota sagatavot šo deklarāciju: [6] Tās personas vārds, uzvārds un adrese, kas ir pilnvarota sastādīt tehnisko dokumentāciju: Benedikts fon Rīdizels Generāldirektors, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Vācija) bvonriedesel@macdon.com</p>
<p>Wij, [1] Verklaren dat het product: Machinetype: [2] Naam en model: [3] Serienummer(s): [4] voldoet aan alle relevante bepalingen van de Richtlijn 2006/42/EC.  Geharmoniseerde normen toegepast, zoals vermeld in Artikel 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Plaats en datum van verklaring: [5] Naam en handtekening van de bevoegde persoon om de verklaring op te stellen: [6] Naam en adres van de geautoriseerde persoon om het technisch dossier samen te stellen: Benedikt von Riedesel Algemeen directeur, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Duitsland) bvonriedesel@macdon.com</p>	<p>My nizej podpisani, [1] Oświadczamy, że produkt: Typ urządzenia: [2] Nazwa i model: [3] Numer seryjny/numery seryjne: [4] spełnia wszystkie odpowiednie przepisy dyrektywy 2006/42/WE.  Zastosowaliśmy następujące (zharmonizowane) normy zgodnie z artykułem 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Data i miejsce oświadczenia: [5] Imię i nazwisko oraz podpis osoby upoważnionej do przygotowania deklaracji: [6] Imię i nazwisko oraz adres osoby upoważnionej do przygotowania dokumentacji technicznej: Benedikt von Riedesel Dyrektor generalny, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Niemcy) bvonriedesel@macdon.com</p>	<p>Nós, [1] Declarámos, que o produto: Tipo de máquina: [2] Nome e Modelo: [3] Número(s) de Série: [4] cumpre todas as disposições relevantes da Directiva 2006/42/CE.  Normas harmonizadas aplicadas, conforme referido no Artigo 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Local e data da declaração: [5] Identidade e assinatura da pessoa autorizada a elaborar a declaração: [6] Nome e endereço da pessoa autorizada a compilar o ficheiro técnico: Benedikt von Riedesel Gerente Geral, MacDon Europa Ltda. Hagenauer Straße 59 65203 Wiesbaden (Alemanha) bvonriedesel@macdon.com</p>	<p>Noi, [1] Declarăm, că următorul produs: Tipul mașinii: [2] Denumirea și modelul: [3] Număr (numere) serie: [4] corespunde tuturor dispozițiilor esențiale ale directivei 2006/42/EC.  Au fost aplicate următoarele standarde armonizate conform articolului 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009  Data și locul declarației: [5] Identitatea și semnătura persoanei împuternicite pentru întocmirea declarației: [6] Numele și semnătura persoanei autorizate pentru întocmirea cărții tehnice: Benedikt von Riedesel Manager General, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Germania) bvonriedesel@macdon.com</p>
<p>Mi, [1] Izjavljujemo da proizvod Tip mašine: [2] Naziv i model: [3] Serijski broj(ovi): [4] Ispunjava sve relevantne odredbe direktive 2006/42/EC. Korišćeni su usklađeni standardi kao što je navedeno u članu 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009 Datum i mesto izdavanja deklaracije: [5] Identitet i potpis lica ovlašćenog za sastavljanje deklaracije: [6] Ime i adresa osobe ovlašćene za sastavljanje tehničke datoteke: Benedikt von Riedesel Generalni direktor, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemačka) bvonriedesel@macdon.com</p>	<p>Vi, [1] Intygat att produkten: Maskintyp: [2] Namn och modell: [3] Serienummer: [4] uppfyller alla relevanta villkor i direktivet 2006/42/EG. Harmonierade standarder används, såsom anges i artikel 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009 Plats och datum för intyget: [5] Identitet och signatur för person med befogenhet att upprätta intyget: [6] Namn och adress för person behörig att upprätta den tekniska dokumentationen: Benedikt von Riedesel Administrativ chef, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Tyskland) bvonriedesel@macdon.com</p>	<p>Mi, [1] izjavljamo, da izdelek: Vrsta stroja: [2] Ime in model: [3] Serijska/-e številka/-e: [4] ustreza vsem zadevnim določbam Direktive 2006/42/ES. Uporabljeni usklajeni standardi, kot je navedeno v členu 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009 Kraj in datum izjave: [5] Istovetnost in podpis osebe, pooblaščenega za pripravo izjave: [6] Ime in naslov osebe, pooblaščenega za pripravo tehnične datoteke: Benedikt von Riedesel Generalni direktor, MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemčija) bvonriedesel@macdon.com</p>	<p>My, [1] týmto prehlasujeme, že tento výrobok: Typ zariadenia: [2] Názov a model: [3] Výrobné číslo: [4] spĺňa príslušné ustanovenia a základné požiadavky smernice č. 2006/42/ES. Použitá harmonizované normy, ktoré sa uvádzajú v článku č. 7(2):  EN ISO 4254-1:2013 EN ISO 4254-7:2009 Miesto a dátum prehlásenia: [5] Meno a podpis osoby oprávnenej vypracovať toto prehlásenie: [6] Meno a adresa osoby oprávnenej zostaviť technický súbor: Benedikt von Riedesel Generálny riaditeľ MacDon Europe GmbH Hagenauer Straße 59 65203 Wiesbaden (Nemecko) bvonriedesel@macdon.com</p>

## List of Revisions

The following list provides an account of major changes from the previous version of this document.

Summary of Change	Location
Added D1 and R1 headers.	Throughout
Deleted diesel exhaust fluid display module topic. Topic remains in Operator's Manual.	—
Added new EC Declaration of Conformity documents.	<ul style="list-style-type: none"> <li>• <i>EC Declaration of Conformity—Windrower Lift Sling, page ii</i></li> <li>• <i>EC Declaration of Conformity—Windrower Assembly Supports, page iv</i></li> </ul>
Added topics to safety chapter.	<ul style="list-style-type: none"> <li>• <i>1.3 Tire Safety, page 4</i></li> <li>• <i>1.5 Welding Precautions, page 6</i></li> <li>• <i>1.6 Engine Safety, page 7</i></li> <li>• <i>1.6.1 High-Pressure Rail, page 7</i></li> <li>• <i>1.6.2 Engine Electronics, page 8</i></li> </ul>
Added image of shipping support tube.	<i>2.5 Removing Platforms, page 22</i>
Added lifting warning.	<i>2.7 Removing Leg Assemblies, page 25</i>
Added image of battery shutoff switch.	<i>3.18 Installing AM/FM Radio, page 74</i>
Rearranged the order of the instruction to ensure predelivery fluid checks happen before starting the windrower engine.	<i>Performing Predelivery Checks, page 78</i>
Updated Recommended Ballast table.	<i>3.2.2 Adding Tire Ballast, page 80</i>
Added topic.	<i>3.6 Checking Engine Oil Level, page 86</i>
<ul style="list-style-type: none"> <li>• Added caution statement to ensure park breaks are engaged.</li> <li>• Added step about diesel exhaust fluid levels.</li> <li>• Added seat position lock illustration.</li> </ul>	<i>3.11 Starting Engine, page 92</i>
Reorganized topics within the chapter.	<i>4.1 Cab Display Module (CDM) Configuration, page 103</i>
Updated cab display module (CDM) and windrower control module (WCM) software.	<i>4.2 Cab Display Options, page 105</i>
Added topics to the Cab Display Module chapter.	<ul style="list-style-type: none"> <li>• <i>4.3.12 Activating the Swath Compressor, page 121</i></li> <li>• <i>4.7 Calibrating the Swath Compressor Sensor, page 145</i></li> </ul>
Updated topic.	<i>5.1 Checking Safety System, page 169</i>
Moved attaching headers chapter after assembly and inspection procedures.	<i>6.1 Attaching Headers, page 187</i>



<b>Summary of Change</b>	<b>Location</b>
Added note about drive tires.	<i>6.1.4 Attaching an R/R1 Series Header, page 210</i>
Added lubricants and fluids topic.	<i>7.4 Lubricants, Fluids, and System Capacities, page 238</i>
Added fuel specifications topic.	<i>7.5 Fuel Specifications, page 240</i>



## TABLE OF CONTENTS

---

Introduction.....	i
EC Declaration of Conformity—Windrower Lift Sling.....	ii
EC Declaration of Conformity—Windrower Assembly Supports.....	iv
List of Revisions .....	vi
<b>Chapter 1: Safety .....</b>	<b>1</b>
1.1 Signal Words .....	1
1.2 General Safety.....	2
1.3 Tire Safety.....	4
1.4 Battery Safety.....	5
1.5 Welding Precautions .....	6
1.6 Engine Safety .....	7
1.6.1 High-Pressure Rail .....	7
1.6.2 Engine Electronics .....	8
1.7 Safety Signs .....	9
<b>Chapter 2: Unloading the Windrower .....</b>	<b>11</b>
2.1 Unloading Container .....	11
2.2 Moving to Assembly Area .....	12
2.2.1 Moving to Assembly Area: Crane Method.....	12
2.2.2 Moving to Assembly Area: Forklift Method.....	14
2.3 Removing Wheel and Step Assembly .....	16
2.4 Removing Drive Wheels .....	20
2.5 Removing Platforms.....	22
2.6 Removing Hand Rails and Exhaust Stack .....	24
2.7 Removing Leg Assemblies .....	25
2.8 Removing Wheel and Platform Support .....	28
<b>Chapter 3: Assembling the Windrower .....</b>	<b>31</b>
3.1 Assembling Support Stand .....	31
3.2 Lifting Windrower onto Stand .....	32
3.2.1 Lifting Windrower onto Stand: Crane Method.....	32
3.2.2 Lifting Windrower onto Stand: Forklift Method.....	33
3.3 Installing Legs .....	35
3.4 Installing Drive Wheels .....	38
3.5 Installing Caster Wheels .....	40
3.6 Installing Hydraulics .....	44
3.7 Removing Battery Shipping Shield .....	54
3.8 Unpacking Ignition Keys .....	55
3.9 Installing Platforms.....	57
3.10 Installing Steps .....	61

## TABLE OF CONTENTS

---

<b>3.11</b> Installing Exhaust Stack .....	62
<b>3.12</b> Installing Pre-cleaner .....	65
3.12.1 Adjusting Pre-cleaner .....	66
<b>3.13</b> Positioning Light and Mirror Assemblies .....	67
<b>3.14</b> Installing Beacons .....	68
<b>3.15</b> Installing the Slow Moving Vehicle (SMV) Sign .....	70
<b>3.16</b> Connecting Batteries .....	71
<b>3.17</b> Lubricating the Windrower .....	72
3.17.1 Lubrication Procedure .....	72
3.17.2 Lubrication Points .....	73
<b>3.18</b> Installing AM/FM Radio .....	74
Performing Predelivery Checks .....	78
3.1 Recording Serial Numbers .....	78
3.2 Checking Tire Pressures and Adding Tire Ballast .....	80
3.2.1 Checking Tire Pressures .....	80
3.2.2 Adding Tire Ballast .....	80
3.3 Checking Engine Air Intake .....	82
3.4 Checking Hydraulic Oil Level .....	84
3.5 Checking Fuel Separator .....	85
3.6 Checking Engine Oil Level .....	86
3.7 Checking Gearbox Lubricant Level .....	87
3.8 Checking Engine Coolant .....	88
3.9 Checking Air Conditioning (A/C) Compressor Belt .....	89
3.10 Draining and Refilling the Diesel Exhaust Fluid (DEF) Tank .....	90
3.11 Starting Engine .....	92
3.12 Priming Hydraulic System on an M155E4 .....	95
3.13 Checking and Adding Wheel Drive Lubricant Level .....	99
3.14 Checking Traction Drive .....	100
<b>3.19</b> Removing Windrower from Stand .....	101
3.19.1 Removing Windrower from Factory Stand .....	101
3.19.2 Removing Windrower from Field Stand .....	102
<b>Chapter 4: Cab Display Module (CDM) .....</b>	<b>103</b>
<b>4.1</b> Cab Display Module (CDM) Configuration .....	103
<b>4.2</b> Cab Display Options .....	105
4.2.1 Setting the Cab Display Language .....	105
4.2.2 Changing the Windrower Display Units .....	106
4.2.3 Adjusting the Cab Display Buzzer Volume .....	107
4.2.4 Adjusting the Cab Display Backlighting .....	108
4.2.5 Adjusting the Cab Display Contrast .....	109
<b>4.3</b> Configuring the Windrower .....	111

## TABLE OF CONTENTS

---

4.3.1 Setting the Header Knife Speed .....	111
4.3.2 Setting the Knife Overload Speed.....	111
4.3.3 Setting the Rotary Disc Overload Speed .....	113
4.3.4 Setting the Hydraulic Overload Pressure.....	114
4.3.5 Setting the Header Index Mode .....	115
4.3.6 Setting the Return to Cut Mode .....	116
4.3.7 Setting the Auto Raise Height.....	116
4.3.8 Activating the Double Windrow Attachment (DWA) .....	117
4.3.9 Activating the Hydraulic Center-Link .....	118
4.3.10 Activating the Rotary Header Drive Hydraulics.....	118
4.3.11 Setting the Header Cut Width .....	119
4.3.12 Activating the Swath Compressor .....	121
4.3.13 Activating the Hay Conditioner .....	123
4.3.14 Displaying Reel Speed.....	124
4.3.15 Setting the Windrower's Tire Size .....	125
4.3.16 Setting the Engine Intermediate Speed Control (ISC) RPM.....	126
4.3.17 Clearing Sub-Acres .....	127
<b>4.4 Activating Cab Display Lockouts .....</b>	<b>128</b>
4.4.1 Activating the Header Tilt Control Lockout.....	128
4.4.2 Activating the Header Float Control Lockout.....	129
4.4.3 Activating the Reel Fore-Aft Control Lockout .....	130
4.4.4 Activating the Draper Speed Control Lockout .....	131
4.4.5 Activating the Auger Speed Control Lockout.....	132
4.4.6 Activating Knife Speed Control Lockout .....	133
4.4.7 Activating Rotary Disc Speed Control Lockout.....	134
4.4.8 Activating the Reel Speed Control Lockout.....	135
<b>4.5 Displaying Activated Cab Display Lockouts .....</b>	<b>137</b>
<b>4.6 Calibrating the Header Sensors .....</b>	<b>139</b>
4.6.1 Calibrating the Header Height Sensor .....	139
4.6.2 Calibrating the Header Tilt Sensor .....	141
4.6.3 Calibrating the Header Float Sensors .....	143
<b>4.7 Calibrating the Swath Compressor Sensor.....</b>	<b>145</b>
<b>4.8 Troubleshooting Windrower Problems .....</b>	<b>147</b>
4.8.1 Displaying the Windrower and Engine Error Codes .....	147
4.8.2 Switching the Installed Header Sensors ON or OFF .....	148
4.8.3 Displaying Header Sensor Input Signals .....	150
4.8.4 Forcing a Header ID .....	151
<b>4.9 Troubleshooting Header Problems .....</b>	<b>153</b>
4.9.1 Testing the Header Up/Down Activate Function Using the Cab Display Module (CDM) .....	153
4.9.2 Testing the Reel Up/Down Activate Function Using the Cab Display Module (CDM) .....	154
4.9.3 Testing the Header Tilt Activate Function Using the Cab Display Module (CDM).....	156
4.9.4 Testing the Knife Drive Circuit Using the Cab Display Module (CDM).....	157
4.9.5 Testing the Draper Drive Circuit Activate Function Using the Cab Display Module (CDM).....	159

## TABLE OF CONTENTS

4.9.6 Testing the Reel Drive Circuit Activate Function Using the Cab Display Module (CDM) .....	161
4.9.7 Testing the Rotary Disc Drive Circuit Activate Function Using the Cab Display Module (CDM) .....	162
4.9.8 Testing the Double Windrower Attachment (DWA) Drive Activate Function Using the Cab Display Module (CDM) .....	164
4.9.9 Testing the Reel Fore-Aft Activate Function Using the Cab Display Module (CDM) .....	166
4.9.10 Activating the Hydraulic Purge Using the Cab Display Module (CDM).....	167
<b>Chapter 5: Performing Operational Checks.....</b>	<b>169</b>
5.1 Checking Safety System.....	169
5.2 Checking Operator's Presence System.....	172
5.3 Checking Windrower Startup .....	173
5.4 Checking Engine Speed .....	174
5.5 Checking Gauges and Cab Display Module (CDM) Display .....	175
5.6 Checking Electrical System.....	176
5.7 Checking Exterior Lights.....	177
5.8 Checking Auto Road Light .....	180
5.9 Checking Horn.....	181
5.10 Checking Interior Lights .....	182
5.11 Checking Air Conditioning (A/C) and Heater .....	183
5.12 Checking Manuals.....	184
5.13 Performing Final Steps .....	185
<b>Chapter 6: Attaching Headers .....</b>	<b>187</b>
6.1 Attaching Headers .....	187
6.1.1 Attaching Header Boots .....	187
6.1.2 Attaching a D Series or D1 Series Header.....	188
Attaching a D Series or D1 Series Header: Hydraulic Center-Link with Optional Self- Alignment .....	188
Attaching a D Series or D1 Series Header: Hydraulic Center-Link without Self-Alignment.....	193
6.1.3 Attaching an A Series Header .....	199
Attaching an A Series Header: Hydraulic Center-Link with Optional Self-Alignment .....	199
Attaching an A Series Header: Hydraulic Center-Link without Self-Alignment .....	204
6.1.4 Attaching an R/R1 Series Header .....	210
Attaching an R/R1 Series Header: Hydraulic Center-Link with Optional Self-Alignment .....	211
Attaching R/R1 Series Header: Hydraulic Center-Link without Optional Self-Alignment .....	216
<b>Chapter 7: Reference .....</b>	<b>223</b>
7.1 Torque Specifications .....	223
7.1.1 SAE Bolt Torque Specifications .....	223
7.1.2 Metric Bolt Specifications .....	225
7.1.3 Metric Bolt Specifications Bolting into Cast Aluminum .....	227
7.1.4 Flare-Type Hydraulic Fittings.....	228
7.1.5 O-Ring Boss (ORB) Hydraulic Fittings (Adjustable).....	229
7.1.6 O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable).....	231

## TABLE OF CONTENTS

---

7.1.7 O-Ring Face Seal (ORFS) Hydraulic Fittings .....	232
7.1.8 Tapered Pipe Thread Fittings .....	233
7.2 Conversion Chart .....	234
7.3 Definitions .....	235
7.4 Lubricants, Fluids, and System Capacities .....	238
7.5 Fuel Specifications .....	240
<b>Predelivery Checklist.....</b>	<b>241</b>





# Chapter 1: Safety

## 1.1 Signal Words

Three signal words, **DANGER**, **WARNING**, and **CAUTION**, are used to alert you to hazardous situations. Signal words are selected using the following guidelines:

### **DANGER**

Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.

### **WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. It may also be used to alert against unsafe practices.

### **CAUTION**

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may be used to alert against unsafe practices.

## 1.2 General Safety

### CAUTION

The following are general farm safety precautions that should be part of your operating procedure for all types of machinery.

Protect yourself.

- When assembling, operating, and servicing machinery, wear all protective clothing and personal safety devices that could be necessary for job at hand. Do **NOT** take chances. You may need the following:
  - Hard hat
  - Protective footwear with slip-resistant soles
  - Protective glasses or goggles
  - Heavy gloves
  - Wet weather gear
  - Respirator or filter mask
- Be aware that exposure to loud noises can cause hearing impairment or loss. Wear suitable hearing protection devices such as earmuffs or earplugs to help protect against loud noises.



Figure 1.1: Safety Equipment



Figure 1.2: Safety Equipment

- Provide a first aid kit for use in case of emergencies.
- Keep a fire extinguisher on the machine. Be sure fire extinguisher is properly maintained. Be familiar with its proper use.
- Keep young children away from machinery at all times.
- Be aware that accidents often happen when Operator is tired or in a hurry. Take time to consider safest way. Never ignore warning signs of fatigue.




Figure 1.3: Safety Equipment

## SAFETY

- Wear close-fitting clothing and cover long hair. Never wear dangling items such as scarves or bracelets.
- Keep all shields in place. **NEVER** alter or remove safety equipment. Make sure driveline guards can rotate independently of shaft and can telescope freely.
- Use only service and repair parts made or approved by equipment manufacturer. Substituted parts may not meet strength, design, or safety requirements.



Figure 1.4: Safety around Equipment

- Keep hands, feet, clothing, and hair away from moving parts. **NEVER** attempt to clear obstructions or objects from a machine while engine is running.
- Do **NOT** modify machine. Unauthorized modifications may impair machine function and/or safety. It may also shorten machine's life.
- To avoid bodily injury or death from unexpected startup of machine, **ALWAYS** stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.




Figure 1.5: Safety around Equipment

- Keep service area clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment. Be sure all electrical outlets and tools are properly grounded.
- Keep work area well lit.
- Keep machinery clean. Straw and chaff on a hot engine is a fire hazard. Do **NOT** allow oil or grease to accumulate on service platforms, ladders, or controls. Clean machines before storage.
- **NEVER** use gasoline, naphtha, or any volatile material for cleaning purposes. These materials may be toxic and/or flammable.
- When storing machinery, cover sharp or extending components to prevent injury from accidental contact.



Figure 1.6: Safety around Equipment

## 1.3 Tire Safety

### WARNING

- Service tires safely.
- A tire can explode during inflation which could cause serious injury or death.
- Follow proper procedures when mounting a tire on a wheel or rim. Failure to do so can produce an explosion that may result in serious injury or death.




Figure 1.7: Overinflated Tire

### WARNING

- Do NOT stand over tire. Use a clip-on chuck and extension hose.
- Do NOT exceed maximum inflation pressure indicated on tire label.
- Replace tires that have defects.
- Replace wheel rims that are cracked, worn, or severely rusted.
- Never weld a wheel rim.
- Never use force on an inflated or partially inflated tire.
- Make sure tire is correctly seated before inflating to operating pressure.
- If tire is not correctly positioned on rim or is overinflated, tire bead can loosen on one side causing air to escape at high speed and with great force. An air leak of this nature can thrust tire in any direction endangering anyone in area.
- Make sure all air is removed from tire before removing tire from rim.
- Do NOT remove, install, or repair a tire on a rim unless you have proper equipment and experience to perform job.
- Take tire and rim to a qualified tire repair shop.




Figure 1.8: Safely Inflating Tire

## 1.4 Battery Safety

### WARNING

- Keep all sparks and flames away from batteries, as a gas given off by electrolyte is explosive.
- Ventilate when charging in enclosed space.



Figure 1.9: Safety around Batteries

### WARNING

- Wear safety glasses when working near batteries.
- Do NOT tip batteries more than 45° to avoid electrolyte loss.
- Battery electrolyte causes severe burns. Avoid contact with skin, eyes, or clothing.
- Electrolyte splashed into eyes is extremely dangerous. Should this occur, force eye open, and flood with cool, clean water for 5 minutes. Call a doctor immediately.
- If electrolyte is spilled or splashed on clothing or body, neutralize it immediately with a solution of baking soda and water, then rinse with clear water.




Figure 1.10: Safety around Batteries

### WARNING

- To avoid injury from spark or short circuit, disconnect battery ground cable before servicing any part of electrical system.
- Do NOT operate engine with alternator or battery disconnected. With battery cables disconnected and engine running, a high voltage can be built up if terminals touch frame. Anyone touching frame under these conditions would be severely shocked.
- When working around storage batteries, remember that all of the exposed metal parts are live. Never lay a metal object across terminals because a spark or short circuit will result.
- Keep batteries out of reach of children.




Figure 1.11: Safety around Batteries

## **1.5 Welding Precautions**

High currents and voltage spikes associated with welding can cause damage to electronic components. Before welding on any part of windrower or an attached header, disconnect all electronic module harness connections as well as battery cables. Refer to technical manual for proper procedures.

## 1.6 Engine Safety

### WARNING

Do NOT use aerosol starting aids such as ether. Such use could result in an explosion and personal injury.

### CAUTION

- On initial start-up of a new, serviced, or repaired engine, always be ready to stop the engine in order to stop an overspeed. This may be accomplished by shutting off the air and/or fuel supply to the engine.
- Do NOT bypass or disable automatic shutoff circuits. The circuits are provided in order to help prevent personal injury. The circuits are also provided in order to help prevent engine damage. Refer to for repairs and adjustments.
- Inspect the engine for potential hazards.
- Before starting the engine, ensure that no one is on, underneath, or close to the engine. Ensure that people clear the area.
- All protective guards and all protective covers must be installed if the engine must be started in order to perform service procedures.
- To help prevent an accident that is caused by parts in rotation, work around parts carefully.
- If a warning tag is attached to engine start switch or to controls, do NOT start engine or move controls. Consult with person who attached warning tag before engine is started.
- Start engine from operator's compartment. Always start engine according to procedure that is described in Starting Engine section of operator's manual. Knowing correct procedure will help to prevent major damage to engine components and prevent personal injury.
- To ensure that the jacket water heater (if equipped) and/or lubricant oil heater (if equipped) is working correctly, check the water temperature gauge and/or oil temperature gauge during heater operation.
- Engine exhaust contains products of combustion, which can be harmful to your health. Always start the engine and operate the engine in a well-ventilated area. If the engine is started in an enclosed area, vent the engine exhaust to the outside.
- Engine exhaust gases become very hot during operation and can burn people and common materials. Stay clear of the rear machine and avoid exhaust gases when engine is running.

#### NOTE:

The engine may be equipped with a device for cold starting. If the engine will be operated in very cold conditions, then an additional cold starting aid may be required.

### 1.6.1 High-Pressure Rail

#### CAUTION

- Contact with high-pressure fuel may cause fluid penetration and burn hazards. High-pressure fuel spray may cause a fire hazard. Failure to follow these instructions may cause personal injury or death.
- Before disconnecting fuel lines or any other components under high-pressure between the fuel pump and high-pressure common rail fuel system, confirm that the fuel pressure is relieved.

## 1.6.2 Engine Electronics

### WARNING

Tampering with electronic system installation or original equipment manufacturer (OEM) wiring installation can be dangerous and could result in personal injury or death and/or engine damage.

### WARNING

**Electrical Shock Hazard.** The electronic unit injectors use DC voltage. The engine control module (ECM) sends this voltage to the electronic unit injectors. Do NOT come in contact with the harness connector for the electronic unit injectors while engine is operating. Failure to follow this instruction could result in personal injury or death.

This engine has a comprehensive, programmable engine monitoring system. The ECM has the ability to monitor engine operating conditions. If conditions exceed the allowable range, the ECM will initiate immediate action.

The following actions are available for engine monitoring control:

- Warning
- Derate
- Shut down

The following monitored engine operating conditions have the ability to limit engine speed and/or engine power:

- Engine coolant temperature
- Engine oil pressure
- Engine speed
- Intake manifold air temperature
- Diesel exhaust fluid (DEF) system performance
- Aftertreatment system performance



## 1.7 Safety Signs

- Keep safety signs clean and legible at all times.
- Replace safety signs that are missing or illegible.
- If original part on which a safety sign was installed is replaced, be sure repair part also bears current safety sign.
- Safety signs are available from your MacDon Dealer.




Figure 1.12: Operator's Manual Decal



## Chapter 2: Unloading the Windrower

Perform all procedures in this chapter in the order in which they are listed.

### 2.1 Unloading Container

#### CAUTION

To prevent injury to bystanders and avoid striking them with machinery, do NOT allow people to stand in the unloading area.

1. Move trailer into position and block trailer wheels.
2. Lower trailer storage stands.
3. Unlock and open container doors and remove all blocking.
4. Check container floor for nails or other obstructions and remove if necessary.
5. Position platform or ramp at container opening.
6. Attach chain/pull strap to slots in support channels (A).
7. Pull the windrower slowly from the container onto the platform.



Figure 2.1: Windrower Shipping Assembly

## UNLOADING THE WINDROWER

### 2.2 Moving to Assembly Area

The windrower can be moved to the assembly area using either a crane (refer to [2.2.1 Moving to Assembly Area: Crane Method, page 12](#)) or a forklift (refer to [2.2.2 Moving to Assembly Area: Forklift Method, page 14](#)).

#### 2.2.1 Moving to Assembly Area: Crane Method

##### CAUTION

To prevent injury to bystanders and avoid striking them with machinery, do NOT allow people to stand in the unloading area.


##### CAUTION

Equipment used for unloading must meet or exceed the requirements specified in this section. Using inadequate equipment may result in chain breakage, vehicle tipping, or machine damage.

Lift Sling	
<b>Maximum Working Load</b>	12,884 kg (28,404 lb.)

Chain	
<b>Type</b>	Overhead 1/2 in. lifting quality
<b>Minimum Working Load</b>	3221 kg (7100 lb.)

Lifting Vehicle	
<b>Minimum Lifting Capacity</b>	9072 kg (20,000 lb.)



**Figure 2.2: Lift Sling**


- A - Lift Sling
- B - Decal (MD #183245) (Four Places)
- C - Decal (MD #183248)

## UNLOADING THE WINDROWER

1. Attach chains or cables to the four lifting points on the lift sling, and connect the loop ends to the crane hook.

**IMPORTANT:**

Use cables or chains with a minimum lifting capacity of 3221 kg (7100 lb.).



**Figure 2.3: Lift Sling**

A - 1500 mm (59 in.) Minimum

B - 2120 mm (83.5 in.) Typical

2. Attach lift sling to the four designated lifting points on the windrower shipping frame.

**⚠ WARNING**

To avoid injury or death from a swinging or falling load, keep all bystanders clear when lifting. Equipment used for lifting must exceed the maximum requirements specified in this section.

3. Lift the windrower off the platform and move to the setup area.



**Figure 2.4: Shipping Frame Lifting Points**

## UNLOADING THE WINDROWER

4. Lower assembly onto 127–152 mm (5–6 in.) blocks (A) as shown.
5. Remove chains from shipping frame.
6. Check for shipping damage and missing parts.




Figure 2.5: Windrower Shipping Assembly on Blocks

### 2.2.2 Moving to Assembly Area: Forklift Method

#### CAUTION

To prevent injury to bystanders and avoid striking them with machinery, do NOT allow people to stand in the unloading area.

#### CAUTION

Equipment used for unloading must meet or exceed the requirements specified in this section. Using inadequate equipment may result in chain breakage, vehicle tipping, or machine damage.

Lifting Vehicle	
Minimum Lifting Capacity <sup>1</sup>	9072 kg (20,000 lb.)

#### IMPORTANT:

Forklifts are normally rated for a load positioned 610 mm (24 in.) forwards from the back end of the forks. To obtain the forklift capacity at 1220 mm (48 in.), check with your forklift distributor.

#### WARNING

Be sure forks are secure before moving away from load. Stand clear when lifting.

1. At 1220 mm (48 in.) from back end of forks.

## UNLOADING THE WINDROWER

1. Approach the windrower from the hood end and slide the forks underneath the lifting framework.
2. Raise the windrower off the platform and move to the assembly area.



Figure 2.6: Forklift Method Lifting Points

3. Lower assembly onto 127–152 mm (5–6 in.) blocks (A) as shown.
4. Check for shipping damage and missing parts.



Figure 2.7: Windrower Shipping Assembly on Blocks

## 2.3 Removing Wheel and Step Assembly

1. Remove shipping wire (A) and bolt securing the hose support to the shipping frame, and remove the hose support.
2. Lay hose support off to the side.



Figure 2.8: Shipping Frame

3. Remove two 3/4 x 16.5 in. bolts (A) (one per side) from the front frame beam. Retain for reinstallation.



Figure 2.9: Front Frame Beam



## UNLOADING THE WINDROWER

4. Remove the 25.4 mm (1 in.) pin (A) from the center-link.



Figure 2.10: Center-Link

5. Remove the four (two per side) carriage bolts from the rear of the wheel/step assembly.



Figure 2.11: Rear of Wheel/Step Assembly

## UNLOADING THE WINDROWER

6. Remove the cable tie (A) and shipping wire (B) securing the hose bundles to the frame.



Figure 2.12: Hose Bundles on Frame



Figure 2.13: Hose Bundles on Frame

## UNLOADING THE WINDROWER

- Using a chain and a lifting device, pull wheel/step assembly (A) away from the shipping assembly.



Figure 2.14: Wheel/Step Shipping Assembly

- Lift center-link (A) until it clears the wheel/step assembly frame (B).




Figure 2.15: Wheel/Step Assembly Frame

- Install leg bolts, washers, and nuts to secure the lifting plate onto the mainframe.



Figure 2.16: Lifting Plate

## 2.4 Removing Drive Wheels

**IMPORTANT:**

To prevent damage to the hood/cab, remove the drive wheels as a pair from above the hood.

1. Remove the two bolts (A) from the front cross member over the hood.



Figure 2.17: Front Cross Member on Hood

2. Remove one bolt (A) from the rear of the hood directly under the center of the drive wheel.




Figure 2.18: Rear of Hood

3. Attach a lifting device to the lift hooks (A) located in the center of each drive wheel.




Figure 2.19: Drive Wheel

## UNLOADING THE WINDROWER

4. Carefully lift the wheels off the frame.

**IMPORTANT:**

Ensure the tires are guided away from the cab roof when lifting wheels to prevent damaging the cab. The chain on the forward wheel should be snug, and the chain on the aft wheel should be loose.

5. Set wheels aside for later installation.



Figure 2.20: Wheels on Frame

## UNLOADING THE WINDROWER

### 2.5 Removing Platforms

1. Remove the support tube (A) on each side of the hood.




Figure 2.21: Shipping Supports

2. Attach two slings and a chain to the platform at the locations shown to prevent damaging the paint.
3. Attach opposite ends of slings and chain to a lifting device with a minimum lifting capacity of 2268 kg (5000 lb.) and a lift height of 4 m (13 ft.).




Figure 2.22: Platforms on Hood

4. Remove two 5/8 x 5 in. bolts (B) from the top of the vertical supports, and remove the two 5/8 x 1-1/4 in. bolts (A) attaching the angle braces to the platforms.
5. Carefully lift the platform assembly off the frame.




Figure 2.23: Platforms on Hood

## UNLOADING THE WINDROWER

6. Back away from the windrower, and set the platform assembly on a level surface.
7. Unhook one sling and chain.
8. Lift one end of the platform assembly so it can be inverted and laid down with the base on the floor. Use a piece of cardboard under the platform assembly to protect the paint.




Figure 2.24: Platforms

9. Unhook the remaining sling.




Figure 2.25: Platforms

## 2.6 Removing Hand Rails and Exhaust Stack

1. Cut the cable ties and move the hose bundle clear of the platform.



Figure 2.26: Hand Rails and Exhaust Stack Shipping Assembly

2. Remove shipping wire and foam from exhaust stack (A).
3. Remove nuts (B) from clamp (C), and remove the exhaust stack (A) and clamp from the shipping frame.
4. Reinstall nuts (B) onto clamp (C) and set exhaust stack (A) aside for later installation.
5. Remove the two bolts (D) securing the hand rail (E) to the shipping frame, and remove hand rail.
6. Repeat for hand rail on the opposite side.
7. Set parts aside for later installation.




Figure 2.27: Hand Rails and Exhaust Stack Shipping Position



## 2.7 Removing Leg Assemblies

### WARNING

Objects are heavy and difficult to maneuver. Use a proper lifting device or arrange for adequate assistance. Falling objects can result in serious personal injury.

1. Ensure lift bar (B) is attached to leg assembly as shown, and the clevis pin is installed with the head on near side.
2. Attach chain (A) to lifting bar (B) on the leg assembly, and connect the chain to a lifting device with a minimum lifting capacity of 2268 kg (5000 lb.).




Figure 2.28: Leg Shipping Assembly

3. Remove two bolts (A) from the lower support channel.




Figure 2.29: Lower Support Channel

## UNLOADING THE WINDROWER

4. Remove two bolts (A) from the shipping channel located at the top of the leg.




Figure 2.30: Shipping Channel on Leg

5. Remove bars (A) from leg.
6. Insert cardboard or foam between leg assembly and hood to avoid damage.




Figure 2.31: Leg Shipping Assembly

## UNLOADING THE WINDROWER

7. Lift leg assembly (A), and set on level ground in position (B) shown.
8. Repeat procedure for the second leg assembly.




Figure 2.32: Leg Assembly Positioning

## 2.8 Removing Wheel and Platform Support

1. Remove cross brace (A) and upright supports (B) and (C) from the frame.



Figure 2.33: Wheel and Platform Support

2. Remove cross member (A) from above hood.




Figure 2.34: Wheel and Platform Support

## UNLOADING THE WINDROWER

3. Remove the uprights (A) on both sides of the hood.



Figure 2.35: Wheel and Platform Support



## Chapter 3: Assembling the Windrower

Perform all procedures in this chapter in the order in which they are listed.

### 3.1 Assembling Support Stand

Special stands for assembling the windrower are available from the factory. If the stands are not available, use an equivalent support system.

#### IMPORTANT:

The stands must be capable of supporting a 6800 kg (15,000 lb.) load.

1. Remove all shipping materials from the stands and set aside the air control valve tripod (D).
2. Arrange forward (A) and rear (B) stands on level ground so the attachment lugs on each stand face each other.
3. Attach four support tubes (C) to the stands as shown, and secure with the hardware provided with the stands.




Figure 3.1: Support Stand

4. Set up the air control valve tripod, remove plug (A) from the valve, and install a 690 kPa (100 psi) air line. The stand is now operational and instructions for its use are provided throughout this manual.

#### **WARNING**

Use stand only as instructed in this manual. Do NOT use stand for any other purpose. Do NOT pressurize air bags beyond 690 kPa (100 psi).




Figure 3.2: Air Control Valve Tripod

## ASSEMBLING THE WINDROWER

### 3.2 Lifting Windrower onto Stand

The windrower can be lifted onto the support stand using either a crane (refer to [3.2.1 Lifting Windrower onto Stand: Crane Method](#), page 32) or a forklift (refer to [3.2.1 Lifting Windrower onto Stand: Crane Method](#), page 32).

#### 3.2.1 Lifting Windrower onto Stand: Crane Method

##### **⚠ CAUTION**

To prevent injury to bystanders and avoid striking them with machinery, do NOT allow people to stand in the unloading area.


##### **⚠ CAUTION**

Equipment used for unloading must meet or exceed the requirements specified in this section. Using inadequate equipment may result in chain breakage, vehicle tipping, or machine damage.

Lift Sling	
Maximum Working Load	12,884 kg (28,404 lb.)

Chain	
Type	Overhead 1/2 in. lifting quality
Minimum Working Load	3221 kg (7100 lb.)

Crane Lifting Vehicle	
Minimum Lifting Capacity	9072 kg (20,000 lb.)



**Figure 3.3: Lift Sling**

- A - Lift Sling
- B - Decal (MD #183245) (Four Places)
- C - Decal (MD #183248)



## ASSEMBLING THE WINDROWER

1. Attach chains or cables to the four lifting points (A) on the lift sling, and connect the loop ends to the crane hook.

### IMPORTANT:

Use cables or chains with a minimum lifting capacity of 3221 kg (7100 lb.).

2. Attach the lift sling to the four designated lifting points on the windrower shipping frame as shown.

### WARNING

To avoid injury or death from a swinging or falling load, keep all bystanders clear when lifting. Equipment used for lifting must exceed the maximum requirements specified in this section.



Figure 3.4: Shipping Frame Lifting Points

3. Lift the windrower onto the support stand (A).
4. Remove chains from shipping frame and move lift sling (B) clear of the work area.




Figure 3.5: Windrower on Support Stand

### 3.2.2 Lifting Windrower onto Stand: Forklift Method

#### CAUTION

To prevent injury to bystanders and avoid striking them with machinery, do NOT allow people to stand in the unloading area.

#### CAUTION

Equipment used for unloading must meet or exceed the requirements specified in this section. Using inadequate equipment may result in chain breakage, vehicle tipping, or machine damage.

## ASSEMBLING THE WINDROWER

Lifting Vehicle	
Minimum Lifting Capacity <sup>2</sup>	9072 kg (20,000 lb.)

### IMPORTANT:

Forklifts are normally rated for a load positioned 610 mm (24 in.) forwards from the back end of the forks. To obtain the forklift capacity at 1220 mm (48 in.), check with your forklift distributor.

1. Approach the windrower from the hood end and slide the forks fully into shipping support channels (A).



Figure 3.6: Forklift Method Lifting Points

2. Raise the windrower and lower onto the support stand.
3. Back away forklift.




Figure 3.7: Windrower on Support Stand

- 
2. At 1220 mm (48 in.) from back end of forks.

### 3.3 Installing Legs

1. Remove the front leg bolts (A) and pins (B) and set aside for reinstallation. Remove carriage bolt (C) and remove lifting plate (D).




Figure 3.8: Lifting Plate

2. Attach the front leg to a lifting device using lifting bar (A).
3. Position the leg at the frame.




Figure 3.9: Leg Position

## ASSEMBLING THE WINDROWER

4. Feed the hydraulic hose bundle (A) into the frame and through hole (B) at the center of the frame.




Figure 3.10: Hydraulic Hoses

5. Insert the leg into the frame and line up the holes in the frame and the leg at the first position (widest tread with one exposed hole [A]).
6. Insert pins and secure with 3/4 x 16-1/2 in. long bolts (B), washers, and nuts. Torque to 136 Nm (100 lbf·ft).
7. Repeat for opposite leg.




Figure 3.11: Leg Position on Frame

## ASSEMBLING THE WINDROWER

8. Use the lifting device to slightly lift the header lift arms, and remove the lifting bars (A) from the legs.
9. Relocate spring locking pins (B) to the front of the lift arms.




Figure 3.12: Header Lift

### 3.4 Installing Drive Wheels

**NOTE:**

If using the factory stand, proceed to Step 1, page 38; otherwise, skip to Step 5, page 38.

1. Ensure the three (one at rear, two at front) lift locks are activated on the lift mechanism.

**NOTE:**

Lock is activated when keeper (A) is vertical and latch (B) is free to move back and forth.

2. Pressurize the air bag system (690 kPa [100 psi] air pressure required) and raise the windrower to the maximum height (approximately 178 mm [7 in.] above the stand).




Figure 3.13: Lift Locks

3. Verify that all three locks are engaged before proceeding to the next step.

**NOTE:**

Lock is engaged when the witness hole (A) above the pin is exposed.

4. Release pressure until the locks support the weight of the windrower.




Figure 3.14: Lift Locks

5. Remove shipping support (A) from the drive wheel hub, and remove the wheel lug nuts (B).




Figure 3.15: Drive Wheel Shipping Support

## ASSEMBLING THE WINDROWER

- Position the wheels against the hubs so the air valves (A) are on the outside and the tire tread points forward.

**NOTE:**

For turf tires (diamond tread), be sure arrow on sidewall points in forward rotation with windrower in cab-forward orientation.

- Lift wheel onto hub using a lifting device.
- Lower lifting device.



Figure 3.16: Wheel Position

- Line up the holes in the rim with the studs on the wheel drive hub and install wheel nuts (A).

**IMPORTANT:**

To avoid damage to wheel rims and studs, tighten nuts by hand. Do **NOT** use an impact gun, do **NOT** use lubricant or Never-Seez® compound, and do **NOT** overtighten wheel nuts.

- Torque drive wheel nuts to 510 Nm (375 lbf-ft) using the tightening sequence shown.

**IMPORTANT:**

Use only manufacturer-specified nuts (MD #205397).




Figure 3.17: Drive Wheel Nuts

- Repeat torque procedure every hour until two consecutive checks confirm there is no movement of the nuts.

### 3.5 Installing Caster Wheels

1. Remove two guide plates (A) from the ends of the walking beam.




Figure 3.18: Guide Plate on Walking Beam

2. Support the shipping frame channel and remove the bolts attaching the shipping frame to the walking beam and mainframe side rail. Remove the shipping frame.

**NOTE:**

Shipping frame does not need to be removed if air bag lifting stand is used; however, ensure the bolts are removed prior to moving the windrower off the stand.

3. Repeat for opposite shipping frame channel.




Figure 3.19: Shipping Frame



## ASSEMBLING THE WINDROWER

4. Remove tie bar (A) from between the caster wheels.



Figure 3.20: Caster Wheel Shipping Assembly

5. Remove the two caster supports (A) from the caster wheels and frame. Retain bolts for attaching caster to walking beam.




Figure 3.21: Caster Supports

## ASSEMBLING THE WINDROWER

6. Attach a chain to the right caster and support caster with lifting device.




Figure 3.22: Lifting Device on Caster

7. Remove the five remaining bolts (A) securing the caster to the shipping frame. Retain bolts for attaching caster to walking beam.

**CAUTION**

Stand clear when lifting, as caster may swing.




Figure 3.23: Shipping Frame on Caster

## ASSEMBLING THE WINDROWER

8. Lift caster assembly off shipping frame and position at end of walking beam (A).
9. Insert right caster extension into walking beam and position for desired tread.



Figure 3.24: Walking Beam

10. Install six 3/4 in. bolts (A) and hardened washers into walking beam and caster beam. Use longer bolts through anti-shimmy bracket (B).
11. Tighten bolts as follows:
  - a. Snug up the two bolts underneath beam.
  - b. Tighten the four back bolts to 447 Nm (330 lbf·ft).
  - c. Tighten bolts underneath beam to 447 Nm (330 lbf·ft).
12. Repeat Steps 7, page 42 through 11, page 43 for left caster.
13. Retighten bolts at 5 and 10 hours of operation.




Figure 3.25: Walking Beam

### 3.6 Installing Hydraulics

1. Remove hose clip (A) from under the cab.




Figure 3.26: Hose Clip

2. Position hose (D) (MD #111323 [orange tie]) and hose (E) (MD #111324 [white tie]) with tee under the center of the clip as shown, and loosely install two bolts and nuts.

**NOTE:**

Part numbers are marked on the hoses.

3. Position remaining hoses under clip as shown and tighten bolts.




Figure 3.27: Hose Routing (View Looking Forward)

- |                            |                             |
|----------------------------|-----------------------------|
| A - Hose Clip              | B - Yellow Tie (MD #111557) |
| C - Blue Tie (MD #111323)  | D - Orange Tie (MD #111323) |
| E - White Tie (MD #111324) | F - Green Tie (MD #111327)  |
| G - White Tie (MD #111328) |                             |

4. Locate two hoses (A) (MD #111327 [green ties]) in frame opening and existing tee fitting (green tie) on the hose from the valve block.
5. Remove caps from the hoses (A) only.
6. Remove one cap from tee fitting, and quickly attach hose (A) to minimize oil spillage.
7. Remove second cap from tee fitting, and quickly connect other hose (A).
8. Tighten fittings.
9. Position hoses into frame.




Figure 3.28: Hose Routing

## ASSEMBLING THE WINDROWER

10. Locate two hoses (white ties) inside frame and hose (MD #111324) with existing tee fitting (A) (white tie).
11. Remove caps, make connections, and tighten fittings.
12. Position hoses into frame.




Figure 3.29: Hose Routing

13. Locate two hoses (A) (red ties) inside frame.
14. Route right hose behind bundle.
15. Remove caps, make connection, and tighten fitting.
16. Position hoses into frame.




Figure 3.30: Hose Routing

17. Retrieve long hose (A) (MD #119328 [white tie]) and route through the hole in the left frame.



Figure 3.31: Hose Routing

## ASSEMBLING THE WINDROWER

18. Remove caps on hose (A) and valve block fitting (B) (white tie) and make connection. Tighten fitting.




Figure 3.32: Valve Block

19. Remove caps with the following colored ties from fittings on the valve block inside the frame:

- Blue (A)
- Orange (B)
- Yellow (C)




Figure 3.33: Valve Block

20. Loosen bolts (A) and move valve block (B) to improve access through the hole in the frame in order to insert wrenches and tighten fittings.




Figure 3.34: Valve Block

## ASSEMBLING THE WINDROWER

21. Retrieve hoses with blue (A), orange (B), and yellow (C) colored ties, and connect to matching ties on valve block. Tighten fittings.
22. Reposition valve block and retighten bolts.




Figure 3.35: Valve Block

23. Remove clamp (A) from round plastic hose block.




Figure 3.36: Hose Block

24. Insert two left traction drive hoses (A) into hose block as shown.
25. Insert two right traction drive hoses (B) into hose block as shown.

**NOTE:**

Case drain hose (C) is preinstalled in block.

26. Reinstall clamp.




Figure 3.37: Hose Block (View Looking Forward)

## ASSEMBLING THE WINDROWER

27. Remove caps and attach hoses with short elbows (A) to respective side of pump (either yellow or no tie). Tighten fittings.




Figure 3.38: Pump

28. Remove caps and attach hoses with long elbows (A) to respective side of pump (either red or no tie). Tighten fittings.




Figure 3.39: Pump



## ASSEMBLING THE WINDROWER

29. Retrieve the two motor case drain hoses (MD #111312) at the front frame and the 7/8 in. tee fitting (B) on the hose from the pump.
30. Remove the caps (A) from the hoses only.




Figure 3.40: Motor Case Drain Hoses

31. Remove one cap from tee fitting (A) and quickly attach hose to minimize oil spillage.
32. Remove second cap from tee (A) and quickly connect other hose.
33. Tighten fittings.




Figure 3.41: Tee Fitting

## ASSEMBLING THE WINDROWER

34. Position hose bundle (A) from the valve blocks on the left side of the frame onto the tire.
35. Note routing of electrical harness.

### IMPORTANT:

The electrical harness must be routed on the topside of the hose bundle and on the outside of the hose support to prevent chafing of the electrical wires when the windrower is operating with a header.




Figure 3.42: Hose Routing

36. Undo strap (A), cut cable ties (B), and move harness (C) away from the hose bundle.




Figure 3.43: Electric Harness and Hose Bundle


## ASSEMBLING THE WINDROWER

37. Route the hose bundle (A) through the hose support and lay hose bundle on the tire.
38. Route the harness along the outside of the hose support and along the hose bundle to the hose ends.



**Figure 3.44: Hose Routing**

39. Attach harness (A) to hose support with hose clip (B).



**Figure 3.45: Hose Support**

## ASSEMBLING THE WINDROWER

40. Secure harness (C) to hose bundle with strap (A) and new cable ties (B). Ensure harness is clear of pinch and friction points.




Figure 3.46: Electric Harness and Hose Bundle

41. Disengage and rotate hook (A) to fully up position.  
42. Position hose bundle (B) over hose support and under hook.




Figure 3.47: Hook Positioning


## ASSEMBLING THE WINDROWER

43. Lower hook (A) and engage in bracket in down position.



**Figure 3.48: Hook Positioning**

44. Attach the reel hose support tube to the right leg with two 3/8 x 1.0 in. carriage bolts (A) and nuts.



**Figure 3.49: Reel Hose Support**

### 3.7 Removing Battery Shipping Shield

1. Loosen nut (A) on the battery clamp.
2. Slide shield (B) out from under the battery and discard.
3. Tighten nut (A) on the battery clamp.




Figure 3.50: Battery Shipping Shield

4. Remove one of the two bolts (A) and nuts, and loosen the other.




Figure 3.51: Bracket Shipping Position

5. Rotate angle (A) 180°, align holes, and reinstall the bolt (B) and nut. Leave bolts loose.




Figure 3.52: Bracket Repositioned

### 3.8 Unpacking Ignition Keys

The fuse box is mounted on the right (cab-forward) side of the frame under the platform.




Figure 3.53: Fuse Box Location

1. Remove wing nut (A) from fuse box cover (B) and remove cover.




Figure 3.54: Fuse Box

## ASSEMBLING THE WINDROWER

2. Remove tape and keys (A) from inside the cover.
3. Unlock cab doors and place keys on console.
4. Close cab doors.
5. Install fuse box cover (B) and secure with wing nut.




Figure 3.55: Fuse Cover



### 3.9 Installing Platforms

**NOTE:**

The procedure for left side installation is shown—right side installation is similar.

1. Remove the two 1/2 x 3/4 in. bolts (A) securing the rails to the shipping beam, and remove the rails. Retain hardware.
2. Remove the shipping brackets from the platform assembly. Retain hardware.




Figure 3.56: Platform Shipping Assembly

3. Attach one end of a sling to the platform and the other end to a lifting device.

**⚠ WARNING**

To avoid injury or death from fall or swinging of raised load, keep all bystanders clear when lifting.




Figure 3.57: Left Platform

4. Position the platform against the windrower frame.




Figure 3.58: Left Platform

## ASSEMBLING THE WINDROWER

5. Attach the main beam of the left platform to the side frame using three 1/2 x 1-1/4 in. long carriage bolts (A). Ensure the bolt heads face inboard, and tighten just enough to permit adjustment.




Figure 3.59: Left Platform – Main Beam

6. Attach the steering arm to the frame with two 3/8 x 3/4 in. long carriage bolts and nuts (A). Ensure the bolt heads face inboard, and tighten bolts.
7. Remove sling.




Figure 3.60: Left Platform – Steering Arm

8. Attach the railings to the platform with 1/2 x 3/4 in. locking bolts (A) provided. Tighten bolts to 102 Nm (75 lbf·ft).




Figure 3.61: Left Platform – Railings

## ASSEMBLING THE WINDROWER

9. Slowly close the platform and check that the vertical rail tubes are parallel with the cab posts when viewing from the rear.




Figure 3.62: Left Platform

10. Laterally adjust the king pin mounting (A) as required.




Figure 3.63: Left Platform – Main Beam

11. Ensure the rubber bumper (A) is contacting the frame.




Figure 3.64: Left Platform – Rubber Bumper

## ASSEMBLING THE WINDROWER

12. Ensure the front of the platform is contacting the guide (A).




Figure 3.65: Left Platform – Guide

13. Adjust the platform horizontally with the 1/2 x 2-1/4 in. bolt (A) as required.



Figure 3.66: Left Platform – Main Beam

14. Relocate the steering arm (A) into either of the other holes on the bracket (B), if major adjustment is required.
15. Tighten the three main beam attachment bolts to 108 Nm (80 lbf·ft).
16. Repeat procedure to install the right side platform.




Figure 3.67: Left Platform – Steering Arm

### 3.10 Installing Steps

**NOTE:**

Procedure for left side installation shown—right side installation similar.

1. Remove the two existing upper bolts (A).
2. Ensure the two lower bolts (B) are not threaded in fully.




Figure 3.68: Left Platform

3. Hang step assembly on lower bolts (B). Back off bolts, if necessary.
4. Install two bolts (A) in upper holes of step and platform.
5. Torque all bolts to 20 Nm (15 lbf·ft).
6. Repeat for opposite step assembly.




Figure 3.69: Left Steps Installed

### 3.11 Installing Exhaust Stack

1. Open the engine compartment hood.
2. Retrieve exhaust stack (A) and clamp (B) (unpacked in [2.6 Removing Hand Rails and Exhaust Stack, page 24](#)).
3. Loosen clamp (B) on exhaust stack (A).




Figure 3.70: Exhaust Stack

4. Remove the covering from exhaust canister (A), and loosen clamp (B) on the exhaust canister.




Figure 3.71: Exhaust Canister

5. Loosen clamp (A) just enough to allow the charge air cooler (CAC) tube (B) to move, and move the CAC tube so the exhaust stack can be installed.
6. Loosen wing nut (C) on exhaust shroud (D), and move shroud so the exhaust stack can be installed.




Figure 3.72: Charge Air Cooler Tube and Exhaust Shroud

## ASSEMBLING THE WINDROWER

- Loosen clamp (A), position stack (B) into the clamp as shown, and connect the stack to exhaust canister (C).

**NOTE:**

If bracket (D) interferes with stack (B), loosen hex nuts (E) on the bracket and move the bracket so the stack can be installed.




Figure 3.73: Exhaust Stack under Hood

- Tighten both clamps (A) just enough to permit the stack (B) to move.




Figure 3.74: Exhaust Stack under Hood

- Reposition CAC tube (B), and tighten clamp (A) just enough to allow the CAC tube to move.
- Reposition exhaust shroud (D), and then tighten wing nut (C) just enough to allow the exhaust shroud to move.




Figure 3.75: Charge Air Cooler Tube and Exhaust Shroud (Exhaust Stack Removed for Clarity)

## ASSEMBLING THE WINDROWER

11. Close the hood slowly so stack (A) enters hole (B) in the hood. Adjust the position of the stack as required to clear the hole in the hood.




Figure 3.76: Exhaust Stack Installed

12. Raise the hood.
13. Tighten clamps (A) on exhaust stack (B).




Figure 3.77: Exhaust Stack under Hood (Charge Air Cooler Tube and Exhaust Shroud Removed for Clarity)

14. Tighten clamp (A) on CAC tube (B).
15. Tighten wing nut (C) on exhaust shroud (D).




Figure 3.78: Charge Air Cooler Tube and Exhaust Shroud (Exhaust Stack Removed for Clarity)



### 3.12 Installing Pre-cleaner

**⚠ WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Open the hood.
2. Retrieve the pre-cleaner (A) and pre-cleaner support (B) from inside the cab, and loosen clamp (C).
3. Remove pre-cleaner (A) and clamp (C) from pre-cleaner support (B).




Figure 3.79: Pre-Cleaner Assembly

4. From inside the hood, loosen hardware (A) and install pre-cleaner support (B) into the cutout in the hood.
5. Install four bolts (A) to secure pre-cleaner support (B) to the hood.




Figure 3.80: Pre-Cleaner Support

6. Close the hood.
7. Install pre-cleaner (B) onto support tube (C).
8. Install clamp (A) to secure pre-cleaner (B).




Figure 3.81: Pre-Cleaner

## ASSEMBLING THE WINDROWER

### 3.12.1 Adjusting Pre-cleaner

1. Open the right platform.
2. Open the hood.
3. From inside the hood, on right panel in the cab-forward position, locate removable access panel (B).
4. Remove the four bolts (A) that secure the access panel (B).
5. Remove access panel (B).
6. Close the hood.




Figure 3.82: Access Panel

#### NOTE:

Side panel has been made transparent to show items under the hood.

7. Check that rubber seal (A) on air intake stack is compressed against plate (B) on the pre-cleaner support.
8. If adjustment is required, open hood and loosen nuts (C) on the air intake stack.
9. Close the hood.
10. Access the air intake stack through access hole (D). Adjust air intake stack.




Figure 3.83: Air Intake Stack

11. Open the hood and install access panel (B).
12. From inside the hood, install four bolts (A) that secure access panel (B) to the side panel.
13. Close the hood.




Figure 3.84: Access Panel

### 3.13 Positioning Light and Mirror Assemblies

1. Remove the nut and bolt (A) securing the light and mirror assembly in the shipping position.
2. Swing the light and mirror assembly (B) forwards and upwards.




Figure 3.85: Light and Mirror Assembly in Shipping Position

3. Reinstall the bolt (A) and nut in other hole.
4. Repeat for opposite mirror assembly.




Figure 3.86: Light and Mirror Assembly in Working Position

### 3.14 Installing Beacons

1. Retrieve the two beacons from the shipment.
2. Remove the hardware and rubber base from one of the beacons as shown.



Figure 3.87: Beacon Light

3. Feed the connectors from the harness through the center hole in the rubber base.
4. Place the base on the beacon bracket ensuring that the mounting holes in the rubber base line up with the holes in the bracket.



Figure 3.88: Rubber Beacon Base on Mounting Bracket

5. Connect the orange wire (A) from the harness to the red wire (B) in the beacon.
6. Connect the black wire (C) from the harness to the ground terminal in the beacon.




Figure 3.89: Beacon Light Wire Routing

## ASSEMBLING THE WINDROWER

7. Fit the beacon onto the base making sure the beacon is oriented with the point on the lens facing forward (cab-forward) as shown.



Figure 3.90: Beacon Light Orientation

8. Mount the beacon to the base using the lock washers and nuts (A) supplied with the beacon.
9. Install the second beacon on the opposite side of the cab roof.



Figure 3.91: Beacon Light

### 3.15 Installing the Slow Moving Vehicle (SMV) Sign

1. Install the SMV sign (A) (shipped inside the cab) onto the windrower in accordance with the instructions supplied with the sign. SMV signs must be visible when travelling on the road.




Figure 3.92: Engine-Forward Location




Figure 3.93: Cab-Forward Location




Figure 3.94: Alternate Location (Cab-Forward)

### 3.16 Connecting Batteries

1. Open the right (cab-forward) maintenance platform.
2. Ensure the battery main disconnect switch (A) is turned to the POWER OFF position (the battery main disconnect switch is located on the right frame rail beside the batteries).
3. Remove the cable ties securing the battery cables to the battery clamps.

**IMPORTANT:**

**Batteries are negative grounded.** Always connect red starter cables to the positive (+) terminals of the batteries and black ground cables to the negative (-) terminals of the batteries. Reversed polarity in the batteries or alternator may result in permanent damage to the electrical system.




Figure 3.95: Battery Main Disconnect Switch

4. Remove the plastic caps from the battery posts.
5. Attach the red positive (+) cable terminals to the positive posts (A) on the batteries and tighten clamps. Reposition plastic covers onto clamps.
6. Attach the black negative (-) cable terminals to the negative posts (B) on the batteries and tighten clamps. Reposition plastic covers onto clamps.
7. Turn the battery switch to the POWER ON position.
8. Move the right (cab-forward) maintenance platform forward to the closed position.




Figure 3.96: Batteries

## 3.17 Lubricating the Windrower

For grease specification, refer to *7.4 Lubricants, Fluids, and System Capacities, page 238*.

### 3.17.1 Lubrication Procedure

#### **WARNING**


**To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.**

1. Wipe grease fitting with a clean cloth before greasing to avoid injecting dirt and grit.
2. Inject grease through fitting with grease gun until grease overflows fitting. Do **NOT** overgrease wheel bearings.
3. Leave excess grease on fitting to keep out dirt.
4. Replace any loose or broken fittings immediately.
5. Remove and thoroughly clean any fittings (including the lubricant passageway) that will not take grease. Replace fitting, if necessary.



### 3.17.2 Lubrication Points

Figure 3.97: Lubrication Points



- A - Forked Caster Wheel Bearing (Two Places) (Outer – Both Wheels)
- B - Top-Link (Two Places) (Both Sides)
- C - Lubrication Decal (MD #183411)
- D - Caster Pivot (Both Sides)
- E - Forked/Formed Caster Wheel Bearing (Two Places) (Inner – Both Wheels) (50 Hrs/250 Hrs)

### 3.18 Installing AM/FM Radio

M155E4 Windrowers are designed to accept a DIN E style AM/FM radio with a depth (X) of 161 mm and having a 5 mm threaded stud (A) centered on the rear for support.

In order to retain radio settings and preset memory with the battery disconnect turned off, select a radio with non-volatile settings memory.

**NOTE:**

An approved radio package is available from Radio Engineering Industries (REI) of Omaha, Nebraska.




Figure 3.98: Mounting Dimension

1. Ensure the battery switch (A) is turned to the OFF position.
2. Ensure the ignition is turned OFF, and remove the key.




Figure 3.99: Radio Panel

## ASSEMBLING THE WINDROWER

3. Remove radio panel by removing four screws (A).




Figure 3.100: Radio Panel

4. Remove screw and nuts (A) and (C) to remove support (B) from panel. Retain nut (C) and lock washer.




Figure 3.101: Panel Support

5. Remove the cutout by cutting tabs (A) in the panel. Remove sharp edges from the panel.




Figure 3.102: Panel

## ASSEMBLING THE WINDROWER

- Position receptacle (A) (supplied with radio) into the opening, and secure by bending tabs (B) on receptacle against panel.




Figure 3.103: Radio Receptacle

- Insert radio into receptacle and attach the radio bezel. Ensure the radio locks into position and faceplate (A) is against the panel.



Figure 3.104: Radio Installed

- Ensure the radio has a six-pin connector (Packard #2977042) and a terminal arrangement as shown at right. This enables the radio to connect to the windrower's six-pin radio connector wiring harness.
- Attach the following two additional wires from the wiring harness to the radio:
  - Circuit 503:** Red live-wire with 1/4 in. female blade terminal provides power for the radio clock/memory if radio is equipped with this feature.
  - Circuit 315:** Black ground-wire attaches to the radio body.
- Plug antenna cable into radio.




Figure 3.105: Six-Pin Connector Terminal Arrangement

- A - Left Speaker Power (+)
- B - Left Speaker Ground (-)
- C - Radio Ground (-)
- D - Right Speaker Ground (-)
- E - Right Speaker Power (+)
- F - Radio Power (+) (Live when Ignition is ON)

## ASSEMBLING THE WINDROWER

11. Attach stud (supplied with radio) to center rear of radio.
12. Attach support (B) to stud on back of radio chassis with nut (A) and lock washer supplied with the support.

**NOTE:**

Support can be attached to chassis in multiple locations to allow for proper radio mounting.

13. Install radio panel using original screws.




Figure 3.106: Radio and Support

14. Adjust bracket (A) (if necessary) by loosening nuts (B) to allow radio to slide into opening and securely capture support (C).




Figure 3.107: Radio and Support

15. Retrieve antenna from inside cab and remove protective cover from base.
16. Remove protective cover (A) from antenna mount on cab roof and thread antenna onto base until hand tight.

**NOTE:**

Store protective cover in cab and reinstall to protect antenna mount if antenna needs to be removed.




Figure 3.108: Antenna Mount on Cab Roof

## PERFORMING PREDELIVERY CHECKS

17. Turn the battery switch (A) to the ON position.
18. Turn the ignition key to ACC, switch radio ON, and check operation in accordance with instructions supplied with the radio.
19. Turn the ignition key to the OFF position, and remove the key.




Figure 3.109: Radio Panel

## Performing Predelivery Checks

Perform all procedures in this chapter in the order in which they are listed.

### IMPORTANT:

The machine should not require further adjustments; however, perform the following checks and complete the yellow pre-delivery checklist at the end of this book to ensure your machine operates at maximum performance. Make adjustments only if absolutely necessary and in accordance with the instructions in this manual.

### 3.1 Recording Serial Numbers

1. Record the windrower and engine serial numbers on the *Predelivery Checklist*, page 241.

The windrower serial number plate (A) is located on the left side of the main frame near the walking beam as shown.

2. Confirm serial number with manifest or work order.





Figure 3.110: / Serial Number Location

## PERFORMING PREDELIVERY CHECKS

The engine serial number plate (A) is located on top of the engine cylinder head cover as shown.



**Figure 3.111: Engine Serial Number Location**

## 3.2 Checking Tire Pressures and Adding Tire Ballast

### 3.2.1 Checking Tire Pressures

Check tire pressures with a gauge.

Recommended pressure depends on tire type.

- Bar: 221 kPa (32 psi)
- Turf: 138 kPa (20 psi)
- Caster: 69 kPa (10 psi)

### 3.2.2 Adding Tire Ballast

When using a large header on a windrower, adding fluid ballast to rear caster tires will improve machine stability. Machine stability is also affected by different attachments, windrower options, terrains, and driving techniques.

Maximum fluid ballast capability per tire is 75% of full, or when fluid is level with the valve stem positioned at 12 o'clock position. Always add an equal amount of fluid on both sides. Fluid can be added to any level up to maximum fill.

**Table 3.1 Fluid per Tire**

Tire Size	Fluid per Tire at 75% Fill liters (U.S. Gal.)	Total Weight of Both Tires kg (lb.) <sup>3</sup>
7.5 x 16	38 (10)	91 (200)
10 x 16	69 (18)	170 (380)
16.5 x 16.1	158 (41)	377 (830)

**Table 3.2 Recommended Ballast**

Type	Size	Recommended Tire Size	Recommended Ballast			
			Level Ground		Hills	
			Per Tire liters (U.S. Gal.)	Both Tires kg (lb.) <sup>4</sup>	Per Tire liters (U.S. Gal.)	Both Tires kg (lb.) <sup>4</sup>
<b>A Series</b> (all options)	All	7.5 x 16 10 x 16 16.5 x 16.1	0	0	0	0
<b>D/D1 Series</b>	7.6 m (25 ft.) and less	7.5 x 16 10 x 16 16.5 x 16.1	0	0	0	0
<b>D/D1 Series</b>	9.1 m (30 ft.) single reel or double reel (without conditioner) 10.7 m (35 ft.) single reel	7.5 x 16 10 x 16 16.5 x 16.1	69 (18)	170 (380)	115 (30)	288 (630)
<b>D/D1 Series</b>	9.1 m (30 ft.) double reel	Level ground: 10 x 16	115 (30)	288 (630)	158 (41)	377 (830)

- Weights typical for calcium chloride and water mixtures. Reduce weight by 20% if only water is used (for areas that do not freeze).
- If only water is used, increase volume of water by 20% (up to maximum allowable fill per tire) to compensate.



**PERFORMING PREDELIVERY CHECKS**

**Table 3.2 Recommended Ballast (continued)**

Type	Size	Recommended Tire Size	Recommended Ballast			
			Level Ground		Hills	
			Per Tire liters (U.S. Gal.)	Both Tires kg (lb.) <sup>5</sup>	Per Tire liters (U.S. Gal.)	Both Tires kg (lb.) <sup>5</sup>
	(with steel fingers and conditioner) 10.7 m (35 ft.) double reel (5- or 6-bat)	16.5 x 16.1 Hills: 16.5 x 16.1				
<b>D/D1 Series</b>	12.2 m (40 ft.)	16.5 x 16.1	115 (30)	288 (630)	158 (41)	377 (830)
<b>R/R1 Series</b> (all options)	4 m (13 ft.)	7.5 x 16 10 x 16 16.5 x 16.1	0	0	0	0

5. If only water is used, increase volume of water by 20% (up to maximum allowable fill per tire) to compensate.

### 3.3 Checking Engine Air Intake

#### WARNING

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Ensure clips (A) are properly latched to, and plenum box (C) is securely attached onto, cover (B).




Figure 3.112: Air Intake System

#### **Checking constant torque gaps:**

2. Check spring coil gap (A) on constant torque clamp by holding a 0.46 mm (0.018 in.) gauge between the middle coils (B). Tighten clamps until gauge is snug, and remove gauge.




Figure 3.113: Constant Torque Clamp

3. Check four constant torque clamps (A) (two at air intake duct [B] and two at turbocharger tube [C]).

#### **NOTE:**

Some parts removed from illustration for clarity.




Figure 3.114: Air Intake System

## PERFORMING PREDELIVERY CHECKS

4. Check the constant torque clamps (A) securing tube (B) from the cooler to the engine air intake.




Figure 3.115: Air Intake System

### 3.4 Checking Hydraulic Oil Level

**⚠ WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Clean filler cap (A) and surrounding area.
2. Turn filler cap (A) counterclockwise to unlock cap and remove dipstick.




Figure 3.116: Engine Hood

3. Ensure hydraulic oil level is between the low (L) and high (H) marks.
4. If necessary, add oil to maintain a level between the low (L) and high (H) marks. Refer to the windrower operator's manual for specifications.
5. Reinstall dipstick and filler cap, and turn clockwise to tighten and lock.




Figure 3.117: Hydraulic Oil Levels

### 3.5 Checking Fuel Separator

1. Place a container under the filter drain (A).
2. Turn drain valve (A) by hand 1-1/2 to 2 turns counterclockwise until fuel begins draining.
3. Drain the filter sump of water and sediment until clear fuel is visible. Clean as necessary.
4. Turn the drain valve (A) by hand 1-1/2 to 2 turns clockwise until tight.
5. Dispose of fluid in container in a safe manner.




Figure 3.118: Fuel Filter

## PERFORMING PREDELIVERY CHECKS

### 3.6 Checking Engine Oil Level

1. Remove dipstick (A) by turning it counterclockwise to unlock.
2. Wipe the dipstick clean and reinsert it into the engine.
3. Remove the dipstick again and check the oil level.




Figure 3.119: Engine Oil Level

4. Add oil if level is below low (L) mark.

**IMPORTANT:**

Oil level should be maintained between low (L) and high (H) mark on the dipstick.




Figure 3.120: Engine Oil Level

5. Replace dipstick (A) and turn it clockwise to lock.




Figure 3.121: Engine Oil Level

### 3.7 Checking Gearbox Lubricant Level

#### WARNING

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Locate gearbox oil level check plug (A) under the machine. Remove plug (A) and ensure lubricant is visible or slightly running out.
2. If lubricant is required, add gearbox oil. Refer to [7.4 Lubricants, Fluids, and System Capacities](#), page 238.
3. Replace plug (A) and tighten.




Figure 3.122: Gearbox

### 3.8 Checking Engine Coolant

1. Visually inspect the coolant level in the pressurized coolant tank (A).

**NOTE:**

Allow the engine to cool before checking coolant level. The pressurized coolant tank has MAX COLD and MIN COLD coolant level indicators (B), and coolant levels should be between these lines.

2. If necessary, add coolant. Refer to windrower operator's manual for procedure specifications.
3. Ensure coolant concentration in the radiator is rated for -34°C (-30°F).




Figure 3.123: Pressurized Coolant Tank



### 3.9 Checking Air Conditioning (A/C) Compressor Belt

1. Ensure A/C compressor belt (A) is tensioned so that a force of 35–55 N (8–12 lbf) on belt deflects belt 5 mm (3/16 in.) at its midspan.




Figure 3.124: A/C Compressor Belt

### 3.10 Draining and Refilling the Diesel Exhaust Fluid (DEF) Tank

Drain the DEF tank and refill with fresh DEF when the windrower is received.

**⚠ WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator’s seat for any reason.

1. Open the maintenance platform on right cab-forward side.
2. Place a drain pan under the DEF tank. Use a sufficiently large drain pan; tank capacity is 29 L (7.5 US gal).

**IMPORTANT:**

Any spilled DEF must be contained and absorbed by non-combustible absorbent material like sand, and then shoveled to a suitable container for disposal. DEF is corrosive. If spilled on tank or any surface of the vehicle, rinse thoroughly with water.

**⚠ WARNING**

Diesel Exhaust Fluid (DEF) contains urea. Do NOT get the substance in your eyes. In case of contact, immediately flush eyes with water for a minimum of 15 minutes. Do NOT swallow. In the event the DEF is ingested, contact doctor immediately.

3. Remove the drain plug (A) from under the tank (B) and drain.
4. Add some DEF to the tank (B) to flush out remaining contaminants.
5. Drain the DEF that was used to clean the tank.
6. Reinstall drain plug (A) in the tank (B).




Figure 3.125: View from beneath Tank

**IMPORTANT:**

Before refilling the DEF tank, read the following instructions from decal (A) located on the tank cover:

- Before storing machine for periods of time greater than six months, drain DEF tank to prevent degradation of fluid.
- Before storing the machine in temperatures below 0°C (32°F), ensure level of fluid in DEF tank is 75 % or lower.




Figure 3.126: DEF Tank

Take the following precautions when handling DEF to prevent contamination:

## PERFORMING PREDELIVERY CHECKS

- Avoid using funnels and containers that have been used with fuels or lubricants.
  - Use only distilled water to rinse the components that store or deliver DEF; tap water can contaminate DEF.
  - If distilled water is not available, use clean tap water, then rinse components with DEF.
7. Clean around filler cap (A).
  8. Turn cap (A) counterclockwise until loose and remove cap.
  9. Fill the tank with an approved DEF. Refer to the windrower operator's manual for specifications.
  10. Replace filler cap (A) and turn clockwise until tight.
  11. Close the maintenance platform.




Figure 3.127: DEF Tank

### 3.11 Starting Engine

**⚠ CAUTION**

Park on a flat, level surface with the ground speed lever in N-DETENT position and the steering wheel in locked position (centered). Wait for the CDM to beep and display an “In Park” message to confirm the park brakes have engaged.

1. Ensure there is sufficient diesel exhaust fluid (DEF) to avoid DEF level warnings.
2. Ensure lock (A) is engaged at the cab-forward or engine-forward position.




Figure 3.128: Operator Console

3. Move the ground speed lever (GSL) (A) into the N-DETENT position.
4. Turn the steering wheel until it locks (center).
5. Push header drive switch (B) to the OFF position.

**⚠ CAUTION**

Check to be sure all bystanders have cleared the area.




Figure 3.129: Operator Console

## PERFORMING PREDELIVERY CHECKS

### Normal start (all engines):

6. Follow these steps when starting engine in temperatures above 16°C (60°F):
  - a. Move throttle fully back to START position (A).
  - b. Sound horn three times.
  - c. Turn ignition key (B) to RUN position.

#### NOTE:

A single loud tone will sound, engine warning lights will illuminate, and the cab display module will display HEADER DISENGAGED and IN PARK.

- d. Turn ignition key (B) to START position until engine starts and then release the key. The tone will cease and warning lights will go out.



### WARNING

If starter engages with steering wheel unlocked, ground speed lever out of NEUTRAL, or header clutch engaged, do NOT start engine. Refer to the technical manual.




Figure 3.130: Operator Console

### IMPORTANT:

- Do NOT operate starter for longer than 15 seconds at a time.
- If engine does NOT start, wait at least 2 minutes before trying again.
- After the third 15-second crank attempt, allow the starter motor to cool for 10 minutes before further cranking attempts.
- If engine still does NOT start, refer to Table 3.3, page 94.

### Cold start:

#### NOTE:

Engines are equipped with cold start assist system.

7. Use cold start for engine temperatures below 5°C (40°F). Refer to Step 6, page 93 for engine temperatures below 5°C (40°F), but adhere to the following NOTE and IMPORTANT statements while starting the engine.

#### NOTE:

Engine will cycle through a period when it appears to labour during engine warm up. The throttle is nonresponsive while engine is in warm up mode. Warm up mode lasts between 30 seconds and 3 minutes depending on the temperature. The throttle will become active after the engine has stabilized and is idling normally.

#### IMPORTANT:

Do NOT operate engine above 1500 rpm until engine temperature is above 40°C (100°F).

## PERFORMING PREDELIVERY CHECKS

**Table 3.3 Engine Start Troubleshooting**

Problem	Solution
Controls not in NEUTRAL	<ul style="list-style-type: none"> <li>• Move GSL to NEUTRAL</li> <li>• Move steering wheel to locked (centered) position</li> <li>• Disengage HEADER switch</li> </ul>
Operator's station not locked	<ul style="list-style-type: none"> <li>• Adjust position of operator's station</li> <li>• Ensure lock is engaged</li> </ul>
Neutral interlock misadjusted	<ul style="list-style-type: none"> <li>• Refer to the windrower technical manual</li> </ul>
No fuel to engine	<ul style="list-style-type: none"> <li>• Fill empty fuel tank</li> <li>• Replace clogged filter</li> <li>• Ensure fuel shut off valve is in open position</li> </ul>
Old fuel in tank	<ul style="list-style-type: none"> <li>• Drain tank</li> <li>• Refill with fresh fuel</li> </ul>
Water, dirt, or air in fuel system	<ul style="list-style-type: none"> <li>• Drain, flush, fill, and prime system</li> </ul>
Improper type of fuel	<ul style="list-style-type: none"> <li>• Drain tank</li> <li>• Refill with correct fuel</li> </ul>
Crankcase oil too heavy	<ul style="list-style-type: none"> <li>• Replace with recommended oil</li> </ul>
Low battery output	<ul style="list-style-type: none"> <li>• Test the battery</li> <li>• Check battery electrolyte level</li> </ul>
Poor battery connection	<ul style="list-style-type: none"> <li>• Clean and tighten loose connections</li> </ul>
Faulty starter	<ul style="list-style-type: none"> <li>• Refer to the windrower technical manual</li> </ul>
Wiring shorted, circuit breaker open	<ul style="list-style-type: none"> <li>• Check continuity of wiring and breaker (manually reset)</li> </ul>
Faulty injectors	<ul style="list-style-type: none"> <li>• Refer to the windrower technical manual</li> </ul>

### 3.12 Priming Hydraulic System on an M155E4

1. Remove the hydraulic oil reservoir filler cap/dipstick (A).
2. Open the engine compartment hood to the highest position.



Figure 3.131: Filler Cap/Dipstick

3. From underneath the machine, locate plug (A) on the side of the header drive pump housing.
4. Loosen plug (A) to bleed the pump housing. Retighten the plug once oil starts to run out.




Figure 3.132: Header Drive Pump Housing

## PERFORMING PREDELIVERY CHECKS

5. From above the machine, locate plug (A) on the top of the header drive pump housing.
6. Loosen plug (A) to bleed the pump housing. Retighten the plug once oil starts to run out.




Figure 3.133: Header Drive Pump Housing

7. From above the machine, locate plug (A) on the top of the traction drive pump housing.
8. Loosen plug (A) to bleed the pump housing. Retighten the plug once oil starts to run out.
9. Replace the hydraulic oil reservoir filler cap.




Figure 3.134: Traction Drive Pump Housing



## PERFORMING PREDELIVERY CHECKS

10. Open the left (cab-forward) platform.
11. Disconnect the brake engage solenoid plug (P44) (A) at the multifunction block on the left side of the windrower.




Figure 3.135: Multifunction Control Manifold

12. Disconnect the electrical connection (A) at the fuel pump on the right side of the engine.




Figure 3.136: Fuel Pump Location

## PERFORMING PREDELIVERY CHECKS

13. Open the maintenance platform on the right (cab-forward) side.
14. Open the circuit breaker/fuse box (A), and remove the engine control module (ECM) ignition fuse (5A) (B).

### CAUTION

Check to be sure all bystanders have cleared the area.

15. Prime the system by cranking the engine with the starter for 15 seconds.
16. Reconnect the electrical connection at the fuel pump and at the brake engage solenoid.
17. Reinstall ECM ignition fuse (5A) (B) and the circuit breaker/fuse box (A).
18. Close the engine compartment hood.




Figure 3.137: Circuit Breaker/Fuse Box

19. Check the hydraulic oil level in the reservoir (remove filler cap/dipstick (A) and add SAE 15W-40 oil if necessary). Refer to [3.4 Checking Hydraulic Oil Level, page 84](#).
20. Close the platforms.




Figure 3.138: Filler Cap/Dipstick

### 3.13 Checking and Adding Wheel Drive Lubricant Level

**⚠ WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator’s seat for any reason.

**⚠ CAUTION**

Park on a flat, level surface with the header on the ground, the ground speed lever in N-DETENT position, and the steering wheel in locked position (centered). Wait for the CDM to beep and display an “In Park” message to confirm the park brakes have engaged.

1. Park the windrower on level ground.
2. Position windrower so plugs (A) and (B) are horizontally aligned with the center (C) of the hub.
3. Stop the engine, and remove the key.
4. Remove plug (A) or (B). The lubricant should be visible through the port or running out slightly.
5. If lubricant needs to be added, remove the second plug (A) or (B), and add lubricant until lubricant runs out from the other port (A). For lubricant specifications, refer to the inside back cover of this book.
6. Reinstall plugs and tighten.





Figure 3.139: Drive Wheel Hub

### 3.14 Checking Traction Drive

#### CAUTION

Check to be sure all bystanders have cleared the area.

1. Move the ground speed lever (GSL) (A) out of N-DETENT and slowly move the GSL forwards. Ensure the wheels are rotating in the forward direction and at the same speed.
2. Turn the steering wheel and observe the motion of the drive wheels. Ensure the wheels rotate at different speeds with the slower rotating wheel on the same side of the machine that the steering wheel is turned towards.
3. Turn the steering wheel in the opposite direction and ensure the slower rotating wheel is on the same side of the machine that the steering wheel is turned towards.
4. Move the GSL backwards into reverse. Ensure the wheels are rotating in the reverse direction and at the same speed.
5. Move the GSL forwards into N-DETENT and shut down the engine.



**Figure 3.140: Operator Console**

### 3.19 Removing Windrower from Stand

The procedure for removing the windrower from the support stand differs depending on whether you are using a factory-built stand or a field-constructed stand. Refer to the following procedures according to for your specific stand:

- [3.19.1 Removing Windrower from Factory Stand, page 101](#)
- [3.19.2 Removing Windrower from Field Stand, page 102](#)

#### 3.19.1 Removing Windrower from Factory Stand

1. Move valve handle (A) upwards to slightly raise the windrower and take load off the lift locks.




Figure 3.141: Air Control Valve Tripod

2. Release the lift lock mechanisms (three places) and turn keeper to keep the lock in the released position.
3. Move the valve handle downwards to slowly release the pressure from the air bag system and lower the windrower to the ground.

**CAUTION**

**Ensure all three lifts have fully retracted and are clear of the windrower frame before driving windrower ahead.**

4. Start the engine and drive the machine straight ahead, leaving the shipping support channels supported on the rear support stand.




Figure 3.142: Lift System

### **3.19.2 Removing Windrower from Field Stand**

1. Position a jack under the jack point of each drive wheel leg and under the rear hitch.
2. Raise the jacks to take the weight off the stands, and remove the stands.
3. Lower the windrower slowly to the ground, and remove the jacks.

# Chapter 4: Cab Display Module (CDM)

Although the other procedures in this instruction are intended to be followed in the order in which they are listed, the sections in this chapter can be referred to in any order according to your specific requirements.

## 4.1 Cab Display Module (CDM) Configuration

Figure 4.1: CDM



A - Side Display  
D - Menu Item Scroll Forward

B - Main Display  
E - Menu Item Scroll Backward

C - Select Switch  
F - Program Switch

**Side Display:** Displays software revision status.

- Upper line – C### (CDM)
- Lower line – E### (WCM)

**Main Display:** Displays menu item and selection<sup>5</sup>.

- Upper line – Menu item
- Lower line – Selection

**Select Switch:** Places monitor into program mode with PROGRAM switch. Press to accept menu item and advance to next item.

**Menu Item Scroll Forward:** Displays value under menu item.

- Push to scroll forward
- Hold down for fast scroll<sup>6</sup>

**Menu Item Scroll Backward:** Displays value under menu item.

5. The current selection is flashing.

6. Fast scroll applies only when changing KNIFE SPEED, OVERLOAD PRESSURE, and TIRE SIZE.

## CAB DISPLAY MODULE (CDM)

- Push to scroll backward
- Hold down for fast scroll<sup>6</sup>

**Program Switch:** Places monitor into program mode. Press while pressing select switch.

**NOTE:**

The following menus are available when ignition key is set to RUN:

- WINDROWER SETUP
- CAB DISPLAY SETUP
- DIAGNOSTIC MODE

The CALIBRATE SENSORS menu is available only when engine is running.



## 4.2 Cab Display Options

The display and sound features of the cab display module (CDM) can be adjusted to suit each particular Operator.

**NOTE:**

The procedures listed in this section are current for CDM software version C512 and windrower control module (WCM) E237. The WCM is supplied preloaded with the latest released version of the operating software. Any subsequent updates will be made available via internet download from the MacDon Dealer Portal (<https://portal.macdon.com>).

**NOTE:**

Pages may appear differently if running newer or older versions of software, and not all features are available on every machine.

### 4.2.1 Setting the Cab Display Language

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.2: Windrower Setup Display

3. Press SELECT (A) until CAB DISPLAY SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.3: Cab Display Setup

## CAB DISPLAY MODULE (CDM)

- Press right arrow (C) to select YES. Press SELECT (D).

- DISPLAY LANGUAGE? is displayed on the upper line.
- Default language is displayed on the lower line.

- Press left (B) or right (C) arrow to select preferred language.

### NOTE:

English, Russian, and Spanish language options are available on windrowers. Not all language options are available on all windrowers.

- Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next CAB DISPLAY SETUP? action.




Figure 4.4: Language Display

## 4.2.2 Changing the Windrower Display Units

- Turn ignition key to RUN, or start the engine.
- Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.

- WINDROWER SETUP? is displayed on the upper line.
- NO/YES is displayed on the lower line.



Figure 4.5: CDM Programming Buttons

- Press SELECT (B) until CAB DISPLAY SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (A) to select YES. Press SELECT (B).
  - DISPLAY LANGUAGE? is displayed on the upper line.



Figure 4.6: Cab Display Setup

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (D) until DISPLAY UNITS? is displayed on the upper line.
  - Default setting is displayed on the lower line.
6. Press left (B) or right (C) arrow to select either METRIC or IMPERIAL speed display.
7. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next CAB DISPLAY SETUP? action.



Figure 4.7: Display Units

### 4.2.3 Adjusting the Cab Display Buzzer Volume

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.8: CDM Programming Buttons

3. Press SELECT (B) until CAB DISPLAY SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).
  - DISPLAY LANGUAGE? is displayed on the upper line.



Figure 4.9: Cab Display Setup

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (D) until BUZZER VOLUME is displayed on the upper line.
  - Previous setting is displayed on the lower line.
6. Press left (B) or right (C) arrows to adjust buzzer volume.
7. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next CAB DISPLAY SETUP? action.




Figure 4.10: Buzzer Volume

### 4.2.4 Adjusting the Cab Display Backlighting

The backlighting feature brightens the display screen helping you read the cab display module (CDM) in low light situations.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.11: CDM Programming Buttons

3. Press SELECT (B) until CAB DISPLAY SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).
  - DISPLAY LANGUAGE? is displayed on the upper line.



Figure 4.12: Cab Display Setup

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (D) until BACKLIGHTING is displayed on the upper line.
  - Default setting is displayed on the lower line.
6. Press left (B) or right (C) arrows to adjust display backlighting.
7. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next CAB DISPLAY SETUP? action.



Figure 4.13: Backlighting

### 4.2.5 Adjusting the Cab Display Contrast

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.14: CDM Programming Buttons

3. Press SELECT (B) until CAB DISPLAY SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).
  - DISPLAY LANGUAGE? is displayed on the upper line.



Figure 4.15: Cab Display Setup

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (D) until DISPLAY CONTRAST is displayed on the upper line.
  - Default setting is displayed on the lower line.
6. Press left (B) or right (C) arrows to adjust display contrast.
7. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next CAB DISPLAY SETUP? action.



Figure 4.16: Display Contrast

## 4.3 Configuring the Windrower

The windrower can be configured to meet changing crop conditions, activate newly added options, indicate a change of header type, or increase operator comfort level.

### 4.3.1 Setting the Header Knife Speed

This topic does not apply to rotary disc headers.

**NOTE:**

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.
  - The current knife speed is displayed on the lower line.




Figure 4.17: CDM Programming Buttons

4. Press left (B) or right (C) arrows to select knife speed. Press SELECT (D).
5. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.18: Knife Speed

### 4.3.2 Setting the Knife Overload Speed

This topic does not apply to rotary disc headers.

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- The recommended knife overload speed is 75% of knife speed.

## CAB DISPLAY MODULE (CDM)

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.



Figure 4.19: CDM Programming Buttons

4. Press SELECT (D) until KNIFE OVERLOAD SPD? is displayed on the upper line.
    - Current overload speed is displayed on the lower line.
- NOTE:**  
Default setting is -300 spm. Range is -500 to -100 spm.
5. Press left (B) or right (C) arrows to set knife overload speed. Press SELECT (D).
  6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.20: Knife Overload Speed



### 4.3.3 Setting the Rotary Disc Overload Speed

This topic applies to rotary disc headers only.

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- The recommended disc overload speed is 75% of disc speed. For more information, refer to the rotary disc header operator's manual to determine proper overload speed.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line. NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.



Figure 4.21: CDM Programming Buttons

4. Press SELECT (D) until DISC OVERLOAD SPD? is displayed on the upper line.
  - The current overload speed is displayed on the lower line.

**NOTE:**

Default setting is -300 rpm. Range is -500 to -100 rpm.

5. Press left (B) or right (C) arrows to set disc overload speed. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.22: Disc Overload Speed

### 4.3.4 Setting the Hydraulic Overload Pressure

**NOTE:**

- This procedure requires installation of the optional pressure sensor (MD #B5574). For overload pressure values, refer to pressure sensor installation instructions (MD #169031).
- To enable sensor, refer to [4.8.2 Switching the Installed Header Sensors ON or OFF, page 148](#).

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.



Figure 4.23: CDM Programming Buttons

4. Press SELECT (D) until OVERLOAD PRESSURE? is displayed on the upper line.
  - The current overload pressure is displayed on lower line.

**NOTE:**

Pressure range is 17,237–34,474 kPa (2500–5000 psi).

5. Press left (B) or right (C) arrows to set hydraulic overload pressure. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.24: Hydraulic Overload Pressure

## CAB DISPLAY MODULE (CDM)

### 4.3.5 Setting the Header Index Mode

Header Index feature is not applicable to rotary disc headers. Index mode links reel and draper speed to ground speed.

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.25: CDM Programming Buttons

4. Press SELECT (D) until HEADER INDEX MODE? is displayed on the upper line.
  - REEL & CONVEYOR or REEL ONLY is displayed on the lower line.
5. Press left (B) or right (C) arrows to set HEADER INDEX mode. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.26: Header Index Mode

## CAB DISPLAY MODULE (CDM)

### 4.3.6 Setting the Return to Cut Mode

Return to Cut allows the operator to resume preferred header positions and headland presets.

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.



Figure 4.27: CDM Programming Buttons

4. Press SELECT (D) until RETURN TO CUT MODE? is displayed on the upper line.
  - HEIGHT & TILT or HEIGHT ONLY will be displayed on the lower line.
5. Press left (B) or right (C) arrows to select RETURN TO CUT MODE. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.28: Return to Cut Mode

### 4.3.7 Setting the Auto Raise Height

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

## CAB DISPLAY MODULE (CDM)

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter Programming Mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.29: CDM Programming Buttons

4. Press SELECT (D) until AUTO RAISE HEIGHT? is displayed on the upper line.
  - Last measurement is displayed on the lower line.

**NOTE:**

The auto raise height ranges from 4.0 (minimum) to 9.5 (maximum), in 0.5 increments. A setting of 10 disables the auto raise function.

5. Press left arrow (B) or right arrow (C) to change auto raise height.
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.30: Auto Raise Height

### 4.3.8 Activating the Double Windrow Attachment (DWA)

**NOTE:**

- Follow this procedure if installing the DWA; however, refer to the DWA manual if you require additional installation instructions.
- The DWA cannot be activated if the swath compressor is enabled.
- Follow this procedure if installing a drive manifold (MD #139508).

### 4.3.9 Activating the Hydraulic Center-Link

1. Turn ignition key to RUN, or start the engine. For instructions, refer to [3.11 Starting Engine, page 92](#).
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.31: CDM Programming Buttons

4. Press SELECT (C) until TILT CYL INSTALLED? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (B) to select YES. Press SELECT (C).
6. Press PROGRAM (A) to exit programming mode or press SELECT (C) to proceed to next WINDROWER SETUP action.



Figure 4.32: Hydraulic Center-Link

### 4.3.10 Activating the Rotary Header Drive Hydraulics

**NOTE:**

This procedure requires installation of the optional Rotary Header Drive Hydraulics (MD #B5510). For more information, refer to the rotary disc header operator's manual.

## CAB DISPLAY MODULE (CDM)

1. Turn ignition key to RUN, or start the engine. For instructions, refer to [3.11 Starting Engine, page 92](#).
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.33: CDM Programming Buttons

4. Press SELECT (C) until DISC BLK INSTALLED? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (B) to select YES. Press SELECT (C).
6. Press PROGRAM (A) to exit programming mode or press SELECT (C) to proceed to next WINDROWER SETUP action.



Figure 4.34: Rotary Disc Hydraulics

### 4.3.11 Setting the Header Cut Width

#### NOTE:

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
  - Header cut width is less than actual header width to accurately measure number of acres cut.
  - The header sends an electrical signal to the windrower to produce a header ID; however, the cut width will always default to the smallest header size available for each header type. For example, A Series Auger Headers come in 4.3, 4.9, and 5.5 m (14, 16, and 18 ft.) sizes, but the cut width will default to 4.3 m (14 ft.). Adjust setting to your specific header size.
1. Turn ignition key to RUN, or start the engine.

## CAB DISPLAY MODULE (CDM)

2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed.




Figure 4.35: CDM Programming Buttons

4. Press SELECT (D) until HDR CUT WIDTH? ##### is displayed on the upper line.
  - Previous cutting width is displayed on the lower line.
5. Press left (B) or right (C) arrows to change the header cut width. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.36: Header Cut Width



### 4.3.12 Activating the Swath Compressor

An optional swath (MD #C2061) is available through Whole Goods.

**NOTE:**

- CDM5 (version 512 or later) and WCM2 (version 237 or later), or WCM3 (version 116 or later), are required to operate the swath compressor.
- The DWA must be disabled in the CDM when setting up the swath compressor.
- Users can activate and set up the swath compressor via in-cab controls without a header attached to an M155E4 windrower.
- Use the following procedure when installing and setting up the swath compressor.

**CAUTION**

**Check to be sure all bystanders have cleared the area.**

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.
4. Press SELECT (B) until SWATH COMPR INSTALL? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).
6. Press SELECT (B) until CALIBRATE SENSORS is displayed on upper line. NO/YES is displayed on lower line.
7. Press right arrow (A) to select YES. Press SELECT (B).
  - TO CALIBRATE SELECT is displayed on upper line.
  - HEADER HEIGHT is displayed on lower line.
8. Press right arrow (A) to scroll through choices until SWATH COMPR HT is displayed. Press SELECT (B).
  - SWATH SENSOR CAL is displayed on upper line.
  - SWATH UP TO START is displayed on lower line.




Figure 4.37: CDM Programming Buttons



Figure 4.38: Swath Compressor Controls

## CAB DISPLAY MODULE (CDM)

9. Press switch (B) on console to raise swath compressor.
  - CALIBRATING SWATH is displayed on upper line.
  - FORM UP and flashing HOLD is displayed on lower line until system has completed reading signal with swath compressor fully raised.
  - SWATH FORM UP and DONE (with buzzer) is displayed on lower line when complete.
  - SWATH SENSOR CAL is displayed on upper line.
  - PRESS SWATH DOWN is displayed on lower line.
10. Press switch (A) on console to lower swath compressor.
  - CALIBRATING SWATH is displayed on upper line.
  - FORM DOWN and HOLD is displayed on lower line.
  - SWATH FORM COMPLETE flashes for 2 seconds on lower line (with buzzer) when calibration is finished.
11. Press PROGRAM (A) to exit programming mode or press SELECT (C) to proceed to next windrower setup action.




Figure 4.39: Swath Compressor Switch




Figure 4.40: CDM Programming Buttons

### 4.3.13 Activating the Hay Conditioner

**NOTE:**

- This procedure is for draper headers only.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.41: CDM Programming Buttons

4. Press SELECT (C) until HAY CONDITIONER? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (B) to select YES. Press SELECT (C).
6. Press PROGRAM (A) to exit programming mode or press SELECT (C) to proceed to next WINDROWER SETUP action.



Figure 4.42: Hay Conditioner

### 4.3.14 Displaying Reel Speed

**NOTE:**

- This procedure is for draper and auger headers. It does not apply to rotary disc headers.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on CDM to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.43: CDM Programming Buttons

4. Press SELECT (D) until HEADER REEL SPEED? is displayed on the upper line.
  - RPM/MPH or RPM/KPH is displayed on the lower line.
5. Press left (B) or right (C) arrow to select either IMPERIAL or METRIC units. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.44: Reel Speed Display

### 4.3.15 Setting the Windrower's Tire Size

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.45: CDM Programming Buttons

4. Press SELECT (D) until SET TIRE SIZE? is displayed on the upper line.
  - Currently installed tire size is displayed on the lower line.

**NOTE:**

The following tire sizes are available:

- 18.4 x 26 TURF
- 18.4 x 26 BAR
- 23.1 x 26 TURF
- 600 – 65 R28

5. Press left (B) or right (C) arrow and select tire size. Press SELECT (D).
6. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.46: Tire Size

### 4.3.16 Setting the Engine Intermediate Speed Control (ISC) RPM

The engine operating speed can be programmed to enable the windrower to operate at reduced engine rpm (that is, 1900, 2050, or 2200 rpm) without significantly affecting the ground or header speeds. The default setting is 2200 rpm or the last selected rpm.

**NOTE:**

The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.47: CDM Programming Buttons

4. Press SELECT (B) until SET ENGINE ISC RPM? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).
  - PRESS HAZARD TO SET is displayed on the upper line.
  - ISC RPM ##### is displayed on the lower line.




Figure 4.48: Engine ISC RPM

Table 4.1 ISC Settings

ISC and RPM		
Off <sup>7</sup>	1	2
High Idle	2050	1900

**NOTE:**

The previously selected ISC rpm will be flashing.

---

7. Off is always used when the header is not engaged.

## CAB DISPLAY MODULE (CDM)

- Press right arrow (C) to cycle between rpm options.  
Press HAZARD (B) to set.
- Press Select (D).
  - EXIT ENGINE ISC? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (C) to select YES. Press SELECT (D).
- Press PROGRAM (A) to exit programming mode.



Figure 4.49: ISC RPM

### 4.3.17 Clearing Sub-Acres

The windrower has two counters for acres: one counter tracks a total count of acres harvested for the machine's lifetime, and the other counter tracks sub-acres harvested for smaller harvesting instances (instances like harvesting a particular field, or for a particular day). The total acres can't be cleared from the windrower's tracking, but the sub-acres can be cleared between smaller harvesting instances.

- With the key in the ON position, and the operator's station in cab-forward mode, press SELECT until the cab display module (CDM) displays sub-acres on the bottom line. Then press and hold the PROGRAM (A) button on the CDM until the sub-acres are cleared.



Figure 4.50: Cab Display Module (CDM)

## 4.4 Activating Cab Display Lockouts

You can lock some of the header functions controlled by the cab display module (CDM) to prevent accidental changes to header settings. You can use this feature to keep header settings constant when several different Operators use the windrower.

**NOTE:**

FUNCTION LOCKED flashes on CDM when locked header function switch is pressed.

### 4.4.1 Activating the Header Tilt Control Lockout

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

- Turn ignition key to RUN, or start the engine.
- Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.51: CDM Programming Buttons

- Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.52: Control Locks



## CAB DISPLAY MODULE (CDM)

- Press SELECT (D) until HEADER TILT is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
- Press left arrow (B) to enable HEADER TILT control switch.  
Press right arrow (C) to lock HEADER TILT control switch.
- Press PROGRAM (A) to exit programming mode, or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.53: Header Tilt Control Lock

### 4.4.2 Activating the Header Float Control Lockout

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

- Turn ignition key to RUN, or start the engine.
- Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.54: CDM Programming Buttons

- Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
- Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.55: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until HEADER FLOAT is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable HEADER FLOAT control switch, or press right arrow (C) to lock HEADER FLOAT control switch.
8. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.56: Header Float Control Lock

### 4.4.3 Activating the Reel Fore-Aft Control Lockout

**NOTE:**

- This procedure is for draper headers only.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.57: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.58: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until REEL FORE/AFT is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable REEL FORE/AFT control switch.
 

Press right arrow (C) to lock REEL FORE/AFT control switch.
8. Press PROGRAM (A) to exit programming mode, or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.59: Reel Fore-Aft Control Lock

### 4.4.4 Activating the Draper Speed Control Lockout

#### NOTE:

- This procedure is for draper headers only.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.60: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.61: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until DRAPER SPEED is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable DRAPER SPEED control switch, or press right arrow (C) to lock DRAPER SPEED control switch.
8. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.62: Draper Control Lock

### 4.4.5 Activating the Auger Speed Control Lockout

#### NOTE:

- This procedure is for A40D headers only.
- An auger header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.63: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.64: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until AUGER SPEED is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable AUGER SPEED control switch.
  - Press right arrow (C) to lock AUGER SPEED control switch.
8. Press PROGRAM (A) to exit programming mode, or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.65: Auger Control Lock

### 4.4.6 Activating Knife Speed Control Lockout

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.66: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.67: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until KNIFE SPEED is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable KNIFE SPEED control switch, or press right arrow (C) to lock KNIFE SPEED control switch.
8. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.



Figure 4.68: Knife Speed Control Lock

### 4.4.7 Activating Rotary Disc Speed Control Lockout

#### NOTE:

- This procedure is for rotary disc headers only.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.69: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.70: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until DISK SPEED is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable DISK SPEED control switch, or press right arrow (C) to lock DISK SPEED control switch.
8. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.71: Disc Speed Control Lock

### 4.4.8 Activating the Reel Speed Control Lockout

#### NOTE:

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.



Figure 4.72: CDM Programming Buttons

4. Press SELECT (B) until SET CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.73: Control Locks

## CAB DISPLAY MODULE (CDM)

6. Press SELECT (D) until REEL SPEED is displayed on the upper line.
  - ENABLED/LOCKED is displayed on the lower line.
7. Press left arrow (B) to enable REEL SPEED control switch.

Press right arrow (C) to lock REEL SPEED control switch.
8. Press PROGRAM (A) to exit programming mode, or press SELECT (D) to proceed to next WINDROWER SETUP action.




Figure 4.74: Reel Speed Control Lock



## 4.5 Displaying Activated Cab Display Lockouts

Displaying the activated control locks allows you to quickly determine which controls are locked on the cab display module (CDM).

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press right arrow (B) to select YES. Press SELECT (C).
  - SET KNIFE SPEED? is displayed on the upper line.




Figure 4.75: CDM Programming Buttons

4. Press SELECT (B) until VIEW CONTROL LOCKS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
5. Press right arrow (A) to select YES. Press SELECT (B).
  - HEADER TILT is displayed on the upper line.
  - The control switch status is displayed on the lower line. The hours displayed indicate when a switch was enabled or locked.



Figure 4.76: Control Locks

6. Press left (B) or right (C) arrow to cycle between control switch lockouts. The displayed control switches are as follows:
  - HEADER TILT
  - HEADER FLOAT
  - REEL FORE/AFT
  - DRAPER SPEED
  - AUGER SPEED
  - KNIFE SPEED
  - DISK SPEED
  - REEL SPEED



Figure 4.77: Control Locks

**NOTE:**

Not all control locks apply to every header.

## CAB DISPLAY MODULE (CDM)

7. Press SELECT (D).
  - EXIT VIEW LOCKOUTS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
8. Press right (C) to select YES.
9. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next WINDROWER SETUP action.

## 4.6 Calibrating the Header Sensors

Sensor calibration programs the windrower control module (WCM) with settings for the attached header.

### 4.6.1 Calibrating the Header Height Sensor

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its configuration for each header type.
- The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
3. Press SELECT (B) until CALIBRATE SENSORS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.78: CDM Programming Buttons

4. Press right arrow (B) to select YES. Press SELECT (C).
  - TO CALIBRATE SELECT is displayed in upper line.
5. Press left (A) or right (B) arrow until HEADER HEIGHT is displayed on the lower line. Press SELECT (C).
  - CALIBRATING HEIGHT is displayed on the upper line.
  - RAISE HEADER HOLD is displayed on the lower line.



Figure 4.79: Header Height Calibration

## CAB DISPLAY MODULE (CDM)

### CAUTION

Check to be sure all bystanders have cleared the area.

6. Press and hold the HEADER UP button (A) on the ground speed lever (GSL).
  - CALIBRATING HEIGHT is displayed on the upper line.
  - RAISE HEADER HOLD is displayed on the lower line.

**NOTE:**

The word HOLD will flash during calibration. RAISE HEADER DONE will display on the lower line once calibration is complete.

7. Release the HEADER UP button (A).
  - HEIGHT SENSOR CAL is displayed on the upper line.
  - PRESS LOWER HEADER is displayed on the lower line.




Figure 4.80: Header Height Controls on GSL

8. Press and hold HEADER DOWN button (A) on the GSL.

**NOTE:**

The word HOLD will flash during calibration. HT SENSOR COMPLETE will display on the lower line once calibration is complete.

9. Release HEADER DOWN button (A).
  - TO CALIBRATE SELECT is displayed on the upper line.
  - HEADER HEIGHT is displayed on the lower line.
10. Press right arrow to select next header sensor calibration or STOP & EXIT. Press SELECT.
11. Press PROGRAM to exit programming mode.




Figure 4.81: Header Height Controls on GSL

## 4.6.2 Calibrating the Header Tilt Sensor

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
3. Press SELECT (B) until CALIBRATE SENSORS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.82: CDM Programming Buttons

4. Press right arrow (B) to select YES. Press SELECT (C).
  - TO CALIBRATE SELECT is displayed in upper line.
5. Press left (A) or right (B) arrow until HEADER TILT is displayed on the lower line. Press SELECT (C).
  - HDR TILT SENSOR CAL is displayed on the upper line.
  - EXTEND TILT TO START is displayed on the lower line.



Figure 4.83: Header Tilt

**CAUTION**

Check to be sure all bystanders have cleared the area.

6. Press and hold the HEADER TILT EXTEND button (A) on the ground speed lever (GSL).
  - CALIBRATING TILT is displayed on the upper line.
  - EXTEND TILT HOLD is displayed on the lower line.

**NOTE:**

The word HOLD will flash during calibration. HEADER TILT DONE will display on the lower line once calibration is complete.

7. Release the HEADER TILT EXTEND button (A).
  - HEADER TILT SENSOR CAL is displayed on upper line.
  - PRESS RETRACT TILT is displayed on the lower line.




Figure 4.84: Header Tilt Controls on GSL

8. Press and hold HEADER TILT RETRACT button (A) on GSL.
  - CALIBRATING TILT is displayed on the upper line.
  - RETRACT TILT HOLD is displayed on the lower line.

**NOTE:**

The word HOLD will flash during calibration. HEADER TILT COMPLETE will display on the lower line once calibration is complete.

9. Release HEADER TILT RETRACT button (A).
  - TO CALIBRATE SELECT is displayed on the upper line.
  - HEADER TILT is displayed on the lower line.
10. Press right arrow to select next header sensor calibration or STOP & EXIT. Press SELECT.
11. Press PROGRAM to exit programming mode.




Figure 4.85: Header Tilt Controls on GSL

## CAB DISPLAY MODULE (CDM)

### 4.6.3 Calibrating the Header Float Sensors

#### NOTE:

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- Use the left or right FLOAT buttons on the cab display module (CDM) to perform this procedure.

#### IMPORTANT:

Ensure float pins (A) are installed in the working position.




Figure 4.86: Float Pin – Right Side

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
3. Press SELECT (B) until CALIBRATE SENSORS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.87: CDM Programming Buttons

4. Press right arrow (B) to select YES. Press SELECT (C).
  - TO CALIBRATE SELECT is displayed in upper line.
5. Press left (A) or right (B) arrow until HEADER FLOAT is displayed on the lower line. Press SELECT (C).
  - CALIBRATING FLOAT is displayed on the upper line.
  - PRESS FLOAT + TO START is displayed on the lower line.



Figure 4.88: Header Float Display

## CAB DISPLAY MODULE (CDM)

### CAUTION

Check to be sure all bystanders have cleared the area.

6. Press and hold FLOAT + button (A) on the CDM.
  - CALIBRATING FLOAT is displayed on the upper line.
  - FLOAT ( + ) HOLD is displayed on the lower line.

#### NOTE:

The word HOLD will flash during calibration. FLOAT (+) DONE will display on the lower line once calibration is complete.

7. Release the FLOAT + button (A).
  - CALIBRATING FLOAT is displayed on the upper line.
  - FLOAT ( - ) HOLD is displayed on the lower line.

8. Press and hold FLOAT – button (A) on CDM.
  - CALIBRATING FLOAT is displayed on the upper line.
  - FLOAT ( - ) HOLD is displayed on the lower line.

#### NOTE:

The word HOLD will flash during calibration. HDR FLOAT COMPLETE will display on the lower line once calibration is complete.

9. Release FLOAT – button (A).
  - TO CALIBRATE SELECT is displayed on the upper line.
  - HEADER FLOAT is displayed on the lower line.

10. Press right arrow to select next header sensor calibration or STOP & EXIT. Press SELECT.

11. Press PROGRAM to exit programming mode.



Figure 4.89: Positive Header Float Display



Figure 4.90: Negative Header Float Display



## 4.7 Calibrating the Swath Compressor Sensor

This topic only applies to machines equipped with a swath compressor. To calibrate the swath compressor sensor, follow these steps:

**NOTE:**

To calibrate the swath compressor sensor, the DWA must be disabled, and the swath compressor enabled in WINDROWER SETUP on the CDM.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
3. Press SELECT (B) until CALIBRATE SENSORS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.91: CDM Programming Buttons

4. Press right arrow (A) to select YES. Press SELECT (B).
  - TO CALIBRATE SELECT is displayed in upper line.
5. Press right arrow (A) to scroll through the choices until SWATH COMPR HT is displayed on the lower line. Press SELECT (B).
  - SWATH SENSOR CAL is displayed on the upper line.
  - SWATH UP TO START is displayed on the lower line.



Figure 4.92: Swath Compressor Sensor Calibration

## CAB DISPLAY MODULE (CDM)

6. Press and hold button (B) to raise the swath compressor.
  - CALIBRATING SWATH is displayed on the upper line.
  - FORM UP and flashing HOLD is displayed on the lower line until the system has completed reading signal with swath compressor fully raised.
  - SWATH FORM UP DONE (with buzzer) is displayed on the lower line when complete.




Figure 4.93: Swath Compressor Controls

- SWATH SENSOR CAL is displayed on the upper line.
- PRESS SWATH DOWN is displayed on the lower line.



Figure 4.94: Swath Compressor Sensor Calibration

7. Press and hold button (A) to lower the swath compressor.
  - CALIBRATING SWATH is displayed on the upper line.
  - FORM DOWN and flashing HOLD is displayed on the lower line.
  - SWATH FORM COMPLETE flashes for 2 seconds on the lower line (with buzzer) when the calibration is complete.
8. Press PROGRAM to exit programming mode.




Figure 4.95: Swath Compressor Controls

## 4.8 Troubleshooting Windrower Problems

### 4.8.1 Displaying the Windrower and Engine Error Codes

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode. Press SELECT (B).
  - WINDROWER SETUP? is displayed on the upper line.
3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.



Figure 4.96: CDM Programming Buttons

4. Press right arrow (A) to select YES. Press SELECT (B).
5. VIEW ERROR CODES? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - VIEW WINDRWR CODES? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.97: Diagnostic Functions

7. Press right arrow (A) to select YES. Press SELECT (C).
  - The most recent error code will be displayed.
8. Press and left (A) or right (B) arrow to cycle through the last ten recorded windrower error codes until EXIT WINDROWER CODES is displayed.
9. Press right arrow (B) to select YES. Press SELECT (C).
  - VIEW ENGINE CODES is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.98: Windrower Codes

## CAB DISPLAY MODULE (CDM)

10. Press right arrow (C) to select YES. Press SELECT (D).
11. Press left (B) or right (C) arrow to cycle through the last ten recorded engine error codes until EXIT ENGINE CODES is displayed.
12. Press right arrow (C) to select YES. Press SELECT (D).
13. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next diagnostic mode.




Figure 4.99: Engine Codes

### 4.8.2 Switching the Installed Header Sensors ON or OFF

You can selectively enable or disable header sensors in the event of a malfunction or as part of a troubleshooting routine.

#### NOTE:

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- Disabled sensors flash the word SENSOR on CDM during regular operation.


1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (C) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
3. Press SELECT (C) until DIAGNOSTIC MODE? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (B) to select YES. Press SELECT (C).
  - VIEW ERROR CODES? is displayed on the upper line.



Figure 4.100: CDM Programming Buttons

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (B) until ENTER SENSOR SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - KNIFE SPEED SENSOR is displayed on the lower line.
  - ENABLE/DISABLE is displayed on the lower line.



**Figure 4.101: Diagnostic Functions**

7. Press left arrow (B) to enable a sensor. Press right arrow (C) to disable sensor. Press SELECT (D) to confirm selection and move on to next sensor.

The following sensors are available:

- HEADER HT SENSOR
- HEADER TILT SENSOR
- KNIFE SPEED SENSOR
- REEL SPEED SENSOR
- HEADER FLOAT SENSOR
- OVERLOAD PRESSURE<sup>8</sup>
- HYD OIL TEMP SENSOR

When sensors have been modified, press SELECT (D) to display the EXIT SENSOR SETUP? selection.

8. Press right arrow (C) to select YES. Press SELECT.
9. Press PROGRAM (A) to exit programming mode or press SELECT to proceed to next diagnostic mode.



**Figure 4.102: Header Sensors**

8. Requires installation of optional pressure sensor (MD #B5574).

### 4.8.3 Displaying Header Sensor Input Signals

You can display individual sensor input signals in the event of a malfunction or as part of a troubleshooting routine.

**NOTE:**

The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.




Figure 4.103: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).
  - VIEW ERROR CODES? is displayed on the upper line.
5. Press SELECT (B) until READ SENSOR SETUP? is displayed on the upper line.
  - NO/YES is displayed on the lower line.



Figure 4.104: Diagnostic Functions

6. Press right arrow (C) to select YES. Press SELECT (D).
  - SENSOR INPUT is displayed on the upper line.
  - HDR HEIGHT 1.23 V is displayed on the lower line.
7. Press left (B) or right (C) arrow to cycle between individual sensor readers.
8. Press SELECT (D) to skip to EXIT READ SENSORS? selection.
9. Press right arrow (C) to select YES. Press SELECT.
10. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next diagnostic mode.



Figure 4.105: Header Sensors

## CAB DISPLAY MODULE (CDM)

### 4.8.4 Forcing a Header ID

The header must be attached to the windrower to troubleshoot certain issues. If damage has occurred to the header wiring or no header is available, you can force the windrower control module (WCM) to read a header ID. The WCM reverts to reading NO HEADER each time the engine ignition is cycled.

#### IMPORTANT:

Forcing a Header ID that is different from the attached header can damage the windrower and header. Doing so can lead to vibration, belt failures, and other overspeeding related problems.

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.




Figure 4.106: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.107: Diagnostic Functions

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (B) until FORCE HEADER TYPE? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - SELECT HEADER TYPE is displayed on the upper line.
  - DISK HEADER is displayed on the lower line.



Figure 4.108: Header Type

7. Press left (A) or right (B) arrow to cycle through list of header types.
8. When desired header type is displayed, press SELECT (C).
  - EXIT FORCE HEADER? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
9. Press right arrow (B) to select YES. Press SELECT (C).  
Proceed to next diagnostic mode, or press PROGRAM to exit programming mode.



Figure 4.109: Header Type



## 4.9 Troubleshooting Header Problems

You can test individual parts of the header as part of a troubleshooting routine.

### 4.9.1 Testing the Header Up/Down Activate Function Using the Cab Display Module (CDM)

**NOTE:**

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
- The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode. Press SELECT (B).
  - WINDROWER SETUP? is displayed on the upper line.




Figure 4.110: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.111: Diagnostic Functions

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).

### CAUTION

Check to be sure all bystanders have cleared the area.



Figure 4.112: Functions

7. Press SELECT (D) until ACTIVATE HEADER HT is displayed on the upper line.
  - DOWN/UP is displayed on the lower line.
8. Press and hold left arrow (B) to lower header, or press and hold right arrow (C) to raise header. Verify header is functioning properly.
9. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next ACTIVATE FUNCTION.



Figure 4.113: Header Height

## 4.9.2 Testing the Reel Up/Down Activate Function Using the Cab Display Module (CDM)

### NOTE:

- This procedure is for draper headers only.
- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.

## CAB DISPLAY MODULE (CDM)

1. Turn ignition key to RUN, or start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode. Press SELECT (B).
  - WINDROWER SETUP? is displayed on the upper line.




Figure 4.114: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.115: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.116: Functions

## CAB DISPLAY MODULE (CDM)

- Press SELECT (D) until ACTIVATE REEL HT is displayed on the upper line.
  - DOWN/UP is displayed on the lower line.

### CAUTION

Check to be sure all bystanders have cleared the area.

- Press and hold left arrow (B) to **lower** reel. Press and hold right arrow (C) to **raise** reel.

#### IMPORTANT:

Verify reel is functioning properly.

- Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next ACTIVATE FUNCTION.



Figure 4.117: Reel Height

### 4.9.3 Testing the Header Tilt Activate Function Using the Cab Display Module (CDM)

#### NOTE:

- The header **MUST** be attached to the windrower to perform this procedure. The cab display module (CDM) automatically adjusts its programming for each header.
  - The engine **MUST** be running to perform this procedure.
- Start the engine.
  - Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
    - WINDROWER SETUP? is displayed on the upper line.




Figure 4.118: CDM Programming Buttons

## CAB DISPLAY MODULE (CDM)

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).




Figure 4.119: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.120: Functions

7. Press SELECT (D) until ACTIVATE HDR TILT is displayed on the upper line.
  - IN/OUT is displayed on the lower line.
8. Press and hold left arrow (B) to **decrease** header tilt. Press and hold right arrow (C) to **increase** header tilt.

### IMPORTANT:

Verify header is functioning properly.

9. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next ACTIVATE FUNCTION.



Figure 4.121: Header Tilt Angle

## 4.9.4 Testing the Knife Drive Circuit Using the Cab Display Module (CDM)

### IMPORTANT:

Do not overspeed a drive. Overspeeding can lead to vibration, belt failures, or other overspeeding related problems.

## CAB DISPLAY MODULE (CDM)

### NOTE:

The header **MUST** be attached to windrower to follow this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode. Press SELECT (B).
  - WINDROWER SETUP? is displayed on the upper line.



Figure 4.122: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.123: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.



Figure 4.124: Functions

## CAB DISPLAY MODULE (CDM)

### CAUTION

Check to be sure all bystanders have cleared the area.

7. Press SELECT (E) until KNIFE DRIVE SPD XXXX is displayed on the upper line.

#### IMPORTANT:

Do **NOT** overspeed the knife drive.

8. Press and hold HAZARD (C) button.
  - Press left arrow (B) to **decrease** knife speed.
  - Press right arrow (D) to **increase** knife speed.

#### IMPORTANT:

Verify the knife drive is functioning properly.

9. Release the HAZARD (C) button. The knife will stop.
10. Press PROGRAM (A) to exit programming mode or press SELECT (E) to proceed to next ACTIVATE FUNCTION.




Figure 4.125: Knife Drive

### 4.9.5 Testing the Draper Drive Circuit Activate Function Using the Cab Display Module (CDM)

#### IMPORTANT:

Do not overspeed a drive. Overspeeding can lead to vibration, belt failures, or other overspeeding related problems.

#### NOTE:

- A draper header **MUST** be attached to windrower to follow this procedure.
  - The engine **MUST** be running to perform this procedure.
1. Start the engine.
  2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
    - WINDROWER SETUP? is displayed on the upper line.



Figure 4.126: CDM Programming Buttons

## CAB DISPLAY MODULE (CDM)

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).




Figure 4.127: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.



Figure 4.128: Functions

### CAUTION

Check to be sure all bystanders have cleared the area.

7. Press SELECT (B) until DRAPER DRV SPD XXXX is displayed on the upper line.

#### IMPORTANT:

Do **NOT** overspeed the drapers.

8. Press and hold HAZARD (C) button.
  - Press left arrow (B) to **decrease** draper speed.
  - Press right arrow (D) to **increase** draper speed.

#### IMPORTANT:

Verify the draper drive is functioning properly.

9. Release the HAZARD (C) button. The drapers will stop.
10. Press PROGRAM (A) to exit programming mode or press SELECT (E) to proceed to next ACTIVATE FUNCTION.




Figure 4.129: Draper Drive



### 4.9.6 Testing the Reel Drive Circuit Activate Function Using the Cab Display Module (CDM)

**IMPORTANT:**

Do not overspeed a drive. Overspeeding can lead to vibration, belt failures, or other overspeeding related problems.

**NOTE:**

- The header **MUST** be attached to windrower to follow this procedure.
- This procedure does not apply to rotary disc headers.
- The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.



Figure 4.130: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.131: Diagnostic Functions

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.




Figure 4.132: Functions

### CAUTION

Check to be sure all bystanders have cleared the area.

7. Press SELECT (E) until REEL DRV SPD XXXX is displayed on the upper line.

#### IMPORTANT:

Do **NOT** overspeed the reel.

8. Press and hold HAZARD (C) button.
  - Press left arrow (B) to **decrease** reel speed.
  - Press right arrow (D) to **increase** reel speed.

#### IMPORTANT:

Verify the reel drive is functioning properly.

9. Release the HAZARD (C) button. The reel will stop.
10. Press PROGRAM (A) to exit programming mode or press SELECT (E) to proceed to next ACTIVATE FUNCTION.



Figure 4.133: Reel Drive

### 4.9.7 Testing the Rotary Disc Drive Circuit Activate Function Using the Cab Display Module (CDM)

#### IMPORTANT:

Do not overspeed a drive. Overspeeding can lead to vibration, belt failures, or other overspeeding related problems.

#### NOTE:

- A rotary disc header **MUST** be attached to windrower to follow this procedure.
- The engine **MUST** be running to perform this procedure.

## CAB DISPLAY MODULE (CDM)

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.



Figure 4.134: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.135: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.



Figure 4.136: Functions

**CAUTION**

Check to be sure all bystanders have cleared the area.

- Press SELECT (E) until DISC DRV SPD XXXX is displayed on the upper line.

**IMPORTANT:**

Do **NOT** overspeed the disc drive.

- Press and hold HAZARD (C) button.
  - Press left arrow (B) to **decrease** disc speed.
  - Press right arrow (D) to **increase** disc speed.

**IMPORTANT:**

Verify the disc drive is functioning properly.

- Release the HAZARD (C) button. The disc drive will stop.
- Press PROGRAM (A) to exit programming mode or press SELECT to proceed to next ACTIVATE FUNCTION.




Figure 4.137: Disc Drive

**4.9.8 Testing the Double Windrower Attachment (DWA) Drive Activate Function Using the Cab Display Module (CDM)**

**IMPORTANT:**

Do not overspeed a drive. Overspeeding can lead to vibration, belt failures, or other overspeeding related problems.

**NOTE:**

- The DWA must be attached to the windrower and activated under the WINDROWER SETUP menu. For more information, refer to [4.3.8 Activating the Double Windrow Attachment \(DWA\), page 117](#).

Engine **MUST** be running to perform this procedure.

- Start the engine.
- Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode. Press SELECT (B).
  - WINDROWER SETUP? is displayed on the upper line.



Figure 4.138: CDM Programming Buttons

## CAB DISPLAY MODULE (CDM)

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.139: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.



Figure 4.140: Functions

7. Press SELECT (E) until ACTIVATE DWA DRV is displayed on the upper line.

### CAUTION

Check to be sure all bystanders have cleared the area.

#### IMPORTANT:

Do **NOT** overspeed the DWA drive.

8. Press and hold HAZARD (C) button.
  - Press left arrow (B) to **decrease** DWA drive speed.
  - Press right arrow (D) to **increase** DWA drive speed.

#### IMPORTANT:

Verify the DWA drive is functioning properly.

9. Release the HAZARD (C) button. The DWA drive will stop.
10. Press PROGRAM (A) to exit programming mode or press SELECT (E) to proceed to next ACTIVATE FUNCTION.




Figure 4.141: DWA Drive

### 4.9.9 Testing the Reel Fore-Aft Activate Function Using the Cab Display Module (CDM)

**NOTE:**

- The header **MUST** be attached to windrower to perform this procedure.
- The engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.




Figure 4.142: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.143: Diagnostic Functions

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).

**CAUTION**

Check to be sure all bystanders have cleared the area.



Figure 4.144: Functions

## CAB DISPLAY MODULE (CDM)

7. Press SELECT (D) until ACTIVATE REEL F/A is displayed on the upper line.
  - FORE/AFT is displayed on the lower line.
8. Verify reel fore-aft is functioning properly.
  - a. Press and hold left arrow (B) to move reel **forward**. Press and hold right arrow (C) to move reel **backward**.
  - b. Press PROGRAM (A) to exit programming mode or press SELECT (D) to proceed to next ACTIVATE FUNCTION.




Figure 4.145: Reel Fore-Aft

### 4.9.10 Activating the Hydraulic Purge Using the Cab Display Module (CDM)

The hydraulic purge removes air from the hydraulic pump system after it has been repaired or changed.

#### NOTE:

Engine **MUST** be running to perform this procedure.

1. Start the engine.
2. Press PROGRAM (A) and SELECT (B) on cab display module (CDM) to enter programming mode.
  - WINDROWER SETUP? is displayed on the upper line.



Figure 4.146: CDM Programming Buttons

3. Press SELECT (B) until DIAGNOSTIC MODE? is displayed in upper line.
  - NO/YES is displayed on the lower line.
4. Press right arrow (A) to select YES. Press SELECT (B).



Figure 4.147: Diagnostic Functions

## CAB DISPLAY MODULE (CDM)

5. Press SELECT (B) until ACTIVATE FUNCTIONS? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
6. Press right arrow (A) to select YES. Press SELECT (B).
  - ACTIVATE HEADER HT is displayed on the upper line.
  - DOWN/UP is displayed on the lower line.



Figure 4.148: Functions

7. Press SELECT (B) until ACTIVATE HYD PURGE? is displayed on the upper line.
  - NO/YES is displayed on the lower line.
8. Press right arrow (A) to select YES. Press SELECT (B).
  - TO ACTIVATE PURGE is displayed on the upper line.
  - PRESS AND HOLD is displayed on the lower line.

**NOTE:**

Holding the right arrow (A) activates a timed purge cycle. The CDM will jump to the exit menu if the arrow is released before the end of the timed cycle.

**CAUTION**

Check to be sure all bystanders have cleared the area.

9. Press and hold right arrow (A) to activate purge cycle.
  - PURGE CYCLE STARTED will display on the upper line.
10. When PURGE CYCLE ENDED is displayed release right arrow (A).
  - NO EXIT YES is displayed on the lower line.
11. Press right arrow to select YES. Press SELECT.
12. Press PROGRAM to exit programming mode or press SELECT to proceed to next ACTIVATE FUNCTION.



Figure 4.149: Hydraulic Purge



Figure 4.150: Hydraulic Purge Cycle



# Chapter 5: Performing Operational Checks

## 5.1 Checking Safety System

### **WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

### **CAUTION**

Check to be sure all bystanders have cleared the area.

A properly functioning safety system should operate as follows. If the system does not function as described, refer to the windrower technical manual for adjustment procedures.

- With the GSL in N-DETENT position and the steering wheel locked (centered), the park brakes engage and the CDM displays IN PARK accompanied by an audible beep.
  - The starter should engage **ONLY** when the ground speed lever (GSL) is in N-DETENT, the steering wheel is locked (centered), and the header drive switch is in the OFF position.
  - The brake should engage and the machine should **NOT** move after engine start-up.
  - The steering wheel should **NOT** lock with the engine running and the GSL out of N-DETENT.
1. Ensure the battery disconnect switch is in the POWER ON position.

#### **NOTE:**

The battery disconnect switch (A) is located on the right (cab-forward) frame rail behind the maintenance platform and can be accessed by moving the platform rearwards.




Figure 5.1: Battery Switch

## PERFORMING OPERATIONAL CHECKS

### *Header drive engaged safety check:*

1. Shut down the engine and pull up on collar (B) while pressing down on switch (A) to engage header drive.
2. Try starting the engine and confirm the cab display module (CDM) displays HEADER ENGAGED on the upper line and DISENGAGE HEADER on the lower line.
3. If the engine turns over, the safety system requires adjustment or repair. Refer to the windrower technical manual for adjustment procedures.




Figure 5.2: Header Drive Switch

### *Pintle switch safety check:*

1. Shut down the engine and remove the key.
2. Open engine compartment hood.
3. Pry the steering interlock away from pintle arms (A) by inserting a wedge or pry bar between one of the interlock channels (B) and pintle arm.
4. Insert a wooden block approximately 19 mm (3/4 in.) thick between the opposite channel and the pintle arm so the interlock channel is clear of the pintle arm.
5. Turn the steering wheel off-center, and move the GSL to N-DETENT.
6. Try starting the engine and confirm the CDM flashes CENTER STEERING accompanied by a short beep with each flash. The engine should **NOT** turn over.
7. If the engine turns over, the safety system requires adjustment or repair. Refer to the windrower technical manual for adjustment procedures.
8. Remove key from ignition.
9. Remove wooden block and close hood.




Figure 5.3: Pintle Arms

## PERFORMING OPERATIONAL CHECKS

### ***Steering and neutral safety check:***

1. Shut down the engine and center the steering wheel. Place the GSL (A) in NEUTRAL but not in N-DETENT.
2. Try starting the engine and confirm the CDM flashes CENTER STEERING on the upper line and PLACE GSL INTO N on the lower line accompanied by a short beep with each flash. The engine should **NOT** turn over.
3. If the engine turns over, the safety system requires adjustment. Refer to the windrower technical manual for adjustment procedures.



Figure 5.4: Operator's Station

### ***Seat base lock safety check:***

1. Ensure the operator's station is **NOT** locked. To unlock operator's station, pull up and hold knob (B) to release latch (C), and turn steering wheel to unlock operator's station.
2. Center the steering wheel and place the GSL (A) in N-DETENT. Try starting the engine and confirm that the engine cranks but does **NOT** start, and the CDM displays SEAT BASE NOT LOCKED.
3. If the engine starts, the safety system requires adjustment. Refer to the windrower technical manual for adjustment procedures.




Figure 5.5: Operator's Station

## 5.2 Checking Operator's Presence System

### CAUTION

Check to be sure all bystanders have cleared the area.

1. Start the engine.
2. Place the ground speed lever (GSL) (A) in NEUTRAL and turn the steering wheel until it locks.
3. Engage header drive switch (B).
4. Stand up from the operator's seat. The header should shut off after approximately 5 seconds. If the header does not shut off, the Operator Presence System requires adjustment. Refer to the technical manual.

**NOTE:**

To restart the header, move the header drive switch (B) to the OFF position and then back to the ON position.




Figure 5.6: Operator Console

5. Position the GSL (A) in NEUTRAL and in N-DETENT.
  - a. Swivel the operator's station but do **NOT** lock it into position.
  - b. Move the GSL out of N-DETENT. The engine should shut down and the lower display will flash LOCK SEAT BASE → CENTER STEERING WHEEL → NOT IN NEUTRAL.
  - c. Swivel and lock the operator's station and the display should return to normal.
  - d. If the engine does not shut down, the seat position switches require adjustment. Refer to the technical manual.
6. Start the engine and drive the windrower at a speed **less than** 8 km/h (5 mph):
  - a. Stand up from the operator's seat.
  - b. Ensure the CDM flashes NO OPERATOR on the upper line and ENGINE SHUTDOWN 5...4...3...2...1...0 on the lower line accompanied by a steady tone. When the CDM display reaches 0, the engine will shut down.
  - c. If the engine does not shut down, the Operator Presence System requires adjustment. Refer to the technical manual.
7. Start the engine and drive the windrower at a speed **more than** 8 km/h (5 mph):
  - a. Stand up from the operator's seat.
  - b. The CDM beeps once and displays NO OPERATOR on the lower line.
  - c. If the CDM does not beep and display message, the Operator Presence System requires adjustment. Refer to the technical manual.

## 5.3 Checking Windrower Startup

### CAUTION

Check to be sure all bystanders have cleared the area.

1. Start the engine. For instructions, refer to [3.11 Starting Engine, page 92](#).

**NOTE:**

The brakes should engage and the machine should not move after engine start-up.

2. Ensure the steering wheel is centered. Move ground speed lever (GSL) (A) straight out of N-DETENT (neither forward nor reverse). The machine should not move.
3. Check that the steering wheel is free to move.
4. If the machine does not function as described, the system requires adjustment. Refer to the windrower technical manual.





Figure 5.7: Operator Console

## 5.4 Checking Engine Speed

1. Move throttle to idle position.
2. Check engine speed on cab display module (CDM) (A) and compare to value in table below.
3. Move throttle to maximum rpm position.
4. Check engine speed on CDM (A) and compare to value in table below.

**Table 5.1 Engine Speed**

Idle rpm	Maximum rpm (No Load)
1000 +/- 30 rpm	2300 +/- 30 rpm



**Figure 5.8: Cab Display Module (CDM)**

## 5.5 Checking Gauges and Cab Display Module (CDM) Display

1. Check that fuel and diesel exhaust fluid (DEF) gauges are working by pressing and holding the fuel gauge icon (A) for 2 seconds—the brightness symbol and backlight function becomes active. The fuel gauge icon will reappear if nothing is pressed for 5 seconds.



Figure 5.9: Fuel and DEF Gauges

2. Ensure the CDM display (A) is working by pushing the SELECT (B) button on the CDM or the SELECT (C) button on the ground speed lever (GSL).
3. If the system does not function as described, refer to the windrower technical manual.




Figure 5.10: Operator Console

## 5.6 Checking Electrical System

1. Push the SELECT button (C) on the ground speed lever (GSL) or the SELECT button (B) on the cab display module (CDM) until the CDM display (A) shows VOLTS. The display indicates the condition of the battery and alternator. Refer to Table 5.2, page 176.




Figure 5.11: Operator Console

Table 5.2 Battery and Alternator Condition

Ignition	Engine	Reading	Indicated Condition
ON	Running	13.8–15.0	Normal
		>16.0 (see note)	Regulator out of adjustment
		<12.5 (see note)	Alternator not working Regulator out of adjustment
	Shut down	12.0	Battery normal

**NOTE:**

Display flashes voltage reading accompanied by a single loud tone every 30 minutes until condition is fixed.



## 5.7 Checking Exterior Lights

1. Rotate the operator's seat to cab-forward mode.
2. Turn field light switch (A) to the ON position and ensure the front field lights (B) and rear swath lights (C) are functioning.




Figure 5.12: Exterior Lights – Cab Forward

## PERFORMING OPERATIONAL CHECKS

3. Turn the road light switch (A) to the ON position and ensure the front road lights (B) and rear red tail/brake lights (C) (if equipped) are functioning.
4. Activate the high/low switch (D) and check lights.
5. Activate the amber turn signal/hazard warning lights (E) using switches on the cab display module (CDM) and check lights.
6. Turn off lights.




Figure 5.13: Exterior Lights – Cab Forward

## PERFORMING OPERATIONAL CHECKS

7. Turn beacon switch (A) to the ON position and ensure the amber beacons (B) are functioning.
8. If an exterior light is not functioning, refer to the windrower technical manual.




Figure 5.14: Exterior Lights – Beacons

## 5.8 Checking Auto Road Light

The beacon and hazard lights are included in the auto road light feature. The beacon and hazard lights will turn on when this feature is activated, and can only be turned off by engaging the header drive.

This feature will activate when

- Windrower is in cab- or engine-forward mode
- Engine is running
- Header is disengaged
- Transmission is in either mid or high range

Moving the ground speed lever (GSL) out of neutral (brake off) will switch the white lights from field/work lights to road lights, if the switch is in the field/road lights position.

## 5.9 Checking Horn

1. Push HORN button (A) and listen for horn.




Figure 5.15: Horn Button

## 5.10 Checking Interior Lights

1. Switch road and field lights ON and OFF using switch (A).

**NOTE:**

Ambient light in roof liner (B) and interior light (C) work only when road or field lights (A) are switched ON.

2. If interior lights do not function properly, refer to windrower technical manual.




Figure 5.16: Interior Lights

## 5.11 Checking Air Conditioning (A/C) and Heater

Figure 5.17: A/C and Heater Controls



1. Confirm that the following A/C and heating controls function properly:
  - **Blower switch (A):** Controls blower speed. Switch settings are OFF, LO, MEDIUM, and HI.
  - **Air conditioning switch (B):** Controls A/C system. When set to ON, A/C operates if blower switch (A) is switched ON. When set to OFF, the A/C system does not operate.
  - **Outside air switch (C):** Controls air source. When set to FRESH AIR, booster fan starts and draws filtered outside air into the cab. When set to RECIRCULATED, booster fan stops and air inside cab is recirculated.
  - **Temperature control (D):** Controls cab temperature. Turn knob clockwise to increase temperature, and turn knob counterclockwise to decrease temperature.

**IMPORTANT:**

To distribute oil throughout the A/C system, perform the following steps:

2. Start engine and turn blower switch (A) to the LO setting then turn temperature control (D) to maximum heating, and turn A/C switch (B) to OFF.
3. Turn A/C switch (B) from OFF to ON position for 1 second, then back to OFF for 5 to 10 seconds. Repeat this step ten times.

## 5.12 Checking Manuals

Manuals are stored in the manual storage case (A) behind the operator's seat.




Figure 5.18: Manual Storage Case

1. Ensure the following manuals are included with the windrower:

- Operator's Manual
- Parts Catalog
- Quick Card
- Engine Manual



Figure 5.19: Manuals and Quick Card



## 5.13 Performing Final Steps

1. When predelivery checks are complete, remove the plastic covering from the cab display module (CDM), and the seats.
2. Locate the bag inside the cab containing the GPS mount kit, and install kit in accordance with the instructions in the kit. If not installing kit, label bag (GPS Completion kit) and place kit in toolbox for safekeeping.
3. **AFTER** the machine is delivered to the end user, remove the decal from the windshield only.



Figure 5.20: Windshield Decal (MD #166705)



# Chapter 6: Attaching Headers

## 6.1 Attaching Headers

### 6.1.1 Attaching Header Boots

Header boots are required to attach a D Series or D1 Series Draper Header to the windrower. Attach header boots (supplied with header) to windrower lift linkage if not already installed.

**IMPORTANT:**

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to the windrower, ensure the float engagement pin is installed in storage position (B) and **NOT** in engaged position (A).




Figure 6.1: Header Float Linkage

1. Remove pin (B) from boot (A).




Figure 6.2: Header Boot

## ATTACHING HEADERS

2. Position boot (B) onto lift linkage (A) and reinstall pin (C). Pin may be installed from either side of boot.
3. Secure pin (C) with hairpin (D).
4. Repeat for opposite side.




Figure 6.3: Header Boot

### 6.1.2 Attaching a D Series or D1 Series Header

D50, D60, D65, and D1 Series headers can be attached to an M155E4 Self-Propelled Windrower.

The M155E4 Self-Propelled Windrower is factory-equipped to run a D/D1 Series Draper Header.

If installing an HC10 Hay Conditioner, Reverser kit (MD #B4656) is recommended. If necessary, obtain the recommended kit and install it in accordance with the instructions supplied with the kit.

Refer to the following instructions based on the type of center-link installed on your windrower:

- [Attaching a D Series or D1 Series Header: Hydraulic Center-Link with Optional Self-Alignment, page 188](#)
- [Attaching a D Series or D1 Series Header: Hydraulic Center-Link without Self-Alignment, page 193](#)




Figure 6.4: M155E4 Draper Header Hydraulics

#### *Attaching a D Series or D1 Series Header: Hydraulic Center-Link with Optional Self-Alignment*

##### NOTE:

Draper header boots must be installed onto the windrower lift linkage before starting this procedure. Refer to [6.1.1 Attaching Header Boots, page 187](#).

##### **WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

## ATTACHING HEADERS

1. Remove hairpin (A) from pins (B), and remove pins from both header legs.




Figure 6.5: Header Leg

### CAUTION

Check to be sure all bystanders have cleared the area.

#### IMPORTANT:

Before starting engine, remove protective cover from exhaust stack.

2. Start the engine and activate the HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.
3. Activate the REEL UP switch (A) on the GSL to raise the center-link until the hook is above the attachment pin on the header.

#### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.6: Ground Speed Lever




Figure 6.7: Ground Speed Lever

## ATTACHING HEADERS

4. Drive the windrower slowly forward until the boots (A) enter the header legs (B). Continue driving slowly forward until lift linkages contact the support plates in the header legs and the header nudges forward.
5. Ensure the lift linkages are properly engaged in the header legs and are contacting the support plates.




Figure 6.8: Header Leg and Boot

6. Use the following GSL functions to position the center-link hook above the header attachment pin:
  - REEL UP (A) to raise the center-link
  - REEL DOWN (B) to lower the center-link
  - HEADER TILT UP (C) to retract the center-link
  - HEADER TILT DOWN (D) to extend the center-link




Figure 6.9: Ground Speed Lever

7. Adjust position of the center-link cylinder (A) with the REEL UP, REEL DOWN, AND HEADER TILT switches on the GSL until the hook is above the header attachment pin.

### IMPORTANT:

Hook release must be down to enable self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

8. Lower center-link (A) onto the header with the REEL DOWN switch on the GSL until it locks into position (hook release [B] is down).
9. Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.




Figure 6.10: Hydraulic Center-Link

### CAUTION

Check to be sure all bystanders have cleared the area.

## ATTACHING HEADERS

10. Press HEADER UP switch (A) to raise the header to maximum height.
11. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

**NOTE:**

It may be necessary to repeat this procedure if there is air in the system.

12. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.




Figure 6.11: Ground Speed Lever




Figure 6.12: Safety Prop

## ATTACHING HEADERS

13. Install pin (B) through the header leg (engaging U-bracket in lift linkage) on both sides and secure with hairpin (A).
14. Raise header stand (D) to storage position by pulling spring pin (C) and lifting stand into uppermost position. Release spring pin.




Figure 6.13: Header Leg

15. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.




Figure 6.14: Header Float Linkage

16. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
17. Repeat for opposite safety prop.




Figure 6.15: Safety Prop Lever



## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

18. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
19. Stop engine and remove key from ignition.




Figure 6.16: Ground Speed Lever

20. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the draper header operator's manual.




Figure 6.17: Header Drive Hoses and Harness

21. Connect reel hydraulics (A) at right cab-forward side of windrower. Refer to the draper header operator's manual.
22. Start the engine and raise and lower the header and the reel a few times to remove trapped air.




Figure 6.18: Reel Hydraulics

*Attaching a D Series or D1 Series Header: Hydraulic Center-Link without Self-Alignment*

#### NOTE:

Draper header boots must be installed onto the windrower lift linkage before starting this procedure.

## ATTACHING HEADERS

### WARNING

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Remove hairpin (A) from pins (B), and remove pins from both header legs.




Figure 6.19: Header Leg

### CAUTION

Check to be sure all bystanders have cleared the area.

#### IMPORTANT:

Before starting engine, remove protective cover from exhaust stack.

2. Start the engine and activate the HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.




Figure 6.20: Ground Speed Lever

3. Remove pin (A) pin in frame linkage and raise center-link (B) until hook is above the attachment pin on header. Replace pin (A) to hold center-link in place.

#### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.21: Hydraulic Center-Link without Self-Alignment Kit

## ATTACHING HEADERS

4. Drive the windrower slowly forward until the boots (A) enter the header legs (B). Continue driving slowly forward until lift linkages contact the support plates in the header legs and the header nudges forward.
5. Ensure the lift linkages are properly engaged in the header legs and are contacting the support plates.




Figure 6.22: Header Leg and Boot

6. Use the following GSL functions to position the center-link hook above the header attachment pin:
  - HEADER TILT UP (A) to retract the center-link
  - HEADER TILT DOWN (B) to extend the center-link
7. Stop engine and remove key from ignition.




Figure 6.23: Ground Speed Lever

8. Push down on rod end of link cylinder (B) until hook engages and locks onto header pin.

**IMPORTANT:**

The hook release must be down to enable the self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

9. Check that center-link (A) is locked onto the header by pulling upward on rod end (B) of cylinder.




Figure 6.24: Hydraulic Center-Link

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

10. Start the engine.
11. Press the HEADER UP switch (A) to raise the header to maximum height.
12. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

#### NOTE:

It may be necessary to repeat this procedure if there is air in the system.

13. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.



Figure 6.25: Ground Speed Lever




Figure 6.26: Safety Prop

## ATTACHING HEADERS

14. Install pin (B) through the header leg (engaging U-bracket in lift linkage) on both sides and secure with hairpin (A).
15. Raise header stand (D) to storage position by pulling spring pin (C) and lifting stand into uppermost position. Release spring pin.




Figure 6.27: Header Leg

16. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.




Figure 6.28: Header Float Linkage

17. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
18. Repeat for opposite safety prop.




Figure 6.29: Safety Prop Lever

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

19. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
20. Stop engine and remove key from ignition.




Figure 6.30: Ground Speed Lever

21. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the draper header operator's manual.




Figure 6.31: Header Drive Hoses and Harness

22. Connect reel hydraulics (A) at right cab-forward side of windrower. Refer to the draper header operator's manual.
23. Start the engine and raise and lower the header and the reel a few times to remove trapped air.




Figure 6.32: Reel Hydraulics

## ATTACHING HEADERS

### 6.1.3 Attaching an A Series Header

A30D, A30S, and A40D headers can be attached to an M155E4 Self-Propelled Windrower.

The M155E4 Self-Propelled Windrower is factory-equipped to run an A Series Auger Header.

Windrowers equipped with A Series hydraulics have four header-drive hoses on the left side.

The attachment procedure varies depending on the type of center-link installed on the windrower. Refer to the following instructions based on the type of center-link installed on your windrower:

- *Attaching an A Series Header: Hydraulic Center-Link with Optional Self-Alignment, page 199*
- *Attaching an A Series Header: Hydraulic Center-Link without Self-Alignment, page 204*



Figure 6.33: M155E4 and A40D Auger Header

#### *Attaching an A Series Header: Hydraulic Center-Link with Optional Self-Alignment*

### **WARNING**

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Remove hairpin (A) from clevis pin (B) and remove clevis pin from the header boots (C) on both sides of the header.




Figure 6.34: Header Boot

## ATTACHING HEADERS

### IMPORTANT:

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to the windrower, ensure the float engagement pin is installed in storage position (B) and **NOT** in engaged position (A).




Figure 6.35: Header Float Linkage

### CAUTION

Check to be sure all bystanders have cleared the area.

### IMPORTANT:

Before starting engine, remove protective cover from exhaust stack.

2. Start the engine and activate the HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.
3. Activate the REEL UP switch (A) on the GSL to raise the center-link until the hook is above the attachment pin on the header.

### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.36: Ground Speed Lever




Figure 6.37: Ground Speed Lever



## ATTACHING HEADERS

4. Drive the windrower slowly forward until the windrower feet (A) enter the header supports (B). Continue driving slowly forward until the feet engage the supports and the header nudges forward.




Figure 6.38: Header Support

5. Use the following GSL functions to position the center-link hook above the header attachment pin:
  - REEL UP (A) to raise the center-link
  - REEL DOWN (B) to lower the center-link
  - HEADER TILT UP (C) to retract the center-link
  - HEADER TILT DOWN (D) to extend the center-link




Figure 6.39: Ground Speed Lever

6. Adjust center-link cylinder (A) position with the REEL UP and REEL DOWN switches on the GSL until the hook is positioned above the header attachment pin.

### IMPORTANT:

The hook release must be down to enable the self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

7. Lower center-link (A) onto the header with the REEL DOWN switch until the center-link locks into position and the hook release (B) is down.
8. Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.




Figure 6.40: Hydraulic Center-Link

### CAUTION

Check to be sure all bystanders have cleared the area.

## ATTACHING HEADERS

9. Press HEADER UP switch (A) to raise the header to maximum height.
10. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

**NOTE:**

It may be necessary to repeat this procedure if there is air in the system.



Figure 6.41: Ground Speed Lever

11. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.




Figure 6.42: Safety Prop

## ATTACHING HEADERS

12. Install clevis pin (A) through support and foot and secure with hairpin. Repeat for opposite support.

**IMPORTANT:**

Ensure clevis pin (A) is fully inserted and hairpin is installed behind bracket.




Figure 6.43: Header Support

13. Remove lynch pin from clevis pin (A) in stand (B).
14. Hold stand (B) and remove pin (A).
15. Move stand (B) to storage position by inverting and relocating onto bracket as shown. Reinsert clevis pin (A) and secure with lynch pin.




Figure 6.44: Header Stand

16. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.




Figure 6.45: Header Float Linkage

## ATTACHING HEADERS

17. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
18. Repeat for opposite safety prop.




Figure 6.46: Safety Prop Lever

### CAUTION

Check to be sure all bystanders have cleared the area.

19. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
20. Stop engine and remove key from ignition.




Figure 6.47: Ground Speed Lever

21. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the draper header operator's manual.




Figure 6.48: Header Drive Hoses and Harness

### *Attaching an A Series Header: Hydraulic Center-Link without Self-Alignment*

### WARNING

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

## ATTACHING HEADERS

1. Remove hairpin (A) from clevis pin (B) and remove clevis pin from the header boots (C) on both sides of the header.




Figure 6.49: Header Boot

### IMPORTANT:

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to the windrower, ensure the float engagement pin is installed in storage position (B) and **NOT** in engaged position (A).




Figure 6.50: Header Float Linkage



### CAUTION

Check to be sure all bystanders have cleared the area.

### IMPORTANT:

Before starting engine, remove protective cover from exhaust stack.

2. Start the engine and activate the HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.




Figure 6.51: Ground Speed Lever

## ATTACHING HEADERS

3. Remove pin (A) pin in frame linkage and raise center-link (B) until hook is above the attachment pin on header. Replace pin (A) to hold center-link in place.

### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.52: Hydraulic Center-Link without Self-Alignment Kit

4. Drive the windrower slowly forward until the windrower feet (A) enter the header supports (B). Continue driving slowly forward until the feet engage the supports and the header nudges forward.




Figure 6.53: Header Support

5. Use the following ground speed lever functions to position the center-link hook above the header attachment pin:
  - HEADER TILT UP (A) to retract center-link
  - HEADER TILT DOWN (B) to extend center-link
6. Stop engine and remove key from ignition.




Figure 6.54: Ground Speed Lever

## ATTACHING HEADERS

7. Push down on rod end of link cylinder (B) until hook engages and locks onto header pin.

### IMPORTANT:

The hook release must be down to enable the self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

8. Check that center-link (A) is locked onto the header by pulling upward on rod end (B) of cylinder.




Figure 6.55: Hydraulic Center-Link

### CAUTION

Check to be sure all bystanders have cleared the area.

9. Start the engine.
10. Press the HEADER UP switch (A) to raise header to maximum height.
11. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

### NOTE:

It may be necessary to repeat this procedure if there is air in the system.




Figure 6.56: Ground Speed Lever

## ATTACHING HEADERS

12. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.




Figure 6.57: Safety Prop

13. Install clevis pin (A) through support and foot and secure with hairpin. Repeat for opposite support.

**IMPORTANT:**

Ensure clevis pin (A) is fully inserted and hairpin is installed behind bracket.




Figure 6.58: Header Support



## ATTACHING HEADERS

14. Remove lynch pin from clevis pin (A) in stand (B).
15. Hold stand (B) and remove pin (A).
16. Move stand (B) to storage position by inverting and relocating onto bracket as shown. Reinsert clevis pin (A) and secure with lynch pin.




Figure 6.59: Header Stand

17. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.




Figure 6.60: Header Float Linkage

18. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
19. Repeat for opposite safety prop.




Figure 6.61: Safety Prop Lever

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

20. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
21. Stop engine and remove key from ignition.




Figure 6.62: Ground Speed Lever

22. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the draper header operator's manual.




Figure 6.63: Header Drive Hoses and Harness

### 6.1.4 Attaching an R/R1 Series Header

Only a 4 m (13 ft.) R/R1 Series Rotary Disc Header can be attached to an M155E4 Self-Propelled Windrower.

#### NOTE:

The 18.4 x 26 drive tire is recommended on the M155E4 Self-Propelled Windrower when operated with a 4 m (13 ft.)

R/R1 Series Disc Header. These drive tires are reversible and should be mounted inset at 3792 mm (149.3 in.) to provide maximum clearance to uncut crop. Mounting these tires outset or mounting all other drive tire options will result in windrower tires slightly wider than the header width. This may cause some uncut crop to be trampled by tires in turns and corners during windrower operation, and may leave some uncut strips of crop in the windrower's next pass.

## ATTACHING HEADERS

The M155E4 Self-Propelled Windrower can operate 13 foot R80, R85, and R113 Rotary Disc Headers **only**. These headers are shipped without the motor or hoses installed, so a separate motor, hose bundle, and hydraulic valve kit is required to operate the header.

If necessary, obtain the following kits and install them in accordance with the instructions supplied with the kits.

**Table 6.1 Rotary Disc Header Bundles (R Series)**

Kit Description	Kit Number
Hydraulic Drive kit	MD #B5510
Hydraulic Valve kit	MD #B4657

**Table 6.2 Rotary Disc Header Bundles (R1 Series)**

Kit Description	Kit Number
Hydraulic Drive kit	MD #B6272

Refer to the following instructions based on the type of center-link installed on your windrower:


- [Attaching an R/R1 Series Header: Hydraulic Center-Link with Optional Self-Alignment, page 211](#)
- [Attaching R/R1 Series Header: Hydraulic Center-Link without Optional Self-Alignment, page 216](#)

### *Attaching an R/R1 Series Header: Hydraulic Center-Link with Optional Self-Alignment*


#### CAUTION

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. Remove hairpin (B) from clevis pin (A) and remove clevis pin from the header supports (C) on both sides of the header.



**Figure 6.64: Hydraulic Drive Kit (MD #B5510)**



**Figure 6.65: Header Support**

## ATTACHING HEADERS

### IMPORTANT:

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to the windrower, ensure the float engagement pin is installed in storage position (B) and **NOT** in engaged position (A).

2. Remove the clevis pin from linkage (A) to disengage float springs, and insert clevis pin into storage hole (B). Secure with lynch pin. Repeat for opposite linkage.




Figure 6.66: Float Linkage

### CAUTION

Check to be sure all bystanders have cleared the area.

3. Start the engine and press the HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.

### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.67: Ground Speed Lever

4. Press the REEL UP switch (A) on the GSL to raise the center-link until the hook is above the attachment pin on the header.




Figure 6.68: Ground Speed Lever

## ATTACHING HEADERS

5. Slowly drive the windrower forward until the windrower feet (A) enter the header supports (B). Continue driving slowly forward until the feet engage the supports and the header nudges forward.




Figure 6.69: Header Support

6. Use the following GSL functions to position the center-link hook above the header attachment pin:
  - REEL UP (A) to raise the center-link
  - REEL DOWN (B) to lower the center-link
  - HEADER TILT UP (C) to retract the center-link
  - HEADER TILT DOWN (D) to extend the center-link




Figure 6.70: Ground Speed Lever

7. Adjust center-link cylinder (A) position with the REEL UP and REEL DOWN switches on the GSL until the hook is positioned above the header attachment pin.

### IMPORTANT:

The hook release must be down to enable the self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

8. Lower center-link (A) onto the header with the REEL DOWN switch until the center-link locks into position and the hook release (B) is down.
9. Check that center-link is locked onto header by pressing the REEL UP switch on the GSL.




Figure 6.71: Hydraulic Center-Link

### CAUTION

Check to be sure all bystanders have cleared the area.

## ATTACHING HEADERS

10. Press HEADER UP switch (A) to raise the header to maximum height.
11. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

**NOTE:**

It may be necessary to repeat this procedure if there is air in the system.



Figure 6.72: Ground Speed Lever

12. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.





Figure 6.73: Safety Prop

## ATTACHING HEADERS

13. Install clevis pin (A) through support and windrower lift member, and secure with hairpin (B). Repeat for opposite side.


**IMPORTANT:**

Ensure clevis pin (A) is fully inserted and hairpin is installed behind bracket.




**Figure 6.74: Header Support**

14. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.



**Figure 6.75: Header Float Linkage**

15. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
16. Repeat for opposite safety prop.



**Figure 6.76: Safety Prop Lever**

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

17. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
18. Stop engine and remove key from ignition.




Figure 6.77: Ground Speed Lever

19. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the disc header operator's manual.




Figure 6.78: Header Drive Hoses and Harness

### *Attaching R/R1 Series Header: Hydraulic Center-Link without Optional Self-Alignment*

### WARNING

To avoid bodily injury or death from unexpected startup of the machine, always stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.

1. Remove hairpin (B) from clevis pin (A), and then remove clevis pin from header supports (C) on both sides of the header.




Figure 6.79: Header Support



## ATTACHING HEADERS

### IMPORTANT:

To prevent damage to the lift system when lowering header lift linkages without a header or weight box attached to the windrower, ensure the float engagement pin is installed in storage position (B) and **NOT** in engaged position (A).

2. Remove the clevis pin from linkage (A) to disengage float springs, and insert clevis pin into storage hole (B). Secure with lynch pin. Repeat for opposite linkage.




Figure 6.80: Header Float Linkage

### CAUTION

Check to be sure all bystanders have cleared the area.

3. Start the engine, and press HEADER DOWN button (A) on the ground speed lever (GSL) to fully retract header lift cylinders.




Figure 6.81: Ground Speed Lever

4. Remove pin (A) pin in frame linkage and raise center-link (B) until hook is above the attachment pin on header. Replace pin (A) to hold center-link in place.

### IMPORTANT:

If the center-link is too low, it may contact the header as the windrower approaches the header for hookup.




Figure 6.82: Hydraulic Center-Link without Self-Alignment Kit

## ATTACHING HEADERS

5. Slowly drive the windrower forward until the windrower feet (A) enter the header supports (B). Continue driving slowly forward until the feet engage the supports and the header nudges forward.




Figure 6.83: Header Support

6. Use the following GSL functions to position the center-link hook above the header attachment pin:
  - HEADER TILT UP (A) to retract the center-link
  - HEADER TILT DOWN (B) to extend the center-link
7. Stop the engine, and remove key from ignition.




Figure 6.84: Ground Speed Lever

8. Push down on rod end of link cylinder (B) until hook engages and locks onto header pin.

### IMPORTANT:

The hook release must be down to enable the self-locking mechanism. If the release is open (up), manually push it down after hook engages header pin.

9. Check that center-link (A) is locked onto the header by pulling upward on rod end (B) of cylinder.




Figure 6.85: Hydraulic Center-Link

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

10. Start the engine.
11. Press HEADER UP switch (A) to raise the header to maximum height.
12. If one end of the header does **NOT** fully raise, rephase the lift cylinders as follows:
  - a. Press and hold the HEADER UP switch until both cylinders stop moving.
  - b. Continue to hold the switch for 3–4 seconds. Cylinders are now phased.

#### NOTE:

It may be necessary to repeat this procedure if there is air in the system.

13. Engage the safety props on both lift cylinders as follows:
  - a. Stop engine and remove key from ignition.
  - b. Pull lever (A) and rotate towards the header to release and lower safety prop (B) onto the lift cylinder.
  - c. Repeat for opposite lift cylinder.




Figure 6.86: Ground Speed Lever




Figure 6.87: Safety Prop

## ATTACHING HEADERS

14. Install clevis pin (A) through the support and windrower lift member, and secure with hairpin (B). Repeat for opposite side.

**IMPORTANT:**

Ensure clevis pin (A) is fully inserted and hairpin is installed behind bracket.




Figure 6.88: Header Support

15. Remove the clevis pin from storage position (B) in linkage and insert into hole (A) to engage the float springs. Secure with hairpin.




Figure 6.89: Header Float Linkage

16. Disengage the safety prop by turning lever (A) downwards until lever locks into vertical position.
17. Repeat for opposite safety prop.




Figure 6.90: Safety Prop Lever

## ATTACHING HEADERS

### CAUTION

Check to be sure all bystanders have cleared the area.

18. Start the engine and press HEADER DOWN switch (A) on the GSL to fully lower the header.
19. Stop engine and remove key from ignition.




Figure 6.91: Ground Speed Lever

20. Connect header drive hoses (A) and electrical harness (B) to header. Refer to the disc header operator's manual.




Figure 6.92: Header Drive Hoses and Harness



# Chapter 7: Reference

## 7.1 Torque Specifications

The following tables provide correct torque values for various bolts, cap screws, and hydraulic fittings.

- Tighten all bolts to torque values specified in charts (unless otherwise noted throughout this manual).
- Replace hardware with same strength and grade of bolt.
- Use torque value tables as a guide and periodically check tightness of bolts.
- Understand torque categories for bolts and cap screws by using their identifying head markings.

### Jam nuts

When applying torque to finished jam nuts, multiply the torque applied to regular nuts by  $f=0.65$ .

### Self-tapping screws


Standard torque is to be used (**NOT** to be used on critical or structurally important joints).

### 7.1.1 SAE Bolt Torque Specifications

Torque values shown in following tables are valid for non-greased, or non-oiled threads and heads; therefore, do **NOT** grease or oil bolts or cap screws unless otherwise specified in this manual.

**Table 7.1 SAE Grade 5 Bolt and Grade 5 Free Spinning Nut**

Nominal Size (A)	Torque (Nm)		Torque (lbf·ft) (*lbf·in)	
	Min.	Max.	Min.	Max.
1/4-20	11.9	13.2	*106	*117
5/16-18	24.6	27.1	*218	*241
3/8-16	44	48	32	36
7/16-14	70	77	52	57
1/2-13	106	118	79	87
9/16-12	153	170	114	126
5/8-11	212	234	157	173
3/4-10	380	420	281	311
7/8-9	606	669	449	496
1-8	825	912	611	676



**Figure 7.1: Bolt Grades**

A - Nominal Size  
C - SAE-5

B - SAE-8  
D - SAE-2

REFERENCE

Table 7.2 SAE Grade 5 Bolt and Grade F Distorted Thread Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
1/4-20	8.1	9	*72	*80
5/16-18	16.7	18.5	*149	*164
3/8-16	30	33	22	24
7/16-14	48	53	35	39
1/2-13	73	80	54	59
9/16-12	105	116	77	86
5/8-11	144	160	107	118
3/4-10	259	286	192	212
7/8-9	413	456	306	338
1-8	619	684	459	507




Figure 7.2: Bolt Grades

A - Nominal Size  
 B - SAE-8  
 C - SAE-5  
 D - SAE-2

Table 7.3 SAE Grade 8 Bolt and Grade G Distorted Thread Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
1/4-20	16.8	18.6	*150	*165
5/16-18	24	26	18	19
3/8-16	42	46	31	34
7/16-14	67	74	50	55
1/2-13	102	113	76	84
9/16-12	148	163	109	121
5/8-11	204	225	151	167
3/4-10	362	400	268	296
7/8-9	583	644	432	477
1-8	874	966	647	716




Figure 7.3: Bolt Grades

A - Nominal Size  
 B - SAE-8  
 C - SAE-5  
 D - SAE-2



REFERENCE

Table 7.4 SAE Grade 8 Bolt and Grade 8 Free Spinning Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
1/4-20	16.8	18.6	*150	*165
5/16-18	35	38	26	28
3/8-16	61	68	46	50
7/16-14	98	109	73	81
1/2-13	150	166	111	123
9/16-12	217	239	160	177
5/8-11	299	330	221	345
3/4-10	531	587	393	435
7/8-9	855	945	633	700
1-8	1165	1288	863	954




Figure 7.4: Bolt Grades

A - Nominal Size  
C - SAE-5

B - SAE-8  
D - SAE-2

7.1.2 Metric Bolt Specifications

Table 7.5 Metric Class 8.8 Bolts and Class 9 Free Spinning Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
3-0.5	1.4	1.6	*13	*14
3.5-0.6	2.2	2.5	*20	*22
4-0.7	3.3	3.7	*29	*32
5-0.8	6.7	7.4	*59	*66
6-1.0	11.4	12.6	*101	*112
8-1.25	28	30	20	23
10-1.5	55	60	40	45
12-1.75	95	105	70	78
14-2.0	152	168	113	124
16-2.0	236	261	175	193
20-2.5	460	509	341	377
24-3.0	796	879	589	651




Figure 7.5: Bolt Grades

REFERENCE

Table 7.6 Metric Class 8.8 Bolts and Class 9 Distorted Thread Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
3-0.5	1	1.1	*9	*10
3.5-0.6	1.5	1.7	*14	*15
4-0.7	2.3	2.5	*20	*22
5-0.8	4.5	5	*40	*45
6-1.0	7.7	8.6	*69	*76
8-1.25	18.8	20.8	*167	*185
10-1.5	37	41	28	30
12-1.75	65	72	48	53
14-2.0	104	115	77	85
16-2.0	161	178	119	132
20-2.5	314	347	233	257
24-3.0	543	600	402	444




Figure 7.6: Bolt Grades

Table 7.7 Metric Class 10.9 Bolts and Class 10 Free Spinning Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
3-0.5	1.8	2	*18	*19
3.5-0.6	2.8	3.1	*27	*30
4-0.7	4.2	4.6	*41	*45
5-0.8	8.4	9.3	*82	*91
6-1.0	14.3	15.8	*140	*154
8-1.25	38	42	28	31
10-1.5	75	83	56	62
12-1.75	132	145	97	108
14-2.0	210	232	156	172
16-2.0	326	360	242	267
20-2.5	637	704	472	521
24-3.0	1101	1217	815	901




Figure 7.7: Bolt Grades

REFERENCE

Table 7.8 Metric Class 10.9 Bolts and Class 10 Distorted Thread Nut

Nominal Size (A)	Torque (Nm)		Torque (lbf-ft) (*lbf-in)	
	Min.	Max.	Min.	Max.
3-0.5	1.3	1.5	*12	*13
3.5-0.6	2.1	2.3	*19	*21
4-0.7	3.1	3.4	*28	*31
5-0.8	6.3	7	*56	*62
6-1.0	10.7	11.8	*95	*105
8-1.25	26	29	19	21
10-1.5	51	57	38	42
12-1.75	90	99	66	73
14-2.0	143	158	106	117
16-2.0	222	246	165	182
20-2.5	434	480	322	356
24-3.0	750	829	556	614




Figure 7.8: Bolt Grades

### 7.1.3 Metric Bolt Specifications Bolting into Cast Aluminum

Table 7.9 Metric Bolt Bolting into Cast Aluminum

Nominal Size (A)	Bolt Torque			
	8.8 (Cast Aluminum)		10.9 (Cast Aluminum)	
	Nm	lbf-ft	Nm	lbf-ft
M3	–	–	–	1
M4	–	–	4	2.6
M5	–	–	8	5.5
M6	9	6	12	9
M8	20	14	28	20
M10	40	28	55	40
M12	70	52	100	73
M14	–	–	–	–
M16	–	–	–	–




Figure 7.9: Bolt Grades

REFERENCE

### 7.1.4 Flare-Type Hydraulic Fittings

1. Check flare (A) and flare seat (B) for defects that might cause leakage.
2. Align tube (C) with fitting (D) and thread nut (E) onto fitting without lubrication until contact has been made between flared surfaces.
3. Torque fitting nut (E) to specified number of flats from finger tight (FFFT) or to a given torque value in Table 7.10, page 228.
4. Use two wrenches to prevent fitting (D) from rotating. Place one wrench on fitting body (D), and tighten nut (E) with other wrench to torque shown.
5. Assess final condition of connection.




Figure 7.10: Hydraulic Fitting

Table 7.10 Flare-Type Hydraulic Tube Fittings

SAE Dash Size	Thread Size (in.)	Torque Value <sup>9</sup>		Flats from Finger Tight (FFFT)	
		Nm	lbf-ft	Tube	Swivel Nut or Hose
-2	5/16-24	4-5	3-4	—	—
-3	3/8-24	7-8	5-6	—	—
-4	7/16-20	18-19	13-14	2-1/2	2
-5	1/2-20	19-21	14-15	2	2
-6	9/16-18	30-33	22-24	2	1-1/2
-8	3/4-16	57-63	42-46	2	1-1/2
-10	7/8-14	81-89	60-66	1-1/2	1-1/2
-12	1-1/16-12	113-124	83-91	1-1/2	1-1/4
-14	1-3/16-12	136-149	100-110	1-1/2	1-1/4
-16	1-5/16-12	160-176	118-130	1-1/2	1
-20	1-5/8-12	228-250	168-184	1	1
-24	1-7/8-12	264-291	195-215	1	1
-32	2-1/2-12	359-395	265-291	1	1
-40	3-12	—	—	1	1

9. Torque values shown are based on lubricated connections as in reassembly.

## REFERENCE

### 7.1.5 O-Ring Boss (ORB) Hydraulic Fittings (Adjustable)

1. Inspect O-ring (A) and seat (B) for dirt or obvious defects.
2. Back off lock nut (C) as far as possible. Ensure that washer (D) is loose and is pushed toward lock nut (C) as far as possible.
3. Check that O-ring (A) is **NOT** on threads and adjust if necessary.
4. Apply hydraulic system oil to O-ring (A).




Figure 7.11: Hydraulic Fitting

5. Install fitting (B) into port until back up washer (D) and O-ring (A) contact part face (E).
6. Position angle fittings by unscrewing no more than one turn.
7. Turn lock nut (C) down to washer (D) and tighten to torque shown. Use two wrenches, one on fitting (B) and other on lock nut (C).
8. Check final condition of fitting.




Figure 7.12: Hydraulic Fitting

**REFERENCE**

**Table 7.11 O-Ring Boss (ORB) Hydraulic Fittings (Adjustable)**

SAE Dash Size	Thread Size (in.)	Torque Value <sup>10</sup>	
		Nm	lbf·ft (*lbf·in)
-2	5/16-24	6-7	*53-62
-3	3/8-24	12-13	*106-115
-4	7/16-20	19-21	14-15
-5	1/2-20	21-33	15-24
-6	9/16-18	26-29	19-21
-8	3/4-16	46-50	34-37
-10	7/8-14	75-82	55-60
-12	1-1/16-12	120-132	88-97
-14	1-3/8-12	153-168	113-124
-16	1-5/16-12	176-193	130-142
-20	1-5/8-12	221-243	163-179
-24	1-7/8-12	270-298	199-220
-32	2-1/2-12	332-365	245-269

10. Torque values shown are based on lubricated connections as in reassembly.

REFERENCE

### 7.1.6 O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable)

1. Inspect O-ring (A) and seat (B) for dirt or obvious defects.
2. Check that O-ring (A) is **NOT** on threads and adjust if necessary.
3. Apply hydraulic system oil to O-ring.
4. Install fitting (C) into port until fitting is hand-tight.
5. Torque fitting (C) according to values in Table 7.12, page 231.
6. Check final condition of fitting.




Figure 7.13: Hydraulic Fitting

Table 7.12 O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable)

SAE Dash Size	Thread Size (in.)	Torque Value <sup>11</sup>	
		Nm	lbf·ft (*lbf·in)
-2	5/16–24	6–7	*53–62
-3	3/8–24	12–13	*106–115
-4	7/16–20	19–21	14–15
-5	1/2–20	21–33	15–24
-6	9/16–18	26–29	19–21
-8	3/4–16	46–50	34–37
-10	7/8–14	75–82	55–60
-12	1-1/16–12	120–132	88–97
-14	1-3/8–12	153–168	113–124
-16	1-5/16–12	176–193	130–142
-20	1-5/8–12	221–243	163–179
-24	1-7/8–12	270–298	199–220
-32	2-1/2–12	332–365	245–269

11. Torque values shown are based on lubricated connections as in reassembly.

## REFERENCE

### 7.1.7 O-Ring Face Seal (ORFS) Hydraulic Fittings

1. Check components to ensure that sealing surfaces and fitting threads are free of burrs, nicks, scratches, or any foreign material.



Figure 7.14: Hydraulic Fitting

2. Apply hydraulic system oil to O-ring (B).
3. Align tube or hose assembly so that flat face of sleeve (A) or (C) comes in full contact with O-ring (B).
4. Thread tube or hose nut (D) until hand-tight. The nut should turn freely until it is bottomed out.
5. Torque fittings according to values in Table 7.13, page 232.

**NOTE:**

If applicable, hold hex on fitting body (E) to prevent rotation of fitting body and hose when tightening fitting nut (D).




Figure 7.15: Hydraulic Fitting

6. Use three wrenches when assembling unions or joining two hoses together.
7. Check final condition of fitting.

**Table 7.13 O-Ring Face Seal (ORFS) Hydraulic Fittings**

SAE Dash Size	Thread Size (in.)	Tube O.D. (in.)	Torque Value <sup>12</sup>	
			Nm	lbf-ft
-3	Note <sup>13</sup>	3/16	–	–
-4	9/16	1/4	25–28	18–21
-5	Note <sup>13</sup>	5/16	–	–
-6	11/16	3/8	40–44	29–32
-8	13/16	1/2	55–61	41–45
-10	1	5/8	80–88	59–65
-12	1-3/16	3/4	115–127	85–94
-14	Note <sup>13</sup>	7/8	–	–

12. Torque values and angles shown are based on lubricated connection as in reassembly.

13. O-ring face seal type end not defined for this tube size.



## REFERENCE

**Table 7.13 O-Ring Face Seal (ORFS) Hydraulic Fittings (continued)**

SAE Dash Size	Thread Size (in.)	Tube O.D. (in.)	Torque Value <sup>14</sup>	
			Nm	lbf·ft
-16	1-7/16	1	150–165	111–122
-20	1-11/16	1-1/4	205–226	151–167
-24	1–2	1-1/2	315–347	232–256
-32	2-1/2	2	510–561	376–414

### 7.1.8 Tapered Pipe Thread Fittings

Assemble pipe fittings as follows:

1. Check components to ensure that fitting and port threads are free of burrs, nicks and scratches, or any form of contamination.
2. Apply pipe thread sealant (paste type) to external pipe threads.
3. Thread fitting into port until hand-tight.
4. Torque connector to appropriate torque angle. The Turns From Finger Tight (TFFT) values are shown in Table 7.14, page 233. Make sure that tube end of a shaped connector (typically 45 degree or 90 degree) is aligned to receive incoming tube or hose assembly. Always finish alignment of fitting in tightening direction. Never back off (loosen) pipe threaded connectors to achieve alignment.
5. Clean all residue and any excess thread conditioner with appropriate cleaner.
6. Assess final condition of fitting. Pay special attention to possibility of cracks to port opening.
7. Mark final position of fitting. If a fitting leaks, disassemble fitting and check for damage.

**NOTE:**

Overtorque failure of fittings may not be evident until fittings are disassembled.

**Table 7.14 Hydraulic Fitting Pipe Thread**

Tapered Pipe Thread Size	Recommended TFFT	Recommended FFFT
1/8–27	2–3	12–18
1/4–18	2–3	12–18
3/8–18	2–3	12–18
1/2–14	2–3	12–18
3/4–14	1.5–2.5	12–18
1–11 1/2	1.5–2.5	9–15
1 1/4–11 1/2	1.5–2.5	9–15
1 1/2–11 1/2	1.5–2.5	9–15
2–11 1/2	1.5–2.5	9–15

14. Torque values and angles shown are based on lubricated connection as in reassembly.

REFERENCE

## 7.2 Conversion Chart

Table 7.15 Conversion Chart

Quantity	SI Units (Metric)		Factor	US Customary Units (Standard)	
	Unit Name	Abbreviation		Unit Name	Abbreviation
Area	hectare	ha	$\times 2.4710 =$	acre	acres
Flow	liters per minute	L/min	$\times 0.2642 =$	US gallons per minute	gpm
Force	Newton	N	$\times 0.2248 =$	pound force	lbf
Length	millimeter	mm	$\times 0.0394 =$	inch	in.
Length	meter	m	$\times 3.2808 =$	foot	ft.
Power	kilowatt	kW	$\times 1.341 =$	horsepower	hp
Pressure	kilopascal	kPa	$\times 0.145 =$	pounds per square inch	psi
Pressure	megapascal	MPa	$\times 145.038 =$	pounds per square inch	psi
Pressure	bar (Non-SI)	bar	$\times 14.5038 =$	pounds per square inch	psi
Torque	Newton meter	Nm	$\times 0.7376 =$	pound feet or foot pounds	lbf-ft
Torque	Newton meter	Nm	$\times 8.8507 =$	pound inches or inch pounds	lbf-in
Temperature	degrees Celsius	°C	$(^{\circ}\text{C} \times 1.8) + 32 =$	degrees Fahrenheit	°F
Velocity	meters per minute	m/min	$\times 3.2808 =$	feet per minute	ft/min
Velocity	meters per second	m/s	$\times 3.2808 =$	feet per second	ft/s
Velocity	kilometers per hour	km/h	$\times 0.6214 =$	miles per hour	mph
Volume	liter	L	$\times 0.2642 =$	US gallon	US gal
Volume	milliliter	ml	$\times 0.0338 =$	ounce	oz.
Volume	cubic centimeter	cm <sup>3</sup> or cc	$\times 0.061 =$	cubic inch	in. <sup>3</sup>
Weight	kilogram	kg	$\times 2.2046 =$	pound	lb.

## REFERENCE

### 7.3 Definitions

The following terms and acronyms may be used in this instruction:

<b>Term</b>	<b>Definition</b>
A Series header	MacDon A30D and A40D auger headers
API	American Petroleum Institute
ASTM	American Society of Testing and Materials
Bolt	A headed and externally threaded fastener that is designed to be paired with a nut
Cab-forward	Windrower operation with Operator and cab facing in direction of travel
CDM	Cab display module on a windrower
Center-link	A hydraulic cylinder link between header and machine used to change header angle
CGVW	Combined gross vehicle weight
D Series header	MacDon D50, D60, and D65 rigid draper headers
D1 SP Series header	MacDon D115, D120, D125, D130, D135, and D140 rigid draper headers for M Series Windrower
DDD	Double-draper drive
DEF	Diesel exhaust fluid; also called AdBlue in Europe, and AUS 32 in Australia
DEF DOSING UNIT	Pump that supplies diesel exhaust fluid through system
DM	Dosing module
DK	Double knife
DKD	Double-knife drive
DOC	Diesel oxidation catalyst
DRT	Aftertreatment decomposition tube
DWA	Double Windrow Attachment
ECM	Engine control module
Engine-forward	Windrower operation with Operator and engine facing in direction of travel
FFFT	Flats from finger tight
Finger tight	Finger tight is a reference position where sealing surfaces or components are making contact with each other, and fitting has been tightened to a point where fitting is no longer loose
GSL	Ground speed lever
GSS	Grass Seed
GVW	Gross vehicle weight
Hard joint	A joint made with use of a fastener where joining materials are highly incompressible
Header	A machine that cuts and lays crop into a windrow and is attached to a windrower
Hex key	A tool of hexagonal cross-section used to drive bolts and screws that have a hexagonal socket in head (internal-wrenching hexagon drive); also known as an Allen key and various other synonyms

## REFERENCE

<b>Term</b>	<b>Definition</b>
HDS	Hydraulic deck shift
hp	Horsepower
ISC	Intermediate Speed Control
JIC	Joint Industrial Council: A standards body that developed standard sizing and shape for original 37° flared fitting
Knife	A cutting device which uses a reciprocating cutter (also called a sickle)
MDS	Mechanical deck shift
n/a	Not applicable
N-DETENT	The slot opposite the NEUTRAL position of M Series SP Windrowers on operator's console
NPT	National Pipe Thread: A style of fitting used for low-pressure port openings. Threads on NPT fittings are uniquely tapered for an interference fit
Nut	An internally threaded fastener that is designed to be paired with a bolt
ORB	O-ring boss: A style of fitting commonly used in port openings on manifolds, pumps, and motors
ORFS	O-ring face seal: A style of fitting commonly used for connecting hoses and tubes. This style of fitting is also commonly called ORS, which stands for O-ring seal
R Series header	MacDon R80 and R85 rotary disc headers
RoHS (Reduction of Hazardous Substances)	A directive by the European Union to restrict use of certain hazardous substances (such as hexavalent chromium used in some yellow zinc platings)
rpm	Revolutions per minute
SAE	Society of Automotive Engineers
SCR	Selective catalytic reduction catalyst
Screw	A headed and externally threaded fastener that threads into preformed threads or forms its own thread into a mating part
SDD	Single-drawer drive
Self-Propelled (SP) Windrower	Self-propelled machine consisting of a power unit with a header
SK	Single knife
SKD	Single-knife drive
Soft joint	A joint made with use of a fastener where joining materials are compressible or experience relaxation over a period of time
spm	Strokes per minute
Tension	Axial load placed on a bolt or screw, usually measured in Newtons (N) or pounds (lb.)
TFFT	Turns from finger tight
Torque	The product of a force X lever arm length, usually measured in Newton-meters (Nm) or foot-pounds (lbf-ft)

## REFERENCE

<b>Term</b>	<b>Definition</b>
Torque angle	A tightening procedure where fitting is assembled to a precondition (finger tight) and then nut is turned farther a number of degrees to achieve its final position
Torque-tension	The relationship between assembly torque applied to a piece of hardware and axial load it induces in bolt or screw
UCA	Upper cross auger
ULSD	Ultra-low sulphur diesel
Washer	A thin cylinder with a hole or slot located in the center that is to be used as a spacer, load distribution element, or locking mechanism
WCM	Windrower control module
Windrower	Power unit of a self-propelled header
WOT	Wide open throttle

REFERENCE

## 7.4 Lubricants, Fluids, and System Capacities

### WARNING

To avoid injury or death, do not allow ANY machine fluids to enter the body.

Table 7.16 M155 System Capacities

Lubricant/Fluid	Location	Description	Capacity
Diesel exhaust fluid (DEF)	Diesel exhaust fluid tank	Must meet ISO 22241 requirements	29 L (7.5 US gal)
Grease	As required unless otherwise specified	SAE multi-purpose high temperature extreme pressure (EP2) performance with 1% max Molybdenum Disulphide (NLGI Grade 2) lithium base	—
Diesel fuel	Fuel tank	Ultra low sulphur diesel (ULSD) Grade No. 2, or ULSD Grade No. 1 and 2 mix <sup>15</sup> ; refer to <i>7.5 Fuel Specifications, page 240</i> for more information	378 L (97 US gal)
Hydraulic oil	Hydraulic reservoir	SAE 15W-40 compliant with SAE specs for API class SJ and CH-4 engine oil.	65 L (17.2 US gal)
Gear lubricant	Gearbox	SAE 80W-140 <sup>16</sup> , API service class GL-5. Fully synthetic gear lubricant, (SAE J2360 preferred)	2.1 L (2.2 US qt.)
Gear lubricant	Wheel drive <sup>17</sup>	SAE 75W-90, API service class GL-5. Fully synthetic gear lubricant, (SAE J2360 preferred)	1.4 L (1.5 US qt.)
Antifreeze	Engine cooling system	ASTM D-6210 and Fleetguard ES Compleat®. See last page of this section	27.5 L (7.3 US gal) <sup>18</sup>
Engine oil	Engine oil pan	SAE 15W-40 compliant with SAE specs for API class SJ and CJ-4 engine oil	11 L (11.6 US qt.)
Air conditioning refrigerant	Air conditioning system	R134A	2.27 kg (5 lb.)
Air conditioning refrigerant oil <sup>19</sup>	Air conditioning system total capacity	PAG SP-15	240 cc (8.1 fl. oz.)

15. Optional when operating temperature is below 0°C (32°F).

16. SAE 75W-140 may be substituted for SAE 80W-140 if necessary.

17. SAE 85W-140 API Service Class GL-5. Extreme Pressure Gear Lubricant is used before initial change.

18. Equal parts with water, high quality, soft, de-ionized or distilled water as recommended by Supplier.

19. New compressor (MD #203013) comes filled.

## REFERENCE

### NOTE:

If Fleetguard® ES Compleat™ is unavailable, use a coolant concentrate or prediluted coolant intended for use with heavy duty diesel engines. Ensure coolant meets a minimum of the following chemical and physical properties:

- Provides cylinder cavitation protection according to fleet study run at or above 60% load capacity.
- Protects the cooling system metals (cast iron, aluminum alloys, and copper alloys such as brass) from corrosion.

An additive package should contain one of the following coolant mixtures:

- Ethylene glycol or propylene glycol base prediluted (40–60%) heavy duty coolant.
- Ethylene glycol or propylene glycol base heavy duty coolant concentrate in a 40–60% mixture of concentrate with quality water.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate.

### IMPORTANT:

Do **NOT** use cooling system sealing additives or antifreeze that contains sealing additives. Ethylene glycol and propylene glycol may alter the freeze temperature. Verify that the mixture meets the freeze protection criteria of its intended use.

## 7.5 Fuel Specifications

Use only ultra low sulphur diesel (ULSD) from a reputable supplier. For most year-round service, No.2 ULSD fuel meeting ASTM specification D975 Grade S15 will provide good performance.

**Table 7.17 Fuel Specification**

Fuel	Specification	Sulphur (by weight)	Water and Sediment (by volume)	Cetane No.	Lubricity
ULSD Grade no. 2	ASTM D975	0.5% maximum	0.05% maximum	40°C (104°F) minimum	520 microns
ULSD Grade no. 1 and 2 mix <sup>20</sup>	n/a	1% maximum 0.5% maximum preferred	0.1% maximum	45–55°C (113–131°F) cold weather / high altitude	460 microns

In extreme situations, when available fuels are of poor quality or problems exist which are peculiar to certain operations, additives can be used. However, the engine manufacturer recommends consultation with the fuel supplier or engine manufacturer before using fuel additives. Situations where additives are useful include:

- A cetane improver additive can be used with low cetane fuels.
- A wax crystal modifier can help with fuels with high cold filter plugging points (CFPP).
- An anti-icer can help prevent ice formation in wet fuel during cold weather.
- An antioxidant or storage stability additive can help with fuel system deposits and poor storage stability.
- A lubricity enhancer can be used to increase the lubricity of fuels so that they meet the requirements given in the table on the previous page.

20. Optional when operating temperature is below 0°C (32°F).



# Predelivery Checklist

Perform these checks and adjustments prior to delivery to your Customer. Complete this checklist and provide it to the Dealer or the Operator.

## CAUTION

Carefully follow the instructions given. Be alert for safety related messages that bring your attention to hazards and unsafe practices.

Windrower Serial Number:

Engine Serial Number:

**Table .18 M155E4 Self-Propelled Windrower Predelivery Checklist – Export**

✓	Item	Reference
	Check for shipping damage or missing parts. Be sure all shipping dunnage is removed.	—
	Check for loose hardware. Tighten to required torque.	<i>7 Reference, page 223</i>
	Check tire air pressures and adjust as required.	<i>3.2.1 Checking Tire Pressures, page 80</i>
	Check final drive hub lubricant level.	<i>3.13 Checking and Adding Wheel Drive Lubricant Level, page 99</i>
	Check engine coolant level and strength at reserve tank.	<i>3.8 Checking Engine Coolant, page 88</i>
	Drain Diesel Exhaust Fluid (DEF) tank and refill with fresh DEF.	<i>3.10 Draining and Refilling the Diesel Exhaust Fluid (DEF) Tank, page 90</i>
	Check air cleaner and clamps.	<i>3.3 Checking Engine Air Intake, page 82</i>
	Check hydraulic oil level and check for leaks along lines.	<i>3.4 Checking Hydraulic Oil Level, page 84</i>
	Check fuel separator for water and foreign material. Drain and clean as necessary. Add fuel.	<i>3.5 Checking Fuel Separator, page 85</i>
	Check engine oil level.	<i>3.6 Checking Engine Oil Level, page 86</i>
	Check gearbox lubricant level.	<i>3.7 Checking Gearbox Lubricant Level, page 87</i>
	Check tension of air conditioning compressor belt.	<i>3.9 Checking Air Conditioning (A/C) Compressor Belt, page 89</i>
	Check that machine is completely lubricated.	<i>3.17 Lubricating the Windrower, page 72</i>
	Check neutral interlock system.	<i>5.1 Checking Safety System, page 169</i>
	<b>Start engine and run to operating temperature.</b>	<i>5.3 Checking Windrower Startup, page 173</i>
	Check CDM for operation.	<i>5.5 Checking Gauges and Cab Display Module (CDM) Display, page 175</i>
	Check Operator's Presence System.	<i>5.2 Checking Operator's Presence System, page 172</i>
	Check alternator charge rate on CDM.	<i>5.6 Checking Electrical System, page 176</i>
	Check fuel gauge/indicator for operation.	<i>5.5 Checking Gauges and Cab Display Module (CDM) Display, page 175</i>
	Check that air conditioning is functioning properly.	<i>5.11 Checking Air Conditioning (A/C) and Heater, page 183</i>

**REFERENCE**

**Table .18 M155E4 Self-Propelled Windrower Predelivery Checklist – Export (continued)**

✓	Item	Reference
	Check that heater is functioning properly.	<i>5.11 Checking Air Conditioning (A/C) and Heater, page 183</i>
	Check instrument console gauge lights.	<i>5.5 Checking Gauges and Cab Display Module (CDM) Display, page 175</i>
	Check maximum (no load) engine speed at CDM.	<i>5.4 Checking Engine Speed, page 174</i>
	Check that exterior lights are functioning properly.	<i>5.7 Checking Exterior Lights, page 177</i>
	Check that interior lights are functioning properly.	<i>5.10 Checking Interior Lights, page 182</i>
	Complete the header's Predelivery Checklist.	—
	Check that manuals are in the windrower manual case.	<i>5.12 Checking Manuals, page 184</i>
	Remove plastic coverings from cab interior.	<i>5.13 Performing Final Steps, page 185</i>

**Date Checked:**

**Checked by:**



**MacDon Industries Ltd.**

680 Moray Street  
Winnipeg, Manitoba  
Canada R3J 3S3  
t. (204) 885-5590 f. (204) 832-7749

**MacDon, Inc.**

10708 N. Pomona Avenue  
Kansas City, Missouri  
United States 64153-1924  
t. (816) 891-7313 f. (816) 891-7323

**MacDon Australia Pty. Ltd.**

A.C.N. 079 393 721  
P.O. Box 103 Somerton, Victoria, Australia  
Australia 3061  
t.+61 3 8301 1911 f.+61 3 8301 1912

**MacDon Brasil Agribusiness Ltda.**

Rua Grã Nicco, 113, sala 202, B. 02  
Mossunguê, Curitiba, Paraná  
CEP 81200-200 Brasil  
t. +55 (41) 2101-1713 f. +55 (41) 2101-1699

**LLC MacDon Russia Ltd.**

123317 Moscow, Russia  
10 Presnenskaya nab, Block C  
Floor 5, Office No. 534, Regus Business  
Centre  
t. +7 495 775 6971 f. +7 495 967 7600

**MacDon Europe GmbH**

Hagenauer Strasse 59  
65203 Wiesbaden  
Germany

**CUSTOMERS**

**MacDon.com**

**DEALERS**

**Portal.MacDon.com**

Trademarks of products are the marks of their  
respective manufacturers and/or distributors.

Printed in Canada