


# **D1 Series Combine Draper Header with FM100 Float Module**

Unloading and Assembly Instructions (North America)

214073 Revision A  
2017 Model Year  
Original Instruction

D1 Series Draper Header for Combines



1017561

Published: December 2016

# Introduction

This instruction manual describes the unloading, setup, and predelivery requirements for the MacDon D1 Series Combine Draper Header with FM100 Float Module.

To ensure the best performance of this product and the safety of your customers, carefully follow the unload and assembly procedure from the beginning through to completion.

**Carefully read all the material provided before attempting to unload, assemble, or use the machine.**

Retain this instruction for future reference.

**NOTE:**

Keep your MacDon publications up-to-date. The latest version can be downloaded from our website ([www.macdon.com](http://www.macdon.com)) or from our Dealer portal (<https://portal.macdon.com>) (login required).

## List of Revisions

Summary of Change	Refer to
All measurements list metric before imperial.	Throughout the book.
Updated procedures and illustrations for new float lock handle on the FM100 Float Module.	Throughout the book.
Shipping stands updated for new model year. Illustrations updated to match new stands.	<a href="#">2.3 Removing Shipping Stands, page 10</a>
Added illustration showing the difference between CNH and John Deere/Lexion reel height sensor configuration.	<a href="#">3.2 Attaching Reel Height Sensor, page 23</a>
Updated Adjusting Auger to Pan Clearance procedure.	<a href="#">5.12 Adjusting Auger to Pan Clearance, page 114</a>
Added Checking and Adjusting Reel Height Sensor procedure.	<a href="#">7 Checking and Adjusting Reel Height Sensor, page 259</a>

## TABLE OF CONTENTS

Introduction .....	i
List of Revisions .....	ii
<b>1 Safety .....</b>	<b>1</b>
1.1 Signal Words .....	1
1.2 General Safety .....	2
1.3 Safety Signs .....	4
<b>2 Unloading Header and Float Module .....</b>	<b>5</b>
2.1 Unloading Header and Float Module from Trailer .....	5
2.2 Lowering Header .....	7
2.3 Removing Shipping Stands .....	10
<b>3 Assembling Header and Float Module.....</b>	<b>15</b>
3.1 Attaching Reel Lift Cylinders.....	15
3.2 Attaching Reel Height Sensor.....	23
3.3 Installing Guards: Single Reel .....	25
3.3.1 Installing Formed Hold-Down .....	25
3.3.2 Forged Hold-Down (Stub Guard Only) .....	26
3.4 Setting up Float Module .....	28
3.4.1 Installing Filler Cap.....	28
3.4.2 Configuring Auger .....	30
3.4.3 Removing Stripper Bars.....	30
3.4.4 Replacing CR Feeder Deflectors .....	30
<b>4 Attaching Header to Combine .....</b>	<b>33</b>
4.1 AGCO (Challenger, Gleaner, and Massey Ferguson) Combines .....	33
4.1.1 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness.....	33
4.1.2 Attaching Header to a Challenger, Gleaner, or Massey Ferguson Combine .....	36
4.2 Case IH Combines.....	41
4.2.1 Attaching Header to Case IH Combine .....	41
4.3 John Deere Combines .....	47
4.3.1 Installing Reel Fore-Aft / Header Tilt Switch: S and T Series Combines .....	47
4.3.2 Installing Reel Fore-Aft / Header Tilt Switch: 60 and 70 Series Combines .....	51
4.3.3 Attaching Header to John Deere Combine .....	55
4.4 Lexion Combines.....	59
4.4.1 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness: 500 Series .....	59
4.4.2 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness: 700 Series .....	66
4.4.3 Attaching Header to Lexion Combine.....	69
4.5 New Holland Combines.....	76
4.5.1 Attaching Header to New Holland CR/CX Combine .....	76
4.6 Completing the Header Assembly .....	81
4.6.1 Attaching Cam Arms.....	81
4.6.2 Repositioning Gearbox .....	82
4.6.3 Removing Shipping Supports.....	83
4.6.4 Positioning Transport Lights.....	84
4.6.5 Crop Dividers .....	85
Removing Crop Dividers from Storage .....	85
Opening Endshields.....	85
Installing Crop Divider without Latch Option.....	86
Installing Crop Divider with Latch Option .....	88
Closing Endshields .....	89
Installing Crop Divider Rods .....	89
4.6.6 Installing Options.....	90
<b>5 Performing Predelivery Checks.....</b>	<b>91</b>
5.1 Checking Tire Pressure: Transport and Stabilizer Wheels .....	91
5.2 Checking Wheel Bolt Torque.....	92

## TABLE OF CONTENTS

5.3	Checking Knife Drive Box .....	93
5.4	Checking Oil Level in Header Drive Gearbox .....	95
5.5	Checking Oil Level in Hydraulic Reservoir .....	96
5.6	Checking and Adjusting Knife Drive Belt Tension .....	97
5.6.1	Tensioning Non-Timed Knife Drive Belts .....	97
5.6.2	Tensioning Timed Knife Drive Belts .....	98
5.7	Checking Knife Hold-Downs .....	100
5.7.1	Adjusting Hold-Downs with Pointed Guards .....	100
5.7.2	Adjusting Hold-Downs with Stub Guards .....	101
5.8	Centering the Reel .....	103
5.9	Checking and Adjusting Header Float .....	105
5.10	Checking and Adjusting Skid Shoe Settings .....	110
5.11	Measuring and Adjusting Reel Clearance to Cutterbar .....	111
5.11.1	Measuring Reel Clearance .....	111
5.11.2	Adjusting Reel Clearance .....	112
5.12	Adjusting Auger to Pan Clearance .....	114
5.13	Checking Auger Finger Timing .....	117
5.13.1	Adjusting Auger Finger Timing .....	117
5.14	Adjusting Draper Tension .....	120
5.15	Adjusting Feed Draper Tension .....	122
5.16	Checking and Adjusting Draper Seal .....	123
5.17	Lubricating the Header .....	125
5.17.1	Greasing Procedure .....	125
5.17.2	Lubrication Points .....	127
5.18	Checking and Adjusting Endshields .....	134
5.19	Checking Manuals .....	137
<b>6</b>	<b>Setting up Auto Header Height Control .....</b>	<b>139</b>
6.1	Auto Header Height Control (AHC) .....	139
6.1.1	Sensor Output Voltage Range – Combine Requirements .....	141
	Manually Checking Voltage Range: One-Sensor System .....	141
	Manually Checking Voltage Range: Two-Sensor System .....	144
	Adjusting Voltage Limits: One-Sensor System .....	146
	Adjusting Voltage Limits: Two-Sensor System .....	148
6.1.2	Case IH 5088/6088/7088 Combines .....	150
	Calibrating the Auto Header Height Control (Case IH 5088/6088/7088) .....	150
	Setting the Sensitivity of the Auto Header Height (Case IH 5088/6088/7088) .....	151
6.1.3	Case IH 5130/6130/7130, 7010/8010, 7120/8120/9120, 7230/8230/9230 and 7240/8240/9240 Combines .....	152
	Checking Voltage Range from the Combine Cab (Case 8010) .....	152
	Checking Voltage Range from the Combine Cab (Case IH 5130/6130/7130, 7010/8010; 7120/8120/9120; 7230/8230/9230) .....	155
	Calibrating the Auto Header Height Control (Case IH 5130/6130/7130, 7010/8010; 7120/8120/9120; 7230/8230/9230) .....	158
	Calibrating the Auto Header Height Control (Case Combines with Version 28.00 or Higher Software) .....	160
	Setting Preset Cutting Height (Case 7010/8010, 7120/8120/9120, 7230/8230/9230) .....	162
6.1.4	Challenger and Massey Ferguson Combines .....	164
	Checking Voltage Range from the Combine Cab (Challenger and Massey Ferguson) .....	164
	Engaging the Auto Header Height Control (Challenger and Massey Ferguson) .....	166
	Calibrating the Auto Header Height Control (Challenger and Massey Ferguson) .....	166
	Adjusting the Header Height (Challenger and Massey Ferguson) .....	168
	Adjusting the Header Raise/Lower Rate (Challenger and Massey Ferguson) .....	169

## TABLE OF CONTENTS

---

	Setting the Sensitivity of the Auto Header Height Control (Challenger and Massey Ferguson).....	170
6.1.5	Gleaner R65/R66/R75/R76 and S Series Combines .....	172
	Checking Voltage Range from the Combine Cab (Gleaner R65/R66/R75/R76 and Pre-2016 S Series).....	172
	Engaging the Auto Header Height Control (Gleaner R65/R66/R75/R76 and Pre-2016 S Series) .....	173
	Calibrating the Auto Header Height Control (Gleaner R65/R66/R75/R76 and Pre-2016 S Series) .....	175
	Turning off the Accumulator (Gleaner R65/R66/R75/R76 and Pre-2016 S Series).....	176
	Adjusting the Header Raise/Lower Rate (Gleaner R65/R66/R75/R76 and Pre-2016 S Series) .....	176
	Adjusting Ground Pressure (Gleaner R65/R66/R75/R76 and Pre-2016 S Series).....	177
	Adjusting the Sensitivity of the Auto Header Height Control (AHHC) (Gleaner R65/R66/R75/R76 and Pre-2016 S Series) .....	178
	Troubleshooting Alarms and Diagnostic Faults (Gleaner R65/R66/R75/R76 and Pre-2016 S Series) .....	179
6.1.6	Gleaner S9 Series Combines .....	181
	Setting up the Header (Gleaner S9) .....	181
	Setting up Reel Settings (Gleaner S9).....	185
	Setting up Automatic Header Controls (Gleaner S9 Series) .....	187
	Calibrating the Header (Gleaner S9 Series).....	189
	Operating with a Gleaner S9 Combine .....	192
	Header In-Field Settings.....	193
6.1.7	John Deere 60 Series Combines .....	195
	Checking Voltage Range from the Combine Cab (John Deere 60 Series) .....	195
	Calibrating the Auto Header Height Control (John Deere 60 Series).....	197
	Turning the Accumulator Off (John Deere 60 Series).....	198
	Setting the Sensing Grain Header Height to 50 (John Deere 60 Series).....	199
	Setting the Sensitivity of the Auto Header Height Control (John Deere 60 Series) .....	200
	Adjusting the Threshold for the Drop Rate Valve (John Deere 60 Series).....	201
6.1.8	John Deere 70 Series Combines .....	203
	Checking Voltage Range from the Combine Cab (John Deere 70 Series) .....	203
	Calibrating Feeder House Speed (John Deere 70 Series).....	206
	Calibrating the Auto Header Height Control (John Deere 70 Series).....	206
	Setting the Sensitivity of the Auto Header Height Control (John Deere 70 Series) .....	208
	Adjusting the Manual Header Raise/Lower Rate (John Deere 70 Series).....	208
6.1.9	John Deere S and T Series Combines .....	210
	Checking Voltage Range from the Combine Cab (John Deere S and T Series) .....	210
	Calibrating the Auto Header Height Control (John Deere S and T Series).....	213
	Setting the Sensitivity of the Auto Header Height Control (John Deere S and T Series).....	215
	Adjusting the Manual Header Raise/Lower Rate (John Deere S and T Series).....	215
	Setting Preset Cutting Height (John Deere S-Series).....	216
	Calibrating Feeder House Fore/Aft Tilt Range (John Deere S and T Series).....	219
6.1.10	Lexion 500 Series Combines .....	222
	Calibrating the Auto Header Height Control (Lexion 500 Series) .....	222
	Setting Cutting Height (Lexion 500 Series) .....	224
	Setting the Sensitivity of the Auto Header Height Control (Lexion 500 Series).....	226
	Adjusting Auto Reel Speed (Lexion 500 Series).....	228
6.1.11	Lexion 600 and 700 Series Combines.....	231
	Calibrating the Auto Header Height Control (Lexion 600 and 700 Series) .....	231
	Setting Cutting Height (Lexion 600 and 700 Series) .....	233

## TABLE OF CONTENTS

---

	Setting the Sensitivity of the Auto Header Height Control (Lexion 600 and 700 Series) .....	233
	Adjusting Auto Reel Speed (Lexion 600 and 700 Series) .....	235
6.1.12	New Holland Combines .....	237
	Checking Voltage Range from the Combine Cab (New Holland) .....	237
	Engaging the Auto Header Height Control (New Holland CR/CX Series) .....	239
	Calibrating the Auto Header Height Control (New Holland CR/CX Series).....	241
	Adjusting Header Raise Rate (New Holland CR/CX Series) .....	243
	Setting the Header Lower Rate (New Holland CR/CX Series) .....	244
	Setting the Sensitivity of the Auto Header Height Control (New Holland CR/CX Series).....	245
6.1.13	New Holland Combines (CR Series—Model Year 2015 and Later).....	247
	Checking Voltage Range from the Combine Cab (New Holland CR Series) .....	247
	Engaging the Auto Header Height Control (New Holland CR Series) .....	249
	Calibrating the Auto Header Height Control (New Holland CR Series) .....	252
	Setting Auto Height (New Holland CR Series).....	254
	Setting Maximum Work Height (New Holland CR Series).....	255
6.1.14	Sensor Operation .....	258
<b>7</b>	<b>Checking and Adjusting Reel Height Sensor .....</b>	<b>259</b>
<b>8</b>	<b>Running up Header .....</b>	<b>261</b>
8.1	Performing Post Run-Up Adjustments .....	263
8.1.1	Adjusting Knife .....	263
8.1.2	Adjusting Knife Speed .....	265
<b>9</b>	<b>Reference .....</b>	<b>267</b>
9.1	Torque Specifications .....	267
9.1.1	Metric Bolt Specifications .....	267
9.1.2	Metric Bolt Specifications Bolting into Cast Aluminum .....	270
9.1.3	Flare-Type Hydraulic Fittings.....	270
9.1.4	O-Ring Boss (ORB) Hydraulic Fittings (Adjustable).....	272
9.1.5	O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable) .....	274
9.1.6	O-Ring Face Seal (ORFS) Hydraulic Fittings.....	275
9.1.7	Tapered Pipe Thread Fittings .....	277
9.2	Lifting Equipment Requirements .....	278
9.3	Conversion Chart.....	279
9.4	Definitions .....	280
	Predelivery Checklist .....	283

# 1 Safety

## 1.1 Signal Words

Three signal words, **DANGER**, **WARNING**, and **CAUTION**, are used to alert you to hazardous situations. The appropriate signal word for each situation has been selected using the following guidelines:

### **DANGER**

Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.

### **WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. It may also be used to alert against unsafe practices.

### **CAUTION**

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may be used to alert against unsafe practices.

## 1.2 General Safety

### CAUTION

The following are general farm safety precautions that should be part of your operating procedure for all types of machinery.

Protect yourself.

- When assembling, operating, and servicing machinery, wear all protective clothing and personal safety devices that could be necessary for job at hand. Do **NOT** take chances. You may need the following:
  - Hard hat
  - Protective footwear with slip resistant soles
  - Protective glasses or goggles
  - Heavy gloves
  - Wet weather gear
  - Respirator or filter mask
- Be aware that exposure to loud noises can cause hearing impairment or loss. Wear suitable hearing protection devices such as ear muffs or ear plugs to help protect against objectionable or loud noises.



Figure 1.1: Safety Equipment



Figure 1.2: Safety Equipment

- Provide a first aid kit for use in case of emergencies.
- Keep a fire extinguisher on the machine. Be sure fire extinguisher is properly maintained. Be familiar with its proper use.
- Keep young children away from machinery at all times.
- Be aware that accidents often happen when Operator is tired or in a hurry. Take time to consider safest way. Never ignore warning signs of fatigue.




Figure 1.3: Safety Equipment

## SAFETY

- Wear close-fitting clothing and cover long hair. Never wear dangling items such as scarves or bracelets.
- Keep all shields in place. **NEVER** alter or remove safety equipment. Make sure driveline guards can rotate independently of shaft and can telescope freely.
- Use only service and repair parts made or approved by equipment manufacturer. Substituted parts may not meet strength, design, or safety requirements.



Figure 1.4: Safety around Equipment

- Keep hands, feet, clothing, and hair away from moving parts. **NEVER** attempt to clear obstructions or objects from a machine while engine is running.
- Do **NOT** modify machine. Unauthorized modifications may impair machine function and/or safety. It may also shorten machine's life.
- To avoid bodily injury or death from unexpected startup of machine, **ALWAYS** stop the engine and remove the key from the ignition before leaving the operator's seat for any reason.




Figure 1.5: Safety around Equipment


- Keep service area clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment. Be sure all electrical outlets and tools are properly grounded.
- Keep work area well lit.
- Keep machinery clean. Straw and chaff on a hot engine is a fire hazard. Do **NOT** allow oil or grease to accumulate on service platforms, ladders, or controls. Clean machines before storage.
- **NEVER** use gasoline, naphtha, or any volatile material for cleaning purposes. These materials may be toxic and/or flammable.
- When storing machinery, cover sharp or extending components to prevent injury from accidental contact.



Figure 1.6: Safety around Equipment

## **1.3 Safety Signs**

- Keep safety signs clean and legible at all times.
- Replace safety signs that are missing or become illegible.
- If original parts on which a safety sign was installed are replaced, be sure repair part also bears current safety sign.
- Safety signs are available from your MacDon Dealer.



**Figure 1.7: Operator's Manual Decal**

## 2 Unloading Header and Float Module

Perform all procedures in this chapter in the order in which they are listed.

### 2.1 Unloading Header and Float Module from Trailer

The following procedure assumes that two headers were shipped on the trailer.

#### CAUTION

To avoid injury to bystanders from being struck by machinery, do not allow people to stand in unloading area.

#### CAUTION

Equipment used for unloading must meet or exceed the requirements specified below. Using inadequate equipment may result in chain breakage, vehicle tipping, or machine damage.

#### IMPORTANT:

Forklifts are normally rated with the load centered 610 mm (24 in.) from the back end of forks. To obtain forklift capacity for a load centered at 1220 mm (48 in.), check with your forklift distributor.

Table 2.1 Lifting Vehicle

<b>Minimum Lifting Capacity</b>	4082 kg (9000 lb.) load center (A) at 1220 mm (48 in.) (B) from back of forks
<b>Minimum Fork Length (C)</b>	1981 mm (78 in.)




Figure 2.1: Minimum Lifting Capacity

A - Center of Gravity of the Load  
B - Load Center 1220 mm (48 in.) from Back of Forks  
C - Minimum Fork Length 1981 mm (78 in.)

To unload headers and float modules from a trailer, follow these steps:

1. Move trailer into position and block trailer wheels.
2. Lower trailer storage stands.

## UNLOADING HEADER AND FLOAT MODULE

3. Approach one of the headers and line up forks (A) with fork slider channels (B) under the float module frame.
4. Slide forks (A) underneath fork slider channels (B) as far as possible without contacting the shipping support of the opposite header.

### IMPORTANT:

Avoid lifting the second header and ensure the forks do not interfere with the shipping frame. If the forks contact the second header, damage to the headers may occur.

5. Remove hauler's tie-down straps, chains, and wooden blocks.
6. Slowly raise header off trailer deck.

### WARNING

Be sure forks are secure before moving away from load. Stand clear when lifting.

7. Back up until header clears trailer and slowly lower to 150 mm (6 in.) from ground.
8. Take header to the storage or setup area. Ensure ground is flat and free of rocks or debris that could damage the header.
9. Repeat above steps for second header.
10. Check for shipping damage and missing parts.




Figure 2.2: Header Shipping Supports




Figure 2.3: Header Lowered onto Level Ground

## 2.2 Lowering Header

1. Approach the underside of the header with the lifting vehicle.




Figure 2.4: Underside of Header

2. Attach chain to shipping support (A) at center reel arm.

**IMPORTANT:**

Do NOT attempt to lift at cutterbar when unloading from trailer. This procedure is ONLY for laying the machine over into working position.

**CAUTION**

Stand clear of header when lowering. Machine may swing.




Figure 2.5: Chain Attachment Locations

A - Double Reel

B - Single Reel

## UNLOADING HEADER AND FLOAT MODULE

3. Back up SLOWLY while lowering forks until header rests on the ground.



Figure 2.6: Header Lowered onto Ground

## UNLOADING HEADER AND FLOAT MODULE

4. Place 150 mm (6 in.) blocks (A) under each end and at the center of cutterbar, then lower header onto blocks.
5. Remove chain.




Figure 2.7: Blocks at Each End of Cutterbar

## 2.3 Removing Shipping Stands

**NOTE:**

Unless otherwise specified, discard stands, shipping material, and hardware. The removable stands are painted yellow.

1. Remove the two bolts (A) securing the right fork channel (B) to the shipping stand (C).

**NOTE:**

To access the bolts at the lower stand support, the header must be supported on 150 mm (6 in.) blocks, as directed in Step 4, page 9.

2. Remove two bolts (D) securing the right fork channel (B) to the lower brace (E).
3. Repeat the steps above for the left side.




Figure 2.8: Shipping Stands and Lower Brace

4. Remove the lower brace (A).





Figure 2.9: Lower Brace Removal


## UNLOADING HEADER AND FLOAT MODULE

- From the upper brace, remove the two bolts (A). Repeat for the opposite side.



**Figure 2.10: Stand Supports and Upper Brace**

- Remove the right and left fork channels (A).
- Remove the upper brace (B).



**Figure 2.11: Upper Brace and Stand Support**

## UNLOADING HEADER AND FLOAT MODULE

- Remove four bolts (A) and remove shipping stands (B) from the bottom of the float module.




Figure 2.12: View from Below the Header

- Remove the two bolts (A) and loosen two bolts (B) securing the coupler cover (C) to the float module.
- Remove the coupler cover.
- Tighten two bolts (B).





Figure 2.13: Coupler Cover


## UNLOADING HEADER AND FLOAT MODULE

12. **30- to 45-foot headers only:** Remove the four bolts (A) from the shipping stands at both outboard header legs. Remove stands.




**Figure 2.14: Shipping Stands at Outboard Header Legs (Right Side Shown)**

13. Remove reel anti-rotation strap (A) between reel and endsheet.



**Figure 2.15: Reel Anti-Rotation Strap**


14. Loosen three bolts (A) in each endshield guard (B) and remove guards. Hardware can be removed when header endshields are opened.



**Figure 2.16: Endshield Guards**

## UNLOADING HEADER AND FLOAT MODULE

15. **Single Reel Only:** Remove the center shipping support by removing the two bolts (A) at the backtube and the three bolts (B) at the cutterbar.



**Figure 2.17: Single Reel Center Shipping Support**


### 3 Assembling Header and Float Module

Perform all the procedures in this chapter in the order in which they are listed.

#### 3.1 Attaching Reel Lift Cylinders

##### CAUTION


Bolts (A) (with tags) on reel arms keep the reel from sliding forward. Ensure fore-aft cylinders are attached before removing bolts.



**Figure 3.1: Right Reel Arm (Parts Removed for Clarity)**

Top Image - Single Reel

Bottom Image - Double Reel



**Figure 3.2: Left Reel Arm**

## ASSEMBLING HEADER AND FLOAT MODULE

1. Remove two top bolts (A) on outboard reel arm supports. Repeat for opposite side.




Figure 3.3: Outboard Reel Arm Support

2. **Double-reel headers only:** Remove two top bolts (A) on center reel arm to allow the center reel arm to move.




Figure 3.4: Center Reel Arm: Double-Reel Header Only

3. Position sling (A) around the reel tube (B) close to the outboard end of reel and attach sling to a forklift (or equivalent).
4. Remove shipping wire/banding from the reel lift cylinder.




Figure 3.5: Reel Tube

## ASSEMBLING HEADER AND FLOAT MODULE

5. Lift reel and remove pins from the endsheet and the reel arm.
6. Align the reel lift cylinder mounting holes until they line up with the lug on the endsheet and the hole in the reel arm.
7. Secure cylinder to endsheet and reel arm with pins as shown.
  - Insert cotter pin (A) **OUTBOARD** at reel arm
  - Insert cotter pin (B) **INBOARD** at endsheet




Figure 3.6: Reel Lift Cylinder, Reel Arm, and Pins (Right-Hand Shown)

8. At outer arm, move reel safety props (A) to engaged position (B).

**NOTE:**

Step 9, [page 18](#) to Step 16, [page 18](#) apply **ONLY** to double-reel headers; for single-reel headers, go to Step 17, [page 18](#).




Figure 3.7: Reel Safety Props

## ASSEMBLING HEADER AND FLOAT MODULE

9. **Double reel only:** Position sling (A) around the reel tube near the reel center support arm.
10. **Double reel only:** Lift reel to gain access to the center lift cylinder.
11. **Double reel only:** Remove shipping wire and banding from center reel lift cylinder.




Figure 3.8: Lifting the Reel: Double Reel Only

12. **Double reel only:** Remove socket head bolt and nut from cylinder rod end.
13. **Double reel only:** Attach rod end of cylinder to reel arm with socket head bolt and nut (A). Access hardware through holes in reel arm braces.
14. **Double reel only:** Torque bolt and nut (A) to 54–61 N·m (40–45 ft·lbf).
15. **Double reel only:** Remove pin at barrel end of cylinder.
16. **Double reel only:** Adjust reel height so pin can be installed at barrel end of cylinder and mounting structure.




Figure 3.9: Reel Arm Braces

17. Reposition the sling (A) around the reel tube near the opposite outboard reel arm.
18. Remove shipping wire and banding from the reel lift cylinder.




Figure 3.10: Outboard Reel Arm

## ASSEMBLING HEADER AND FLOAT MODULE

19. Lift reel and remove pins from the endsheet and the reel arm.
20. Align the reel lift cylinder mounting holes until they line up with the lug on the endsheet and the hole in the reel arm.
21. Secure cylinder to endsheet and reel arm with pins as shown.
  - Insert cotter pin (A) **OUTBOARD** at reel arm
  - Insert cotter pin (B) **INBOARD** at endsheet




Figure 3.11: Cylinder and Endsheet

22. Move the reel safety props (A) to engaged position (B).





Figure 3.12: Reel Safety Prop


## ASSEMBLING HEADER AND FLOAT MODULE

23. **Double reel only:** Remove the remaining bolt (A), disengage center reel arm shipping support (B) from cutterbar, and remove shipping support.



**Figure 3.13: Center Reel Arm Shipping Support**


24. Remove bolts (A) from reel arm support at endsheet and remove support. Repeat at other side.



**Figure 3.14: Outboard Reel Arm Supports**

## ASSEMBLING HEADER AND FLOAT MODULE


25. Remove brace bolts and tags (A) locking the reel fore-aft position at outer reel arms.



**Figure 3.15: Right Reel Arm**

Top Image - Single Reel


Bottom Image - Double Reel



**Figure 3.16: Left Reel Arm**

## ASSEMBLING HEADER AND FLOAT MODULE

26. **Double reel only:** Remove the remaining three bolts (A) locking the reel fore-aft position at the center reel arm and remove shipping channel (B).




**Figure 3.17: Center Reel Arm Shipping Channel (Double-Reel Header Only)**

### 3.2 Attaching Reel Height Sensor

The reel height sensor linkage was disconnected prior to shipping. Reconnect the sensor using the following procedure:

1. Remove the shipping wire.
2. Check that arm (C) and sensor pointer (D) are configured properly for your combine. Refer to Fig. 3.18: *Reel Height Sensor Configuration*, page 23.




**Figure 3.18: Reel Height Sensor Configuration**

A – CNH Configuration

B – John Deere/Lexion Configuration

## ASSEMBLING HEADER AND FLOAT MODULE

3. Attach the ball joint (A) to the sensor plate (B).
4. Secure the ball joint in place using the provided flange nut.



**Figure 3.19: Reel Height Sensor**

### 3.3 Installing Guards: Single Reel

**Double-Reel Headers:** Proceed to [3.4 Setting up Float Module, page 28](#).

**Single-Reel Headers:** Choose between the following procedures for installing cutterbar components at the center shipping beam location depending on whether the header has formed hold-downs (A) or forged hold-downs (B).




Figure 3.20: Knife Hold-Downs

#### 3.3.1 Installing Formed Hold-Down

1. If installed, position the cutterbar wearplate (A) on the cutterbar and install with two 7/16 in. x 1-1/2 in. long carriage bolts (B).




Figure 3.21: Cutterbar Wearplate

## ASSEMBLING HEADER AND FLOAT MODULE

- Place hold-down (A) on cutterbar as shown and secure with existing nuts (B). Adjuster bolt (C) should NOT require adjusting.

**NOTE:**

Cutterbar wearplates should be installed with special bolts (D) as shown.

- Repeat the previous steps for the second (adjacent) location.
- Torque nuts to 72 N·m (53 ft·lbf).




Figure 3.22: Pointed Guard




Figure 3.23: Stub Guard

### 3.3.2 Forged Hold-Down (Stub Guard Only)

- Position the cutterbar wearplate (A) on the cutterbar and install with two 7/16 in. x 1-1/2 in. long carriage bolts (B).




Figure 3.24: Cutterbar Wearplates

## ASSEMBLING HEADER AND FLOAT MODULE

2. Place adjuster plate (D) and hold-down (A) on cutterbar as shown and secure with 7/16 in. hex nuts (B). Adjuster bolt (C) should NOT require adjusting.
3. Repeat the previous steps for the second (adjacent) location.
4. Torque nuts to 72 N·m (53 ft·lbf).




Figure 3.25: Stub Guard

## 3.4 Setting up Float Module

Complete the following procedures in the order in which they are listed:

- [3.4.1 Installing Filler Cap, page 28](#)
- [3.4.2 Configuring Auger, page 30](#)
- [3.4.3 Removing Stripper Bars, page 30](#)
- [3.4.4 Replacing CR Feeder Deflectors, page 30](#)

### 3.4.1 Installing Filler Cap

1. Remove filler cap from bag (A).




Figure 3.26: Hardware Bag

### CAUTION

Fluid may be under pressure. Allow pressure to equalize by loosening screws and lifting the shipping cover slightly.

2. Remove yellow shipping cover (A) from float module frame. Discard cover. Keep screws.



Figure 3.27: Yellow Shipping Cover

## ASSEMBLING HEADER AND FLOAT MODULE

3. Remove top gasket (A) for use in the next step.

**NOTE:**

There are two gaskets—one on each side of the filler strainer flange.




Figure 3.28: Top Gasket

4. Place gasket (A) (removed from the top of the filler strainer) onto the filler cap neck (B) and align holes.
5. Install #10-32 screws on filler cap neck (B) pressing screws through the gasket (A).
6. Apply Loctite® #565 (or equivalent) to screws.




Figure 3.29: Filler Cap Neck

7. Place filler cap neck (A) (complete with screws) over opening and ensure the machine screws are aligned with the threaded holes.
8. Carefully thread in the machine screws using a cross pattern (as shown) in order to prevent cross threading of tapped holes.
9. Repeat pattern to gradually tighten screws to 3.5 N·m (31 in·lbf).




Figure 3.30: Screw Hole Locations

## ASSEMBLING HEADER AND FLOAT MODULE

10. Install filler cap (A).




Figure 3.31: Filler Cap

### 3.4.2 Configuring Auger

The auger has been configured with the correct amount of flighting and fingers to perform well in most crop conditions. Options exist to further optimize the auger for specific combines and crop conditions. Refer to Float Module Feed Auger Configurations in the header operator's manual for more information about conversions.

### 3.4.3 Removing Stripper Bars

Stripper bar kits may have been supplied with your header to improve feeding in certain crops such as rice. They are **NOT** recommended for cereal crops.

**NOTE:**

New Holland CR960, 9060, 970, 9070, and 9080 combines are not equipped with stripper bars. The following procedure does NOT apply to those models.

If necessary, remove auger stripper bars as follows:

1. Remove four bolts (A) and nuts securing bars (B) to float module frame, and remove bars.
2. Repeat for opposite set of stripper bars.




Figure 3.32: Auger Stripper Bar

### 3.4.4 Replacing CR Feeder Deflectors

If the header is configured for a New Holland CR 960, 9070, or 9080 combine, the float module has a factory installed feeder deflector kit to improve feeding into the feeder house. The kit can be replaced if necessary.

**⚠ DANGER**

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under machine for any reason.

## ASSEMBLING HEADER AND FLOAT MODULE


The D1 Series/FM100 combine completion package for the New Holland models includes both a short feeder kit (installed at the factory) and a long feeder kit for narrow feeder house combines. Refer to Table 3.1 *FM100 Feeder Kits for CR Model Combines*, page 31.

**Table 3.1 FM100 Feeder Kits for CR Model Combines**


Combine Model	Feeder House Size	Feeder Kit Size
CR970, 9070, 9080	Wide	Short: 200 mm
CR960, 9060, 940, 9040	Narrow	Long: 325 mm

If required, replace the feeder deflectors as follows:

1. Determine the position of existing deflector (A) by measuring the gap (X) between the deflector's forward edge and the pan. Record this measurement.
2. Remove the two bolts and nuts (B) securing the deflector (A) to the float module frame and remove deflector.
3. Position the replacement deflector and reinstall bolts and nuts (B). Do not tighten bolts.



**Figure 3.33: Side View of Deflector**



**Figure 3.34: Replacement Deflector: Left-Hand Shown – Right-Hand Opposite**

## ASSEMBLING HEADER AND FLOAT MODULE

4. Set the gap (X) to the dimension recorded in Step 1., [page 31](#) and tighten the nuts.
5. Repeat for the opposite deflector.

### CAUTION


**Never start or move the machine until you are sure all bystanders have cleared the area.**

6. Attach the header to a combine and fully extend center-link.
7. Turn off the combine and remove the key from the ignition.
8. Recheck the gap (X) between the deflector (A) and the pan.

#### NOTE:

The minimum gap, when attached to the combine, should be 19–25 mm (6/8–1 in.).

9. If necessary, detach header from the combine and adjust the deflector to achieve the minimum gap.



**Figure 3.35: Side View of Deflector**

## 4 Attaching Header to Combine

The procedures for attaching the header to a combine vary depending on the combine model. Refer to the following table for the appropriate procedure:

**Table 4.1 Combine Model Header Attachment Procedures**

Combine	Refer to
AGCO Gleaner R and S Series; Challenger 660, 670, 680B, 540C, and 560C; Massey 9690, 9790, 9895, 9520, 9540, and 9560	<a href="#">4.1 AGCO (Challenger, Gleaner, and Massey Ferguson) Combines, page 33</a>
Case IH 7010, 8010, 7120, 8120, 9120, 5088, 6088, 7088, 5130, 6130, 7130, 7230, 8230, and 9230	<a href="#">4.2 Case IH Combines, page 41</a>
John Deere 60, 70, S, and T Series	<a href="#">4.3 John Deere Combines, page 47</a>
Lexion 500, 600, and 700 (R Series)	<a href="#">4.4 Lexion Combines, page 59</a>
New Holland CR and CX	<a href="#">4.5 New Holland Combines, page 76</a>

### IMPORTANT:

Ensure applicable functions (Automatic Header Height Control [AHHC], Draper Header Option, Hydraulic Center-Link Option, Hydraulic Reel Drive, etc.) are enabled on the combine and in the combine computer. Failure to do so may result in improper header operation.

## 4.1 AGCO (Challenger, Gleaner, and Massey Ferguson) Combines

### 4.1.1 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness

Gleaner combines prior to 2014 are not equipped to accommodate hydraulic reel fore-aft and header tilt options. The following additional items are required and not supplied by MacDon:

- Valve (A) (AGCO #71389745)
- Hoses
- Electrical components
- Couplers


### NOTE:

Model year 2014 and later Gleaner combines will have the above parts factory-installed.

To enable the reel fore-aft and header tilt options, install the switch and harness as follows:

### IMPORTANT:

To prevent possible damage to electronic components, disconnect the positive cable from the combine battery before connecting harness to combine connectors.



**Figure 4.1: Converted Gleaner R72 Shown**

## ATTACHING HEADER TO COMBINE

1. Before attaching any cable ties, route switch harness (A) from the front of the feeder house to the power connection point in the cab. Ensure the harness is long enough to reach the wiring at the selector valve with the header tilted forward, and that the feeder house can be fully lowered with adequate slack in the harness.




Figure 4.2: Switch Harness Routing

2. Use the cable ties provided to fasten the switch harness (A) to the main harness on the left side of the feeder house and under the cab floor at location (B).

### IMPORTANT:

To prevent damage to harness, fully lower feeder house and ensure there is adequate slack before attaching cable ties (B) to the harness.




Figure 4.3: Left-Hand Side of Feeder House

3. Route the switch harness (A) at the rear of the feeder house up to the underside of the cab floor at (B).
4. Use the cable ties provided to fasten the switch harness (A) to the main harness under cab floor at (B).




Figure 4.4: Harness under Right-Hand Side of Cab Floor

## ATTACHING HEADER TO COMBINE

5. Route the switch harness (A) under the cab, through cab floor, and into console (B) at the foam seal (C).




Figure 4.5: Harness through Cab Floor

6. Remove the console cover (A) as shown.
7. Connect the switch harness to the power supply inside the console at (B).
  - The red wire from the inline fuse goes to the switched power supply (B).
  - The double black wire goes to ground.

### IMPORTANT:

Connecting the switch harness to an unswitched power supply or cigarette lighter will supply constant power to the header tilt side of the solenoid valve and drain the combine battery during extended shutdown periods.

8. Route switch harness through grommet (C), and replace cover (A).




Figure 4.6: Switched Power Supply

## ATTACHING HEADER TO COMBINE

9. Mount switch plate onto console (A) in a comfortable position.
10. Connect harness to switch with red wire to center terminal (B), and white wire to either outer terminal (C).
11. Reconnect the battery cable.
12. Operate the switch to select either REEL FORE-AFT or HEADER TILT function.




Figure 4.7: Switch and Console

### 4.1.2 Attaching Header to a Challenger, Gleaner, or Massey Ferguson Combine

#### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. Use the lock handle (B) to retract the lugs (A) at the base of the feeder house.




Figure 4.8: AGCO Group Feeder House

## ATTACHING HEADER TO COMBINE

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

2. Start the engine and slowly approach the header until the feeder house is directly under the float module top cross member (A) and the alignment pins (C) on the feeder house (shown in the image below) are aligned with the holes (B) in the float module frame.

### NOTE:

Your combine feeder house may not be exactly as shown.

3. Raise the feeder house slightly to lift the header, ensuring the feeder house saddle (A) is properly engaged in the float module frame.
4. Stop the engine and remove the key from the ignition.




Figure 4.9: Float Module




Figure 4.10: AGCO Group Alignment Pins



Figure 4.11: Feeder House and Float Module

## ATTACHING HEADER TO COMBINE

- Use the lock handle (B) to engage lugs (A) with the float module.




Figure 4.12: AGCO Group Feeder House

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

- Start the engine and lower the header.
- Stop the engine and remove the key from the ignition.

#### NOTE:

The FM100 Float Module is equipped with a multicoupler that connects to the combine. If your combine is equipped with individual connectors, a multicoupler kit (single-point connector) must be installed. Refer to Table 4.2 *Multicoupler Kits*, page 38 for a list of kits and installation instructions that are available through your combine Dealer.

Table 4.2 Multicoupler Kits

Combine	Kit Number
Challenger	71530662
Gleaner R/S Series	71414706
Massey Ferguson	71411594

- Raise the handle (A) to release the multicoupler (B) from the float module.




Figure 4.13: Float Module Multicoupler

## ATTACHING HEADER TO COMBINE

9. Push the handle (A) on the combine to the fully open position.
10. Clean the mating surfaces of the multicoupler (B) and receptacle if necessary.




Figure 4.14: Combine Receptacle

11. Position the multicoupler (A) onto the combine receptacle, and pull the handle (B) to fully engage the multicoupler into the receptacle.
12. Connect the reel fore-aft/header tilt selector harness (C) to the combine harness (D).




Figure 4.15: Multicoupler

13. Pull collar (A) back to release driveline (B) from support bracket (C). Remove the driveline from support bracket.




Figure 4.16: Driveline

## ATTACHING HEADER TO COMBINE

14. Pull back the collar (A) on the end of the driveline, and push the driveline onto the combine output shaft (B) until the collar locks.




Figure 4.17: Driveline

15. Proceed to [4.6.1 Attaching Cam Arms, page 81](#).


## 4.2 Case IH Combines

### 4.2.1 Attaching Header to Case IH Combine

#### DANGER


To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. On the upper left-hand side of the combine float module, remove nut (A) and flip lever (B) horizontally.



**Figure 4.18: Combine Float Module Upper Left-Hand Side**


2. Position lever (A) onto stud (B).



**Figure 4.19: Combine Float Module Upper Left-Hand Side**


## ATTACHING HEADER TO COMBINE

- Place spring arm (C) into hook on lever (B) to preload it, and tighten nut (A) with washer onto the combine float module.



**Figure 4.20: Combine Float Module Left-Hand Side**

- On the combine, ensure the lock handle (A) is positioned so the hooks (B) can engage the float module.




**Figure 4.21: Feeder House Locks**

### CAUTION

**Never start or move the machine until you are sure all bystanders have cleared the area.**

- Start the engine and slowly drive the combine up to the header until the feeder house saddle (A) is directly under the float module top cross member (B).
- Raise the feeder house slightly to lift the header, ensuring the feeder saddle is properly engaged in the float module frame.
- Stop the engine and remove the key from the ignition.



**Figure 4.22: Combine and Float Module**

## ATTACHING HEADER TO COMBINE

8. On the left side of the feeder house, lift lever (A) on the float module and push handle (B) on the combine to engage locks (C) on both sides of the feeder house.
9. Push down on the lever (A) so the slot in the lever engages the handle and locks the handle in place.
10. If lock (C) does not fully engage the pin on the float module, loosen bolts (D) and adjust lock. Retighten bolts.




Figure 4.23: Combine and Float Module

11. Open the cover on the receptacle (A) located on the left side of the float module.
12. Press the lock button (B) and pull the handle (C) to the fully open position.
13. Clean the receptacle mating surfaces.




Figure 4.24: Float Module Receptacle

14. Remove the hydraulic quick coupler (A) from the combine and clean the mating surfaces.



Figure 4.25: Combine Connectors

## ATTACHING HEADER TO COMBINE

15. Position the coupler onto the coupler receptacle (A) and push the handle (B) (not shown) to engage the multicoupler pins into the receptacle.
16. Push the handle (B) to the closed position until the lock button (C) snaps out.




Figure 4.26: Hydraulic Connection

17. Remove the cover from the electrical receptacle (A). Ensure the receptacle is clean and has no signs of damage.




Figure 4.27: Electrical Receptacle

18. Remove the electrical connector (A) from the storage cup on the combine and route it to the float module receptacle.



Figure 4.28: Combine Connectors

## ATTACHING HEADER TO COMBINE

- Align the lugs on the connector (A) with the slots in the receptacle (B), push the connector onto the receptacle, and turn the collar on the connector to lock it in place.




Figure 4.29: Electrical Connection

- Pull collar (A) back to release driveline (B) from support bracket (C). Remove the driveline from support bracket.




Figure 4.30: Driveline

- Pull back the collar (A) on the end of the driveline and push the driveline onto the combine output shaft (B) until the collar locks.





Figure 4.31: Combine Output Shaft

## ATTACHING HEADER TO COMBINE

22. Disengage the float locks by pulling each float lock handle (A) away from the float module and setting it in the unlocked position (B).
23. Proceed to [4.6.1 Attaching Cam Arms, page 81](#).



**Figure 4.32: Float Lock Handles - RH Shown in Detail, LH Opposite**

## 4.3 John Deere Combines

The D1 Series Draper Header is compatible with John Deere 60, 70, S, and T Series combines.

### 4.3.1 Installing Reel Fore-Aft / Header Tilt Switch: S and T Series Combines

The reel fore-aft/header tilt switch allows the combine Operator to select either reel FORE-AFT or HEADER TILT mode.

#### WARNING

**To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under machine for any reason.**

This procedure is applicable to John Deere S and T Series combines. For John Deere 60 or 70 Series combines, refer to [4.3.2 Installing Reel Fore-Aft / Header Tilt Switch: 60 and 70 Series Combines, page 51](#).

#### IMPORTANT:

To prevent damage to electronic components, disconnect the positive cable from the combine battery and turn the battery disconnect switch to the OFF position before connecting the reel fore-aft/header tilt harness to the combine's auxiliary power connectors.

Prepare the combine cab for switch and harness installation as follows:

1. Open storage compartment on the console.
2. Remove the two screws (A) attaching compartment cover (B) to console and remove cover.
3. Lift floor mat (A) at forward right corner to access knockout (B).
4. Remove the knockout (B).




Figure 4.33: Storage Compartment and Cover




Figure 4.34: Floor Mat at Forward Right Corner and Knockout

## ATTACHING HEADER TO COMBINE

5. Retrieve switch (A), harness (B), and support (C) provided with kit.
6. Install switch (A) into support (C) from the top. Ensure lugs on underside of support have secured the switch.




Figure 4.35: Switch and Harness

7. Connect the switch end of harness (A) to switch (B) with one of the wires to center terminal and the other wire to either outer terminal. The color of the wires does not matter; ensure one wire terminates at the center terminal.





Figure 4.36: Switch End of Harness and Switch


## ATTACHING HEADER TO COMBINE

8. Position support (C) onto console and align the holes in support with holes in the console.
9. Reinstall cover (B) with existing screws (A).




**Figure 4.37: Support Position on Console**

10. Close cover and ensure that switch (A) and support (B) are secure.



**Figure 4.38: Secured Switch**

11. Connect the feed end of harness (A) to the auxiliary power outlet strip on the right side of the cab floor.



**Figure 4.39: Feed End of Harness**

## ATTACHING HEADER TO COMBINE

12. Connect the harness end to one of the auxiliary power supply points (D).
13. Connect the wire (from the in-line fuse) to the switched power supply (C).
14. Connect the other wire to ground (B).

### IMPORTANT:

Connecting the switch harness to an unswitched power supply or cigarette lighter will supply constant power to the header tilt side of the solenoid valve and drain the combine battery during extended shutdown periods.

15. Tape unused wire jumpers to harness.




Figure 4.40: Combine Auxiliary Power Supply

16. Route plug end of harness (A) through hole (B) in cab floor, and feed the entire length outside the cab. Leave some slack in the cab to allow for console adjustment.
17. Reinstall floor mat.




Figure 4.41: Plug End of Harness

## ATTACHING HEADER TO COMBINE

18. Route harness (A) under the cab (along the existing hoses) to the left side of the feeder house, under hose shield (C), and to the multicoupler (B).
19. Secure the harness to hoses with cable ties as required.




Figure 4.42: Harness and Feeder House Multicoupler

### 4.3.2 Installing Reel Fore-Aft / Header Tilt Switch: 60 and 70 Series Combines

The reel fore-aft/header tilt switch allows the combine Operator to select either reel FORE-AFT or HEADER TILT mode.

#### **WARNING**

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under machine for any reason.

This procedure applies to John Deere 60 and 70 Series combines. For John Deere S and T Series combines, refer to [4.3.1 Installing Reel Fore-Aft / Header Tilt Switch: S and T Series Combines, page 47](#).

#### **IMPORTANT:**

To prevent damage to electronic components, disconnect the positive cable from the combine battery and turn the battery disconnect switch to the OFF position before connecting the reel fore-aft/header tilt harness to the combine's auxiliary power connectors.

1. To ensure the switch harness will attach to selector valve wiring harness (with header tilted forward) and that the feeder house can be fully lowered with adequate slack in the harness, lay the switch harness along the route from front of the feeder house to the auxiliary power supply in the cab.
2. Route the switch harness (A) through an existing grommet (B) on the combine's electrical plate (located at the rear of the right-hand side window).

#### **NOTE:**

To simplify feeding the harness through the grommet, wrap the switch and power plugs with electrical tape.




Figure 4.43: Switch Harness Routing

## ATTACHING HEADER TO COMBINE

3. Retrieve switch (A) and support (C) provided with kit.
4. Install switch (A) into support (C) from the top. Ensure lugs on underside of support have secured the switch.

**NOTE:**

Image at right shows switch (A) connected to the harness (B).




Figure 4.44: Switch and Harness

5. Mount switch plate (A) between the armrest cover hinge and the armrest using existing screws (B).




Figure 4.45: Switch Plate Mounting

## ATTACHING HEADER TO COMBINE

6. Connect the switch end of harness (A) to switch (B) with one of the wires to center terminal and the other wire to either outer terminal.

**NOTE:**

The color of the wires does not matter; ensure one wire terminates at the center terminal.




Figure 4.46: Switch End of Harness and Switch

7. Connect the switch harness to the auxiliary power supply (D). Connect the wire with the in-line fuse to the switched power supply (C) and the second wire to the ground (B).

**IMPORTANT:**

Connecting the switch harness to an unswitched power supply or cigarette lighter will supply constant power to the header tilt side of the solenoid valve and drain the combine battery during extended shutdown periods.

8. Tape the unused wire jumpers to the harness.




Figure 4.47: Auxiliary Power Supply

## ATTACHING HEADER TO COMBINE

9. Route the switch harness (A) across the underside of the cab, alongside an existing harness, to the left side of the feeder house.

### IMPORTANT:

To prevent damage to harness, ensure adequate slack by lowering the feeder house fully before securing harness with cable ties.




Figure 4.48: Switch Harness Routing

10. Secure the switch harness (A) at the rear of the feeder house with cable tie.



Figure 4.49: Switch Harness Routing

11. Route the switch harness (A) through the welded hose guide on feeder house.




Figure 4.50: 60/70 Series Harness Routing

## ATTACHING HEADER TO COMBINE

- Secure the switch harness (A) at multicoupler with a cable tie. Leave 100 cm (40 in.) extending past location (B).




Figure 4.51: Switch Harness Routing

### 4.3.3 Attaching Header to John Deere Combine

#### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

- Push the handle (A) on the combine multicoupler receptacle towards the feeder house to retract the pins (B) at the bottom corners of the feeder house. Clean the receptacle.

#### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

- Start the engine and slowly drive the combine up to the header until the feeder house saddle (C) is directly under the float module top cross member (D).
- Raise the feeder house slightly to lift the header ensuring the feeder house saddle is properly engaged in the float module frame.
- Stop the engine and remove the key from the ignition.




Figure 4.52: Combine and Float Module

## ATTACHING HEADER TO COMBINE

5. Pull the handle (A) on the float module to release the multicoupler (B) from the storage position. Remove the multicoupler, and push the handle back into the float module to store.




Figure 4.53: Multicoupler Storage

6. Position the multicoupler (A) onto the receptacle, and pull the handle (B) to engage the lugs on the multicoupler into the handle.
7. Pull the handle (B) to a horizontal position and ensure the multicoupler (A) is fully engaged into the receptacle.




Figure 4.54: Multicoupler

8. Ensure that both feeder house pins (C) are fully engaged into the float module brackets.

### NOTE:

If the pins (C) do not fully engage the float module brackets, loosen the bolts (D) and adjust the bracket as required.

9. Tighten bolts (D).





Figure 4.55: Feeder House Pin


## ATTACHING HEADER TO COMBINE

- Slide the latch (A) to lock the handle (B) in position and secure with the lynch pin (C).
- If the float module is equipped with the reel fore-aft/header tilt selector, connect the harness (D) to the combine connector (E).




**Figure 4.56: Multicoupler**

- Pull collar (A) back to release driveline (B) from support bracket (C). Remove the driveline from support bracket.



**Figure 4.57: Driveline**


- Pull back the collar (A) on the end of the driveline, and push the driveline onto the combine output shaft (B) until the collar locks.



**Figure 4.58: Driveline**

## ATTACHING HEADER TO COMBINE

14. Disengage the float locks by pulling each float lock handle (A) away from the float module and setting it in the unlocked position (B).
15. Proceed to [4.6.1 Attaching Cam Arms, page 81](#).



**Figure 4.59: Float Lock Handles - RH Shown in Detail, LH Opposite**

## 4.4 Lexion Combines

The D1 Series Draper Header is compatible with Lexion 500, 600, and 700 Series combines.

### 4.4.1 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness: 500 Series

1. Remove storage tray (A) from console.



Figure 4.60: Console Tray

2. Remove 13 mm hex nut (A) and washer from under combine monitor at front of console as shown.




Figure 4.61: Combine Monitor

## ATTACHING HEADER TO COMBINE

3. Tilt console (A) back.




Figure 4.62: Tilted Console

4. Remove plug (A) from cab floor under console. Install adapter connector through hole and route harness through hole.
5. Cut a slit in the rubber floor plug (A) and slide plug over wiring harness.

**NOTE:**

Maintain some wire slack to prevent damage to harness.




Figure 4.63: Harness through Hole in Floor

## ATTACHING HEADER TO COMBINE

6. Remove five screws (A) to access wiring connections underneath console.




Figure 4.64: Five Screws in Console


7. Remove switch plug from top side of console at location shown (A) and push switch connector through the backside of console.



Figure 4.65: Switch Plug in Console

## ATTACHING HEADER TO COMBINE

8. Connect switch (A) to the switch harness. Connect the red wire to the center terminal, and the white wire to either outer terminal.




**Figure 4.66: Back of Console (Rocker Switch [A] Shown before Placement)**

9. Snap switch (A) into place.



**Figure 4.67: Rocker Switch in Place**

10. Attach switch harness to existing wires (A) using a cable tie.



**Figure 4.68: Cable Ties, Harness, and Existing Wires**

## ATTACHING HEADER TO COMBINE

11. Reinstall plug (A) in floor.
12. Return switch console to its original position and tilt console back. Replace the five screws that were removed in Step 6., [page 61](#).




Figure 4.69: Plug in Floor

### 13. For two-connector hookups:

- a. Remove the brown wire (A) from the power source under the console and replace it with the black wire (B).
- b. Remove the black wire from the power source and replace it with the red wire (C).
- c. Attach the brown wire (removed from the power source) to the other red wire coming from the harness.
- d. Attach the black wire (removed from the power source) to the other black wire coming from the harness.




Figure 4.70: Two-Connector Hookup: Switch Harness Installed


## ATTACHING HEADER TO COMBINE

### 14. For single-connector hookups:

**NOTE:**

Remove the insulation from the male blades on the wire harness to allow the blades to attach to plug (A).


- a. Remove the white plug (A) with the brown and black wire from the power source under the console.
- b. Replace the white plug with the black wire (B) from the switch harness on the top terminal and the red wire (C) on the bottom terminal.
- c. Attach the remaining wires coming from harness to the white plug (D). Ensure the wires are attached black to black, and brown to red.



**Figure 4.71: Single-Connector Hookup**

Top - Before Connecting the Switch Harness  
Bottom - After Connecting the Switch Harness


15. Return console to its original position and install the washer and 13 mm hex nut (A) removed in Step 2., [page 59](#).



**Figure 4.72: Combine Monitor in Original Position**


## ATTACHING HEADER TO COMBINE

16. Route wiring harness (A) underneath cab floor. Place harness in steel tray (B) along underside of cab floor to prevent it from being damaged.



**Figure 4.73: Harness underneath Cab Floor**

17. Route wiring harness from the left corner of steel tray to conduit (A), between cab floor and frame as shown at location (B), and along conduit (A) to the multicoupler.




**Figure 4.74: Harness between Steel Tray and Conduit**

A - Conduit  
C - Cable Tie

B - Routing Location

18. Secure wiring harness to conduit (B) (starting from the multicoupler end) using cable ties at location (A).



**Figure 4.75: Cable Ties, Harness, and Conduit**

#### 4.4.2 Installing Reel Fore-Aft / Header Tilt Selector Switch and Harness: 700 Series

1. Remove two screws (A) from panel, and remove panel to access compartment.
2. Pull up on tab (B) to unlatch console.
3. Rotate the console upwards to expose the underside and make it easier to insert the tilt selector switch harness.



Figure 4.76: Console in Cab

4. Insert wire through bottom of console alongside wire (A) that goes to the CEBIS monitor.




Figure 4.77: Bottom of Console

5. Remove blank cap from operator's panel at location (A).
6. Run wire from the panel that was previously removed through the opening and connect the switch (not shown) to harness (B). The red wire is connected to center terminal, and the white wire is connected to either outer terminal.
7. Snap switch into place.





Figure 4.78: Switch and Console

## ATTACHING HEADER TO COMBINE

8. Secure switch (A) into console and screw down the operator's panel.
9. Pull back the slack on the switch harness and use cable ties to secure it to the existing wire harness running to the CEBIS monitor (refer to Step 4., page 66).


**NOTE:**

If autosteer is installed, select the blank plug next to (A).




**Figure 4.79: Switch in Console**

10. Locate terminal compartment (A) on the floor at the right-hand side of the cab, and remove lid to access the 12 volt switched power.



**Figure 4.80: Lid of Terminal Compartment**

11. Locate the single-wire harness (A) that provides switch power.
  - a. Remove the insulation from the two male blades on the switch harness.
  - b. Connect the red wire in plug (B) to the brown wire in plug (C).
  - c. Connect the black wire in plug (C) to the black wire in plug (A).



**Figure 4.81: Wire Harness**

## ATTACHING HEADER TO COMBINE

12. Make an exit hole for the switch harness in one of the blank covers to the left side of the box at location (A).
13. Route the two-prong wire (black/white connector) of the switch harness through the hole.




Figure 4.82: Exit Hole and Switch Harness

14. Route switch harness (A) under the cab floor alongside the existing harnesses. Do NOT secure harness with cable ties until routing is complete.




Figure 4.83: Harness under Cab Floor (500 Series Lexion Shown)

15. Route the wiring harness from bottom left corner of cab to the conduit (A), between cab floor and frame as shown at location (B), and along conduit (A) to multicoupler.





Figure 4.84: Harness through Conduit (500 Series Lexion Shown)

A - Conduit  
C - Cable Tie

B - Routing Location


## ATTACHING HEADER TO COMBINE

16. Secure wiring harness to conduit (B) (starting from the multicoupler end) using cable ties at location (A).



**Figure 4.85: Cable Ties, Harness, and Conduit (500 Series Lexion Shown)**

17. Push excess harness back into terminal box once harness is secured with cable ties, and use cable ties to attach MacDon harness to existing harness (A) running to the console. This will prevent the harness from getting tangled when seat or console are moved.



**Figure 4.86: Existing Harness and MacDon Harness**

### 4.4.3 Attaching Header to Lexion Combine

#### **DANGER**

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

## ATTACHING HEADER TO COMBINE

1. Move the handle (A) on the FM100 Float Module into the raised position, and ensure the pins (B) at the bottom corners of the float module are retracted.




Figure 4.87: Pins Retracted

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

2. Start the engine and slowly drive the combine up to the header until the feeder house saddle (A) is directly under the float module top cross member (B).
3. Raise the feeder house slightly to lift the header ensuring the feeder saddle is properly engaged in the float module frame.
4. Stop the engine and remove the key from the ignition.
5. Remove the locking pin (B) from the float module pin (A).




Figure 4.88: Header on Combine




Figure 4.89: Locking Pins

## ATTACHING HEADER TO COMBINE


6. Lower the handle (A) to engage the float module pins (B) into the feeder house. Reinsert the locking pin (C) and secure with the hairpin.

7. Remove the blocks from under the cutterbar.

### CAUTION


**Never start or move the machine until you are sure all bystanders have cleared the area.**

8. Start the engine and lower the header.
9. Stop the engine and remove the key from the ignition.



**Figure 4.90: Engaging Pins**

10. Unscrew the knob (A) on the combine coupler (B) to release the coupler from the combine receptacle and clean the coupler.



**Figure 4.91: Combine Coupler**

## ATTACHING HEADER TO COMBINE

11. Remove float module receptacle cover (A).




Figure 4.92: Receptacle Cover

12. Place the float module receptacle cover (A) onto the combine receptacle.





Figure 4.93: Receptacle Cover


## ATTACHING HEADER TO COMBINE

13. Clean the mating surface of the coupler (A) and position onto the float module receptacle (B).
14. Turn the knob (C) to secure the coupler to the receptacle.



**Figure 4.94: Coupler**


15. Connect the combine harness to the reel fore-aft/header tilt receptacle (A).



**Figure 4.95: Coupler**


## ATTACHING HEADER TO COMBINE

16. Pull collar (A) back to release driveline (B) from support bracket (C). Remove the driveline from support bracket.



**Figure 4.96: Driveline**


17. Attach the driveline (A) to the combine output shaft.



**Figure 4.97: Driveline and Output Shaft**

## ATTACHING HEADER TO COMBINE

18. Disengage both header float locks by pulling each float lock handle (A) away from the float module and setting it in the unlocked position (B).
19. Proceed to [4.6.1 Attaching Cam Arms, page 81](#).



**Figure 4.98: Float Lock Handles - RH Shown in Detail, LH Opposite**

## 4.5 New Holland Combines

The D1 Series Draper Header is compatible with the following New Holland combines:


Series	Combine Model
CR	920, 940, 960, 970, 980
	9020, 9040, 9060, 9065, 9070, 9080
	6090, 7090, 8080, 8090, 9090
	6.80, 6.90, 7.90, 8.90, 9.90, 10.90
CX	840, 860, 870, 880
	8070, 8080, 8090
	8080 Elevation, 8090 Elevation

### 4.5.1 Attaching Header to New Holland CR/CX Combine

#### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.


1. On the upper left-hand side of the combine float module, remove nut (A) and flip lever (B) horizontally.



**Figure 4.99: Combine Float Module Upper Left-Hand Side**


## ATTACHING HEADER TO COMBINE

2. Position lever (A) onto stud (B).




**Figure 4.100: Combine Float Module Upper Left-Hand Side**

3. Place spring arm (C) into hook on lever (B) to preload it, and tighten nut (A) with washer onto the combine float module.



**Figure 4.101: Combine Float Module Upper Left-Hand Side**

4. Ensure the handle (A) is positioned so the hooks (B) can engage the float module.



**Figure 4.102: Feeder House Locks**

## ATTACHING HEADER TO COMBINE

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

5. Start the engine and slowly drive the combine up to the float module until the feeder house saddle (A) is directly under the float module top cross member (B).
6. Raise the feeder house slightly to lift the header ensuring the feeder saddle is properly engaged in the float module frame.
7. Stop the engine and remove the key from the ignition.




Figure 4.103: Header on Combine

8. Lift lever (A) on the float module on the left side of the feeder house, and push the handle (B) on the combine to engage the locks (C) on both sides of the feeder house.
9. Push down on the lever (A) so the slot in the lever engages the handle and locks the handle in place.
10. If the lock does not fully engage the pin on the float module when the lever (A) and handle (B) are engaged, loosen bolts (E) and adjust the lock (C). Retighten bolts.




Figure 4.104: Feeder House Locks

11. Open the cover on the receptacle (A) located on the left side of the float module.
12. Push in the lock button (B) and pull the handle (C) to the full open position.
13. Clean the receptacle mating surfaces.




Figure 4.105: Float Module Receptacle

## ATTACHING HEADER TO COMBINE

14. Remove the hydraulic quick coupler (A) from the storage plate on the combine, and clean the mating surface of the coupler.




Figure 4.106: Combine Coupler

15. Position the coupler (A) onto the float module receptacle, and push the handle (B) to engage the pins into the receptacle.
16. Push the handle (B) to closed position until the lock button (C) snaps out.
17. Remove the cover on the float module electrical receptacle.
18. Remove the connector (D) from the combine.
19. Align the lugs on the connector (D) with the slots in the float module receptacle, and push the connector onto the receptacle. Turn the collar on the connector to lock it in place.
20. Pull collar (A) back to release driveline (B) from support bracket (C). Remove the driveline from support bracket.




Figure 4.107: Connections




Figure 4.108: Driveline

## ATTACHING HEADER TO COMBINE

21. Pull back the collar on the end of the driveline, and push the driveline onto the combine output shaft (A) until the collar locks.




Figure 4.109: Driveline and Output Shaft

22. Disengage the float locks by pulling each float lock handle (A) away from the float module and setting it in the unlocked position (B).
23. Proceed to [4.6.1 Attaching Cam Arms, page 81](#).




Figure 4.110: Float Lock Handles - RH Shown in Detail, LH Opposite

## 4.6 Completing the Header Assembly

### 4.6.1 Attaching Cam Arms

To attach the reel cam arms, follow these steps:

1. Rotate the reel manually until the tine bars with disconnected cam links are accessible.
2. Remove shipping wire (A) (if not already removed).




Figure 4.111: Disconnected Cam Links and Shipping Wire

3. Remove bag of hardware (A) from tine bar. It contains hardware for cam links and endshields.




Figure 4.112: Hardware Bag Right-Hand Reel

4. Rotate tine bar crank (A) and position link (B) so attachment holes in bar crank are aligned with hole in link.
5. Install bolt (C) in link and position shim (D) on bolt so that shim is between link and tine bar crank.

**NOTE:**

Bolts are pre-coated with Loctite®, so no further locking method is required.

6. Realign link (B) and tine bar crank (A) and thread in bolt (C).
7. Repeat for remaining tine bars and torque bolts to 165 N·m (120 ft·lbf).




Figure 4.113: Bar Crank Attachment Holes and Link Alignment

## ATTACHING HEADER TO COMBINE

### 4.6.2 Repositioning Gearbox

To reposition the gearbox, follow these steps:

1. Remove shipping wire and wrapping on brace (A). Swing brace clear of gearbox.
2. Loosen nut (A) and move bolt out of shipping position slot.
3. Rotate gearbox and insert bolt into working position slot (A). Tighten nut.




Figure 4.114: Shipping Wire and Brace




Figure 4.115: Shipping Position




Figure 4.116: Working Position

## ATTACHING HEADER TO COMBINE

4. Remove bolt and nut from bracket on gearbox.
5. Position brace (A) inside bracket, and reinstall bolt (B) and nut.




Figure 4.117: Brace Position




Figure 4.118: Brace Position

### 4.6.3 Removing Shipping Supports

The removable supports are painted yellow. Refer to illustrations and remove the remaining supports as follows:

**NOTE:**

Unless otherwise specified, discard supports as well as all shipping material and hardware.

1. Remove two bolts (A) and remove strap (B) from both sides of center frame.

**NOTE:**

If strap is difficult to remove, lift on one end of header to release the load on the strap so that bolts can be removed.




Figure 4.119: Strap on Center Frame

## ATTACHING HEADER TO COMBINE

2. Remove lynch pin (A), nut and bolt (B), and remove shipping brace (C).
3. Reinstall lynch pin (A).




Figure 4.120: Lynch Pin, Hardware, and Shipping Brace

### 4.6.4 Positioning Transport Lights

Transport lights are located on each of the outboard reel arms.

1. Position lights (A) perpendicular to header.




Figure 4.121: Transport Light Perpendicular to Header

### 4.6.5 Crop Dividers

Crop dividers are used to help divide the crop when harvesting. They are removable to allow installation of vertical knives and to decrease transport width.

#### *Removing Crop Dividers from Storage*

Crop dividers are shipped attached to the inboard side of the endsheets. To remove the crop dividers, follow these steps:

1. Support the crop divider and remove the shipping wire at the front end (A).
2. Remove bolt (B).
3. Remove the bolt with washer (C) and retain for installation.




Figure 4.122: Crop Divider Stored on Endsheet

#### *Opening Endshields*

1. Push release lever (A) located on the backside of the endshield to unlock the shield.
2. Pull endshield open using handle depression (B).




Figure 4.123: Left Endshield

## ATTACHING HEADER TO COMBINE

3. Pull endshield at handle depression (A). Endshield is retained by a hinge tab (B) and will open in direction (C).




Figure 4.124: Left Endshield

4. Pull the endshield free of hinge tab (A) if additional clearance is required, and swing shield towards the rear of the header.
5. Engage safety latch (B) on hinge arm to secure the shield in fully open position.




Figure 4.125: Left Endshield

### *Installing Crop Divider without Latch Option*

**NOTE:**

If the crop divider latch option was ordered with the header, proceed to [Installing Crop Divider with Latch Option, page 88](#). Otherwise, complete the following procedure:

1. Position crop divider as shown by inserting lugs (A) into the holes (B) in endsheet.




Figure 4.126: Crop Divider Lugs and Endsheets Slots

## ATTACHING HEADER TO COMBINE

2. Lift the forward end of the crop divider and install bolt (B) and special stepped washer (A) (step towards divider). Tighten bolt.




Figure 4.127: Installation Hardware

3. Check that divider does NOT move laterally. Adjust bolts (A) as required to tighten divider and remove lateral play when pulling at divider tip.





Figure 4.128: Adjustment Hardware

## ATTACHING HEADER TO COMBINE


### *Installing Crop Divider with Latch Option*

1. Position the crop divider as shown by inserting the lugs (A) into holes in the endsheet.
2. Lift the forward end of the divider until the pin (B) engages and closes the latch (C).
3. Push the safety lever (D) down to lock the pin in latch.



**Figure 4.129: Crop Divider Lugs and Endsheet Slots**

4. Adjust bolts (A) to tighten divider and remove lateral play when pulling at divider tip.




**Figure 4.130: Adjustment Hardware**

## ATTACHING HEADER TO COMBINE


### *Closing Endshields*

1. Disengage lock (B) to allow endshield to move.
2. Insert front of endshield behind hinge tab (A) and into divider cone.



**Figure 4.131: Left Endshield**


3. Swing endshield in direction (A) into closed position. Engage lock with a firm push.
4. Verify that endshield is locked.



**Figure 4.132: Left Endshield**

### *Installing Crop Divider Rods*

1. Remove divider rods from shipping location on header endsheet.
2. Position crop divider rod (B) on tip of crop divider as shown and tighten bolt (A).
3. Repeat procedure at opposite end of header.



**Figure 4.133: Divider Rod on Crop Divider**

## 4.6.6 Installing Options

1. Retrieve the kits supplied as options with the header and install them according to the instructions supplied with each kit.
2. Proceed to [5 Performing Predelivery Checks, page 91](#).

## 5 Performing Predelivery Checks

This machine has been set at the factory and should not require further adjustments; however, the following checks will ensure your machine provides maximum performance. If adjustments are necessary, follow the procedures in this chapter.

### **WARNING**

**To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.**

#### **IMPORTANT:**

To avoid machine damage, check that no shipping material has fallen into the machine.

1. Perform the final checks as listed on the **Predelivery Checklist** (yellow sheet attached to this instruction – [Predelivery Checklist, page 283](#)) to ensure the machine is field-ready. Refer to the following pages for detailed instructions as indicated on the Checklist. The completed Checklist should be retained either by the Operator or the Dealer.

### 5.1 Checking Tire Pressure: Transport and Stabilizer Wheels

Check tire inflation pressure. If necessary, inflate tires according to the following table:

**Table 5.1 Tire Inflation Pressure**

Size	Load Range	Pressure
ST205/75 R15	D	448 kPa (65 psi)
	E	552 kPa (80 psi)

#### **IMPORTANT:**

Do **NOT** exceed maximum pressure specified on tire sidewall.

## 5.2 Checking Wheel Bolt Torque

Perform the following procedure to ensure that transport and stabilizer wheel bolts are correctly torqued:

1. Check wheel bolt torque is 110–120 N·m (80–90 ft·lbf) and adjust as necessary. Refer to bolt tightening sequence illustration at right.




Figure 5.1: Bolt Tightening Sequence

### 5.3 Checking Knife Drive Box

To access the knife drive box(es), endshield(s) must be fully opened. Single-knife headers have one knife-drive box and double-knife headers have two knife-drive boxes.

#### **WARNING**

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.

1. Press down on the latch in the opening (A) on the inboard side of the endsheet.
2. Pull endshield open using handle depression (B).




Figure 5.2: Endshield Latch Access

3. Swivel the endshield toward the back of the header and use the safety latch (B) to secure the endshield support tube (A) to the endsheet.




Figure 5.3: Left-Hand Endshield Support Tube

## PERFORMING PREDELIVERY CHECKS

### IMPORTANT:

The knife drive box breather is shipped in position (A) (forward) to prevent oil loss during transport. The breather plug MUST be repositioned to location (B) to prevent oil loss during normal operation. Failure to do so can result in damage to the knife drive box.

4. Check position of plug (A) and breather (B) at knife drive box. Position MUST be as shown.
5. Check oil level. It should be between the lower hole (C) on the dipstick and the bottom end of the dipstick.

### NOTE:

Check oil level with top of knife drive box horizontal and with the dipstick screwed in.




Figure 5.4: Knife Drive Box

## 5.4 Checking Oil Level in Header Drive Gearbox

### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. Lower the cutterbar to the ground and ensure the gearbox is in working position.
2. Shut down the combine, and remove the key from the ignition.
3. Remove the oil level plug (A) and check that the oil level is up to the bottom of the hole.
4. Replace the oil level plug (A).




Figure 5.5: Header Drive Gearbox

## 5.5 Checking Oil Level in Hydraulic Reservoir

1. Check the oil level using the lower sight (A) and the upper sight (B) with the cutterbar just touching the ground and with center-link retracted.

**NOTE:**

Check the level when the oil is cold.

2. Ensure the oil is at the appropriate level for the terrain as follows:
  - **Hilly terrain** : Maintain level so lower sight (A) is full, and upper sight (B) is up to one-half filled.
  - **Normal terrain** : Maintain level so lower sight (A) is full, and upper sight (B) is empty.
  - **Level ground** : For slopes of 6° or less, oil level may be kept slightly lower if desired. Maintain level so lower sight (A) is one-half filled or slightly higher.
3. Maintain level for normal terrain (D) so lower sight (A) is full, and upper sight (B) is empty.

**NOTE:**

It may be necessary to slightly reduce the oil level when ambient temperatures are above 35°C (95°F) to prevent overflow at the breather when normal operating temperatures are reached.




Figure 5.6: Oil Level Sight Glass




Figure 5.7: Oil Level Sight Glass

## 5.6 Checking and Adjusting Knife Drive Belt Tension

Refer to the appropriate section for your equipment type:

- [5.6.1 Tensioning Non-Timed Knife Drive Belts, page 97](#)
- [5.6.2 Tensioning Timed Knife Drive Belts, page 98](#)

### 5.6.1 Tensioning Non-Timed Knife Drive Belts

#### WARNING

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.

#### IMPORTANT:

To prolong the belt and drive life, do **NOT** overtighten the belt.

1. Open the left endshield.
2. Loosen the two bolts (A) securing the motor assembly to the header endsheet.
3. Turn the adjuster bolt (B) clockwise to move the drive motor until a force of 133 N (30 lbf) deflects the belt (C) 24–28 mm (15/16–1-1/8 in.) at the midspan.




Figure 5.8: Left Side Shown – Right Side Opposite for Double-Knife Headers

4. Ensure the clearance between the belt (A) and the belt guide (B) is 1 mm (1/16 in.).
5. Loosen the three bolts (C), and adjust the position of the guide (B) as required.
6. Tighten the three bolts (C).
7. Close the endshield.
8. **Double-knife headers only:** Repeat procedure on the other side of the header.




Figure 5.9: Knife Drive

## 5.6.2 Tensioning Timed Knife Drive Belts

The procedure for tensioning timed knife drive belts is the same for both sides of the header. The illustrations shown are for the left side—the right side is opposite.

### WARNING

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.

#### IMPORTANT:

To prolong belt and drive life, do **NOT** over-tighten belt.

#### IMPORTANT:

Do **NOT** use the adjuster bolt at the drive pulley to adjust timing belt tension.

1. Shut down the combine, and remove the key from the ignition.
2. Open the endshield.
3. Loosen two nuts (A) on the knife drive belt idler bracket.




Figure 5.10: Left Side Knife Drive

4. Position the pry bar (A) under the idler bracket (C), and push the bracket upwards until a force of 27 N (6 lbf) deflects the belt 13 mm (1/2 in.) at the mid-point of the upper span.

#### NOTE:

Protect the paint by placing a piece of wood (B) under the pry bar (A).




Figure 5.11: Left Side Knife Drive

## PERFORMING PREDELIVERY CHECKS

5. Tighten the nuts (C) to 73–80 N·m (54–59 ft·lbf) after achieving the proper belt tension.
6. Remove the pry bar (A) and wood (B).

**NOTE:**

Readjust the tension of a new belt after a short run-in period (about five hours).




Figure 5.12: Left Side Knife Drive

7. Ensure the clearance (A) between the belt (B) and the guide (C) is 0.5–1.5 mm (1/32–1/16 in.).
8. Loosen bolts (D) and adjust the guide if necessary. Tighten bolts.
9. Close the endshield.
10. Repeat procedure for the opposite side of the header.




Figure 5.13: Left Side Belt Guide

## 5.7 Checking Knife Hold-Downs

Perform daily inspections to ensure the knife hold-downs are preventing the knife sections from lifting off the guards while permitting the knife to slide without binding. Use a feeler gauge to measure the clearance between the hold-downs and knife sections and refer to the following for adjustment procedures:

- [5.7.1 Adjusting Hold-Downs with Pointed Guards, page 100](#)
- [5.7.2 Adjusting Hold-Downs with Stub Guards, page 101](#)

### 5.7.1 Adjusting Hold-Downs with Pointed Guards

#### WARNING

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.

1. Shut down the combine, and remove the key from the ignition.
2. Use a feeler gauge to measure the clearance between the normal guard hold-down (A) and the knife section. Ensure the clearance is 0.1–0.6 mm (0.004–0.024 in.).
3. To lower the front of the hold-down and decrease clearance, turn bolt (B) clockwise; to raise the front of the hold-down and increase clearance, turn bolt (B) counterclockwise.

#### NOTE:

For larger adjustments, it may be necessary to loosen nuts (C), turn adjuster bolt (B), and then retighten nuts.




Figure 5.14: Normal Guard Hold-Down

4. Use a feeler gauge to measure the clearance between the center guard hold-down (A) and the knife section. Ensure the clearance is between the following measurements:
  - **At guide tip (B):** 0.1–0.4 mm (0.004–0.016 in.)
  - **At rear of guide (C):** 0.1–1.0 mm (0.004–0.040 in.)
5. Adjust the clearance as follows:
  - a. Tighten nuts (D) until they are finger tight.
  - b. Turn the three adjuster bolts (E) clockwise to raise the front of the hold-down and increase clearance, or counterclockwise to lower the front of the hold-down and decrease clearance.
  - c. Torque the nuts (D) to 72 N·m (53 ft·lbf) after all the adjustments are complete and the specified clearances are achieved.




Figure 5.15: Center Guard Hold-Down

**⚠ WARNING**

Check to be sure all bystanders have cleared the area.

6. Complete the hold-down adjustments, run the header at low engine speed, and listen for noise caused by insufficient clearance.

**NOTE:**

Insufficient hold-down clearance will result in overheating of the knife and guards—readjust as necessary.

### 5.7.2 Adjusting Hold-Downs with Stub Guards

**⚠ WARNING**

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.

1. Shut down the combine, and remove the key from the ignition.
2. Use a feeler gauge to measure the clearance between the stub guard hold-down (A) and the knife section. Ensure the clearance is between the following measurements:
  - **At guide tip (B):** 0.1–0.4 mm (0.004–0.016 in.)
  - **At rear of guide (C):** 0.1–1.0 mm (0.004–0.040 in.)
3. Adjust the clearance as follows:
  - a. Tighten nuts (D) until they are finger tight.
  - b. To lower the front of the hold-down and decrease clearance, turn the three adjuster bolts (E) clockwise; to raise the front of the hold-down and increase clearance, turn the adjuster bolts (E) counterclockwise.
  - c. Torque the nuts (D) to 72 N·m (53 ft·lbf) after all the adjustments are complete and the specified clearances are achieved.




Figure 5.16: Stub Guards

## PERFORMING PREDELIVERY CHECKS

### **WARNING**

**Check to be sure all bystanders have cleared the area.**

4. Complete the hold-down adjustments, run the header at low engine speed, and listen for noise caused by insufficient clearance.

**NOTE:**

Insufficient hold-down clearance will result in overheating of the knife and guards—readjust as necessary.

## 5.8 Centering the Reel

To check and center the reel, follow these steps:

### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

1. Start combine and lower reel and header fully.
2. Stop engine and remove key from ignition.
3. Measure clearance between reel and both endsheets. The clearances should be the same if the reel is centered.




Figure 5.17: Double Reel Measurement Locations

4. **Double Reel Only:** If the reel is not centered, follow these steps:
  - a. Loosen bolt (A) on each brace (B).
  - b. Move the forward end of center support arm (C) laterally as required to center both reels.
  - c. Tighten bolts (A) and torque to 359 N·m (265 ft·lbf).





Figure 5.18: Center Support Arm and Braces – Double Reel Only

## PERFORMING PREDELIVERY CHECKS

5. **Single Reel Only:** If the reel is not centered, follow these steps:
  - a. Loosen bolt (A) on brace (B) at both ends of reel.
  - b. Move the forward end of reel support arm (C) laterally as required to center reel.
  - c. Tighten bolts (A), and torque to 359 N·m (265 ft·lbf).



**Figure 5.19: Support Arm and Brace – Single Reel Only**

## 5.9 Checking and Adjusting Header Float

The header is equipped with a suspension system that floats the header over the ground to compensate for ridges, trenches, and other variations in ground contour. If the header float is not set properly, it may cause the cutterbar to push into the ground or leave uncut crop. This procedure describes how to check header float and adjust to the factory-recommended settings.

### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. Level the header and float module. If the header and float module are not level, perform the following checks before adjusting the float:

#### IMPORTANT:

Do **NOT** use the float module float springs to level the header.

- Park the combine on a level surface.
  - Check that the combine feeder house is level. Refer to your combine operator's manual for instructions.
  - Check that the top of the float module is level with the combine axle.
  - Ensure the combine tires are inflated equally.
2. Adjust header so that the cutterbar is 150–254 mm (6–10 in.) off the ground.
  3. Adjust the center-link to between B and C on the indicator (A).
  4. Adjust the reel fore-aft position to between 5 and 6 on the position indicator decal (A) located on the right side reel arm.
  5. Lower the reel fully.
  6. Shut down the combine, and remove the key from the ignition.




Figure 5.20: Center-Link





Figure 5.21: Fore-Aft Position


## PERFORMING PREDELIVERY CHECKS

7. Disengage both header float locks by pulling the float lock handle (A) away from the float module and pushing the float lock handle down and into position (B) (UNLOCK).



**Figure 5.22: Header Float Lock (in Locked Position)**

8. Place stabilizer wheels and slow speed transport wheels (if equipped) in storage position as follows:
  - a. Support the wheel weight by lifting slightly with one hand, and pull up on handle (A) to release the lock.
  - b. Lift the wheels to the desired height, and engage the support channel into the slot (B) in the upper support.
  - c. Push down on the handle (A) to lock.



**Figure 5.23: Left Wheel**

## PERFORMING PREDELIVERY CHECKS

9. Remove the supplied torque wrench (A) from its storage position at the right-hand side of the float module frame. Pull in the direction shown to disengage the wrench from the hook.




Figure 5.24: Torque Wrench Storage Location

10. Place the supplied torque wrench (A) onto the float lock (B). Note the position of the wrench for checking left or right side.
11. Push down on wrench to rotate bell crank (C) forward.




Figure 5.25: Left Side




Figure 5.26: Right Side

## PERFORMING PREDELIVERY CHECKS

12. Push down on the wrench until indicator (A) reaches a maximum reading and then begins to decrease. Note the maximum reading and repeat at opposite side.




Figure 5.27: Indicator

13. Use the following table as a guide for float settings:
  - If reading on the wrench is high, the header is heavy
  - If reading on the wrench is low, the header is light

Table 5.2 Float Settings

Header Size (feet)	Torque Settings	
	Cutting on the Ground	Cutting off the Ground
20, 25, 30, and 35	1-1/2 to 2	2 to 2-1/2
40 and 45	2 to 2-1/2	2-1/2 to 3

14. Before adjusting the float spring adjustment bolts (A), rotate the spring locks by loosening bolts (B).
15. To increase float (decrease header weight), turn both adjustment bolts (A) on the left side clockwise. Repeat adjustment at opposite side.
16. To decrease float (increase header weight), turn left side adjustment bolts (A) counterclockwise. Repeat at opposite side.




Figure 5.28: Float Adjustment (Left Side Shown)

17. Use the following guidelines when adjusting float:
  - Adjust the float so the wrench readings are equal on both sides of the header.

## PERFORMING PREDELIVERY CHECKS

- Turn each bolt pair equal amounts. Refer to Step [12, page 108](#), and repeat torque wrench reading procedure.
- Set header float as light as possible without causing excessive bouncing to prevent knife component breakage, soil scooping, or soil build-up at the cutterbar in wet conditions.
- Use a slower ground speed with a light float setting, if necessary, to avoid excessive bouncing and leaving a ragged cut.
- Use the stabilizer wheels in conjunction with header float to minimize bouncing at the header ends and to control cut height when cutting off the ground.

**NOTE:**

If adequate header float cannot be achieved using all of the available adjustments, an optional heavy duty spring is available.

## 5.10 Checking and Adjusting Skid Shoe Settings

Check skid shoes and adjust, if necessary.

### **⚠️ WARNING**

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under machine for any reason.

### **⚠️ DANGER**

Engage header safety props and reel props before working under header or reel.

1. Note the adjustment hole positions on the lugs (A) on each skid shoe. They should be the same.
2. If necessary, adjust skid shoe as follows:
  - a. Remove lynch pin (B).
  - b. Hold shoe and remove pin (C) by disengaging frame and then pulling away from shoe.
  - c. Raise or lower skid shoe to desired position using holes in support as a guide.
  - d. Reinsert pin (C), engage in frame, and secure with lynch pin (B).
  - e. Check that all skid shoes are adjusted to the same position.




Figure 5.29: Inner Skid Shoe




Figure 5.30: Outer Skid Shoe


## 5.11 Measuring and Adjusting Reel Clearance to Cutterbar

The minimum clearance between the reel fingers and the cutterbar ensures that the reel fingers do not contact the cutterbar during operation. The clearance is set at the factory, but some adjustment may be necessary before operation.

The finger to guard/cutterbar clearances with reels fully lowered are shown in Table 5.3 *Finger to Guard/Cutterbar Clearance*, page 111.

**Table 5.3 Finger to Guard/Cutterbar Clearance**

Header Width	(X) 3 mm (+/- 1/8 in.) at Reel Ends	
	Single Reel	Double Reel
20 ft.	20 mm (3/4 in.)	-
25 ft.	25 mm (1 in.)	
30 ft.	45 mm (1-3/4 in.)	20 mm (3/4 in.)
35 ft.	60 mm (2-3/8 in.)	
40 ft.	-	
45 ft.	-	




**Figure 5.31: Finger Clearance**

### 5.11.1 Measuring Reel Clearance

#### DANGER

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under header for any reason.

1. Park the header on level ground.
2. Set the fore-aft position to the middle position (5) on the fore-aft position decal (A).
3. Lower the reel fully.
4. Shut down the engine and remove key from the ignition.



**Figure 5.32: Fore-Aft Position**

## PERFORMING PREDELIVERY CHECKS

5. Measure the clearance (X) at all possible points of contact between points (B) and (C) at the ends of each reel (A).

**NOTE:**

The reel is factory-set to provide more clearance at the center of the reel than at the ends (frown) to compensate for reel flexing.

**NOTE:**

When measuring reel clearance at the center of a double reel header, measure the lowest reel.

6. Check all possible points of contact between points (B) and (C). Depending on the reel fore-aft position, minimum clearance can result at the guard tine, hold-down, or cutterbar.
7. Adjust the reel if necessary. Refer to [5.11.2 Adjusting Reel Clearance](#), page 112.




Figure 5.33: Reel Clearance

### 5.11.2 Adjusting Reel Clearance

#### DANGER

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under header for any reason.

**IMPORTANT:**

After setting the recommended reel clearance to cutterbar, while reel is still fully lowered, move reel back to ensure steel end fingers do NOT contact deflector shields. If contact is detected, adjust reel upward until contact to deflector shields is avoided at all reel fore/aft positions. Alternatively, with the reel fully lowered, trim the steel end fingers until contact to deflector shields is avoided at all reel fore/aft positions. Periodically monitor to ensure contact is avoided and repeat procedure if necessary.

1. Shut down the combine, and remove the key from the ignition.
2. Adjust outboard reel arm lift cylinders to set clearance at outboard ends of reel as follows:
  - a. Loosen bolt (A).
  - b. Turn cylinder rod (B) out of clevis to raise reel and increase clearance to cutterbar, or turn cylinder rod into clevis to lower reel and decrease clearance.
  - c. Tighten bolt (A).
  - d. Repeat at opposite side.




Figure 5.34: Outside Reel Arm


## PERFORMING PREDELIVERY CHECKS

3. **For double reel only:** Adjust center arm lift cylinder stop (A) to change clearance at inboard ends of reels as follows:

**NOTE:**

Instructions apply to double-reel headers only and are performed from the underside of the arm.

- a. Loosen nut (B).
  - b. Turn nut (C) counterclockwise to raise reel and increase clearance to cutterbar, or clockwise to lower reel and decrease clearance.
  - c. Tighten nut (B).
4. Check measurements and if necessary, repeat adjustment procedures.



**Figure 5.35: Underside of Center Arm**

## 5.12 Adjusting Auger to Pan Clearance

### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

#### IMPORTANT:

Maintain an appropriate distance between the auger and the auger pan. Too little clearance may result in the fingers or flighting contacting and damaging the feed draper or pan when operating the header at certain angles. Look for evidence of contact when greasing the float module.

1. Extend the center-link to the steepest header angle, and position the header 150–254 mm (6–10 in.) off the ground.
2. Shut down the combine, and remove the key from the ignition.
3. Ensure the float lock linkage is on the down stops (washer [A] cannot be moved) at both locations.




Figure 5.36: Float Lock

## PERFORMING PREDELIVERY CHECKS

4. Before adjusting the auger to pan clearance, check the auger float position to determine how much clearance is required:
  - If the bolt head (A) is closest to the floating symbol (B), the auger is in the floating position.

### CAUTION

Make sure the two bolts (A) are in the same location to prevent damage to the machine during operation.




Figure 5.37: Floating Position

- If the bolt head (A) is closest to the rigid symbol (B), the auger is in the rigid position.




Figure 5.38: Rigid Position

## PERFORMING PREDELIVERY CHECKS

- Loosen two nuts (B).
- Using the adjuster bolt (A), set clearance (C) to 22–26 mm (7/8–1.0 in.) if feed auger is in rigid position, and 11–15 mm (7/16–5/8 in.) if feed auger is in floating position. Turn bolt clockwise to increase clearance and counterclockwise to decrease clearance.

**NOTE:**


The clearance increases between 25–40 mm (1–1-1/2 in.) when the center-link is fully retracted.

- Repeat Step 5, [page 116](#) and Step 6, [page 116](#) for the opposite end of the auger.

**IMPORTANT:**

Adjusting one side of the auger can affect the other side so recheck both sides after final adjustment is made.

- Tighten nuts (B) on both ends of the feed auger. Torque the nuts to 93–99 N·m (68–73 lbf ft).



**Figure 5.39: Auger Clearance**

## 5.13 Checking Auger Finger Timing

This procedure checks to see when the auger fingers are extending from the auger.

**NOTE:**


Left-hand side shown.

1. Raise the reel to maximum height. Engage reel safety props.
2. Shut down the combine and remove the key from the ignition.
3. Check that tine timing indicator (B) is set to the same position (A) on each end of the auger. There are two different auger tine extension positions A or B. Setting A would be used for rape seed and setting B would be used for grains.

**IMPORTANT:**

It is extremely important that both sides are set the same, if not the drum will have a catastrophic failure.

4. Disengage reel safety props.



**Figure 5.40: Auger Tine Timing (Left-Hand Side Shown)**


### 5.13.1 Adjusting Auger Finger Timing

This procedure adjusts when the auger fingers extend and retract from the auger.

**NOTE:**

Left-Hand side shown.

1. Raise the reel to maximum height. Engage reel safety props.
2. Shut down the combine and remove the key from the ignition.
3. Locate indicator (B) that specifies when the fingers in the drum extend. There are two settings: A and B.



**Figure 5.41: Auger Tine Timing Indicator**

## PERFORMING PREDELIVERY CHECKS

- Loosen nuts (A) and adjust tine timing indicator (B) to desired position.

### IMPORTANT:

It is extremely important that both sides are set the same, if not the drum will have a catastrophic failure.




Figure 5.42: Auger Tine Timing Indicator

- If the tine timing indicator is pointing at setting A, it indicates that at that point the auger finger will be fully extended. This allows the crop to be engaged and released earlier before entering the feeder house. This setting is best used for rape seed.




Figure 5.43: Auger Setting A

- If the indicator is pointing at setting B, it indicates that at that point the auger finger will be fully extended. This allows the crop to be engaged and released later before entering the feeder house. This setting is best used for grains.





Figure 5.44: Auger Setting B

## PERFORMING PREDELIVERY CHECKS

7. Tighten nuts (A) once adjustment is complete.
8. Disengage reel safety props.



**Figure 5.45: Auger Tine Timing Indicator**

## 5.14 Adjusting Draper Tension

### WARNING

To avoid bodily injury or death from unexpected start-up or fall of raised machine, always stop engine, remove key, and engage safety props before going under machine for any reason.

1. Ensure the white indicator bar (A) is at the halfway point in the window.

### WARNING

Check to be sure all bystanders have cleared the area.

2. Start the engine and fully raise the header.
3. Shut down the combine, and remove the key from the ignition.
4. Engage the header safety props.

5. Ensure the draper guide (the rubber track on the underside of the draper) is properly engaged in the groove (A) on the drive roller.

6. Ensure the idler roller (A) is between the draper guides (B).

**NOTE:**

If adjustment is required, tension the drapers just enough to prevent slipping and to keep the draper from sagging below the cutterbar.




Figure 5.46: Left Tension Adjuster Shown – Right Opposite




Figure 5.47: Drive Roller




Figure 5.48: Idler Roller

## PERFORMING PREDELIVERY CHECKS

### IMPORTANT:

Do **NOT** adjust nut (C). This nut is used for draper alignment only.

7. To loosen the adjuster bolt (A), turn it counterclockwise. The white indicator bar (B) will move outboard in the direction of arrow (D) to indicate that the draper is loosening. Loosen until the white indicator bar is at the halfway point in the window.
8. To tighten the adjuster bolt (A), turn it clockwise. The white indicator bar (B) will move inboard in the direction of arrow (E) to indicate that the draper is tightening. Tighten until the white indicator bar is at the halfway point in the window.

### IMPORTANT:

- To avoid premature failure of the draper, draper rollers, and/or tightener components, do not operate with the tension set so the white bar is not visible.
- To prevent scooping dirt, ensure the draper is tight enough that it does not sag below the point where the cutterbar contacts the ground.




Figure 5.49: Left Tension Adjuster Shown – Right Opposite

## 5.15 Adjusting Feed Draper Tension

### **⚠ DANGER**


To avoid bodily injury or death from unexpected start-up or fall of a raised machine, always stop engine and remove key before leaving the operator's seat, and always engage safety props before going under the machine for any reason.

1. Raise the header to its full height, stop the engine, and the remove key from the ignition.
2. Engage the header safety props.
3. Ensure the draper guide (rubber track on the underside of the draper) is properly engaged in the groove on the drive roller and the idler roller is between the guides.
4. Loosen jam nut (A) and turn bolt (C) clockwise to increase draper tension or counterclockwise to decrease draper tension.
5. Adjust the draper tension until the white indicator (C) is centered within the indicator window on the spring box.

**IMPORTANT:**

Adjust both sides equally.

6. Tighten jam nut (A).



**Figure 5.50: Tensioner**

## 5.16 Checking and Adjusting Draper Seal

Maintain the deck height such that the draper runs just below the cutterbar.

### IMPORTANT:

New factory installed drapers are pressure and heat checked at the factory. The gap between the draper (A) and cutterbar (B) is set to 1–3 mm (1/32–1/8 in.). To prevent material from entering the drapers and cutterbar, you may need to decrease the deck clearance to 0 mm (0 in.) after an initial break-in period of approximately 50 hours.

1. Check deck height. Draper (A) should run just below cutterbar (B) with a gap of 1–3 mm (1/32–1/8 in.) between the top of deck front track and cutterbar.
  - If deck height is acceptable, skip the remaining steps and proceed to [5.17 Lubricating the Header](#), [page 125](#).
  - If deck height is **NOT** acceptable, adjust seal as described in the following steps:

### NOTE:

Take measurement at deck supports (A) with the header in working position. There are between two and five supports per deck depending on header size.

2. Loosen tension on drapers. For instructions, refer to [5.14 Adjusting Draper Tension](#), [page 120](#).
3. Lift draper (A) up at front edge past cutterbar (B).




Figure 5.51: Draper/Cutterbar Gap




Figure 5.52: Draper Deck Supports





Figure 5.53: Draper and Cutterbar

## PERFORMING PREDELIVERY CHECKS

4. Loosen two lock nuts (A) only one-half-turn on deck support (B).
5. Tap deck (C) to lower deck relative to supports and achieve the recommended setting. Tap support (B) using a punch to raise deck relative to supports.
6. Tighten deck support hardware (A).
7. Tension drapers. Refer to [5.14 Adjusting Draper Tension, page 120](#).



**Figure 5.54: Draper Deck Supports (Draper Removed)**

## 5.17 Lubricating the Header

Table 5.4 Recommended Lubricant

Specification	Description	Use
SAE multipurpose	High temperature, extreme pressure (EP2) performance with 1% max molybdenum disulphide (NLGI Grade 2) lithium base	As required unless otherwise specified
	High temperature, extreme pressure (EP) performance with 10% max molybdenum disulphide (NLGI Grade 2) lithium base	Driveline slip-joints

### 5.17.1 Greasing Procedure

Greasing points are marked on the machine by decals showing a grease gun and grease interval in hours of operation. Master grease point location decals are provided on the header and the float module right-hand hydraulic tank.

 **DANGER**

**To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.**

## PERFORMING PREDELIVERY CHECKS

1. Wipe grease fitting with a clean cloth before greasing to avoid injecting dirt and grit.

**IMPORTANT:**

Use clean, high-temperature, extreme-pressure grease only.

2. Inject grease through fitting with grease gun until grease overflows fitting (except where noted).
3. Leave excess grease on fitting to keep out dirt.
4. Replace any loose or broken fittings immediately.
5. Remove and thoroughly clean any fitting that will not take grease. Also clean lubricant passageway. Replace fitting if necessary.
6. Use clean, high-temperature, extreme-pressure grease only.




Figure 5.55: FM100 Master Grease Point Decal




Figure 5.56: Single-Knife Header Master Grease Point Decal




Figure 5.57: Double-Knife Header Master Grease Point Decal


## 5.17.2 Lubrication Points

### Knifehead

#### IMPORTANT:

Overgreasing can cause the knife to bend and make contact with the guards closest to the knifehead. Check for signs of excessive heating on first few guards after greasing. If required, relieve some pressure by removing the grease fitting.

- To prevent binding and/or excessive wear caused by knife pressing on guards, do **NOT** over grease the knifehead (A).
- Apply only 1–2 pumps of grease with a grease gun, or just until the knifehead starts to move away from the arm. Do **NOT** use an electric grease gun.
- If more than 6–8 pumps of the grease gun are required to fill the cavity, replace the seal in the knifehead.
- Check for signs of excessive heating on first few guards after greasing. If required, relieve pressure by pressing check-ball in grease fitting.



**Figure 5.58: Knifehead**


(Single Knife – One Place)

(Double Knife – Two Places)

#### NOTE:

Use High Temperature Extreme Pressure (EP2) Performance with 1% Max Molybdenum Disulphide (NLGI Grade 2) Lithium Base grease unless otherwise specified.


## PERFORMING PREDELIVERY CHECKS



**Figure 5.59: Knife Drive Bearing and Driveshaft (Double-Knife Timed Drive Only)**

A - Knife Drive Bearing - Double-Knife Drive - (Both Sides)    B - Knife Driveshaft - Double-Knife Timed Drive (Both Sides) (15 Pumps Minimum)

## PERFORMING PREDELIVERY CHECKS



**Figure 5.60: Drive Roller Bearing, Idler Roller, Slip Joint, and Driveline Universal**

A - Drive Roller Bearing


B - Idler Roller - Both Sides

C - Driveline Slip Joint<sup>1</sup>

D - Driveline Universal (Two Places)

1. 10% moly grease is recommended for the driveline slip joint.


PERFORMING PREDELIVERY CHECKS



**Figure 5.61: Upper Cross Auger and Knife Drive (Double-Knife Timed Drive)**

- A - Upper Cross Auger U-Joint and Bearing      B - Upper Cross Auger Bearing (One Place)      C - Upper Cross Auger (One Place)
- D - Knife Drive Bearing - Double-Knife Timed Drive (Both Sides)
- E - Knife Driveshaft - Double-Knife Timed Drive (Both Sides) 15 Pumps Minimum

PERFORMING PREDELIVERY CHECKS



**Figure 5.62: Auger Pivot, Float Pivot, Driveline Guard, and Float Spring Tensioners**

A - Float Spring Tensioner (LH and RH)  
 D - Driveline Guard (Two Places)


B - Auger Pivot  
 E - Float Pivot (Two Places)

C - Auger Pivot

## PERFORMING PREDELIVERY CHECKS

### IMPORTANT:

The reel U-joint (C) has an extended lubrication cross and bearing kit. Stop greasing when greasing becomes difficult or if U-joint stops taking grease. **OVERGREASING WILL DAMAGE U-JOINT.** Six to eight pumps is sufficient at first grease (factory). As U-joint wears and requires more than six pumps, grease the joint more often.



**Figure 5.63: Reel Shaft Bearings**

A - Reel Shaft Right-Hand Bearing (One Place)  
C - Reel U-joint (One Place)

B - Reel Center Bearing (One Place)  
D - Reel Shaft Left-Hand Bearing (One Place)

## PERFORMING PREDELIVERY CHECKS



**Figure 5.64: Rear Wheel Axle, Wheel Bearings, Frame/Wheel Pivot, and Front Wheel Pivot**

A - Wheel Bearings (Four Places)

B - Front Wheel Pivot (One Place)

C - Frame/Wheel Pivot (One Place) Both Sides

## 5.18 Checking and Adjusting Endshields

Endshields are subject to expansion or contraction caused by large temperature variations. The position of the top pin and lower latch can be adjusted to compensate for dimensional changes.


1. Check gap (X) between front end of shields and header frame and compare to the values in Table 5.5 *Endshield Gap at Various Temperatures*, page 134.

**Table 5.5 Endshield Gap at Various Temperatures**

Temperature in Degrees °C (°F)	Gap (X) in mm (in.)
7 (45)	13–18 (1/2 – 23/32)
18 (65)	10–15 (3/8 – 19/32)
29 (85)	7–12 (9/32 – 15/32)
41 (105)	4–9 (5/32 – 11/32)

**NOTE:**


If the endshield gap is correct, skip to the next procedure. If adjustment is required, follow these steps:



**Figure 5.65: Gap between Endshield and Header Frame**

**Opening the endshield:**

2. Push release lever (A) located on the backside of the endshield to unlock the shield.
3. Pull endshield open using handle depression (B).



**Figure 5.66: Left Endshield**

## PERFORMING PREDELIVERY CHECKS

4. Pull endshield at handle depression (A). Endshield is retained by a hinge tab (B) and will open in direction (C).




Figure 5.67: Left Endshield

5. Pull the endshield free of hinge tab (A) if additional clearance is required, and swing shield towards the rear of the header.
6. Engage safety catch (B) on hinge arm to secure the shield in fully open position.




Figure 5.68: Left Endshield

### ***Adjusting the endshield gap:***

7. Loosen the four bolts (A) on the support tube bracket (B).




Figure 5.69: LH Endshield Support Tube

## PERFORMING PREDELIVERY CHECKS

8. Loosen the three bolts (A) on latch assembly (B).
9. Adjust latch assembly (B) to achieve the desired gap between the front end of shield and header frame in accordance with Table 5.5 *Endshield Gap at Various Temperatures*, page 134.
10. Tighten the three bolts (A) on the latch assembly.
11. Tighten the four bolts on the support tube bracket.
12. Close endshield.




Figure 5.70: LH Endshield Latch Assembly

### ***Closing the endshield:***

13. Disengage lock (B) to allow endshield to move.
14. Insert front of endshield behind hinge tab (A) and into divider cone.




Figure 5.71: Left Endshield

15. Swing endshield in direction (A) into closed position. Engage lock with a firm push.
16. Verify that endshield is locked.




Figure 5.72: Left Endshield

## 5.19 Checking Manuals

Check manual case contents. The manual case is located inside the left-hand endshield.

1. Open the left-hand endshield and remove the cable tie on the manual case.
2. Confirm that the case contains the following manuals:
  - D1 Series Draper Header for Combines Operator's Manual
  - D1 Series Draper Header with FM100 Float Module Parts Catalog
3. Close case and endshield.




Figure 5.73: Manual Case




## 6 Setting up Auto Header Height Control

### 6.1 Auto Header Height Control (AHHC)

MacDon's auto header height control (AHHC) feature works in conjunction with the AHHC option available on certain combine models.

A sensor is installed in the float indicator box (A) on the FM100 Float Module. This sensor sends a signal to the combine allowing it to maintain a consistent cutting height and an optimum float as the header follows ground contours. A two-sensor system is also available as an optional kit.



**Figure 6.1: FM100 Float Module**

FM100 Float Modules are factory-equipped for AHHC; however, before using the AHHC feature, you must do the following:

1. Ensure that the AHHC sensor's output voltage range is appropriate for the combine.  
For more information, refer to [6.1.1 Sensor Output Voltage Range – Combine Requirements, page 141](#).
2. Prepare the combine to use the AHHC feature (applies only to some combine models—refer to the instructions for your combine).
3. Calibrate the AHHC system so that the combine can correctly interpret data from the height sensor on the combine float module (refer to the instructions for your combine).

**NOTE:**

Once calibration is complete, you are ready to use the AHHC feature in the field. Individual combine settings can improve AHHC performance (refer to your combine instruction manual).

## SETTING UP AUTO HEADER HEIGHT CONTROL

Refer to the following instructions for your specific combine model:

- [6.1.2 Case IH 5088/6088/7088 Combines, page 150](#)
- [6.1.3 Case IH 5130/6130/7130, 7010/8010, 7120/8120/9120, 7230/8230/9230 and 7240/8240/9240 Combines, page 152](#)
- [6.1.4 Challenger and Massey Ferguson Combines, page 164](#)
- [6.1.5 Gleaner R65/R66/R75/R76 and S Series Combines, page 172](#)
- [6.1.7 John Deere 60 Series Combines, page 195](#)
- [6.1.8 John Deere 70 Series Combines, page 203](#)
- [6.1.9 John Deere S and T Series Combines, page 210](#)
- [6.1.10 Lexion 500 Series Combines, page 222](#)
- [6.1.11 Lexion 600 and 700 Series Combines, page 231](#)
- [6.1.12 New Holland Combines, page 237](#)

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.1 Sensor Output Voltage Range – Combine Requirements

The auto header height control (AHHC) sensor output must be within a specific voltage range for each combine, or the AHHC feature will not work properly.

**Table 6.1 Combine Voltage Limits**

Combine	Low Voltage Limit	High Voltage Limit	Range (Difference between High and Low Limits)
Challenger, Gleaner A, Massey Ferguson	0.5 V	4.5 V	2.5 V
Case IH 5088/6088/7088, 5130/6130/7130, 7010/8010, 7120/8120/9120, 7230/8230/9230, and 7240/8240/9240	0.5 V	4.5 V	2.5 V
Case IH 2588/2577	2.8 V	7.2 V	4.0 V
Gleaner R and S Series	0.5 V	4.5 V	2.5 V
John Deere 60, 70, S, and T Series	0.5 V	4.5 V	2.5 V
Lexion 500/600/700 Series	0.5 V	4.5 V	2.5 V
New Holland CR/CX - 5 V system	0.7 V	4.3 V	2.5 V
New Holland CR/CX - 10 V system	2.8 V	7.2 V	4.1–4.4 V
<p><b>NOTE:</b> Some combine models do not support checking sensor output voltage from the cab (early 23/2588 series, Lexion 500/600/700 series). For these models, check output voltage manually. Refer to <a href="#">Manually Checking Voltage Range: One-Sensor System, page 141</a> or <a href="#">Manually Checking Voltage Range: Two-Sensor System, page 144</a>.</p>			

#### *Manually Checking Voltage Range: One-Sensor System*

The one-sensor system is standard for the FM100 Float Module. If equipped with the optional two-sensor system, refer to [Manually Checking Voltage Range: Two-Sensor System, page 144](#).

The output voltage range of the auto header height control (AHHC) sensors in some combines can be checked from the cab. For instructions, refer to your combine operator's manual or the AHHC instructions later in this document.

To manually check the sensor's output voltage range, follow these steps:

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.

## SETTING UP AUTO HEADER HEIGHT CONTROL

2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.2: Float Lock

3. Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.





Figure 6.3: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Use a voltmeter (A) to measure the voltage between the ground (Pin 2) and signal (Pin 3) wires at the AHHC sensor in the float indicator box. Ensure it is at the high voltage limit for the combine. Refer to [Table 6.1 Combine Voltage Limits, page 141](#).

**NOTE:**

The wiring harness connector must be attached to the sensor. Do NOT disconnect it.



**Figure 6.4: Measuring Voltage at Float Indicator Box**

5. Fully lower the combine feeder house, and float the header up off the down stops (float indicator should be at 4, and the float module should be fully separated from the header).

**NOTE:**


You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

6. Use a voltmeter (A) to measure the voltage between the ground and signal wires at the AHHC sensor in the float indicator box. It should be at the low voltage limit for the combine. Refer to [Table 6.1 Combine Voltage Limits, page 141](#).

**NOTE:**

The wiring harness connector must be attached to the sensor. Do NOT disconnect it.

7. If the sensor voltage is not within the low and high limits or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).



**Figure 6.5: Measuring Voltage at Float Indicator Box**

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Manually Checking Voltage Range: Two-Sensor System

FM100 Float Modules equipped with the optional two-sensor system have a left- and right-hand sensor located on the back frame of the float module.

To manually check the sensor's output voltage range, follow these steps:

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module's float.




Figure 6.6: Optional Two-Sensor System

2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.7: Float Lock

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.8: Float Indicator Box

- Use a voltmeter to measure the voltage between the ground (Pin 2) and signal (Pin 3) wires of the AHHC sensor (A) at the back of the float module side frame. Ensure it is at the high voltage limit for the combine. Refer to Table 6.1 *Combine Voltage Limits*, page 141.

**NOTE:**

The wiring harness connector must be attached to the sensor. Do NOT disconnect it.

- Repeat at the opposite side.




Figure 6.9: Optional Two-Sensor Kit – RH Sensor

- Fully lower the combine feeder house, and float the header up off the down stops (float indicator [A] should be at 4, and the float module should be fully separated from the header).

**NOTE:**

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.




Figure 6.10: Float Indicator Box


## SETTING UP AUTO HEADER HEIGHT CONTROL

- Using a voltmeter, measure the voltage between the ground (Pin 2) and signal (Pin 3) wires of the AHHC sensor (A) at the back of the side frame. Ensure it is at the high voltage limit for the combine. Refer to [Table 6.1 Combine Voltage Limits, page 141](#).

**NOTE:**

The wiring harness connector must be attached to the sensor. Do NOT disconnect it.

- If the sensor voltage is not within the low and high limits, or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: Two-Sensor System, page 148](#).
- Repeat at the opposite side.



**Figure 6.11: Optional Two-Sensor Kit – RH Sensor**

### *Adjusting Voltage Limits: One-Sensor System*

Follow this procedure if you have checked the voltage range (either manually or from the cab) and found that the sensor voltage is not within the low and high limits or that the range between the low and high limits is insufficient.

**⚠ DANGER**

**To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.**

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Follow these steps to adjust the upper voltage limit:
  - a. Extend guard angle fully; the header angle indicator should be at D.
  - b. Position header 152–254 mm (6–10 in.) above the ground; the float indicator should be at 0.
  - c. Check the upper voltage limit using the combine display or voltmeter. Refer to Table [6.1 Combine Voltage Limits, page 141](#).
  - d. Loosen sensor mounting nuts (A).
  - e. Rotate sensor (B) counterclockwise to increase high voltage limit and clockwise to decrease it.
  - f. Tighten sensor mounting nuts (A).
2. Follow these steps to adjust the lower voltage limit:
  - a. Extend guard angle fully; the header angle indicator should be at D.
  - b. Fully lower header on the ground; the float indicator should be at 4.
  - c. Check the lower voltage limit using the combine display or voltmeter. Refer to Table [6.1 Combine Voltage Limits, page 141](#).
  - d. Loosen sensor mounting nuts (A).
  - e. Rotate sensor (B) counterclockwise to increase low voltage limit and clockwise to decrease it.
  - f. Tighten sensor mounting nuts (A).
3. After making adjustments, recheck both the upper and lower voltage limits to make sure they are within the required range according to Table [6.1 Combine Voltage Limits, page 141](#).
4. If unable to get the voltage within the required range, loosen mounting bolts (A) and shift sensor assembly (B) inboard as shown in the illustration at right.

### NOTE:

If sensor assembly is shifted right or left, it may be necessary to repeat Steps [1., page 147](#) and [2., page 147](#) to achieve the proper voltage limits.




Figure 6.12: AHC Sensor Assembly




Figure 6.13: AHC Sensor Assembly

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Adjusting Voltage Limits: Two-Sensor System

#### DANGER

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

1. Extend guard angle fully; the header angle indicator should be at D.
2. Position header 150–254 mm (6–10 in.) above the ground; the float indicator should be at 0.
3. Adjust left-hand sensor voltage:
  - a. Loosen sensor mounting nuts (A).
  - b. Rotate sensor (B) counterclockwise to lower the voltage. Rotate sensor clockwise to raise the voltage.
  - c. Check that the left-hand sensor is at the correct upper voltage limit according to Table [6.1 Combine Voltage Limits](#), page 141.
  - d. Tighten sensor mounting nuts (A).





Figure 6.14: Optional Two Sensor Kit – LH Sensor


## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Adjust right-hand sensor voltage:
  - a. Loosen sensor mounting nuts (A).
  - b. Rotate sensor (B) clockwise to lower the voltage. Rotate sensor counterclockwise to raise the voltage.
  - c. Check that the right-hand sensor is at the correct upper voltage limit according to Table [6.1 Combine Voltage Limits, page 141](#).
  - d. Tighten sensor mounting nuts (A).



**Figure 6.15: Optional Two Sensor Kit – RH Sensor**

5. Fully lower the header; the float indicator should be at 4.
6. Check that both sensors are at the correct lower voltage limit according to Table [6.1 Combine Voltage Limits, page 141](#).



**Figure 6.16: Float Indicator Box**

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.2 Case IH 5088/6088/7088 Combines


#### *Calibrating the Auto Header Height Control (Case IH 5088/6088/7088)*

For best performance of the auto header height control (AHHC) system, perform ground calibration with center-link set to D. When calibration is complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Set the flotation on the header. Refer to operator's manual for instructions. Position fore-aft in mid span.
3. Start the combine engine, but do NOT have separator or feeder house engaged.
4. Locate header control switch (A) on the right console, and set to HT (this is AHHC mode).




**Figure 6.17: Right Console**

5. Press the header lower switch (A) on the joystick lever until the float module and header are fully lowered. You may need to hold the switch for several seconds.
6. Press the header raise switch (A) on the joystick lever. The header should stop at about the halfway point. Continue holding the header raise switch, and the header will rise until the feeder house reaches its upper limit. The AHHC system is now calibrated.

**NOTE:**

If float was set heavier to complete the ground calibration procedure, adjust to recommended operating float after the calibration is complete.



**Figure 6.18: Joystick Lever (Case IH 2300/2500)**

## SETTING UP AUTO HEADER HEIGHT CONTROL




Figure 6.19: Joystick Lever (Case IH 5088/6088/7088)

### Setting the Sensitivity of the Auto Header Height (Case IH 5088/6088/7088)

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Use the HEADER SETTINGS key (M) to display the HEADER SENSITIVITY CHANGE page.
2. Use the UP or DOWN keys (E) and (H) to adjust the highlighted item. The height sensitivity setting range is 0 (least sensitive) to 250 (most sensitive) in increments of 10.

#### NOTE:

Adjustments take effect immediately. Use the CANCEL key to return to the original settings.

3. Use the HEADER SETTINGS key (M) to highlight the next changeable item.
4. Use the ENTER key (D) to save changes and return to the monitor page. If there are no changes, the screen will return to the monitor page after 5 seconds.




Figure 6.20: Combine Controls

## SETTING UP AUTO HEADER HEIGHT CONTROL




Figure 6.21: Height Sensitivity Change Page

### 6.1.3 Case IH 5130/6130/7130, 7010/8010, 7120/8120/9120, 7230/8230/9230 and 7240/8240/9240 Combines

#### *Checking Voltage Range from the Combine Cab (Case 8010)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**⚠ CAUTION**

**Check to be sure all bystanders have cleared the area.**

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.

## SETTING UP AUTO HEADER HEIGHT CONTROL

2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.22: Float Lock

3. Adjust cable take-up bracket (B) (if necessary) until pointer (A) on float indicator is on 0.




Figure 6.23: Float Indicator box

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Ensure header float is unlocked.
5. Select DIAG (A) on the Universal display MAIN page. The DIAG page displays.




Figure 6.24: Case 8010 Combine Display

6. Select SUB SYSTEM (A). The SUB SYSTEM page displays.




Figure 6.25: Case 8010 Combine Display

7. Select HDR HEIGHT/TILT (A). The SENSOR page displays.




Figure 6.26: Case 8010 Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Select LEFT SEN (A). The exact voltage is displayed. Raise and lower the header to see the full range of voltage readings.




Figure 6.27: Case 8010 Combine Display

- If the sensor voltage is not within the low and high limits, or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).



Figure 6.28: Case 8010 Combine Display

*Checking Voltage Range from the Combine Cab (Case IH 5130/6130/7130, 7010/8010; 7120/8120/9120; 7230/8230/9230)*

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

### CAUTION

**Check to be sure all bystanders have cleared the area.**


- Position the header 150 mm (6 in.) above the ground, and unlock the float module float.

## SETTING UP AUTO HEADER HEIGHT CONTROL

2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.


**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.



**Figure 6.29: Float Lock**

3. Adjust cable take-up bracket (B) (if necessary) until pointer (A) on float indicator is on 0.



**Figure 6.30: Float Indicator box**

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Ensure header float is unlocked.
5. Select DIAGNOSTICS (A) on the MAIN page. The DIAGNOSTICS page opens.
6. Select SETTINGS. The SETTINGS page opens.




Figure 6.31: Case IH Combine Display

7. Select the GROUP arrow (A). The GROUP dialog box opens.




Figure 6.32: Case IH Combine Display

8. Select HEADER HEIGHT/TILT (A). The PARAMETER page opens.




Figure 6.33: Case IH Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

9. Select LEFT HEADER HEIGHT SEN (A), and then select the GRAPH button (B). The exact voltage is displayed at top of page. Raise and lower the header to see the full range of voltage readings.
10. If the sensor voltage is not within the low and high limits or, if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).




Figure 6.34: Case IH Combine Display

### Calibrating the Auto Header Height Control (Case IH 5130/6130/7130, 7010/8010; 7120/8120/9120; 7230/8230/9230)

For best performance from the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### NOTE:

This procedure applies to combines with a software version below 28.00. For instructions on calibrating the AHHC for combines with software version 28.00 or above, refer to [Calibrating the Auto Header Height Control \(Case Combines with Version 28.00 or Higher Software\), page 160](#).

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Ensure all header and float module electrical and hydraulic connections are made.
3. Select TOOLBOX on the MAIN page, and then select HEADER.
4. Set appropriate HEADER STYLE.



Figure 6.35: Case IH Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Set AUTO REEL SPEED SLOPE.
6. Set HEADER PRESSURE FLOAT to NO if equipped, and ensure REEL DRIVE is HYDRAULIC.




Figure 6.36: Case IH Combine Display

7. Install REEL FORE-BACK (if applicable).
8. Set HEIGHT SENSITIVITY to desired value. The recommended starting point is 180.




Figure 6.37: Case IH Combine Display

9. Install FORE-AFT CONTROL and HDR FORE-AFT TILT (if applicable).




Figure 6.38: Case IH Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

10. Press HEAD2 at bottom of page.
11. Ensure HEADER TYPE is DRAPER.

**NOTE:**

If recognition resistor is plugged in to header harness, you will not be able to change this.

12. Set cutting type to PLATFORM.
13. Set appropriate HEADER WIDTH and HEADER USAGE.




Figure 6.39: Case IH Combine Display

### *Calibrating the Auto Header Height Control (Case Combines with Version 28.00 or Higher Software)*

For best performance of the auto header height control (AHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Select TOOLBOX on the MAIN page, and then select HEADER SETUP.
3. Locate the HEADER SUB TYPE field. It will be located on either the HEAD 1 or the HEAD 2 tab.
4. Select 2000 (A).



Figure 6.40: Case IH Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Locate the HEADER SENSORS and HEADER PRESSURE FLOAT fields. They will be located on either the HEAD 1 or the HEAD 2 tab.
6. Select ENABLE (A) in the HEADER SENSORS field.
7. Select NO (B) in the HEADER PRESSURE FLOAT field.




Figure 6.41: Case IH Combine Display

8. Ensure AUTO HEIGHT icon (A) appears on the monitor and is displayed as shown at location (B). When the header is set for cutting on the ground, this verifies that the combine is correctly using the potentiometer on the header to sense ground pressure.

**NOTE:**

AUTO HEIGHT field (B) may appear on any of the RUN tabs and not necessarily on the RUN 1 tab.




Figure 6.42: Case IH Combine Display

9. Select CALIBRATION on the combine display, and press the right arrow navigation key to enter the information box.
10. Select HEADER (A), and press ENTER. The CALIBRATION dialog box opens.

**NOTE:**

You can use the up and down navigation keys to move between options.




Figure 6.43: Case IH Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

11. Follow the calibration steps in the order in which they appear in the dialog box. As you proceed through the calibration process, the display will automatically update to show the next step.

**NOTE:**

Pressing the ESC key during any of the steps or letting the system sit idle for more than 3 minutes will cause the calibration procedure to stop.

**NOTE:**

Refer to your combine operator's manual for an explanation of any error codes.



Figure 6.44: Case IH Combine Display

12. When all steps have been completed, CALIBRATION SUCCESSFUL message is displayed on the page. Exit the CALIBRATION menu by pressing the ENTER or ESC key.

**NOTE:**

If float was set heavier to complete ground calibration procedure, adjust to recommended operating float after the calibration is complete.

13. If the unit does not function properly, conduct the maximum stubble height calibration.

### *Setting Preset Cutting Height (Case 7010/8010, 7120/8120/9120, 7230/8230/9230)*

To set the preset cutting height, follow these steps:

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Engage separator and header.
2. Manually raise or lower the header to the desired cutting height.
3. Press the SET #1 switch (A). The HEADER HEIGHT MODE lamp (C), next to the SET #1 switch, turns on.
4. Manually raise or lower the header to a second desired cutting height.
5. Press the SET #2 switch (B). The HEADER HEIGHT MODE lamp (D), next to the SET #2 switch, turns on.




Figure 6.45: Case Combine Controls

## SETTING UP AUTO HEADER HEIGHT CONTROL

- To swap between set points, press HEADER RESUME (A).
- To pick up header at headlands, press HEADER RESUME (A) twice. To lower, press HEADER RESUME (A).

**NOTE:**

You can fine adjust these set points by using the FINE ADJUST switch (A).

**NOTE:**

Pressing the HEADER RAISE/LOWER switch will disengage AUTO HEIGHT mode. Press HEADER RESUME to reengage.

**NOTE:**

The indicator reading with the header off the ground (6 in. [152 mm]) should be at 0 (B). If not, refer to Step 3., page 142. Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 (A) is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.46: Case Combine Controls




Figure 6.47: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.4 Challenger and Massey Ferguson Combines

#### Checking Voltage Range from the Combine Cab (Challenger and Massey Ferguson)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the auto header height control (AHHC) system.

3. Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.48: Float Lock




Figure 6.49: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Go to the FIELD page on the combine monitor, and then press the diagnostics icon. The MISCELLANEOUS page displays.
- Press the VMM DIAGNOSTIC button (A). The VMM DIAGNOSTIC page displays.




Figure 6.50: Challenger Combine Display

- Go to the ANALOG IN tab (A), and then select VMM MODULE 3 by pressing the text box below the four tabs. The voltage from the AHC sensor is now displayed on page as HEADER HEIGHT RIGHT POT and HEADER HEIGHT LEFT POT. The readings may be slightly different.




Figure 6.51: Challenger Combine Display

- Fully lower the combine feeder house (float module should be fully separated from the header).

**NOTE:**

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

- Read voltage.
- Raise header so cutterbar is 150 mm (6 in.) off the ground.
- Read voltage.
- If the sensor voltage is not within the low and high limits, or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#) or [Adjusting Voltage Limits: Two-Sensor System, page 148](#).



Figure 6.52: Challenger Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Engaging the Auto Header Height Control (Challenger and Massey Ferguson)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

The following system components are required in order for the auto header height control (AHHC) to work:


- Main module (PCB board) and header driver module (PCB board) mounted in card box in fuse panel module (FP)
- Multi-function control handle operator inputs
- Operator inputs mounted in the control console module (CC) panel

**NOTE:**

In addition to the above components, the electrohydraulic header lift control valve is an integral part of the system.

Engage the AHHC as follows:

1. Scroll through the header control options on the combine display using the header control switch until the AHHC icon (A) is displayed in the first message box. The AHHC will adjust the header height in relation to the ground according to the height setting and sensitivity setting.



**Figure 6.53: Challenger Combine Display**

### *Calibrating the Auto Header Height Control (Challenger and Massey Ferguson)*

**NOTE:**

For best performance of the auto header height control (AHHC) system, perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.

## SETTING UP AUTO HEADER HEIGHT CONTROL

2. On the FIELD page, press the DIAGNOSTICS icon (A). The MISCELLANEOUS page appears.




Figure 6.54: Challenger Combine Display

3. Press the CALIBRATIONS button (A). The CALIBRATIONS page appears.




Figure 6.55: Challenger Combine Display

4. Press the HEADER button (A). The HEADER CALIBRATION page displays a warning.




Figure 6.56: Challenger Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Read the warning message, and then press the green check mark button.




Figure 6.57: Challenger Combine Display

6. Follow the on-screen prompts to complete calibration.

**NOTE:**

The calibration procedure can be cancelled at anytime by pressing the cancel button in the bottom right corner of the screen. While the header calibration is running, the calibration can also be canceled by using the up, down, tilt right, or tilt left buttons on the control handle.

**NOTE:**

If the combine does not have header tilt installed or if it is inoperable, you may receive warnings during calibration. Press the green check mark if these warnings appear. This will not affect the AHHC calibration.




Figure 6.58: Challenger Combine Display

### *Adjusting the Header Height (Challenger and Massey Ferguson)*

Once the auto header height control (AHHC) is activated, press and release the HEADER LOWER button on the control handle. The AHHC will automatically lower the header to the selected height setting.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

You can adjust the selected AHHC height using the HEIGHT ADJUSTMENT knob (A) on the control console. Turning the knob clockwise increases the selected height, and turning the knob counterclockwise decreases the selected height.




**Figure 6.59: Height Adjustment Knob on the Combine Control Console**

### *Adjusting the Header Raise/Lower Rate (Challenger and Massey Ferguson)*

**NOTE:**


Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Press the Header icon (A) on the FIELD page. The HEADER page displays.



**Figure 6.60: Challenger Combine Display**

2. Press HEADER CONTROL (A). The HEADER CONTROL page displays.



**Figure 6.61: Challenger Combine Display**

## SETTING UP AUTO HEADER HEIGHT CONTROL

3. Go to the TABLE SETTINGS tab.
4. Press up arrow on MAX UP PWM to increase percentage number and increase raise speed; Press down arrow on MAX UP PWM to decrease percentage number and decrease raise speed.
5. Press up arrow on MAX DOWN PWM to increase percentage number and increase lower speed; Press down arrow on MAX DOWN PWM to decrease percentage number and decrease lower speed.




Figure 6.62: Challenger Combine Display

### *Setting the Sensitivity of the Auto Header Height Control (Challenger and Massey Ferguson)*

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Press the HEADER icon on the FIELD page. The HEADER page appears.
2. Press the HEADER CONTROL button (A). The HEADER CONTROL page appears. You can adjust sensitivity on this page using the up and down arrows.




Figure 6.63: Challenger Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

3. Adjust the sensitivity to the maximum setting.
4. Activate the AHHC, and press the HEADER LOWER button on the control handle.
5. Decrease the sensitivity until the feeder house remains steady and does not bounce up and down.

**NOTE:**

This is the maximum sensitivity and is only an initial setting. The final setting must be made in the field as the system reaction will vary with changing surfaces and operating conditions.

**NOTE:**

If maximum sensitivity is not needed, a less sensitive setting will reduce the frequency of header height corrections and component wear. Partially opening the accumulator valve will cushion the action of the header lift cylinders and reduce header hunting.



Figure 6.64: Challenger Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.5 Gleaner R65/R66/R75/R76 and S Series Combines

#### Checking Voltage Range from the Combine Cab (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.65: Float Lock

3. Ensure pointer (A) on the float indicator box is on 0. If necessary, adjust the cable take-up bracket (B) until pointer is on 0.





Figure 6.66: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL



**Figure 6.67: Combine Heads Up Display**

4. Ensure header float is unlocked.
5. Press and hold button (A) on the heads-up display for 3 seconds to enter diagnostic mode.
6. Scroll down using button (B) until LEFT is displayed on the LCD screen.
7. Press the OK button (C). The number indicated on the LCD screen is the voltage reading from the sensor of the AHHC. Raise and lower the header to see the full range of voltage readings.

### *Engaging the Auto Header Height Control (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

The following system components are required in order for the auto header height control (AHHC) to work:

- Main module (PCB board) and header driver module (PCB board) mounted in card box in fuse pane module (FP).
- Multi-Function Control Handle operator inputs.
- Operator inputs mounted in the control console module (CC) panel.

**NOTE:**

In addition to the above components, the electro hydraulic header lift control valve also is an integral part of the system.


## SETTING UP AUTO HEADER HEIGHT CONTROL



1003579

**Figure 6.68: Combine Auto Header Height Controls**

1. Press the AUTO MODE (A) button until the AHC LED light (B) begins flashing. If the RTC light is flashing, press the AUTO MODE (A) button again until it switches to AHC.
2. Briefly press button (A) on the control handle. The AHC light should change from flashing to solid. The header also should drop toward the ground. The AHC is now engaged and can be adjusted for height and sensitivity.
3. Use controls to adjust height and sensitivity to changing ground conditions such as shallow gullies and field drainage trenches.



1003580

**Figure 6.69: Control Handle**

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Calibrating the Auto Header Height Control (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

Calibration should be done on flat, level ground without the header clutches engaged. Header height and header tilt must not be in auto or standby modes. The engine rpm must be above 2000 rpm. The header tilt option on 2004 and earlier model combines does not work with MacDon headers. This system will have to be removed and disabled in order to calibrate the auto header height control (AHHC). Refer to combine manual for instructions.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.



**Figure 6.70: Combine Auto Header Height Controls**

A - AUTO MODE Button  
D - Raise Header  
G - CAL2 Button

B - AHHC Light  
E - Lower Header

C - CAL1 Button  
F - AUTO Mode

#### **NOTE:**

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

1. Ensure center-link is set to D.
2. Press AUTO MODE button (A) until the AHHC light (B) is illuminated.
3. Press and hold CAL1 button (C) until you see the following lights flash: raise header (D), lower header (E), tilt auto mode (F), and AHHC (B).
4. Fully lower the header, and continue to hold the HEADER LOWER button for 5–8 seconds to ensure float module has separated from header.

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Press CAL2 button (G) until lower header light (E) stops flashing, and release it when the raise header light (D) begins flashing.
6. Raise header to its maximum height (ensure the header is resting on the down-stop pads).
7. Press CAL2 button (G) until the raise header light (D) turns off.

### NOTE:

The following steps are applicable only to 2005 and newer combines with the Smartrac feeder house.

8. Wait for the HEADER TILT LEFT light (not shown) to start flashing, and then tilt header to the maximum left position.
9. Press CAL2 button (G) until the HEADER TILT LEFT light (not shown) stops flashing, and release button when the HEADER TILT RIGHT light (not shown) begins flashing.
10. Tilt the header to the maximum right position.
11. Press CAL2 button (G) until all of the following lights flash: raise header (D), lower header (E), height auto mode (A), right header and left header (not shown), and tilt auto mode (F).
12. Center the header.
13. Press CAL1 button (C) to exit calibration and save all values to the memory. All lights should stop flashing.

### *Turning off the Accumulator (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

The accumulator will affect the combine's reaction time and greatly inhibit the auto header height control's performance.

Refer to the combine operator's manual for proper procedure when turning accumulator off and on. For best performance, turn the feeder house accumulator off.

### NOTE:

The accumulator is located in front of the front left axle beam.



**Figure 6.71: Combine Accumulator On/Off Switch**

A - Accumulator Lever (Off Position)

### *Adjusting the Header Raise/Lower Rate (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

The auto header height control (AHHC) system's stability is affected by hydraulic flow rates. Ensure that the header raise (A) and header lower (B) adjustable restrictors in the hydraulic valve block are adjusted so that it takes approximately 6 seconds to raise the header from ground level to maximum height (hydraulic cylinders fully extended), and approximately 6 seconds to lower the header from maximum height to ground level.

If there is too much header movement (for example, hunting) when the header is on the ground, adjust the lower rate to a slower rate of drop: 7 or 8 seconds.

### NOTE:

Make this adjustment with the hydraulic system at normal operating temperature (54.4°C [130°F]) and the engine running at full throttle.




Figure 6.72: Header Raise and Lower Adjustable Restrictors

### Adjusting Ground Pressure (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

To adjust header height, ensure the header is in auto header height control (AHHC) mode. This is indicated by the AUTO MODE LED light (A) displaying a continuous, solid light. The header will lower to the height (ground pressure) corresponding to the position selected with the height control knob (B).

Turn the knob counterclockwise for minimum ground pressure, and clockwise for maximum ground pressure.




Figure 6.73: AHHC Console

## SETTING UP AUTO HEADER HEIGHT CONTROL

### NOTE:

The indicator reading with the header off the ground (152 mm [6 in.]) should be at 0 (B). If not, refer to Step 3., page 142. Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 (A) is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.74: Float Indicator Box

### *Adjusting the Sensitivity of the Auto Header Height Control (AHHC) (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.



Figure 6.75: Auto Header Height Control Console

## SETTING UP AUTO HEADER HEIGHT CONTROL

The SENSITIVITY ADJUSTMENT dial (A) controls the distance the cutterbar must travel up or down before the AHHC reacts and raises or lowers the feeder house.

When the SENSITIVITY ADJUSTMENT dial (A) is set to maximum (turned completely clockwise), only small changes in ground height are needed to cause the feeder house to raise or lower. In this position, the cutterbar moves up and down approximately 19 mm (3/4 in.) before the control module signals the hydraulic control valve to raise or lower the header frame.

When the SENSITIVITY ADJUSTMENT dial (A) is set to minimum (turned completely counterclockwise), large changes in ground height are needed to cause the feeder house to raise or lower. In this position, the cutterbar moves up and down approximately 51 mm (2 in.) before the control module signals the hydraulic control valve to raise or lower the header frame.

The HEADER SENSE LINE input also changes the range of the sensitivity. When connected to a draper, the counterclockwise position (least sensitive) allows for approximately 102 mm (4 in.) of vertical travel before correction is made.

### *Troubleshooting Alarms and Diagnostic Faults (Gleaner R65/R66/R75/R76 and Pre-2016 S Series)*

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **Display type:**


Displayed on tachometer (A) as XX or XXX.



**Figure 6.76: Tachometer**

## SETTING UP AUTO HEADER HEIGHT CONTROL

Displayed on LCD (A) as XX in. or XXX cm.



**Figure 6.77: Combine Heads up Display**

### Alarm conditions:

If an error message is received from the fuse panel, an audible alarm sounds. The LCD on the electronic instrument panel (EIP) indicates the header system in error as HDR CTRL followed by HGT ERR for height, and HDR CTRL followed by TILT ERR for tilt. The header height LED flashes yellow two times every second.

The alarm also is noted by the buzzer sounding five times every 10 seconds.

When an alarm condition occurs, a green LED flashes on and off (green, yellow, or red depending on the input). In addition, a message is displayed on the LCD to identify the nature of the alarm. For example, HYD TEMP, OPEN, SHRT will be flashed alternately.

## SETTING UP AUTO HEADER HEIGHT CONTROL

**Diagnostic fault failures:** Refer to Figure 6.77: *Combine Heads up Display, page 180*.

Pressing the header height switch (B) for a minimum of 5 seconds will put the EIP in header diagnostic mode. The LCD (shown on previous page) will display the message HDR DIAG when the EIP has entered header diagnostic mode.

In this mode, after 3 seconds, header fault parameter labels are displayed on the EIP LCD. All the information displayed is read-only.

The OK (C) and CLEAR (D) buttons allow you to scroll through the list of parameters. If there are no active fault codes, the EIP LCD will display NO CODE.

When a parameter is displayed, its label is displayed for 3 seconds, after which its value is automatically displayed.

Pressing the OK button (C) while the value is displayed will advance to the next parameter and display its label.

When a parameter label is displayed and the OK button (C) is pressed before 3 seconds, the parameter's value will be displayed.

Pressing AREA (E) will cycle through the options. When LEFT is displayed on the LCD, press the OK button (C), and the auto header height control (AHHC) voltage will be shown on the display.

Press the DIST button (F) to cycle back through the table.

Press the CLEAR button (D) to exit header diagnostics and return to normal mode.

Refer to [6.1.14 Sensor Operation, page 258](#).

### 6.1.6 Gleaner S9 Series Combines

#### *Setting up the Header (Gleaner S9)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

The AGCO Tyton terminal (A) is used to set up and manage a MacDon draper header on a Gleaner S9 combine. Use the touch screen display to select the desired item on the screen.



**Figure 6.78: Gleaner S9**

A - Tyton Terminal    B - Hydro Handle / Ground Speed Lever  
C - Throttle Lever    D - Header Control Cluster

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. On the top right quadrant of the home page, touch the COMBINE icon (A). The COMBINE MAIN MENU opens.



Figure 6.79: Combine Icon on Home Page

2. On the COMBINE MAIN MENU, touch HEADER SETTINGS (A). The HEADER SETTINGS page opens.




Figure 6.80: Header Settings in Combine Main Menu

## SETTING UP AUTO HEADER HEIGHT CONTROL

3. Touch the HEADER CONFIGURATION field (A). A page showing predefined headers opens.

- If your MacDon header is already set up, it appears on the header list. Touch the MacDon header title (B) to highlight the selection in blue, and then touch the green check mark (E) to continue.
- If only the default header (D) is shown, touch the ABC button (C), and use the on-screen keyboard to enter the MacDon header information. When complete, select one of the following options to return to the HEADER SETTINGS page:
  - The green check mark (E) saves the settings
  - The garbage can icon (F) deletes the highlighted header from the list
  - The red X (G) cancels the change(s)





Figure 6.81: Header Configuration Menu on Header Settings Page

## SETTING UP AUTO HEADER HEIGHT CONTROL

- To specify the type of header installed on the machine, touch the HEADER TYPE field (A).




Figure 6.82: Header Settings

- A list of predefined header types appears.
  - For MacDon D1 Series Draper and FD1 Series FlexDraper headers, touch POWER FLOW (A)
  - Touch the green check mark (B) to save the selection and continue




Figure 6.83: Header Type

- Make sure that the HEADER HAS REEL ATTACHED check box (A) is checked.




Figure 6.84: Header Settings

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. Touch the REEL DIAMETER field (A) and a numeric keypad displays. Enter **40** for a MacDon reel.
8. Touch the REEL PPR (Pulses Per Revolution) field (B) and enter **30** as the value for your MacDon header. (PPR is determined by the number of teeth on the reel speed sprocket).




Figure 6.85: Header Settings

9. Touch the green check mark (B) at the bottom of the numeric keypad (A) when complete, or the red X to cancel.




Figure 6.86: Numeric Keypad

10. When complete, touch the green check mark (A) at the bottom of the HEADER SETTINGS page.




Figure 6.87: Header Settings Page

### Setting up Reel Settings (Gleaner S9)

#### CAUTION

Clear the area of other persons, pets etc. Keep children away from machinery. Walk around the machine to be sure no one is under, on, or close to it.

## SETTING UP AUTO HEADER HEIGHT CONTROL

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. From the COMBINE MAIN MENU, touch REEL SETTINGS (A) to open the REEL SETTINGS page.



Figure 6.88: Reel Settings on Combine Main Menu

2. To set minimum reel speed, touch the SPEED MINIMUM FIELD (B). The on-screen keyboard displays. Enter the desired value. Touch the green check mark to accept the new value, or the red X to cancel. The reel speed (in mph) and rpm are shown.

### NOTE:

At the bottom of the REEL SETTINGS page, the reel diameter and reel pulses per revolution (PPR) are displayed. These values have already been set in the HEADER SETTINGS page.

3. Reel speed is calibrated in the REEL SETTINGS page by touching the CALIBRATE button (A) in the top right of the page.
4. The CALIBRATION WIZARD opens and displays a hazard message warning page.
5. Make sure to meet all the conditions listed on the CALIBRATION WIZARD warning page. Press the green check mark to accept and start reel calibration. Pressing the red X will cancel the calibration procedure.




Figure 6.89: Reel Settings Calibration




Figure 6.90: Calibration Wizard

## SETTING UP AUTO HEADER HEIGHT CONTROL

- An informational message appears in the CALIBRATION WIZARD that reel calibration has started. The reel will begin turning slowly and increase to high speed. A progress bar is provided. If necessary, touch the red X to cancel. Otherwise, wait for the message that reel calibration has completed successfully. Touch the green check mark to save the calibrated settings.




Figure 6.91: Calibration Progress

### Setting up Automatic Header Controls (Gleaner S9 Series)

Automatic header functions are configured on the HEADER SETTINGS page.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

- Automatic Control Functions:** There are toggle (OFF/ON) switches on the HEADER SETTINGS page for the automatic control functions. For MacDon headers, ensure the following two functions are enabled as shown:

- RTC (return to cut) (A)
- AHHC (automatic header height control) (B)

All other switches are disabled (not highlighted).

- The **Sensitivity** setting (C) controls how responsive a control (RTC or AHHC) is to a given change in sensor feedback. The setting fields are located directly below the toggle switches. To enter a new sensitivity setting, touch the setting field below the specific toggle switch, and enter the new value in the on-screen keyboard.

- Increase sensitivity if the combine does not change the feeder position quickly enough when in Auto Mode.
- Decrease sensitivity if the combine hunts for a position in Auto Mode.

#### NOTE:

Recommended sensitivity starting points for MacDon headers are:

- 50** for RTC (A)
- 60** for AHHC (B)




Figure 6.92: Automatic Controls and Sensitivity Settings

## SETTING UP AUTO HEADER HEIGHT CONTROL

3. **Header Speed:** The HEADER CONTROL SPEED area (A) on the HEADER SETTINGS page is used to adjust the following speeds:

- Tilt left and right is the lateral tilt of the combine faceplate
- Header up and down (slow and fast speeds) is a two-stage button with slow speed on the first detent and fast on the second

**NOTE:**

Recommended header control speed starting points

- Slow: 45 up / 40 down
- Fast: 100 up / 100 down

4. **Header Offsets (A):** Offset distances are important for yield mapping. There are two adjustable dimensions on the HEADER SETTINGS page:

- Header Lateral Offset: the distance between the centerline of the header and the centerline of the machine. This should be set at **0** for a MacDon header.
- Feeder House to Cutter: the distance from the machine interface to the cutterbar. This should be set at **68** for a MacDon header.




Figure 6.93: Header Speed Control Settings




Figure 6.94: Header Offset Settings

## SETTING UP AUTO HEADER HEIGHT CONTROL




Figure 6.95: MacDon Header Settings Inputs

### Calibrating the Header (Gleaner S9 Series)

The auto header control functions are configured on the HEADER SETTINGS page.

#### CAUTION

Clear the area of other persons, pets etc. Keep children away from machinery. Walk around the machine to be sure no one is under, on, or close to it.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. On the COMBINE MAIN MENU, touch HEADER SETTINGS (A).



Figure 6.96: Combine Main Menu

## SETTING UP AUTO HEADER HEIGHT CONTROL

2. Touch CALIBRATE (A) at the bottom right of the page. The HEADER CALIBRATION page displays.




Figure 6.97: Calibration

The right side of the page shows the Header Calibration information (A). Results are shown for a variety of sensors (B)

- Left and right header sensor (voltage) (values will be the same with MacDon headers)
- Header height sensor (mA)
- Tilt position sensor (mA)

The following valid modes are shown with check marks (C) below the sensor values (B):

- Return to cut
- Automatic header height control




Figure 6.98: Header Calibration Page

### CAUTION

Clear the area of other persons, pets etc. Keep children away from machinery. Walk around the machine to be sure no one is under, on, or close to it.

3. On the ground speed lever (GSL), touch the HEADER DOWN button (A). Sensor values start changing on the HEADER CALIBRATION page as the header lowers.

#### NOTE:

The header needs to be lowered all the way, and then raised off the ground. The range should be between **0.5 and 4.5 V**. If the value is not in that range, the sensor needs to be adjusted. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#) or [Adjusting Voltage Limits: Two-Sensor System, page 148](#).



Figure 6.99: Header Down Switch

## SETTING UP AUTO HEADER HEIGHT CONTROL

- When the sensor values are stable, touch the CALIBRATE icon (A).




Figure 6.100: Header Calibration

- The hazard message warning page for HEADER CALIBRATION appears. Make sure that all conditions are met.
- Touch the green check mark at the bottom of the page to start the CALIBRATION WIZARD.




Figure 6.101: Header Calibration Warning

A progress bar is provided and the wizard can be stopped at any time by touching the red X. The header moves automatically and erratically during this process.




Figure 6.102: Calibration In Progress

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. When the calibration is complete, a message displays, and summary information (A) is shown. Green check marks confirm the functions have been calibrated (B). Touch the bottom green check mark (C) to save.




Figure 6.103: Completed Calibration Page

### TIP:

Touch the CALIBRATION icon (A) on the COMBINE MAIN MENU page to open the CALIBRATION MENU where you can choose from a variety of calibrations including header and reel calibration.



Figure 6.104: Direct Calibration Menu

## Operating with a Gleaner S9 Combine

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

The following controls are used to operate the auto header height control (AHHC) functions:

- Tyton Terminal (A)
- Hydro Handle / Ground Speed Lever (B)
- Throttle Lever (C)
- Header Control Cluster (D)

Use the combine operator's manual to familiarize yourself with the controls.



Figure 6.105: Gleaner S9

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. With the header running, set lateral tilt switch (A) to MANUAL.
2. Engage the AHHC by pressing the switch (B) upward to the I position.




Figure 6.106: Header Control Cluster

3. Press the AHHC control switch (A) on the ground speed lever (GSL) to engage the AHHC. The header moves to the current setpoint position.




Figure 6.107: AHHC on GSL

4. Use the HEADER HEIGHT SETPOINT control dial (A) as necessary to fine-tune the position.




Figure 6.108: Header Control Cluster

### *Header In-Field Settings*

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. To view header group settings, touch the HEADER icon (A) on the right side of the home page.
2. The following information is displayed:
  - Current position of the header (B).
  - Setpoint cut-off position (C) (indicated by red line)
  - HEADER symbol (D) – touch to adjust the setpoint cut-off position using the scroll wheel on the right-hand side of the Tyton terminal.
  - Cut height for the AHHC (E) – fine-tune with the header height setpoint control dial on the header control cluster.
  - Header working width (F)
  - Header pitch (G)
3. Touching a field opens the on-screen keyboard so that values can be adjusted. Enter the new value and touch the green check mark when complete.

### NOTE:

The scroll wheel (A) is located on the right side of the Tyton terminal.

### NOTE:

Header height setpoint control dial (A) is on the header control cluster.




Figure 6.109: Header Groups



Figure 6.110: Scroll Wheel for Adjustments




Figure 6.111: Header Control Cluster

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.7 John Deere 60 Series Combines

#### Checking Voltage Range from the Combine Cab (John Deere 60 Series)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**CAUTION**

Check to be sure all bystanders have cleared the area.

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.112: Float Lock

3. Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.





Figure 6.113: Float Indicator box

## SETTING UP AUTO HEADER HEIGHT CONTROL



**Figure 6.114: John Deere Combine Display**

4. Press the DIAGNOSTIC button (D) on the monitor—DIA appears on the monitor.
5. Press the UP button (A) until EO1 appears on the monitor—this is the header adjustments.
6. Press the ENTER button (C).
7. Press the UP (A) or DOWN button (B) until 24 is displayed on the top portion of the monitor—this is the voltage reading for the sensor.
8. Ensure header float is unlocked.
9. Start the combine, and fully lower feeder house to the ground.

**NOTE:**

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

10. Check the sensor reading on the monitor. The reading should be above 0.5 volts.
11. Raise the header so it is just off the ground. The reading on the monitor should read below 4.5 volts.
12. If the sensor voltage is not within the low and high limits or if the range between the low and high limits is insufficient, refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Calibrating the Auto Header Height Control (John Deere 60 Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.


#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **CAUTION**

**Check to be sure all bystanders have cleared the area.**

1. Ensure center-link is set to D.
2. Rest header on down stops, and unlock float module float.
3. Start the combine.
4. Press the DIAGNOSTIC button (A) on the monitor. DIA appears on the monitor.
5. Press the CAL button (B). DIA-CAL appears on the monitor.



**Figure 6.115: John Deere Combine Display**

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Press the UP or DOWN buttons until HDR appears on the monitor.
- Press the ENTER button. HDR H-DN appears on the monitor.




Figure 6.116: John Deere Combine Display

- Fully lower feeder house to the ground.

**NOTE:**

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

- Press the CAL button (A) to save the calibration of the header. HDR H-UP appears on the monitor.
- Raise the header 3 feet off the ground and press the CAL (A) button. EOC appears on the monitor.
- Press the ENTER button (B) to save the calibration of the header. Your AHHC is now calibrated.

**NOTE:**

If an error code appears during calibration, the sensor is out of voltage range and will require adjustment. Refer to [Checking Voltage Range from the Combine Cab \(John Deere 60 Series\)](#), page 195.

**NOTE:**

After the calibration is complete, adjust combine operation settings to ensure proper field operation.




Figure 6.117: John Deere Combine Display

### *Turning the Accumulator Off (John Deere 60 Series)*

The accumulator is a hydraulic device used to cushion the shock of hydraulic fluid when installing a heavy header onto the combine.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press the DIAGNOSTIC button (A) on the monitor. DIA appears on the monitor.
2. Press the UP button (B) until EO1 appears on the monitor, and press ENTER (D). This is the header adjustment.
3. Press the UP (B) or DOWN (C) button until 132 is displayed on the top portion of the monitor. This is the reading for the accumulator.
4. Press ENTER (D) to select 132 as the accumulator reading (this will allow you to change the display to a three-digit number so it has a 0 in it, for example, x0x).
5. Press the UP (B) or DOWN (C) button until the desired number is displayed, and press the CAL (E) button.
6. Press ENTER (D) to save the changes. The accumulator is now deactivated.




Figure 6.118: John Deere Combine Display

### *Setting the Sensing Grain Header Height to 50 (John Deere 60 Series)*

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

To set the sensing grain header height, follow these steps:

1. Press the DIAGNOSTIC button (A) on the monitor. DIA appears on the monitor.
2. Press the UP button (B) until EO1 appears on the monitor, and press ENTER (D). This is the header adjustment.
3. Press the UP (B) or DOWN (C) button until 128 is displayed on the top portion of the monitor. This is the reading for the sensor.
4. Press ENTER (D) to select 128 as the sensor reading (this will allow you to change the display to a three-digit number so it has a 50 in it).
5. Press the UP (B) or DOWN (C) button until the desired number is displayed, and press the CAL (E) button.
6. Press ENTER (D) to save the changes. The height is now set.




Figure 6.119: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### NOTE:

Do **NOT** use the active header float function (A) in combination with the MacDon auto header height control (AHHC)—the two systems will counteract one another. The header symbol (B) on the display should NOT have a wavy line under it and should appear exactly as shown on the Active Header Control Display in Figure 6.120: *John Deere Combine Display*, page 200.




Figure 6.120: John Deere Combine Display

### *Setting the Sensitivity of the Auto Header Height Control (John Deere 60 Series)*

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press the DIAGNOSTIC button (A) on the monitor. DIA appears on the monitor.
2. Press the UP button (B) until EO1 appears on the monitor, and press ENTER (D). This is the header adjustment.
3. Press the UP (B) or DOWN (C) button until 112 is displayed on the monitor. This is your sensitivity setting.

**NOTE:**

The lower the reading, the higher the sensitivity. Ideal operating range is typically between 50 and 80.




Figure 6.121: John Deere Combine Display

4. Press ENTER (D) to select 112 as the sensitivity setting (this will allow you to change the first digit of the number sequence).
5. Press UP (B) or DOWN (C) until the desired number is displayed, then press the CAL (E) button. This will bring you to the second digit. Repeat this procedure until the desired setting is achieved.
6. Press ENTER (D) to save changes.

**NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.

### *Adjusting the Threshold for the Drop Rate Valve (John Deere 60 Series)*

This procedure explains how to adjust the point at which the restrictor valve opens allowing full flow to the lift cylinders.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press the DIAGNOSTIC button (A) on the monitor. DIA appears on the monitor.
2. Press the UP button (B) until EO1 appears on the monitor and press ENTER (C). This is the header adjustment.
3. Press the UP (B) or DOWN button until 114 is displayed on the top portion of the monitor. This is the setting that adjusts when the fast drop rate starts with respect to the dead band.

**NOTE:**

The default setting is 100. Ideal operating range is typically between 60 and 85.




Figure 6.122: John Deere Combine Display

4. Press ENTER (C) to select 114 as the fast drop rate (this will allow you to change the first digit of the number sequence).
5. Press UP (B) or DOWN (E) until the desired number is displayed, then press the CAL button (D). This will bring you to the second digit. Repeat this procedure until the desired setting is achieved.
6. Press ENTER (C) to save changes.

**NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.8 John Deere 70 Series Combines

#### Checking Voltage Range from the Combine Cab (John Deere 70 Series)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**CAUTION**

Check to be sure all bystanders have cleared the area.

1. Position the header 150 mm ( 6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.123: Float Lock

3. Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.124: Float Indicator box

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Press the HOME PAGE button (A) on the main page of the monitor.



Figure 6.125: John Deere Combine Display

5. Ensure the three icons (A) depicted in the illustration at right appear on the monitor.



Figure 6.126: John Deere Combine Display

6. Use scroll knob (A) to highlight the middle icon (the green i) and press the check mark button (B) to select it. This will bring up the Message Center.




Figure 6.127: John Deere Combine Control Console

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. Use the scroll knob to highlight DIAGNOSTIC ADDRESSES (A) from the right column and select it by pressing the check mark button.
8. Use the scroll knob to highlight the drop-down box (B) and press the check mark button to select it.



Figure 6.128: John Deere Combine Display

9. Use the scroll knob to highlight LC 1.001 VEHICLE (A) and press the check mark button to select it.



Figure 6.129: John Deere Combine Display

10. Use the scroll knob to highlight the down arrow (A) and press the check mark button to scroll through the list until 029 DATA (B) is displayed and voltage reading (C) appears on the monitor.




Figure 6.130: John Deere Combine Display

11. Ensure header float is unlocked.
12. Start the combine and fully lower feeder house to the ground.

### NOTE:

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

## SETTING UP AUTO HEADER HEIGHT CONTROL

13. Check the sensor reading on the monitor.
14. Raise the header so it is just off the ground and recheck the sensor reading.
15. If the sensor voltage is not within the low and high limits or if the range between the low and high limits is insufficient, refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).

### Calibrating Feeder House Speed (John Deere 70 Series)

The feeder house speed must be calibrated before you calibrate the auto header height control (AHHC) system. Refer to the combine operator's manual for instructions.

### Calibrating the Auto Header Height Control (John Deere 70 Series)

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### CAUTION

Check to be sure all bystanders have cleared the area.

1. Ensure center-link is set to D.
2. Rest header on down stops and unlock float module float.
3. Start the combine.
4. Press the button located fourth from the left along the top of the monitor (A) to select the icon that resembles an open book with a wrench on it (B).
5. Press the top button (A) a second time to enter diagnostics and calibration mode.




Figure 6.131: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

6. Select HEADER in box (A) by scrolling down to the box using the scroll knob, and then pressing the check mark button (knob and button are shown in Figure 6.133: [John Deere Combine Control Console](#), page 207).
7. Scroll down to the lower right icon that resembles an arrow in a diamond (B) and press the check mark button to select it.




Figure 6.132: John Deere Combine Display



Figure 6.133: John Deere Combine Control Console

A - Scroll Knob

B - Check Mark Button

8. Follow the steps listed on the monitor to perform the calibration.

### NOTE:

If an error code appears on page, the sensor is not in the correct working range. Refer to [Checking Voltage Range from the Combine Cab \(John Deere S and T Series\)](#), page 210 to check and adjust the range.

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Setting the Sensitivity of the Auto Header Height Control (John Deere 70 Series)*

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.


#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Press button (A) twice and the current sensitivity setting will appear on the monitor (the lower the reading, the lower the sensitivity).
2. Use scroll knob (B) to adjust the sensitivity setting. The adjustment will be saved automatically.

#### **NOTE:**

If the page remains idle for a short period of time, it will automatically return to the previous page. Pressing the check mark button (C) also will return the monitor to the previous page.



**Figure 6.134: John Deere Combine Control Console**

#### **NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.



**Figure 6.135: John Deere Combine Display**

### *Adjusting the Manual Header Raise/Lower Rate (John Deere 70 Series)*

The weight of the header will dictate the rate at which the header can be raised or lowered during operation.

To manually adjust the header raise/lower rate, do the following steps:

#### **NOTE:**


Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press button (A) and the current raise/lower rate setting will appear on the monitor (the lower the reading, the slower the rate).
2. Use scroll knob (B) to adjust the rate. The adjustment will be saved automatically.

**NOTE:**

If the page remains idle for a short period of time, it will automatically return to the previous page. Pressing the check mark button (C) will also return the monitor to the previous page.



**Figure 6.136: John Deere Combine Control Console**

**NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.



**Figure 6.137: John Deere Combine Display**

## 6.1.9 John Deere S and T Series Combines

### Checking Voltage Range from the Combine Cab (John Deere S and T Series)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**CAUTION**

Check to be sure all bystanders have cleared the area.

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.

3. Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.138: Float Lock




Figure 6.139: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Press the CALIBRATION icon (A) on the main page of the monitor. The CALIBRATION page appears.




Figure 6.140: John Deere Combine Display

5. Press the DIAGNOSTIC READINGS icon (A) on the CALIBRATION page. The DIAGNOSTIC READINGS page appears. This page provides access to calibrations, header options, and diagnostic information.




Figure 6.141: John Deere Combine Display

6. Select AHHC RESUME (A) and a list of calibration options appears.



Figure 6.142: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. Select the AHHC SENSING option.
8. Press the icon that resembles an arrow in a box (A). The AHHC SENSING menu appears and five pages of information are displayed.



Figure 6.143: John Deere Combine Display

9. Press icon (A) until it reads Page 5 near the top of the page and the following sensor readings appear:
  - LEFT HEADER HEIGHT
  - CENTER HEADER HEIGHT
  - RIGHT HEADER HEIGHT

A reading is displayed for both left- and right sensors. On the MacDon header, there may be one sensor located in the float indicator box (standard) or two sensors located at the back of the float module side frame (optional).



Figure 6.144: John Deere Combine Display

10. Ensure header float is unlocked.
11. Start the combine and fully lower feeder house to the ground.

### NOTE:

You may need to hold the HEADER DOWN switch for a few seconds to ensure the feeder house is fully lowered.

12. Check the sensor reading on the monitor.
13. If the sensor voltage is not within the low and high limits or if the range between the low and high limits is insufficient refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).

## SETTING UP AUTO HEADER HEIGHT CONTROL


### *Calibrating the Auto Header Height Control (John Deere S and T Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### **NOTE:**


Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Rest header on down stops and unlock float module float.
3. Press the DIAGNOSTIC icon (A) on the main page of the monitor. The CALIBRATION page appears.



**Figure 6.145: John Deere Combine Display**

4. Select THRESHING CLEARANCE (A) and a list of calibration options appears.



**Figure 6.146: John Deere Combine Display**

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Select FEEDER HOUSE SPEED (A) and calibrate.
6. Select HEADER (B) and calibrate.




Figure 6.147: John Deere Combine Display

7. Press icon (A) with either FEEDER HOUSE SPEED or HEADER selected and the icon will turn green.




Figure 6.148: John Deere Combine Display

8. Click button (A) and instructions will appear on screen to guide you through the remaining calibration steps.

### NOTE:

If an error code appears during calibration, the sensor is out of voltage range and will require adjustment. Refer to [Checking Voltage Range from the Combine Cab \(John Deere S and T Series\)](#), page 210.




Figure 6.149: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Setting the Sensitivity of the Auto Header Height Control (John Deere S and T Series)*

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Press button (A) twice and the current sensitivity setting will appear on the monitor.




**Figure 6.150: John Deere Combine Command Center**

2. Press the – or + icon (A) to adjust rates.

#### **NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.



**Figure 6.151: John Deere Combine Display**

### *Adjusting the Manual Header Raise/Lower Rate (John Deere S and T Series)*

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press button (A) and the current sensitivity setting will appear on the monitor.



Figure 6.152: John Deere Combine Command Center

2. Press the – or + icon (A) to adjust rates.

**NOTE:**

The numbers depicted on the displays in these illustrations are for reference purposes only; they are not intended to represent the specific settings for your equipment.




Figure 6.153: John Deere Combine Display

**NOTE:**

The indicator reading with the header off the ground (6 in. [152 mm]) should be at 0 (B). If not, refer to Step 3., [page 142](#). Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 (A) is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.154: Float Indicator Box

### Setting Preset Cutting Height (John Deere S-Series)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Press the COMBINE – HEADER SETUP icon (A) on the main page. The COMBINE – HEADER SETUP page appears. This page is used to set various header settings such as reel speed, header width, and height of feeder house for acre counter engagement.



Figure 6.155: Combine Display

2. Select the COMBINE – HEADER SETUP AHC icon (A). The COMBINE – HEADER SETUP AHC screen appears.



Figure 6.156: Combine Display

3. Select the top-left and top-center icons for auto height sensing and return to cut.




Figure 6.157: Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

4. Select an appropriate ground pressure setting. Preset button 2 (B) on the joystick for a light ground pressure setting in muddy or soft soil conditions, or preset button 3 (C) for a heavy ground pressure setting in harder soil conditions and a faster ground speed.

**NOTE:**

Preset button 1 (A) is reserved for header lift on the headland and is not used for ground cutting.



Figure 6.158: Joystick Buttons

**NOTE:**

The indicator reading with the header off the ground (152 mm [6 in.]) should be at 0 (A). If not, refer to [Manually Checking Voltage Range: One-Sensor System, page 141](#). Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.159: Float Indicator Box

5. Use control knob (A) to scroll through the different button options.



Figure 6.160: Combine Control Console

## SETTING UP AUTO HEADER HEIGHT CONTROL

**NOTE:**

When the AHHC is engaged, the AHHC icon (A) appears on the monitor and the number indicating which button was pressed (B) is displayed on the screen.




Figure 6.161: Combine Display

### *Calibrating Feeder House Fore/Aft Tilt Range (John Deere S and T Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

This procedure applies only to model year 2015 and later John Deere S and T Series combines.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

The feeder house fore/aft tilt is controlled by buttons (C) and (D) at the back of the hydro handle.



Figure 6.162: John Deere Hydro Handle

## SETTING UP AUTO HEADER HEIGHT CONTROL

### NOTE:

The feeder house fore/aft tilt controls can be changed to work with buttons E and F by pressing the hydro handle icon (A) and then selecting FEEDER HOUSE FORE/AFT TILT from the drop-down menu (B).




Figure 6.163: John Deere Combine Display

To calibrate the feeder house fore/aft tilt range, follow these steps:

1. Ensure center-link is set to D.
2. Rest header on down stops and unlock float module float.
3. Press the DIAGNOSTIC icon (A) on the main page of the monitor. The CALIBRATION page displays.




Figure 6.164: John Deere Combine Display

4. Select the CALIBRATIONS drop-down menu (A) to view the list of calibration options.




Figure 6.165: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Press the arrow (A) to cycle up through the calibration options and select FEEDER HOUSE FORE/AFT TILT RANGE.




Figure 6.166: John Deere Combine Display

6. Press the ENTER icon (A).




Figure 6.167: John Deere Combine Display

7. Follow the instructions that appear on the screen. As you proceed through the calibration process, the display will automatically update to show the next step.

### NOTE:

If an error code appears during calibration, the sensor is out of voltage range and will require adjustment. Refer to [Checking Voltage Range from the Combine Cab \(John Deere S and T Series\)](#), page 210.




Figure 6.168: John Deere Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.10 Lexion 500 Series Combines


#### *Calibrating the Auto Header Height Control (Lexion 500 Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

**NOTE:**


Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Use the < key (A) or > key (B) to select AUTO HEADER, and press the OK key (C). The E5 page displays whether the automatic header height is on or off.



**Figure 6.169: Lexion Combine Controls**

3. Use the – key (A) or the + key (B) to turn the AHHC on, and press the OK key (C).
4. Engage the threshing mechanism and the header.



**Figure 6.170: Lexion Combine Controls**

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Use the < or > key to select CUTT.HEIGHT LIMITS, and press the OK key (C).
- Follow the procedure displayed on the screen to program the upper and lower limits of the header into the CEBIS.




Figure 6.171: Lexion Combine Display

- Use the < or > key to select SENSITIVITY CAC, and press the OK key (C).

**NOTE:**

Setting the sensitivity of the AHHC system impacts the reaction speed of the AHHC on the header.

- Use the – key or the + key to change the setting of the reaction speed, and press the OK key (C).




Figure 6.172: Lexion Combine Display

- Use line (A) or value (B) to determine the sensitivity setting.

**NOTE:**

The setting can be adjusted from 0–100%. When sensitivity is adjusted to 0%, the signals from the sensing bands have no effect on the automatic cutting height adjustment. When sensitivity is adjusted to 100%, the signals from the sensing bands have maximum effect on the automatic cutting height adjustment. The recommended starting point is 50%.




Figure 6.173: Lexion Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Setting Cutting Height (Lexion 500 Series)

Cutting heights can be programmed into the preset cutting height and auto contour systems. Use the preset cutting height system for cutting heights above 150 mm (5.9 in.), and use the auto contour system for cutting heights below 150 mm (5.9 in.).

### Setting Preset Cutting Height (Lexion 500 Series)

#### CAUTION

Check to be sure all bystanders have cleared the area.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Start the engine.
2. Activate the machine enable switch.
3. Engage the threshing mechanism.
4. Engage the header.
5. Briefly press button (A) in order to activate the auto contour system, or briefly press button (B) in order to activate the preset cutting height system.

#### NOTE:

Button (A) is used only with auto header height control (AHHC) function. Button (B) is used only with the return to cut function.



Figure 6.174: Joystick Buttons

6. Use the < key (C) or > key (D) to select the CUTTING HEIGHT page, and press the OK key (E).
7. Use the – key (A) or the + key (B) to set the desired cutting height. An arrow indicates the selected cutting height on the scale.




Figure 6.175: Lexion Combine Controls

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Briefly press button (A) or button (B) in order to select the set point.
- Repeat Step 7., [page 224](#) for the set point.



Figure 6.176: Joystick Buttons

### Setting Cutting Height Manually (Lexion 500 Series)

#### CAUTION

Check to be sure all bystanders have cleared the area.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

- Use button (A) to raise the header or button (B) to lower the header to the desired cutting height.
- Press and hold button (C) for 3 seconds to store the cutting height into the CEBIS (an alarm will sound when the new setting has been stored).
- Program a second set point, if desired, by using button (A) to raise the header or button (B) to lower the header to the desired cutting height, and briefly press button (C) to store the second set point into the CEBIS (an alarm will sound when the new setting has been stored).

#### NOTE:

For above the ground cutting, repeat Step 1., [page 225](#), and use button (D) instead of button (C) while repeating Step 2., [page 225](#).



Figure 6.177: Joystick Buttons

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Setting the Sensitivity of the Auto Header Height Control (Lexion 500 Series)

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

#### NOTE:

The upper and lower limits of the header must be programmed into the CEBIS before adjusting the sensitivity of the AHHC system. The setting can be adjusted from 0–100%. When sensitivity is adjusted to 0%, the signals from the sensing bands have no effect on the automatic cutting height adjustment. When sensitivity is adjusted to 100%, the signals from the sensing bands have maximum effect on the automatic cutting height adjustment. The recommended starting point is 50%.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Use the < key (C) or the > key (D) to select SENSITIVITY CAC, and press the OK key (E).
2. Use the – key (A) or the + (B) key to change the reaction speed setting, and press the OK key (E).




Figure 6.178: Lexion Combine Controls

3. Use line (A) or value (B) to determine the sensitivity setting.





Figure 6.179: Lexion Combine Display

# SETTING UP AUTO HEADER HEIGHT CONTROL



1003798

Figure 6.180: Flow Chart for Setting the Sensitivity of the Float Optimizer

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Adjusting Auto Reel Speed (Lexion 500 Series)

The preset reel speed can be set when the automatic header functions are activated.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Use the < or > key to select REEL WINDOW. Window E15 will display the current advance or retard speed of the reel in relation to the ground speed.




Figure 6.181: Lexion Combine Display

2. Press the OK key (C) to open the REEL SPEED window.
3. Use the – key (A) or the + key (B) to set the reel speed in relation to the current ground speed. Window E15 will display the selected reel speed.




Figure 6.182: Lexion Combine Controls

4. Manually adjust the reel speed by rotating the rotary switch to the reel position (A), and then use the – or + key to set the reel speed.



Figure 6.183: Lexion Combine Rotary Switch

## SETTING UP AUTO HEADER HEIGHT CONTROL

5. Press and hold button (A) or button (B) for 3 seconds to store the setting into the CEBIS (an alarm will sound when the new setting has been stored).

**NOTE:**

Whenever button (A) or button (B) is pressed for 3 seconds, the current positions for reel speed and cutting height are stored.



Figure 6.184: Lexion Joystick Buttons

6. Use the < or > key to select the REEL WINDOW. Window E15 will display the current advance or retard speed of the reel in relation to the ground speed.




Figure 6.185: Lexion Combine Display




Figure 6.186: Lexion Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. Press the OK key (E), and use the < key (C) or the > key (D) to select the REEL FORE AND AFT window.
8. Use the – key (A) or the + key (B) to set the reel fore-aft position.

**NOTE:**

Joystick button (A) or button (B) also can be used to set the reel fore-aft position.




Figure 6.187: Lexion Combine Controls

9. Press and hold button (C) or button (D) for 3 seconds to store the setting into the CEBIS (an alarm will sound when the new setting has been stored).

**NOTE:**

Whenever button (C) or button (D) is pressed for 3 seconds, the current positions for reel speed and cutting height are stored.



Figure 6.188: Lexion Joystick Buttons

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.11 Lexion 600 and 700 Series Combines

#### Calibrating the Auto Header Height Control (Lexion 600 and 700 Series)

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Ensure center-link is set to D.
2. Ensure that the header float is unlocked (A).
3. Use control knob (A) to highlight the AUTO CONTOUR icon (B) and press control knob (A) to select it.




Figure 6.189: Lexion Combine Display, Console, and Joystick Lever


4. Use control knob (A) to highlight the icon that resembles a header with up and down arrows (not shown), and press control knob (A) to select it. The highlighted header icon (B) will be displayed on the screen.



Figure 6.190: Lexion Combine Display, Console, and Joystick Lever

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Use control knob (A) to highlight the icon that resembles a header with up and down arrows (C), and press control knob (A) to select it.



**Figure 6.191: Lexion Combine Display, Console, and Joystick Lever**

- Use control knob (A) to highlight the icon that resembles a screwdriver (B).
- Engage the combine separator and feeder house.
- Press control knob (A) and a progress bar chart will appear.



**Figure 6.192: Lexion Combine Display, Console, and Joystick Lever**

- Fully raise the feeder house and the progress bar chart will advance to 25% (A).
- Fully lower the feeder house, and the progress bar chart will advance to 50%.
- Fully raise the feeder house and the progress bar chart will advance to 75%.
- Fully lower the feeder house, and the progress bar chart will advance to 100%.



**Figure 6.193: Lexion Combine Display, Console, and Joystick Lever**

## SETTING UP AUTO HEADER HEIGHT CONTROL

13. Ensure the progress bar chart displays 100% (A). The calibration procedure is now complete.

**NOTE:**

If the voltage is not within the range of 0.5–4.5 volts at any time throughout the calibration process, the monitor will indicate learning procedure not concluded.

**NOTE:**

If header float is set too light, an error message will appear. Back float off three full-turns of the adjuster bolts to adjust float to approximately 45–57 kg (100–125 lb.).



Figure 6.194: Lexion Combine Display, Console, and Joystick Lever

### Setting Cutting Height (Lexion 600 and 700 Series)

#### CAUTION

Check to be sure all bystanders have cleared the area.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Lower the header to desired cutting height or ground pressure setting. The float indicator box should be set to 1.5.
2. Hold the left side of the header raise and lower switch (A) until you hear a ping.

**NOTE:**

You can set two different cutting heights.



Figure 6.195: Lexion Combine Display, Console, and Joystick Lever

### Setting the Sensitivity of the Auto Header Height Control (Lexion 600 and 700 Series)

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Use control knob (A) to highlight the HEADER/REEL icon (B), and press control knob (A) to select it. The HEADER/REEL dialog box opens.
2. Select HEADER icon.




Figure 6.196: Lexion Combine Display, Console, and Joystick Lever

3. Select the FRONT ATTACHMENT PARAMETER SETTINGS icon (A). A list of settings appears.
4. Select SENSITIVITY CAC (B) from the list.



Figure 6.197: Lexion Combine Display, Console, and Joystick Lever

5. Select the SENSITIVITY CAC icon (A).

### NOTE:

To set the sensitivity, you will have to change the CUTTING HEIGHT ADJUSTMENT from the 0 default. The settings from 1–50 provide a faster response, whereas the settings from -1 to -50 provide a slower response. For best results, make adjustments in increments of five.

6. Increase the CUTTING HEIGHT ADJUSTMENT setting if the reaction time between the header and the float module is too slow while cutting on the ground, and decrease the CUTTING HEIGHT ADJUSTMENT setting if the reaction time between the header and the float module is too fast.
7. Increase the sensitivity if the header is lowered too slowly, and decrease the sensitivity if the header hits the ground too hard or is lowered too quickly.



Figure 6.198: Lexion Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### Adjusting Auto Reel Speed (Lexion 600 and 700 Series)

#### NOTE:

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Use control knob (A) to highlight the HEADER/REEL icon (B), and press control knob (A) to select it. The HEADER/REEL dialog box opens.




Figure 6.199: Lexion Combine Display, Console, and Joystick Lever

2. Use control knob (A) to select REEL SPEED (B), and adjust the reel speed (if you are NOT using Auto Reel Speed). A graph displays in the dialog box.



Figure 6.200: Lexion Combine Display, Console, and Joystick Lever

## SETTING UP AUTO HEADER HEIGHT CONTROL

3. Select ACTUAL VALUE (A) from the AUTO REEL SPEED dialog box (if you are using Auto Reel Speed). The ACTUAL VALUE dialog box indicates the auto reel speed.



Figure 6.201: Lexion Combine Display, Console, and Joystick Lever

4. Use control knob (A) to raise or lower the reel speed.

**NOTE:**

This option is only available at full throttle.



Figure 6.202: Lexion Combine Display, Console, and Joystick Lever

**NOTE:**

The indicator reading with the header off the ground (152 mm [6 in.]) should be at 0 (B). If not, refer to Step 3., [page 142](#). Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 (A) is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.203: Float Indicator Box

## SETTING UP AUTO HEADER HEIGHT CONTROL

### 6.1.12 New Holland Combines

This section applies only to pre-2015 CR/CX models. For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

#### Checking Voltage Range from the Combine Cab (New Holland)

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

**CAUTION**

Check to be sure all bystanders have cleared the area.

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.




Figure 6.204: Float Lock

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.205: Float Indicator box

- Ensure header float is unlocked.
- Select DIAGNOSTICS (A) on the main page. The DIAGNOSTICS page displays.
- Select SETTINGS. The SETTINGS page displays.




Figure 6.206: New Holland Combine Display

- Select the GROUP drop-down arrow (A). The GROUP dialog box displays.




Figure 6.207: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

8. Select HEADER HEIGHT/TILT(A). The PARAMETER page displays.




Figure 6.208: New Holland Combine Display

9. Select LEFT HEADER HEIGHT SEN (A), and then select GRAPH button (B). The exact voltage is displayed at the top of the page.
10. Raise and lower the header to see the full range of voltage readings.
11. If the sensor voltage is not within the low and high limits, or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).




Figure 6.209: New Holland Combine Display

### *Engaging the Auto Header Height Control (New Holland CR/CX Series)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\), page 247](#).

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Select HEADER LATERAL FLOAT on the combine display, and press ENTER.
2. Use the up and down navigation keys to move between options, and select INSTALLED.



Figure 6.210: New Holland Combine Display

3. Select HEADER AUTOFLOAT, and press ENTER.
4. Use the up and down navigation keys to move between options, and select INSTALLED.



Figure 6.211: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Calibrating the Auto Header Height Control (New Holland CR/CX Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

### **CAUTION**

**Check to be sure all bystanders have cleared the area.**

Check the following conditions before starting the header calibration procedure:


- The header is attached to the combine.
- The combine is on level ground, with the header level to the ground.
- The header is on down stops, and the center-link is set to D.
- The engine is running.
- The combine is not moving.
- No faults have been received from the Header Height Controller (HHC) module.
- Header/feeder is disengaged.
- Lateral flotation buttons are NOT pressed.
- ESC key is NOT pressed.

To calibrate the AHHC, follow these steps:

1. Select CALIBRATION on the combine display, and press the right arrow navigation key to enter the information box.
2. Select HEADER (A), and press ENTER. The CALIBRATION dialog box opens.

#### **NOTE:**

You can use the up and down navigation keys to move between options.



**Figure 6.212: New Holland Combine Display**

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Follow the calibration steps in the order in which they appear in the dialog box. As you proceed through the calibration process, the display will automatically update to show the next step.

**NOTE:**

Pressing the ESC key during any of the steps or letting the system sit idle for more than 3 minutes will cause the calibration procedure to stop.

**NOTE:**

Refer to your combine operator's manual for an explanation of any error codes.



Figure 6.213: New Holland Combine Display

- When all steps have been completed, CALIBRATION SUCCESSFUL message is displayed on the page. Exit the CALIBRATION menu by pressing the ENTER or ESC key.

**NOTE:**

If float was set heavier to complete ground calibration procedure, adjust to recommended operating float after the calibration is complete.

- If the unit does not function properly, conduct the maximum stubble height calibration.

### Calibrating Maximum Stubble Height

This procedure describes how to calibrate the area counter to stop or start counting at the correct height. Program the header to a height that will never be reached while cutting. The area counter will stop counting when the header is above the programmed height, and will begin counting when the header is below the programmed height.

Select the height of the header that corresponds to the description above.

**IMPORTANT:**


- If the value is set too low, area may NOT be counted since the header is sometimes raised above this threshold although the combine is still cutting.
- If the value is set too high, the area counter will keep counting even when the header is raised (but below this threshold) and the combine is no longer cutting crop.

**CAUTION**

Check to be sure all bystanders have cleared the area.


## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Select the MAXIMUM STUBBLE HEIGHT calibration dialog box. As you proceed through the calibration process, the display will automatically update to show the next step.



**Figure 6.214: New Holland Calibration Dialog Box**

2. Move header to the correct position using the header up or down control switch on the multifunction handle.
3. Press ENTER to continue. As you proceed through the calibration process, the display will automatically update to show the next step.
4. Press ENTER or ESC to close the calibration page. The calibration is now complete.



**Figure 6.215: New Holland Calibration Dialog Box**

### *Adjusting Header Raise Rate (New Holland CR/CX Series)*

If necessary, the header raise rate (the first speed on the HEADER HEIGHT rocker switch of the multifunctional handle) can be adjusted.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Select HEADER RAISE RATE on the combine display.
2. Use the + or – buttons to change the setting.
3. Press ENTER to save the new setting.

**NOTE:**

The raise rate can be changed from 32–236 in steps of 34. The factory setting is 100.




Figure 6.216: New Holland Combine Display

### Setting the Header Lower Rate (New Holland CR/CX Series)

If necessary, the header lower rate (the automatic header height control button or second speed on the header height rocker switch of the multi-function handle) can be adjusted.

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

1. Select HEADER LOWER RATE on the combine display.
2. Use the + or – buttons to change the setting to 50.
3. Press ENTER to save the new setting.

**NOTE:**

The lower rate can be changed from 2–247 in steps of 7. It is factory-set to 100.




Figure 6.217: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

### *Setting the Sensitivity of the Auto Header Height Control (New Holland CR/CX Series)*

The sensitivity adjustment controls the distance the cutterbar must travel up or down before the auto header height control (AHHC) reacts and raises or lowers the feeder house. When the sensitivity is set to maximum, only small changes in ground height are needed to cause the feeder house to raise or lower. When the sensitivity is set to minimum, large changes in the ground height are needed to cause the feeder house to raise or lower.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.



### **CAUTION**

**Check to be sure all bystanders have cleared the area.**

1. Engage threshing and feeder house.
2. Select HEIGHT SENSITIVITY on the combine display screen.
3. Use the + or – buttons to change the setting to 200.
4. Press ENTER to save the new setting.

#### **NOTE:**

The sensitivity can be changed from 10–250 in steps of 10. It is factory-set to 100.



**Figure 6.218: New Holland Combine Display**

### *Setting Preset Cutting Height (New Holland CR/CX Series)*

To set the preset cutting height, follow these steps:

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **NOTE:**

For New Holland CR models 6.80, 6.90, 7.90, 8.90, 9.90, and 10.90, refer to [6.1.13 New Holland Combines \(CR Series—Model Year 2015 and Later\)](#), page 247.

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Engage the threshing mechanism and the feeder with switches (A) and (B).
2. Set HEADER MEMORY rocker switch (D) in STUBBLE HEIGHT/AUTOFLOAT MODE position (A) or (B).
3. Lower the header to the desired cutting height using the HEADER HEIGHT AND HEADER LATERAL FLOTATION rocker switch (C).
4. Press AUTOMATIC HEADER HEIGHT CONTROL button (E) for a minimum of 2 seconds to store the height position. A beep will confirm the setting.

### NOTE:

It is possible to store two different header height values by using HEADER MEMORY rocker switch (D) in STUBBLE HEIGHT/AUTOFLOAT MODE position (A) or (B).

5. To change one of the memorized header height set points while the combine is in use, use the HEADER HEIGHT AND HEADER LATERAL FLOTATION rocker switch (C) (slow up/down) to raise or lower header to the desired value. Press the AUTOMATIC HEADER HEIGHT CONTROL button (E) for a minimum of 2 seconds to store the new height position. A beep will confirm setting.

### NOTE:

Do not press too hard on AUTOMATIC HEADER HEIGHT CONTROL button (E), or float mode will be disengaged.

### NOTE:

It is not necessary to press rocker switch (D) again after adjusting.

### NOTE:

The indicator reading with the header off the ground (152 mm [6 in.]) should be at 0 (B). If not, refer to Step 3., [page 142](#). Ground and crop conditions will dictate what number you will need to be set at. A reading at 1 (A) is set to light and 4 is set to heavy. The ideal setting is as light as possible without bouncing or missing crop. Operating with heavier pressures can wear the cutterbar wearplate prematurely.




Figure 6.219: New Holland Combine Controls




Figure 6.220: Float Indicator Box

### 6.1.13 New Holland Combines (CR Series—Model Year 2015 and Later)

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).

#### *Checking Voltage Range from the Combine Cab (New Holland CR Series)*

**NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

**NOTE:**

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).


**⚠ CAUTION**

**Check to be sure all bystanders have cleared the area.**

1. Position the header 150 mm (6 in.) above the ground, and unlock the float module float.
2. Check that float lock linkage is on down stops (washer [A] cannot be moved) at both locations.

**NOTE:**

If the header is not on down stops during the next two steps, the voltage may go out of range during operation causing a malfunction of the AHHC system.



**Figure 6.221: Float Lock**

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Adjust the cable take-up bracket (B) (if necessary) until the pointer (A) on the float indicator is on 0.




Figure 6.222: Float Indicator box

- Ensure header float is unlocked.
- Select DIAGNOSTICS (A) on the main page. The DIAGNOSTICS page displays.




Figure 6.223: New Holland Combine Display

- Select SETTINGS (A). The SETTINGS page displays.



Figure 6.224: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

7. Select HEADER HEIGHT/TILT (A) from the GROUP drop-down menu.
8. Select HEADER HEIGHT SENS. L (B) from the PARAMETER drop-down menu.



Figure 6.225: New Holland Combine Display

9. Select GRAPH (A). The exact voltage (B) is displayed at the top of the page.
10. Raise and lower the header to see the full range of voltage readings.
11. If the sensor voltage is not within the low and high limits, or if the range between the low and high limits is insufficient, adjust the voltage limits. Refer to [Adjusting Voltage Limits: One-Sensor System, page 146](#).




Figure 6.226: New Holland Combine Display

### *Engaging the Auto Header Height Control (New Holland CR Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **NOTE:**

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Ensure center-link is set to D.
2. Select TOOLBOX (A) on the main page. The TOOLBOX page displays.




Figure 6.227: New Holland Combine Display

3. Simultaneously press both the UNLOAD (A) and RESUME (B) buttons on the hydro handle.




Figure 6.228: New Holland Combine Controls

4. Select HEAD 1 (A). The HEADER SETUP 1 page displays.
5. Select the CUTTING TYPE drop-down arrow (B) and change the CUTTING TYPE to PLATFORM (C).



Figure 6.229: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

6. Select the HEADER SUB TYPE drop-down arrow (A). The HEADER SUB TYPE dialog box displays.



Figure 6.230: New Holland Combine Display

7. Select HEAD 2 (A). The HEADER SETUP 2 page displays.



Figure 6.231: New Holland Combine Display

8. Select the AUTOFLOAT drop-down arrow and set AUTOFLOAT to INSTALLED (A).
9. Select the AUTO HEADER LIFT drop-down arrow and set AUTO HEADER LIFT to INSTALLED (B).

**NOTE:**

With AUTO HEADER LIFT installed and AHHC engaged, the header will lift up automatically when you pull back on the ground speed lever (GSL).

10. Set the values for MANUAL HHC RAISE RATE (C) and MANUAL HHC LOWER RATE (D) for best performance according to ground conditions.



Figure 6.232: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

11. Set the values for HHC HEIGHT SENSITIVITY (A) and HHC TILT SENSITIVITY (B) for best performance according to ground conditions.




Figure 6.233: New Holland Combine Display

### *Calibrating the Auto Header Height Control (New Holland CR Series)*

For best performance of the auto header height control (AHHC), perform these procedures with the center-link set to D. When setup and calibration are complete, adjust the center-link back to desired header angle. Refer to Header Angle in the header operator's manual for instructions.

#### **NOTE:**

Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

#### **NOTE:**

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).

### **CAUTION**

**Check to be sure all bystanders have cleared the area.**

Check the following conditions before starting the header calibration procedure:

- The header is attached to the combine.
- The combine is on level ground, with the header level to the ground.
- The header is on down stops, and the center-link is set to D.
- The engine is running.
- The combine is not moving.
- No faults have been received from the header height controller (HHC) module.
- Header/feeder is disengaged.
- Lateral flotation buttons are NOT pressed.
- ESC key is NOT pressed.

To calibrate the AHHC, follow these steps:

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Select CALIBRATIONS (A) on the main page. The CALIBRATION page displays.



Figure 6.234: New Holland Combine Display

2. Select the CALIBRATION drop-down arrow (A).



Figure 6.235: New Holland Combine Display

3. Select HEADER (A) from the list of calibration options.



Figure 6.236: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL

- Follow the calibration steps in the order in which they appear on the screen. As you proceed through the calibration process, the display will automatically update to show the next step.

**NOTE:**

Pressing the ESC key during any of the steps or letting the system sit idle for more than 3 minutes will cause the calibration procedure to stop.

**NOTE:**

Refer to your combine operator's manual for an explanation of any error codes.



Figure 6.237: New Holland Combine Display

- When all steps have been completed, CALIBRATION COMPLETED message is displayed on the screen.

**NOTE:**

If float was set heavier to complete ground calibration procedure, adjust to recommended operating float after the calibration is complete.



Figure 6.238: New Holland Combine Display

### Setting Auto Height (New Holland CR Series)

**NOTE:**

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).

The console has two buttons used for auto height presets. The toggle switch that was present on previous models is now configured as shown at right. MacDon headers only require the first two buttons (A) and (B). The third button (C) is not configured.

**CAUTION**

Check to be sure all bystanders have cleared the area.




Figure 6.239: New Holland Combine Controls

## SETTING UP AUTO HEADER HEIGHT CONTROL

To set the auto height, follow these steps:

1. Engage separator and header.
2. Select RUN SCREENS (A) on the main page.



Figure 6.240: New Holland Combine Display

3. Select the RUN tab that shows MANUAL HEIGHT.

**NOTE:**

The MANUAL HEIGHT field may appear on any of the RUN tabs. When an auto height set point button is pressed, the display will change to AUTO HEIGHT (A).

4. Lower the header to the ground.
5. Select one of the auto height set point buttons shown in Figure 6.239: *New Holland Combine Controls, page 254*.

- Press the SET 1 button for a light ground setting (1 on the float indicator box).
- Press the SET 2 button for a heavier ground setting (2 on the float indicator box).



Figure 6.241: New Holland Combine Display

### Setting Maximum Work Height (New Holland CR Series)

This procedure applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90).

**NOTE:**

This section applies only to 2015 and later CR models (6.80, 6.90, 7.90, 8.90, 9.90, and 10.90). For other pre-2015 New Holland combine models, refer to [6.1.12 New Holland Combines, page 237](#).

## SETTING UP AUTO HEADER HEIGHT CONTROL

1. Select TOOLBOX (A) on the main page. The TOOLBOX page displays.




Figure 6.242: New Holland Combine Display

2. Select FEEDER (A). The FEEDER SETUP page displays.
3. Select the MAXIMUM WORK HEIGHT field (B).




Figure 6.243: New Holland Combine Display

4. Set MAXIMUM WORK HEIGHT to desired value.
5. Press SET and then press ENTER.



Figure 6.244: New Holland Combine Display

## SETTING UP AUTO HEADER HEIGHT CONTROL


### *Configuring Reel Fore-Aft, Header Tilt, and Header Type (New Holland CR Series)*

This procedure applies only to 2016 New Holland CR models 6.90, 7.90, 8.90, and 9.90.

#### **NOTE:**


Changes may have been made to the combine controls or display since this document was published. Refer to the combine operator's manual for updates.

1. Simultaneously press both the UNLOAD (A) and RESUME (B) buttons on the hydro handle.




**Figure 6.245: New Holland Combine Controls**

2. On the HEAD 1 page, change the CUTTING TYPE from FLEX to PLATFORM as shown at location (A).



**Figure 6.246: New Holland Combine Display**

3. On the HEAD 2 page, change HEADER SUB TYPE from DEFAULT to 80/90 as shown at location (A).



**Figure 6.247: New Holland Combine Display**

## SETTING UP AUTO HEADER HEIGHT CONTROL

There are now two different buttons for ON GROUND presets. The toggle switch that was present on previous models is now configured as shown at right. MacDon headers only require the first two buttons (A) and (B). The third button down (C) is not configured.




Figure 6.248: New Holland Combine Controls

### 6.1.14 Sensor Operation

The position sensors supplied with the auto header height control (AHC) system are hall-effect sensors containing sealed connectors. Normal operating signal voltages for the sensors fall between 10% (0.5VDC) and 90% (4.5VDC). An increase in sensor voltage correlates to an increase in header height.

Any sensor error results in a 0 V signal, which indicates either a faulty sensor or lack of supply voltage.

## 7 Checking and Adjusting Reel Height Sensor

The output voltage range of the auto reel height sensor can be checked from inside the combine or manually at the sensor. For in-cab instructions, refer to the combine operator's manual. To check the voltage range manually, refer to the procedure below.

### **DANGER**

To avoid bodily injury or death from unexpected start-up of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

### **CAUTION**

Check to be sure all bystanders have cleared the area.

#### **IMPORTANT:**

Ensure reel height is properly set before adjusting reel height sensor. Refer to [5.11.1 Measuring Reel Clearance](#), page 111.

#### **IMPORTANT:**

To measure the output voltage of the reel height sensor, the combine needs to be turned ON and supplying power to the sensor. Always engage the combine parking brake and stay away from the reel.

**Table 7.1 Reel Height Sensor Voltage Limits**

Combine Type	Voltage Range	
	X Voltage	Y Voltage
Case New Holland	0.5–0.9 V	4.1–4.5 V
John Deere	4.1–4.5 V	0.5–0.9 V
Lexion	4.1–4.5 V	0.5–0.9 V


#### **NOTE:**

For Lexion Combines: To avoid a collision of the reel with the cab, the machine is equipped with an automatic reel height limitation. When raising the header by more than 80 percent, the reel is automatically lowered. The automatic lower of the reel can be overridden manually, and a warning will appear on the CEBIS terminal.

1. Engage the combine parking brake.
2. Start the combine engine and lower reel fully.


## CHECKING AND ADJUSTING REEL HEIGHT SENSOR

3. Use the combine display or a voltmeter (if measuring the sensor manually), to measure voltage range X. Refer to Table 7.1 *Reel Height Sensor Voltage Limits*, page 259 for range requirements.
4. If using a voltmeter, measure the voltage between the ground (Pin 2 wire) and the signal (Pin 3 wire) at the reel height sensor (B).
5. Stop the combine engine and remove key.
6. Adjust length of threaded rod (A) to modify voltage range X.
7. Repeat checking and adjusting until voltage range X is within the range specified.



**Figure 7.1: Reel Height Sensor – Right Reel Arm (Reel Down)**

8. Start the combine engine, and raise the reel fully.
9. Use the combine display or a voltmeter (if measuring the sensor manually), to measure voltage range Y. Refer to Table 7.1 *Reel Height Sensor Voltage Limits*, page 259 for range requirements.
10. If using a voltmeter, measure the voltage between the ground (Pin 2 wire) and the signal (Pin 3 wire) at the reel height sensor (A).
11. Stop the combine engine and remove key.
12. Loosen two M5 hex nuts (B) and rotate sensor (A) to achieve voltage range Y.
13. Repeat checking and adjusting until voltage range Y is within the range specified.
14. Start the combine engine and lower reel fully.
15. Recheck voltage range X and ensure it is still within the range specified. Adjust if required.



**Figure 7.2: Reel Height Sensor – Right Reel Arm (Reel Up)**

## 8 Running up Header

To run up the header, follow these steps:

### DANGER

Engage header safety props and reel props before working under header or reel.

### DANGER

To avoid bodily injury or death from unexpected start-up or fall of a raised machine, always stop engine and remove key before leaving the operator's seat, and always engage safety props before going under the machine for any reason.

### CAUTION

Never start or move the machine until you are sure all bystanders have cleared the area.

1. Start combine, raise header fully, and engage header lift cylinder locks.
2. Stop engine and remove key.
3. Lower plastic pan under float module and check for shipping materials/debris that may have fallen under float module draper.
4. Rotate latches (A) to unlock handles (B).
5. Hold pan (C) and rotate handles (B) to release pan. Lower pan to expose draper.





Figure 8.1: Float Module Plastic Pan


## RUNNING UP HEADER

6. Check and remove debris from pan (A) and draper.




**Figure 8.2: Float Module Plastic Pan**

7. Raise pan and rotate handle (A) so that rod engages clips (B) on pan.



**Figure 8.3: Clips Engaged**

8. Push handle (B) into slot and secure it with latches (A).
9. Open left-hand endshield.



**Figure 8.4: Latches Secured**

## RUNNING UP HEADER

10. Ensure flow control (A) is set to position 6.
11. Ensure feeder house variable speed is set to MINIMUM.

### CAUTION

**Never start or move the machine until you are sure all bystanders have cleared the area.**

12. Start combine and run the machine slowly for 5 minutes while watching and listening **from the operator's seat** for binding or interfering parts.

#### NOTE:

Reel and side drapers will not operate until oil flow fills the lines.

13. Run the machine at operating speed for 15 minutes. Listen for any unusual sounds or abnormal vibration.
14. Perform run-up check as listed on [Predelivery Checklist, page 283](#) (yellow sheet attached to this instruction) to ensure the machine is field-ready.




Figure 8.5: Flow Control

## 8.1 Performing Post Run-Up Adjustments

Perform post run-up check as listed on the Predelivery Checklist (yellow sheet attached to this instruction [Predelivery Checklist, page 283](#)) to ensure machine is field-ready.

### WARNING

**To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.**

Some adjustments may be necessary after the run-up. Refer to the following:

- [8.1.1 Adjusting Knife, page 263](#)
- [8.1.2 Adjusting Knife Speed, page 265](#)

### 8.1.1 Adjusting Knife

#### WARNING

**To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key before making adjustments to machine.**

## RUNNING UP HEADER

1. Stop engine and remove the key.
2. Check guards for signs of heating during run-up due to insufficient clearance between guard and knife.
3. If heating is evident, check gap between knifehead (A) and pitman arm (B). A business card should slide easily through the gap. If not, adjust gap by loosening bolt and tapping knifehead (A) with a hammer. Retighten bolt.




Figure 8.6: Knifehead and Pitman Arm

4. Adjust guard alignment as necessary using guard straightening tool (MD #140135). Adjust guard tips upwards by positioning tool as shown and pulling up.



Figure 8.7: Guard Tips – Upward Adjustment

5. Adjust guard tips downward by positioning tool as shown and pushing down.




Figure 8.8: Guard Tips – Downward Adjustment

## 8.1.2 Adjusting Knife Speed

The header knife drive is driven by the hydraulic pump mounted on the float module. The following speeds are factory-set for the combine feeder house:

- AGCO: 625 rpm (includes Challenger, Gleaner, and Massey Ferguson)
- Case: 580 rpm
- John Deere: 490 rpm
- Lexion: 750 rpm (420 on combine display)
- New Holland: 580 rpm

### DANGER

To avoid bodily injury or death from unexpected startup of machine, always stop engine and remove key from ignition before leaving operator's seat for any reason.

#### IMPORTANT:

This is the **minimum** speed setting for variable speed feeder houses. To avoid damage to the header, do NOT operate at speeds higher than the minimum speed settings.

1. Stop combine engine and remove key.
2. Push release lever (A) located on the backside of the endshield to unlock the shield.
3. Pull endshield open using handle depression (B).




Figure 8.9: Endshield Latch Access

4. Pull endshield at handle depression (A). Endshield is retained by a hinge tab (B) and will open in direction (C).




Figure 8.10: Left-Hand Endshield

## RUNNING UP HEADER

- Pull the endshield free of hinge tab (A) if additional clearance is required, and swing shield towards the rear of the header.
- Engage safety catch (B) on hinge arm to secure the shield in fully open position.




Figure 8.11: Left Endshield

### CAUTION

Clear the area of other persons, pets etc. Keep children away from machinery. Walk around the machine to be sure no one is under, on, or close to it.

- Start engine, engage header drive, and run combine at operating rpm.
- Check the rpm of knife drive box pulley using a handheld tachometer.
- Stop engine, remove key, and close endshield.




Figure 8.12: Knife Drive Box

- Compare actual pulley rpm with values in the following chart:

**Table 8.1 Recommended Knife Drive Speed (rpm)**

Header Size	Recommended Knife Drive Speed Range (rpm)	
	Single Knife	Double Knife
20 ft.	N/A	700–850
25 ft.	600–725	
30 ft.	600–700	600–750
35 ft.	550–650	
40 ft.	525–600	550–700
45 ft.	N/A	

- If adjustment to knife drive box pulley rpm is necessary, refer to the header technical manual.

## 9 Reference

### 9.1 Torque Specifications

The following tables provide correct torque values for various bolts, cap screws, and hydraulic fittings.

- Tighten all bolts to torque values specified in charts (unless otherwise noted throughout this manual).
- Replace hardware with same strength and grade of bolt.
- Use torque value tables as a guide and periodically check tightness of bolts.
- Understand torque categories for bolts and cap screws by using their identifying head markings.

#### **Jam Nuts**

When applying torque to finished jam nuts, multiply the torque applied to regular nuts by  $f=0.65$ .


#### **Self-Tapping Screws**

Standard torque is to be used (not to be used on critical or structurally important joints).

#### 9.1.1 Metric Bolt Specifications

**Table 9.1 Metric Class 8.8 Bolts and Class 9 Free Spinning Nut**

Nominal Size (A)	Torque (N·m)		Torque (ft·lbf) (*in·lbf)	
	Min.	Max.	Min.	Max.
3-0.5	1.4	1.6	*13	*14
3.5-0.6	2.2	2.5	*20	*22
4-0.7	3.3	3.7	*29	*32
5-0.8	6.7	7.4	*59	*66
6-1.0	11.4	12.6	*101	*112
8-1.25	28	30	20	23
10-1.5	55	60	40	45
12-1.75	95	105	70	78
14-2.0	152	168	113	124
16-2.0	236	261	175	193
20-2.5	460	509	341	377
24-3.0	796	879	589	651



**Figure 9.1: Bolt Grades**

REFERENCE

Table 9.2 Metric Class 8.8 Bolts and Class 9 Distorted Thread Nut

Nominal Size (A)	Torque (N·m)		Torque (ft·lbf) (*in·lbf)	
	Min.	Max.	Min.	Max.
3-0.5	1	1.1	*9	*10
3.5-0.6	1.5	1.7	*14	*15
4-0.7	2.3	2.5	*20	*22
5-0.8	4.5	5	*40	*45
6-1.0	7.7	8.6	*69	*76
8-1.25	18.8	20.8	*167	*185
10-1.5	37	41	28	30
12-1.75	65	72	48	53
14-2.0	104	115	77	85
16-2.0	161	178	119	132
20-2.5	314	347	233	257
24-3.0	543	600	402	444




Figure 9.2: Bolt Grades

Table 9.3 Metric Class 10.9 Bolts and Class 10 Free Spinning Nut

Nominal Size (A)	Torque (N·m)		Torque (ft·lbf) (*in·lbf)	
	Min.	Max.	Min.	Max.
3-0.5	1.8	2	*18	*19
3.5-0.6	2.8	3.1	*27	*30
4-0.7	4.2	4.6	*41	*45
5-0.8	8.4	9.3	*82	*91
6-1.0	14.3	15.8	*140	*154
8-1.25	38	42	28	31
10-1.5	75	83	56	62
12-1.75	132	145	97	108
14-2.0	210	232	156	172
16-2.0	326	360	242	267
20-2.5	637	704	472	521
24-3.0	1101	1217	815	901




Figure 9.3: Bolt Grades

REFERENCE

Table 9.4 Metric Class 10.9 Bolts and Class 10 Distorted Thread Nut

Nominal Size (A)	Torque (N·m)		Torque (ft·lbf) (*in·lbf)	
	Min.	Max.	Min.	Max.
3-0.5	1.3	1.5	*12	*13
3.5-0.6	2.1	2.3	*19	*21
4-0.7	3.1	3.4	*28	*31
5-0.8	6.3	7	*56	*62
6-1.0	10.7	11.8	*95	*105
8-1.25	26	29	19	21
10-1.5	51	57	38	42
12-1.75	90	99	66	73
14-2.0	143	158	106	117
16-2.0	222	246	165	182
20-2.5	434	480	322	356
24-3.0	750	829	556	614




Figure 9.4: Bolt Grades

### 9.1.2 Metric Bolt Specifications Bolting into Cast Aluminum

Table 9.5 Metric Bolt Bolting into Cast Aluminum

Nominal Size (A)	Bolt Torque			
	8.8 (Cast Aluminum)		10.9 (Cast Aluminum)	
	N·m	ft·lbf	N·m	ft·lbf
M3	–	–	–	1
M4	–	–	4	2.6
M5	–	–	8	5.5
M6	9	6	12	9
M8	20	14	28	20
M10	40	28	55	40
M12	70	52	100	73
M14	–	–	–	–
M16	–	–	–	–




Figure 9.5: Bolt Grades

### 9.1.3 Flare-Type Hydraulic Fittings

1. Check flare (A) and flare seat (B) for defects that might cause leakage.
2. Align tube (C) with fitting (D) and thread nut (E) onto fitting without lubrication until contact has been made between flared surfaces.
3. Torque fitting nut (E) to specified number of flats from finger tight (FFFT) or to a given torque value in [Table 9.6 Flare-Type Hydraulic Tube Fittings, page 271](#).
4. Use two wrenches to prevent fitting (D) from rotating. Place one wrench on fitting body (D), and tighten nut (E) with other wrench to torque shown.
5. Assess final condition of connection.




Figure 9.6: Hydraulic Fitting

**REFERENCE**

**Table 9.6 Flare-Type Hydraulic Tube Fittings**


SAE Dash Size	Thread Size (in.)	Torque Value <sup>2</sup>		Flats from Finger Tight (FFFT)	
		N·m	ft·lbf	Tube	Swivel Nut or Hose
-2	5/16-24	4-5	3-4	—	—
-3	3/8-24	7-8	5-6	—	—
-4	7/16-20	18-19	13-14	2-1/2	2
-5	1/2-20	19-21	14-15	2	2
-6	9/16-18	30-33	22-24	2	1-1/2
-8	3/4-16	57-63	42-46	2	1-1/2
-10	7/8-14	81-89	60-66	1-1/2	1-1/2
-12	1-1/16-12	113-124	83-91	1-1/2	1-1/4
-14	1-3/16-12	136-149	100-110	1-1/2	1-1/4
-16	1-5/16-12	160-176	118-130	1-1/2	1
-20	1-5/8-12	228-250	168-184	1	1
-24	1-7/8-12	264-291	195-215	1	1
-32	2-1/2-12	359-395	265-291	1	1
-40	3-12	—	—	1	1

2. Torque values shown are based on lubricated connections as in reassembly.


## REFERENCE

### 9.1.4 O-Ring Boss (ORB) Hydraulic Fittings (Adjustable)

1. Inspect O-ring (A) and seat (B) for dirt or obvious defects.
2. Back off lock nut (C) as far as possible. Ensure that washer (D) is loose and is pushed toward lock nut (C) as far as possible.
3. Check that O-ring (A) is **NOT** on threads and adjust if necessary.
4. Apply hydraulic system oil to O-ring (A).



5. Install fitting (B) into port until back up washer (D) and O-ring (A) contact part face (E).
6. Position angle fittings by unscrewing no more than one turn.
7. Turn lock nut (C) down to washer (D) and tighten to torque shown. Use two wrenches, one on fitting (B) and other on lock nut (C).
8. Check final condition of fitting.



**REFERENCE**

**Table 9.7 O-Ring Boss (ORB) Hydraulic Fittings (Adjustable)**

SAE Dash Size	Thread Size (in.)	Torque Value <sup>3</sup>	
		N·m	ft·lbf (*in·lbf)
-2	5/16-24	6-7	*53-62
-3	3/8-24	12-13	*106-115
-4	7/16-20	19-21	14-15
-5	1/2-20	21-33	15-24
-6	9/16-18	26-29	19-21
-8	3/4-16	46-50	34-37
-10	7/8-14	75-82	55-60
-12	1-1/16-12	120-132	88-97
-14	1-3/8-12	153-168	113-124
-16	1-5/16-12	176-193	130-142
-20	1-5/8-12	221-243	163-179
-24	1-7/8-12	270-298	199-220
-32	2-1/2-12	332-365	245-269

---

3. Torque values shown are based on lubricated connections as in reassembly.

## REFERENCE

### 9.1.5 O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable)

1. Inspect O-ring (A) and seat (B) for dirt or obvious defects.
2. Check that O-ring (A) is **NOT** on threads and adjust if necessary.
3. Apply hydraulic system oil to O-ring.
4. Install fitting (C) into port until fitting is hand tight.
5. Torque fitting (C) according to values in Table 9.8 *O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable)*, page 274.
6. Check final condition of fitting.




Figure 9.9: Hydraulic Fitting

**Table 9.8 O-Ring Boss (ORB) Hydraulic Fittings (Non-Adjustable)**

SAE Dash Size	Thread Size (in.)	Torque Value <sup>4</sup>	
		N·m	ft·lbf (*in·lbf)
-2	5/16–24	6–7	*53–62
-3	3/8–24	12–13	*106–115
-4	7/16–20	19–21	14–15
-5	1/2–20	21–33	15–24
-6	9/16–18	26–29	19–21
-8	3/4–16	46–50	34–37
-10	7/8–14	75–82	55–60
-12	1-1/16–12	120–132	88–97
-14	1-3/8–12	153–168	113–124
-16	1-5/16–12	176–193	130–142
-20	1-5/8–12	221–243	163–179
-24	1-7/8–12	270–298	199–220
-32	2-1/2–12	332–365	245–269

4. Torque values shown are based on lubricated connections as in reassembly.

### 9.1.6 O-Ring Face Seal (ORFS) Hydraulic Fittings

1. Check components to ensure that sealing surfaces and fitting threads are free of burrs, nicks, scratches, or any foreign material.



Figure 9.10: Hydraulic Fitting

2. Apply hydraulic system oil to O-ring (B).
3. Align tube or hose assembly so that flat face of sleeve (A) or (C) comes in full contact with O-ring (B).
4. Thread tube or hose nut (D) until hand-tight. The nut should turn freely until it is bottomed out.
5. Torque fittings according to values in Table 9.9 *O-Ring Face Seal (ORFS) Hydraulic Fittings, page 276*.

**NOTE:**

If applicable, hold hex on fitting body (E) to prevent rotation of fitting body and hose when tightening fitting nut (D).




Figure 9.11: Hydraulic Fitting

6. Use three wrenches when assembling unions or joining two hoses together.
7. Check final condition of fitting.

**REFERENCE**

**Table 9.9 O-Ring Face Seal (ORFS) Hydraulic Fittings**

SAE Dash Size	Thread Size (in.)	Tube O.D. (in.)	Torque Value <sup>5</sup>	
			N·m	ft·lbf
-3	Note <sup>6</sup>	3/16	–	–
-4	9/16	1/4	25–28	18–21
-5	Note <sup>6</sup>	5/16	–	–
-6	11/16	3/8	40–44	29–32
-8	13/16	1/2	55–61	41–45
-10	1	5/8	80–88	59–65
-12	1-3/16	3/4	115–127	85–94
-14	Note <sup>6</sup>	7/8	–	–
-16	1-7/16	1	150–165	111–122
-20	1-11/16	1-1/4	205–226	151–167
-24	1–2	1-1/2	315–347	232–256
-32	2-1/2	2	510–561	376–414

5. Torque values and angles shown are based on lubricated connection as in reassembly.

6. O-ring face seal type end not defined for this tube size.

## REFERENCE

### 9.1.7 Tapered Pipe Thread Fittings

Assemble pipe fittings as follows:

1. Check components to ensure that fitting and port threads are free of burrs, nicks and scratches, or any form of contamination.
2. Apply pipe thread sealant (paste type) to external pipe threads.
3. Thread fitting into port until hand-tight.
4. Torque connector to appropriate torque angle. The Turns From Finger Tight (T.F.F.T.) values are shown in Table [9.10 Hydraulic Fitting Pipe Thread, page 277](#). Make sure that tube end of a shaped connector (typically 45° or 90°) is aligned to receive incoming tube or hose assembly. Always finish alignment of fitting in tightening direction. Never back off (loosen) pipe threaded connectors to achieve alignment.
5. Clean all residue and any excess thread conditioner with appropriate cleaner.
6. Assess final condition of fitting. Pay special attention to possibility of cracks to port opening.
7. Mark final position of fitting. If a fitting leaks, disassemble fitting and check for damage.

**NOTE:**

Over-torque failure of fittings may not be evident until fittings are disassembled.

**Table 9.10 Hydraulic Fitting Pipe Thread**

Tapered Pipe Thread Size	Recommended T.F.F.T.	Recommended F.F.F.T.
1/8-27	2-3	12-18
1/4-18	2-3	12-18
3/8-18	2-3	12-18
1/2-14	2-3	12-18
3/4-14	1.5-2.5	12-18
1-11 1/2	1.5-2.5	9-15
1 1/4-11 1/2	1.5-2.5	9-15
1 1/2-11 1/2	1.5-2.5	9-15
2-11 1/2	1.5-2.5	9-15

REFERENCE

## 9.2 Lifting Equipment Requirements

The following topic describes the minimum equipment requirements for lifting headers.

**⚠ CAUTION**

To avoid injury to bystanders from being struck by machinery, do not allow people to stand in unloading area.

**⚠ CAUTION**


Equipment used for loading and unloading must meet or exceed the minimum specified requirements. Using inadequate equipment may result in vehicle tipping, machine damage, or chain breakage.

**NOTE:**

When a header and float module are ordered together, they are shipped with the float module already installed in the header.

**IMPORTANT:**

Forklifts are normally rated for a load center 610 mm (24 in.) ahead of back end of the forks. To obtain the forklift capacity for a load center (A) at 1220 mm (48 in.) (B), check with your forklift distributor. The minimum fork length (C) is 1981 mm (78 in.).



**Figure 9.12: Minimum Lifting Capacity**

- A - Center of Gravity of the Load
- B - Load Center 1220 mm (48 in.) from Back of Forks
- C - Minimum Fork Length 1981 mm (78 in.)

**Table 9.11 Lifting Chain Requirements**

Type	Overhead lifting quality (1/2 in.)
Minimum Load	2270 kg (5000 lb.)

REFERENCE

## 9.3 Conversion Chart

Table 9.12 Conversion Chart

Quantity	SI Units (Metric)		Factor	Inch-Pound Units	
	Unit Name	Abbreviation		Unit Name	Abbreviation
Area	hectares	ha	$\times 2.4710 =$	acres	acres
Flow	liters per minute	L/min	$\times 0.2642 =$	US gallons per minute	gpm
Force	Newtons	N	$\times 0.2248 =$	pounds force	lbf
Length	millimeters	mm	$\times 0.0394 =$	inch	in.
	meters	m	$\times 3.2808 =$	foot	ft.
Power	kilowatts	kW	$\times 1.341 =$	horsepower	hp
Pressure	kilopascals	kPa	$\times 0.145 =$	pounds per square inch	psi
	megapascals	MPa	$\times 145.038 =$		
	bar (Non-SI)	bar	$\times 14.5038$		
Torque	Newton meters	N·m	$\times 0.7376 =$	pound feet or foot pounds	ft·lbf
	Newton meters	N·m	$\times 8.8507 =$	pound inches or inch pounds	in·lbf
Temperature	Celsius	°C	$(C^{\circ} \times 1.8) + 32 =$	degrees Fahrenheit	°F
Velocity	meters per minute	m/min	$\times 3.2808 =$	feet per minute	ft/min
	meters per second	m/s	$\times 3.2808 =$	feet per second	ft/s
	kilometers per hour	km/h	$\times 0.6214 =$	miles per hour	mph
Volume	liters	L	$\times 0.2642 =$	US gallons	US gal
	milliliters	ml	$\times 0.0338 =$	ounces	oz.
	cubic centimeters	cm <sup>3</sup> or cc	$\times 0.061 =$	cubic inches	in. <sup>3</sup>
Weight	kilograms	kg	$\times 2.2046 =$	pounds	lb.

## REFERENCE

### 9.4 Definitions

The following terms and acronyms may be used in this manual.

<b>Term</b>	<b>Definition</b>
AHHC	Automatic Header Height Control
API	American Petroleum Institute
ASTM	American Society of Testing and Materials
Bolt	A headed and externally threaded fastener that is designed to be paired with a nut
Center-link	A hydraulic cylinder link between header and machine used to change header angle
CGVW	Combined vehicle gross weight
D1 Series header	MacDon D120, D125, D130, D135, D140, or D145 combine draper header from D1 model number series
DK	Double knife
DKD	Double-knife drive
DDD	Double-draper drive
DR	Double reel
Export header	Header configuration typical outside North America
Finger tight	Finger tight is a reference position where sealing surfaces or components are making contact with each other and fitting has been tightened to a point where fitting is no longer loose
FFFT	Flats from finger tight
GSL	Ground speed lever
GVW	Gross vehicle weight
Hard joint	A joint made with use of a fastener where joining materials are highly incompressible
Header	A machine that cuts and lays crop into a windrow and is attached to a self-propelled windrower
Hex key	A tool of hexagonal cross-section used to drive bolts and screws that have a hexagonal socket in head (internal-wrenching hexagon drive); also known as an Allen key and various other synonyms
HDS	Hydraulic deck shift
hp	Horsepower
JIC	Joint Industrial Council: A standards body that developed standard sizing and shape for original 37° flared fitting
Knife	A cutting device which uses a reciprocating cutter (also called a sickle)
MDS	Mechanical deck shift
n/a	Not applicable
Nut	An internally threaded fastener that is designed to be paired with a bolt
NPT	National Pipe Thread: A style of fitting used for low pressure port openings Threads on NPT fittings are uniquely tapered for an interference fit

## REFERENCE

<b>Term</b>	<b>Definition</b>
ORB	O-ring boss: A style of fitting commonly used in port opening on manifolds, pumps, and motors
ORFS	O-ring face seal: A style of fitting commonly used for connecting hoses and tubes This style of fitting is also commonly called ORS, which stands for O-ring seal
rpm	Revolutions per minute
RoHS (Reduction of Hazardous Substances)	A directive by the European Union to restrict use of certain hazardous substances (such as hexavalent chromium used in some yellow zinc platings)
SAE	Society of Automotive Engineers
Screw	A headed and externally threaded fastener that threads into preformed threads or forms its own thread into a mating part
SDD	Single-drapeer drive
Soft joint	A joint made with use of a fastener where joining materials are compressible or experience relaxation over a period of time
spm	Strokes per minute
SR	Single reel
Truck	A four-wheel highway/road vehicle weighing no less than 3400 kg (7500 lb.)
Timed knife drive	Synchronized motion applied at cutterbar to two separately driven knives from a single hydraulic motor
Tension	Axial load placed on a bolt or screw, usually measured in Newtons (N) or pounds (lb.)
TFFT	Turns from finger tight
Torque	The product of a force X lever arm length, usually measured in Newton-meters (N·m) or foot-pounds (ft·lbf)
Torque angle	A tightening procedure where fitting is assembled to a precondition (finger tight) and then nut is turned farther a number of degrees to achieve its final position
Torque-tension	The relationship between assembly torque applied to a piece of hardware and axial load it induces in bolt or screw
UCA	Upper cross auger
Untimed knife drive	Unsynchronized motion applied at cutterbar to two separately driven knives from a single hydraulic motor or two hydraulic motors
Washer	A thin cylinder with a hole or slot located in the center that is to be used as a spacer, load distribution element, or a locking mechanism



# Predelivery Checklist

Perform these checks and adjustments prior to delivery to your Customer. **Adjustments are normally not required as the machine is factory-assembled and adjusted.** If adjustments are required, refer to the appropriate page number in this manual. The completed checklist should be retained by either the Operator or the Dealer.

## CAUTION

Carefully follow the instructions given. Be alert for safety related messages that bring your attention to hazards and unsafe practices.

Header Serial Number:

Float Module Serial Number:

**Table 1 D1 Series Draper Header / FM100 Float Module Predelivery Checklist – North America**

✓	Item	Reference
	Check for shipping damage or missing parts. Be sure all shipping dunnage is removed.	—
	Check for loose hardware. Tighten to required torque.	<a href="#">9.1 Torque Specifications, page 267</a>
	Check tire pressure (Transport/Stabilizer Option).	<a href="#">5.1 Checking Tire Pressure: Transport and Stabilizer Wheels, page 91</a>
	Check wheel bolt torque (Transport/Stabilizer Option).	<a href="#">5.2 Checking Wheel Bolt Torque, page 92</a>
	Check knife drive box breather position.	<a href="#">5.3 Checking Knife Drive Box, page 93</a>
	Check knife drive box lube level.	<a href="#">5.3 Checking Knife Drive Box, page 93</a>
	Check float module gearbox lube level.	<a href="#">5.4 Checking Oil Level in Header Drive Gearbox, page 95</a>
	Check hydraulic reservoir lube level before and after run-up.	<a href="#">5.5 Checking Oil Level in Hydraulic Reservoir, page 96</a>
	Check knife drive belt(s) tension.	<a href="#">5.6 Checking and Adjusting Knife Drive Belt Tension, page 97</a>
	Check if reel is centered between header endsheets.	<a href="#">5.8 Centering the Reel, page 103</a>
	Grease all bearings and drivelines.	<a href="#">5.17 Lubricating the Header, page 125</a>
	Check side draper tension.	<a href="#">5.14 Adjusting Draper Tension, page 120</a>
	Check draper seal.	<a href="#">5.16 Checking and Adjusting Draper Seal, page 123</a>
	Check header float.	<a href="#">5.9 Checking and Adjusting Header Float, page 105</a>
	Check reel tine to cutterbar clearance.	<a href="#">5.11.1 Measuring Reel Clearance, page 111</a>
	Check auger flighting to feed pan clearance.	<a href="#">5.12 Adjusting Auger to Pan Clearance, page 114</a>
	Check the knife hold-down adjustment.	<a href="#">5.7 Checking Knife Hold-Downs, page 100</a>
	Check fitment of endshields.	<a href="#">5.18 Checking and Adjusting Endshields, page 134</a>

## PREDELIVERY CHECKLIST

✓	Item	Reference
	Check skid shoes are evenly adjusted at a setting appropriate for first crop.	—
	Ensure feeder house variable speed is set to minimum.	—
	Ensure auto header height is calibrated and functioning correctly.	<a href="#">6.1 Auto Header Height Control (AHHC), page 139</a>
<b>Run-up procedure</b>		<a href="#">8 Running up Header, page 261</a>
	Check hydraulic hose and wiring harness routing for clearance when raising or lowering header and reel.	—
	Check lights are functional.	—
	Check knife speed.	<a href="#">8.1.2 Adjusting Knife Speed, page 265</a>
<b>Post run-up check. Stop engine.</b>		<a href="#">8.1 Performing Post Run-Up Adjustments, page 263</a>
	Check knife sections for discoloration caused by misalignment of components.	<a href="#">8.1.1 Adjusting Knife, page 263</a>
	Check for hydraulic leaks.	—
	Check that the manual storage case contains all of the required manuals.	<a href="#">5.19 Checking Manuals, page 137</a>

**Date Checked:**

**Checked by:**



**MacDon Industries Ltd.**

680 Moray Street  
Winnipeg, Manitoba  
Canada R3J 3S3  
t. (204) 885-5590  
f. (204) 832-7749

**MacDon, Inc.**

10708 N. Pomona Avenue  
Kansas City, Missouri  
United States 64153-1924  
t. (816) 891-7313  
f. (816) 891-7323

**MacDon Australia Pty. Ltd.**

A.C.N. 079 393 721  
P.O. Box 103 Somerton, Victoria, Australia 3062  
54 National Boulevard, Campbellfield, Victoria,  
Australia 3061  
t. 61 3 8301-1911  
f. 61 3 8301-1912

**MacDon Brasil Agribusiness Ltda.**

Rua Grã Nicco, 113, sala 202, B. 02  
Mossunguê, Curitiba, Paraná  
CEP 81200-200 Brasil  
t. +55 (41) 2101-1713  
f. +55 (41) 2101-1699

**LLC MacDon Russia Ltd.**

123317 Moscow, Russia  
10 Presnenskaya nab, Block C  
Floor 5, Office No. 534, Regus Business Centre  
t. +7 495 775-6971  
f. +7 495 967-7600

## CUSTOMERS

**MacDon.com**

## DEALERS

**Portal.MacDon.com**

Trademarks of products are the marks of their  
respective manufacturers and/or distributors.

Printed in Canada